




IBM System x3850 X5 and x3950 X5
Types 7145, 7146, 7143, and 7191

Problem Determination and Service Guide





IBM System x3850 X5 and x3950 X5
Types 7145, 7146, 7143, and 7191

Problem Determination and Service Guide

Note

Before using this information and the product it supports, read the general information in “Notices” on page 1031, the *Safety Information* and *Environmental Notices and User Guide* documents on the IBM *Documentation* CD, and the *Warranty Information* document that comes with the product.

Nineteenth Edition (October 2013)

© Copyright IBM Corporation 2014.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Safety	v
Guidelines for trained service technicians	vii
Inspecting for unsafe conditions	vii
Guidelines for servicing electrical equipment	viii
Safety statements	ix
Chapter 1. Start here	1
Diagnosing a problem	1
Undocumented problems	3
Chapter 2. Introduction	5
Related documentation	6
Notices and statements in this document	7
Server features and specifications	7
x3850 X5 Memory Reliability Accessibility and Serviceability (RAS) Features	10
Server controls, connectors, LEDs, and power	13
Front view	13
Rear view	16
Rear view LEDs	17
Server power features	20
Internal LEDs, connectors, and jumpers	22
Memory-card DIMM connectors	22
Memory-card LEDs and button	23
Microprocessor-board connectors	24
Microprocessor-board LEDs	24
I/O-board connectors	26
I/O-board LEDs	26
I/O-board jumpers	27
SAS-backplane connectors	29
Memory expansion module features and specifications	29
Memory expansion module indicators, LEDs, and power	32
Front view	32
Rear view	33
Turning the memory expansion module on and off	34
Memory expansion module internal connectors and buttons	34
Chapter 3. Diagnostics	37
Diagnostic tools	37
Event logs	38
Viewing event logs through the Setup utility	39
Viewing event logs without restarting the server	39
Checkout procedures	40
About the checkout procedure	40
Performing the checkout procedure	41
Troubleshooting tables	42
CD or DVD drive problems	43
Embedded hypervisor problems	44
General problems	44
Hard disk drive problems	45
Intermittent problems	45

USB keyboard, mouse, or pointing-device problems	46
Memory problems	47
Microprocessor problems	49
Monitor or video problems	50
Optional-device problems	52
Power problems	53
Serial-device problems	55
ServerGuide problems	55
Software problems	56
Universal Serial Bus (USB) port problems	57
Video problems	57
Light path diagnostics	57
Remind button	62
Light path diagnostics LEDs	63
Power-supply LEDs	69
IBM Dynamic System Analysis	71
DSA editions	72
Running DSA Preboot	73
Recovering the server firmware	73
In-band automatic recovery method	74
In-band manual recovery method	74
Out-of-band method	75
Nx boot failure	75
Confirm and recover IMM boot image failure	75
System-event log	76
Solving Ethernet controller problems	76
Solving undetermined problems	77
Problem determination tips	78

Chapter 4. Parts listing, Types 7145, 7146, 7143, and 7191.	81
Replaceable server components	83
Replaceable memory expansion module components	90
Power cords	92
Product recovery CDs	94
VMware ESXi recovery CDs (Type 7145)	95

Chapter 5. Removing and replacing components	97
Installation guidelines	97
A single-power-supply server operating at 208 V ac	99
System reliability guidelines	99
Working inside the server with the power on	99
Handling static-sensitive devices	100
Servicing multi-node systems	100
Internal cable routing and connectors	101
Returning a device or component	104
Connecting the cables	104
Removing and replacing server components	105
Removing and replacing consumable parts and Tier 1 CRUs	105
Removing and replacing Tier 2 CRUs	139
Removing and replacing FRUs	160

Removing and replacing the memory expansion module components	176
Removing and replacing memory expansion module Tier 1 CRUs	176
Removing and replacing memory expansion module Tier 2 CRUs	197

Chapter 6. Configuration information and instructions 201

Updating the firmware	201
Configuring the server	202
Setup utility menu choices	203
Passwords	207
Using the Boot Selection Menu program	208
Starting the backup UEFI firmware	209
Using the ServerGuide Setup and Installation CD	209
Using the integrated management module.	211
Using the embedded hypervisor	214
Using the remote presence capability and blue-screen capture	215
Enabling the Broadcom Gigabit Ethernet Utility program	216
Configuring the Broadcom Gigabit Ethernet controller.	216
Configuring RAID arrays	216
IBM Advanced Settings Utility program	217
Updating IBM Systems Director	217
Configuring an EXA multi-node system	218
Configuring a QPI multi-node system	226

Appendix A. DSA diagnostic test results 227

DSA Broadcom network test results	227
DSA Brocade test results.	236
DSA checkpoint panel test results	244
DSA CPU stress test results.	245
DSA Emulex adapter test results	248
DSA EXA port ping test results	251
DSA hard drive test results	253
DSA Intel network test results	255
DSA LSI hard drive test results	260
DSA Mellanox adapter test results	261
DSA memory isolation test results	264
DSA memory stress test results	334
DSA Nvidia GPU test results	337
DSA optical drive test results	343
DSA system management test results	347
DSA tape drive test results	361

Appendix B. Integrated management module error messages	367
IMM Events that automatically notify Support	367

Appendix C. UEFI/POST error codes 1013

Appendix D. Getting help and technical assistance 1027

Before you call	1027
Using the documentation	1028
Getting help and information from the World Wide Web	1028
Software service and support.	1028
Hardware service and support	1028
IBM Taiwan product service	1029

Notices 1031

Trademarks	1032
Important notes	1032
Particulate contamination	1033
Documentation format	1034
Telecommunication regulatory statement	1034
Electronic emission notices	1035
Federal Communications Commission (FCC) statement	1035
Industry Canada Class A emission compliance statement	1035
Avis de conformité à la réglementation d'Industrie Canada	1035
Australia and New Zealand Class A statement	1035
European Union EMC Directive conformance statement	1036
Germany Class A statement	1036
Japan VCCI Class A statement	1037
Japan Electronics and Information Technology Industries Association (JEITA) statement	1038
Japan Electronics and Information Technology Industries Association (JEITA) statement	1038
Korea Communications Commission (KCC) statement	1038
Russia Electromagnetic Interference (EMI) Class A statement	1038
People's Republic of China Class A electronic emission statement	1039
Taiwan Class A compliance statement	1039

Index 1041

Safety

Before installing this product, read the Safety Information.

قبل تركيب هذا المنتج، يجب قراءة الملاحظات الأمنية

Antes de instalar este produto, leia as Informações de Segurança.

在安装本产品之前，请仔细阅读 **Safety Information** (安全信息)。

安裝本產品之前，請先閱讀「安全資訊」。

Prije instalacije ovog produkta obavezno pročitajte Sigurnosne Upute.

Před instalací tohoto produktu si přečtěte příručku bezpečnostních instrukcí.

Læs sikkerhedsforskrifterne, før du installerer dette produkt.

Lees voordat u dit product installeert eerst de veiligheidsvoorschriften.

Ennen kuin asennat tämän tuotteen, lue turvaohjeet kohdasta Safety Information.

Avant d'installer ce produit, lisez les consignes de sécurité.

Vor der Installation dieses Produkts die Sicherheitshinweise lesen.

Πριν εγκαταστήσετε το προϊόν αυτό, διαβάστε τις πληροφορίες ασφάλειας (safety information).

לפני שתתקינו מוצר זה, קראו את הוראות הבטיחות.

A termék telepítése előtt olvassa el a Biztonsági előírásokat!

Prima di installare questo prodotto, leggere le Informazioni sulla Sicurezza.

製品の設置の前に、安全情報をお読みください。

본 제품을 설치하기 전에 안전 정보를 읽으십시오.

Пред да се инсталира овој продукт, прочитајте информацијата за безбедност.

بئىر
تەخنىكا
بىلىم
بىلىم
بىلىم
بىلىم
بىلىم
بىلىم
بىلىم
بىلىم

Les sikkerhetsinformasjonen (Safety Information) før du installerer dette produktet.

Przed zainstalowaniem tego produktu, należy zapoznać się z książką "Informacje dotyczące bezpieczeństwa" (Safety Information).

Antes de instalar este produto, leia as Informações sobre Segurança.

Перед установкой продукта прочтите инструкции по технике безопасности.

Pred inštaláciou tohto zariadenia si pečítajte Bezpečnostné predpisy.

Pred namestitvijo tega proizvoda preberite Varnostne informacije.

Antes de instalar este producto, lea la información de seguridad.

Läs säkerhetsinformationen innan du installerar den här produkten.

ཐོན་ཁུངས་འདི་བདེ་སྤྱོད་མ་བྱས་གོང་། རྒྱུ་ལྷིང་གཟུང་
བྱ་འདུ་མིན་ཡོད་པའི་འོད་སྤེར་བལྟ་དགོས།

Bu ürünü kurmadan önce güvenlik bilgilerini okuyun.

مەزكۇر مەھسۇلاتنى ئورنىتىشتىن بۇرۇن بىخەتەرلىك ئۇچۇرلىرىنى ئوقۇپ چىقىڭ.

Youq mwngz yungh canjbinj neix gaxgonq, itding aeu doeg aen
canjbinj soengq cungj vahgangj ancien siusik.

Guidelines for trained service technicians

This section contains information for trained service technicians.

Inspecting for unsafe conditions

Use this information to help you identify potential unsafe conditions in an IBM® product that you are working on.

Each IBM product, as it was designed and manufactured, has required safety items to protect users and service technicians from injury. The information in this section addresses only those items. Use good judgment to identify potential unsafe conditions that might be caused by non-IBM alterations or attachment of non-IBM features or optional devices that are not addressed in this section. If you identify an unsafe condition, you must determine how serious the hazard is and whether you must correct the problem before you work on the product.

Consider the following conditions and the safety hazards that they present:

- Electrical hazards, especially primary power. Primary voltage on the frame can cause serious or fatal electrical shock.
- Explosive hazards, such as a damaged CRT face or a bulging capacitor.
- Mechanical hazards, such as loose or missing hardware.

To inspect the product for potential unsafe conditions, complete the following steps:

1. Make sure that the power is off and the power cords are disconnected.
2. Make sure that the exterior cover is not damaged, loose, or broken, and observe any sharp edges.
3. Check the power cords:
 - Make sure that the third-wire ground connector is in good condition. Use a meter to measure third-wire ground continuity for 0.1 ohm or less between the external ground pin and the frame ground.
 - Make sure that the power cords are the correct type.
 - Make sure that the insulation is not frayed or worn.
4. Remove the cover.
5. Check for any obvious non-IBM alterations. Use good judgment as to the safety of any non-IBM alterations.
6. Check inside the system for any obvious unsafe conditions, such as metal filings, contamination, water or other liquid, or signs of fire or smoke damage.
7. Check for worn, frayed, or pinched cables.
8. Make sure that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.

Guidelines for servicing electrical equipment

Observe these guidelines when you service electrical equipment.

- Check the area for electrical hazards such as moist floors, nongrounded power extension cords, and missing safety grounds.
- Use only approved tools and test equipment. Some hand tools have handles that are covered with a soft material that does not provide insulation from live electrical current.
- Regularly inspect and maintain your electrical hand tools for safe operational condition. Do not use worn or broken tools or testers.
- Do not touch the reflective surface of a dental mirror to a live electrical circuit. The surface is conductive and can cause personal injury or equipment damage if it touches a live electrical circuit.
- Some rubber floor mats contain small conductive fibers to decrease electrostatic discharge. Do not use this type of mat to protect yourself from electrical shock.
- Do not work alone under hazardous conditions or near equipment that has hazardous voltages.
- Locate the emergency power-off (EPO) switch, disconnecting switch, or electrical outlet so that you can turn off the power quickly in the event of an electrical accident.
- Disconnect all power before you perform a mechanical inspection, work near power supplies, or remove or install main units.
- Before you work on the equipment, disconnect the power cord. If you cannot disconnect the power cord, have the customer power-off the wall box that supplies power to the equipment and lock the wall box in the off position.
- Never assume that power has been disconnected from a circuit. Check it to make sure that it has been disconnected.
- If you have to work on equipment that has exposed electrical circuits, observe the following precautions:
 - Make sure that another person who is familiar with the power-off controls is near you and is available to turn off the power if necessary.
 - When you work with powered-on electrical equipment, use only one hand. Keep the other hand in your pocket or behind your back to avoid creating a complete circuit that could cause an electrical shock.
 - When you use a tester, set the controls correctly and use the approved probe leads and accessories for that tester.
 - Stand on a suitable rubber mat to insulate you from grounds such as metal floor strips and equipment frames.
- Use extreme care when you measure high voltages.
- To ensure proper grounding of components such as power supplies, pumps, blowers, fans, and motor generators, do not service these components outside of their normal operating locations.
- If an electrical accident occurs, use caution, turn off the power, and send another person to get medical aid.

Safety statements

These statements provide the caution and danger information that is used in this documentation.

Important:

Each caution and danger statement in this documentation is labeled with a number. This number is used to cross reference an English-language caution or danger statement with translated versions of the caution or danger statement in the *Safety Information* document.

For example, if a caution statement is labeled “Statement 1,” translations for that caution statement are in the *Safety Information* document under “Statement 1.”

Be sure to read all caution and danger statements in this documentation before you perform the procedures. Read any additional safety information that comes with your system or optional device before you install the device.

Statement 1



DANGER

Electrical current from power, telephone, and communication cables is hazardous.

To avoid a shock hazard:

- **Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.**
- **Connect all power cords to a properly wired and grounded electrical outlet.**
- **Connect to properly wired outlets any equipment that will be attached to this product.**
- **When possible, use one hand only to connect or disconnect signal cables.**
- **Never turn on any equipment when there is evidence of fire, water, or structural damage.**
- **Disconnect the attached power cords, telecommunications systems, networks, and modems before you open the device covers, unless instructed otherwise in the installation and configuration procedures.**
- **Connect and disconnect cables as described in the following table when installing, moving, or opening covers on this product or attached devices.**

To Connect:

1. Turn everything OFF.
2. First, attach all cables to devices.
3. Attach signal cables to connectors.
4. Attach power cords to outlet.
5. Turn device ON.

To Disconnect:

1. Turn everything OFF.
2. First, remove power cords from outlet.
3. Remove signal cables from connectors.
4. Remove all cables from devices.

Statement 2



CAUTION:

When replacing the lithium battery, use only IBM Part Number 15F8409 or an equivalent type battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- Throw or immerse into water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.

Statement 3



CAUTION:

When laser products (such as CD-ROMs, DVD drives, fiber optic devices, or transmitters) are installed, note the following:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.




DANGER

Some laser products contain an embedded Class 3A or Class 3B laser diode. Note the following.

Laser radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.

Class 1 Laser Product
Laser Klasse 1
Laser Klass 1
Luokan 1 Laserlaite
Appareil À Laser de Classe 1


Statement 4



≥ 18 kg (39.7 lb)



≥ 32 kg (70.5 lb)




≥ 55 kg (121.2 lb)

CAUTION:
Use safe practices when lifting.

Statement 5



CAUTION:
The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



Statement 8



CAUTION:

Never remove the cover on a power supply or any part that has the following label attached.



Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

Statement 11



CAUTION:

The following label indicates sharp edges, corners, or joints nearby.



Statement 12



CAUTION:

The following label indicates a hot surface nearby.



Statement 13



DANGER

Overloading a branch circuit is potentially a fire hazard and a shock hazard under certain conditions. To avoid these hazards, ensure that your system electrical requirements do not exceed branch circuit protection requirements. Refer to the information that is provided with your device for electrical specifications.

Statement 15



CAUTION:

Make sure that the rack is secured properly to avoid tipping when the server unit is extended.

Statement 17



CAUTION:

The following label indicates moving parts nearby.



Statement 26



CAUTION:

Do not place any object on top of rack-mounted devices.



Statement 27



CAUTION:
Hazardous moving parts are nearby.



Statement 37



DANGER

When you populate a rack cabinet, adhere to the following guidelines:

- Always lower the leveling pads on the rack cabinet.
- Always install the stabilizer brackets on the rack cabinet.
- Always install the heaviest devices in the bottom of the rack cabinet.
- Do not extend multiple devices from the rack cabinet simultaneously, unless the rack-mounting instructions direct you to do so. Multiple devices extended into the service position can cause your rack cabinet to tip.
- If you are not using the IBM 9308 rack cabinet, securely anchor the rack cabinet to ensure its stability.

Attention: This product is suitable for use on an IT power distribution system whose maximum phase-to phase-voltage is 240 V under any distribution fault condition.

Chapter 1. Start here

You can solve many problems without outside assistance by following the troubleshooting procedures in this documentation and on the World Wide Web.

This document describes the diagnostic tests that you can perform, troubleshooting procedures, and explanations of error messages and error codes. The documentation that comes with your operating system and software also contains troubleshooting information.

Diagnosing a problem

Before you contact IBM or an approved warranty service provider, follow these procedures in the order in which they are presented to diagnose a problem with your server.

Procedure

1. **Return the server to the condition it was in before the problem occurred.** If any hardware, software, or firmware was changed before the problem occurred, if possible, reverse those changes. This might include any of the following items:
 - Hardware components
 - Device drivers and firmware
 - System software
 - UEFI firmware
 - System input power or network connections
2. **View the light path diagnostics LEDs and event logs.** The server is designed for ease of diagnosis of hardware and software problems.
 - **Light path diagnostics LEDs:** See for information about using light path diagnostics LEDs.
 - **Event logs:** See for information about notification events and diagnosis.
 - **Software or operating-system error codes:** See the documentation for the software or operating system for information about a specific error code. See the manufacturer's website for documentation.
3. **Run IBM Dynamic System Analysis (DSA) and collect system data.** Run Dynamic System Analysis (DSA) to collect information about the hardware, firmware, software, and operating system. Have this information available when you contact IBM or an approved warranty service provider. For instructions for running DSA, see the *Dynamic System Analysis Installation and User's Guide*.

To download the latest version of DSA code and the *Dynamic System Analysis Installation and User's Guide*, go to .
4. **Check for and apply code updates.** Fixes or workarounds for many problems might be available in updated UEFI firmware, device firmware, or device drivers. To display a list of available updates for the server, go to .

Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

- a. **Install UpdateXpress system updates.** You can install code updates that are packaged as an UpdateXpress System Pack or UpdateXpress CD image. An UpdateXpress System Pack contains an integration-tested bundle of online firmware and device-driver updates for your server. In addition, you can use IBM ToolsCenter Bootable Media Creator to create bootable media that is suitable for applying firmware updates and running preboot diagnostics. For more information about UpdateXpress System Packs, see [. For more information about the Bootable Media Creator, see \[.\]\(#\)](#)

Be sure to separately install any listed critical updates that have release dates that are later than the release date of the UpdateXpress System Pack or UpdateXpress image (see step 4b).

- b. **Install manual system updates.**

- 1) **Determine the existing code levels.**

In DSA, click **Firmware/VPD** to view system firmware levels, or click **Software** to view operating-system levels.

- 2) **Download and install updates of code that is not at the latest level.**

To display a list of available updates for the server, go to [.](#)

When you click an update, an information page is displayed, including a list of the problems that the update fixes. Review this list for your specific problem; however, even if your problem is not listed, installing the update might solve the problem.

5. **Check for and correct an incorrect configuration.** If the server is incorrectly configured, a system function can fail to work when you enable it; if you make an incorrect change to the server configuration, a system function that has been enabled can stop working.

- a. **Make sure that all installed hardware and software are supported.** See to verify that the server supports the installed operating system, optional devices, and software levels. If any hardware or software component is not supported, uninstall it to determine whether it is causing the problem. You must remove nonsupported hardware before you contact IBM or an approved warranty service provider for support.

- b. **Make sure that the server, operating system, and software are installed and configured correctly.** Many configuration problems are caused by loose power or signal cables or incorrectly seated adapters. You might be able to solve the problem by turning off the server, reconnecting cables, reseating adapters, and turning the server back on. For information about performing the checkout procedure, see [. For information about configuring the server, see \[.\]\(#\)](#)

6. **See controller and management software documentation.** If the problem is associated with a specific function (for example, if a RAID hard disk drive is marked offline in the RAID array), see the documentation for the associated controller and management or controlling software to verify that the controller is correctly configured.

Problem determination information is available for many devices such as RAID and network adapters.

For problems with operating systems or IBM software or devices, go to [.](#)

7. **Check for troubleshooting procedures and RETAIN tips.** Troubleshooting procedures and RETAIN tips document known problems and suggested solutions. To search for troubleshooting procedures and RETAIN tips, go to [.](#)
8. **Use the troubleshooting tables.** See to find a solution to a problem that has identifiable symptoms.

A single problem might cause multiple symptoms. Follow the troubleshooting procedure for the most obvious symptom. If that procedure does not diagnose the problem, use the procedure for another symptom, if possible.

If the problem remains, contact IBM or an approved warranty service provider for assistance with additional problem determination and possible hardware replacement. To open an online service request, go to . Be prepared to provide information about any error codes and collected data.

Undocumented problems

If you have completed the diagnostic procedure and the problem remains, the problem might not have been previously identified by IBM. After you have verified that all code is at the latest level, all hardware and software configurations are valid, and no light path diagnostics LEDs or log entries indicate a hardware component failure, contact IBM or an approved warranty service provider for assistance.

To open an online service request, go to . Be prepared to provide information about any error codes and collected data and the problem determination procedures that you have used.

Chapter 2. Introduction

This topic provides a brief introduction to the IBM System x3850 X5 and x3950 X5 Types 7145, 7146, 7143, and 7191.

This information supports your IBM System x3850 X5 and x3950 X5 Types 7145 and 7146 server and the optional IBM MAX5 for System x (MAX5) memory expansion module. It describes the diagnostic tools that come with the server, error codes and suggested actions, and instructions for replacing failing components in the server and the MAX5 memory expansion module (see “Memory expansion module features and specifications” on page 29 for more information on the MAX5).

Important: The IBM MAX5 for System x memory expansion module is a Listed Accessory for use with the IBM System x3850 X5 and x3950 X5 only.

If you are adding an optional memory expansion module or scaling to another server, see the rack installation instructions that come with the cable option kit.

The most recent version of this document is available at <http://www.ibm.com/systems/support/>.

Replaceable components are of four types:

- **Consumable part:** Purchase and replacement of consumable parts (components, such as batteries and printer cartridges, that have depletable life) is your responsibility. If IBM acquires or installs a consumable part at your request, you will be charged for the service.
- **Tier 1 customer replaceable unit (CRU):** Replacement of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request without a service contract, you will be charged for the installation.
- **Tier 2 customer replaceable unit:** You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service that is designated for your server.
- **Field replaceable unit (FRU):** FRUs must be installed only by trained service technicians.

For information about the terms of the warranty and getting service and assistance, see the *Warranty Information* document that came with your server. For information about getting service and assistance, see “Getting help and information from the World Wide Web” on page 1028.

Related documentation

In addition to this document, the following documentation also comes with the server:

- *Installation and User's Guide*

This document is in Portable Document Format (PDF) on the IBM *Documentation* CD. It provides general information about setting up and cabling the server, including information about features, and how to configure the server. It also contains detailed instructions for installing, removing, and connecting optional devices that the server supports.

- *Rack Installation Instructions*

This printed document contains instructions for installing the server in a rack.

- *Safety Information*

This document is in PDF on the IBM *Documentation* CD. It contains translated caution and danger statements. Each caution and danger statement that appears in the documentation has a number that you can use to locate the corresponding statement in your language in the *Safety Information* document.

- *IBM Warranty Information*

This printed document contains the warranty terms and a pointer to the IBM Statement of Limited Warranty on the IBM Web site.

- *Environmental Notices and User Guide*

This document is in PDF on the IBM *Documentation* CD. It contains translated environmental notices.

- *IBM License Agreement for Machine Code*

This document is in PDF on the IBM *Documentation* CD. It provides translated versions of the IBM License Agreement for Machine code for your server.

- *Licenses Attributions Document*

This document is in PDF on the IBM *Document* CD. It provides information about the open-source notices.

Depending on the server model, additional documentation might be included on the IBM *Documentation* CD.

ToolsCenter for System x and BladeCenter is an online information center that contains information about tools for updating, managing, and deploying firmware, device drivers, and operating systems. The ToolsCenter for System x and BladeCenter is at <http://publib.boulder.ibm.com/infocenter/toolsctr/v1r0/index.jsp>.

The server might have features that are not described in the documentation that you received with the server. The documentation might be updated occasionally to include information about those features, or technical updates might be available to provide additional information that is not included in the server documentation. These updates are available from the IBM website. To check for updated documentation and technical updates, go to <http://www.ibm.com/systems/support/>.

Notices and statements in this document

The caution and danger statements in this document are also in the multilingual *Safety Information* document, which is on the IBM *Documentation* CD. Each statement is numbered for reference to the corresponding statement in your language in the *Safety Information* document.

The following notices and statements are used in this document:

- **Note:** These notices provide important tips, guidance, or advice.
- **Important:** These notices provide information or advice that might help you avoid inconvenient or problem situations.
- **Attention:** These notices indicate potential damage to programs, devices, or data. An attention notice is placed just before the instruction or situation in which damage might occur.
- **Caution:** These statements indicate situations that can be potentially hazardous to you. A caution statement is placed just before the description of a potentially hazardous procedure step or situation.
- **Danger:** These statements indicate situations that can be potentially lethal or extremely hazardous to you. A danger statement is placed just before the description of a potentially lethal or extremely hazardous procedure step or situation.

Server features and specifications

This topic provides a table with the server features and specifications.

The following information is a summary of the features and specifications of the server. Depending on the server model, some features might not be available, or some specifications might not apply.

Notes:

1. Racks are marked in vertical increments of 4.45 cm (1.75 inches). Each increment is referred to as a unit, or "U." A 1-U-high device is 4.45 cm (1.75 inches) tall.
2. Power consumption and heat output vary depending on the number and type of optional features that are installed and the power-management optional features that are in use.
3. The sound levels were measured in controlled acoustical environments according to the procedures specified by the American National Standards Institute (ANSI) S12.10 and ISO 7779 and are reported in accordance with ISO 9296. Actual sound-pressure levels in a given location might exceed the average values stated because of room reflections and other nearby noise sources. The declared sound-power levels indicate an upper limit, below which a large number of computers will operate.

Table 1. Features and specifications

<p>Microprocessor:</p> <ul style="list-style-type: none"> • Intel Xeon EX versions of the 6000 and 7000 Series or E7 Series multi-core microprocessor with up to 24 MB or 30 MB last level cache. • 1066 MHz front-side bus (FSB) • Support for up to four microprocessors <ul style="list-style-type: none"> – Four Quick Path Interconnect (QPI) links per microprocessor at up to 6.4 GT/s (gigatransfers per second) – Four Scalable Memory Interconnect (SMI) links per microprocessor at up to 6.4 GT/s <p>Note: Use the Setup utility to determine the type and speed of the microprocessors. The server does not support mixing microprocessor types.</p> <p>Memory:</p> <ul style="list-style-type: none"> • Type: Registered, ECC, PC3-10600 double data rate (DDR) III, SDRAM • Sizes: 1 GB (Types 7145 and 7146 only) and 2 GB (PC3-10600 running at 1066 Mb/sec), 4 GB, 8 GB, 16 GB, and 32 GB Types 7143 and 7191 Only) (PC3L-8500-777 DDR3 ECC running at 1066 Mb/sec) in pairs • Minimum (Types 7145 and 7146): 2 GB (two DIMMs per memory card minimum) • Minimum (Types 7143 and 7191): 4 GB (two DIMMs per memory card minimum) • Maximum: 1 TB (2 TB when using 32 GB DIMMs in Types 7143 and 7191) (eight memory cards, each card containing 8 DIMM connectors for a total of 64 DIMMs) • Connectors: Two-way interleaved, eight dual inline memory module (DIMM) connectors per memory card • Supports 1.35 V (low-voltage) and 1.5 V registered DIMMs (see “Replacing a DIMM” on page 138 for more information). • Machine Types 7145 and 7146 uses the Intel 7500 Scalable Memory Buffer only • Machine Types 7143 and 7191 uses the Intel 7510 Scalable Memory Buffer only 	<p>Expansion slots:</p> <ul style="list-style-type: none"> • Six non-hot-swap PCI Express x8 (three full-length and three half-length) slots • One non-hot-swap PCI Express x16 (full-length) slot • Emulex 10 GbE Custom Adapter for IBM System x in slot 7 (optional in some models) <p>Upgradeable microcode:</p> <p>System UEFI, FPGA, diagnostics, service processor, IMM, and SAS microcode</p> <p>Power supply:</p> <ul style="list-style-type: none"> • Standard: One or two dual-rated power supplies (depending on the model). <ul style="list-style-type: none"> – 1975 watts at 220 V ac input – 875 watts at 110 V ac input • Hot-swappable and redundant at 220 V ac, only with two power supplies • If the server is operating at 110 V ac, a second power supply must be installed. <p>Size:</p> <ul style="list-style-type: none"> • 4U • Height: 172.8 mm (6.81 in.) • Depth: 712.13 mm (28.04 in.) • Width: (without rack EIA brackets) 440 mm (17.32 in.) • Width: (with rack EIA brackets) 482.6 mm (19 in.) • Weight: approximately 49.90 kg (110 lb) when fully configured <p>Drives:</p> <ul style="list-style-type: none"> • Slim CD/DVD-ROM: SATA (optional) • Serial Attached SCSI (SAS) 2.5-inch hard disk drives (optional) • Solid state 1.8-inch drives (optional) <p>Expansion bays:</p> <ul style="list-style-type: none"> • Eight SAS, 2.5-inch bays or sixteen solid state 1.8-inch bays • One 12.7 mm removable-media drive bay (CD/DVD drive optional) 	<p>Acoustical noise emissions:</p> <ul style="list-style-type: none"> • Sound power, idle: 5.8 bel declared • Sound power, operating: 6.3 bel declared <p>Airflow:</p> <ul style="list-style-type: none"> • Nominal airflow: 67 cubic feet per minute (CFM) • Typical airflow: 100 CFM • Maximum airflow: 241 CFM <p>Environment:</p> <ul style="list-style-type: none"> • Air temperature: <ul style="list-style-type: none"> – Server on: <ul style="list-style-type: none"> - 10°C to 35°C (50°F to 95°F); altitude: 0 to 914 m (3000 ft). - 10°C to 32°C (50°F to 90°F); altitude: 914 to 2133 m (7000 ft). – Server off: 10°C to 43°C (50.0°F to 109.4°F); maximum altitude: 2133 m (6998.0 ft) • Humidity: <ul style="list-style-type: none"> – Server on: 8% to 80% – Server off: 8% to 80% • Particulate contamination: <p>Attention: Airborne particulates and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the server. For information about the limits for particulates and gases, see “Particulate contamination” on page 1033.</p> <p>Heat output:</p> <p>Approximate heat output:</p> <ul style="list-style-type: none"> • Minimum configuration: 648 Btu per hour (190 watts) • Typical configuration: 3753 Btu per hour (1100 watts) • Design maximum configuration: <ul style="list-style-type: none"> – 5971 Btu per hour (1930 watts) at 110 V ac – 6739 Btu per hour (2150 watts) at 220 V ac
---	---	---

Table 2. Features and specifications (continued)

<p>Scalability and memory expansion:</p> <ul style="list-style-type: none"> • Eight-socket scalability option uses 4 QPI external cables • Multi-node configurations require 4 microprocessors in each node • MAX5 memory expansion module option uses four QPI ports <p>Note: When you add an optional memory expansion module to your server configuration and you plan to use the optional USB flash device with VMware ESXi embedded hypervisor software, see the documentation that comes with the USB flash device and the operation system installation instructions for installing VMware ESXi (or ESX, depending on your environment) on your server at the IBM website at http://www.ibm.com/systems/support/. The documentation provides additional installation and configuration information that you need to follow before you use the memory expansion module.</p>	<p>Integrated functions:</p> <ul style="list-style-type: none"> • Integrated management module (IMM), which provides service processor control and monitoring functions, video controller, and remote keyboard, video, mouse, and remote hard disk drive capabilities • Light path diagnostics • Eight Universal Serial Bus (USB) ports (2.0) <ul style="list-style-type: none"> – Four on rear of server – Two on front of server – Two internal • Broadcom 5709 dual 10/100/1000 MB Ethernet controller • Matrox video <ul style="list-style-type: none"> – 16 MB video memory – SVGA compatible • Serial-attached SCSI (SAS) controller with RAID capabilities • ServeRAID-BR10i SAS/SATA controllers (Types 7145 and 7146 only) or ServeRAID-M1015 SAS/SATA controllers (Types 7143 and 7191 only) and ServeRAID-M5015 SAS/SATA/SSD controllers (all Types) • Serial connector • QPI Expansion Ports 	<p>Electrical input:</p> <ul style="list-style-type: none"> • Sine-wave input (50 - 60 Hz) required • Input voltage low range: <ul style="list-style-type: none"> – Minimum: 100 V ac – Maximum: 127 V ac • Input voltage high range: <ul style="list-style-type: none"> – Minimum: 200 V ac – Maximum: 240 V ac • Approximate input kilovolt-amperes (kVA): <ul style="list-style-type: none"> – Minimum: 0.20 kVA – Typical: 1.12 kVA – Maximum: 1.95 kVA (110 V ac) – Maximum: 2.17 kVA (220 V ac)
--	---	---

EU Regulation 617/2013 Technical Documentation:

International Business Machines Corporation
New Orchard Road
Armonk, New York 10504
<http://www.ibm.com/customersupport/>

Product Type:

Rack server

Year first manufactured:

2010

Internal/external power supply efficiency:

- http://www.plugloadsolutions.com/psu_reports/IBM_7001524-XXXX_1975W_SO-484_Report.pdf

Maximum power (watts):

See Power supply.

Idle state power (watts):

561

Sleep mode power (watts):

Not applicable for servers.

Off mode power (watts):

38

Noise levels (the declared A-weighted sound power level of the server)
See Acoustical noise emissions.

Test voltage and frequency:
230V / 50 Hz or 60 Hz

Total harmonic distortion of the electricity supply system:
The maximum harmonic content of the input voltage waveform will be equal or less than 2%. The qualification is compliant with EN 61000-3-2.

Information and documentation on the instrumentation setup and circuits used for electrical testing:
ENERGY STAR Test Method for servers; ECOVA Generalized Test Protocol for Calculating the Energy Efficiency of Internal Ac-Dc and Dc-Dc Power Supplies.

Measurement methodology used to determine information in this document:
ENERGY STAR Servers Version 2.0 Program Requirements; ECOVA Generalized Test Protocol for Calculating the Energy Efficiency of Internal Ac-Dc and Dc-Dc Power Supplies.

x3850 X5 Memory Reliability Accessibility and Serviceability (RAS) Features

This topic provides information on the x3850 X5 Memory Reliability, Accessibility, and Serviceability (RAS) features.

The following information is a summary of the x3850 X5 Memory Reliability, Accessibility, and Serviceability (RAS) features.

Table 3. x3850 X5 Memory RAS Features

Nodes	Hemisphere Mode (DIMM configuration match between both CPU memory controllers) (Note 1)	Memory Mirroring (Note 2)	DIMM Sparing (2 DIMMs spare per memory card) (Note 3)	DDDC Sparing (1 x4 DRAM spare per DIMM pair) (Note 4)	RBS Sparing (1 x4 DRAM spare per DIMM pair) (Note 5)
1 node	Auto enabled when conditions met on all installed CPUs.	CPU Intrasocket enabled by UEFI setting.	Enabled by UEFI setting when conditions met.	Auto enabled for x4 memory controlled by Westmere-EX CPUs.	Not supported
1 node and MAX5	Auto enabled when conditions met on all installed CPUs; always enabled on MAX5	CPU Intrasocket and MAX5 mirroring enabled by UEFI setting	Enabled by UEFI setting when conditions met. Unsupported in MAX5 memory	Auto enabled for x4 memory controlled by Westmere-EX CPUs	Auto enabled in MAX5 with x4 DIMMs

Table 3. x3850 X5 Memory RAS Features (continued)

Nodes	Hemisphere Mode (DIMM configuration match between both CPU memory controllers) (Note 1)	Memory Mirroring (Note 2)	DIMM Sparing (2 DIMMs spare per memory card) (Note 3)	DDDC Sparing (1 x4 DRAM spare per DIMM pair) (Note 4)	RBS Sparing (1 x4 DRAM spare per DIMM pair) (Note 5)
2 nodes (QPI scaling)	Required for QPI scaled 2-node. Unmatched memory is discarded to enable Hemisphere Mode on all installed CPUs	Not supported	Not supported	Auto enabled for x4 memory controlled by Westmere-EX CPUs.	Not supported
2 nodes and MXA5 (EXA scaling)	Not required for EXA 2-node. Auto enabled when conditions met on all installed CPUs; always enabled on MAX5.	CPU Intrasocket and MAX5 mirroring enabled by UEFI setting.	Enabled by UEFI setting when conditions met. Unsupported in MAX5 memory.	Auto enabled for x4 memory controlled by Westmere-EX CPUs.	Auto enabled in MAX5 with x4 DIMMs.

Notes:

1. Hemisphere Mode

- a. Both memory controllers in a CPU have the same DIMM configuration; improves performance 16-56%.
- b. UEFI automatically enables CPU Hemisphere mode when all installed CPUs meet the requirement.
- c. Memory configurations from one CPU to another need not match.
- d. There is no separate UEFI Setup setting for Hemisphere mode.
- e. CPU Hemisphere Mode is disabled when Memory Sparing (DIMM sparing) or Mirroring is enabled in UEFI Setup.
- f. At least 4 DIMMs per CPU are required for Hemisphere mode, but 8 DIMMs per CPU is better because it avoids a 50% performance loss.
- g. Hemisphere mode is required for 8 socket QPI scaled (non EXA MAX5) configuration (Memory Sparing/Mirroring Settings are ignored).
- h. Hemisphere mode is not required in an 8 socket EXA scaled (via MAX5). Each node would auto enable Hemisphere Mode in it's CPUs based on the CPU memory configurations in that node alone.
- i. MAX5 memory is always in Hemisphere Mode, irrespective of the CPU Hemisphere Mode.

2. Memory Mirroring (CPU and MAX5 mirroring is conditionally supported as described below.)
 - a. CPU "Intrsocket" mirroring is supported: the memory controlled by one CPU memory controller is mirrored to the memory controlled by the second memory controller of the same CPU.
 - b. Each of the two mirrored memory cards must have same total memory size (DIMM population may or may not be the same).
 - c. Partial mirroring is permitted, when only some CPU's Mirroring Configuration conditions have been met.
 - d. MAX5 Mirroring is supported as follows: Port 0 mirrors Port 1 and Port 2 mirrors Port 3, if and only if they have matching DIMM population.
 - e. CPU and MAX5 Mirroring is enabled by a single setting in UEFI Setup.
 - f. When CPU mirroring is enabled, UEFI disables CPU Hemisphere mode if it was previously enabled.
 - g. MAX5 Mirroring and Hemisphere modes are independent features and both can be enabled for MAX5.
 - h. Mirroring is not supported in 2-node with QPI scaling because CPU Hemisphere mode is required.
 - i. Although Intel CPUs can support Inter-socket Mirroring in Hemisphere Mode, IBM eX5 only supports IntraSocket Mirroring.
3. DIMM Sparing
 - a. 2 unused DIMMs are spared per memory card.
 - b. The spare DIMMs must have the same rank and capacity as the largest DIMMs being spared.
 - c. The size of the two unused DIMMs for sparing is subtracted from the usable capacity that is presented to the OS.
 - d. DIMM sparing is applied on all memory cards in the system.
 - e. DIMM sparing is only supported on memory controlled by CPUs, i.e. not available for memory in MAX5.
 - f. Enabled via "Memory Sparing" setting in UEFI Setup.
 - g. DIMM sparing disables Hemisphere mode, not a hardware requirement.
 - h. DIMM sparing is unsupported in 2-node QPI Scaled configuration because 8-socket "glueless" (non-EXA) configurations require Hemisphere mode.
 - i. Intel CPUs support Rank or DIMM sparing, but IBM eX5 UEFI only supports DIMM sparing.
4. DDDC Sparing
 - a. Intel Double Device Data Correction
 - b. Similar to RBS, except spare x4 DRAM is designated within each DIMM pair.
 - c. Requires Westmere-EX CPUs and x4 DIMMs. x8 DIMM technology is not supported.
 - d. Automatically enabled if above requirements are met.
 - e. Not affected by the "Memory Sparing" setting in UEFI Setup.
 - f. Runs with Hemisphere Mode enabled.
 - g. Doesn't lose any memory capacity to provide spare.
5. RBS (Redundant Bit Steering) Sparing
 - a. One x4 DRAM spare maintained in each DIMM pair.
 - b. Requires x4 DIMMs in MAX5. x8 DIMM technology is not supported.

- c. Automatically enabled if above requirements are met.
 - d. Not affected by the "Memory Sparing" setting in UEFI Setup
 - e. RBS is an EXA Chipset function and is only supported in MAX5.
6. Rank Sparing (not supported)
 7. Hot-swap Memory (not supported)
 8. Refer to the IBM eX5 Portfolio Overview: "IBM System x3850 X5, x3950 X5, x3690 X5, and BladeCenter HX5 Redbook" for detailed descriptions of the Memory RAS features, go to .

Server controls, connectors, LEDs, and power

This topic provides information about server controls, connectors, LEDs, and power.


This section describes the controls, light-emitting diodes (LEDs), connectors on the front and rear of the server, and how to turn the server on and off.

Note: The illustrations in this document might differ slightly from your server.

Front view

This topic provides an illustration that shows the controls, LEDs, and connectors on the front of the server.

The following illustration shows the controls, LEDs, and connectors on the front of the server. The DVD drive is optional in some models.



Electrostatic-discharge connector: Connect an electrostatic-discharge wrist strap to this connector when you work with static-sensitive devices.

DVD-eject button: Press this button to release a CD or DVD from the DVD drive.

DVD drive activity LED: When this LED is lit, it indicates that the DVD drive is in use.

USB 1 and 2 connectors: Connect USB devices to these connectors.

Scalability LED: This white LED is lit when the server is connected to another server in a multi-node configuration.


Hard disk drive activity LED: When this LED is flashing, it indicates that the drive is in use.

Hard disk drive status LED: On some server models, each hot-swap hard disk drive has a status LED. When this LED is lit, it indicates that the drive has failed. If an optional IBM ServeRAID controller is installed in the server, when this LED is flashing slowly (one flash per second), it indicates that the drive is being rebuilt. When the LED is flashing rapidly (three flashes per second), it indicates that the controller is identifying the drive.

Operator information panel

This topic provides illustrations of the LEDs on the operator information panel.

The following illustration shows the controls and LEDs on the operator information panel.



The following controls and LEDs are on the operator information panel:

- **Power-control button and power-on LED:** Press this button to turn the server on and off manually or to wake the server from a reduced-power state. The states of the power-on LED are as follows:
 - Off:** AC power is not present, or the power supply or the LED itself has failed.
 - Flashing rapidly (4 times per second):** The server is turned off and is not ready to be turned on. The power-control button is disabled. In a fully configured server, it could take up to 8 minutes after the server is connected to ac power, before the power-control button becomes active.
 - Flashing slowly (once per second):** The server is turned off and is ready to be turned on. You can press the power-control button to turn on the server.
 - Lit:** The server is turned on.
 - Fading on and off:** The server is in a reduced-power state. To wake the server, press the power-control button or use the IMM web interface. For information about logging on to the IMM web interface, see “Logging on to the IMM web interface” on page 213.
- **Ethernet icon LED:** This LED lights the Ethernet icon.
- **Information LED:** When this LED is lit, it indicates that a noncritical event has occurred. An LED on the light path diagnostics panel is also lit to help isolate the error.
- **System-error LED:** When this LED is lit, it indicates that a system error has occurred. An LED on the light path diagnostics panel is also lit to help isolate the error.
- **Locator button and locator LED:** Use this LED to visually locate the server among other servers. It is also used as the physical presence for Trusted

Platform Module (TPM). Press this button to turn on or turn off this LED locally. You can use IBM Systems Director to light this LED remotely.

In a two-node configuration, this LED is lit on the primary server and flashes on the secondary server during POST.

You can press this button or use an IPMI command to turn this LED on or off.


- **Ethernet port activity LEDs:** When either of these LEDs is lit, it indicates that the server is transmitting to or receiving signals from the Ethernet LAN that is connected to the Ethernet port that corresponds to that LED.

Light path diagnostics panel

This topic provides illustrations that show the operator information panel, as well as the controls and LEDs on the light path diagnostics panel.

The light path diagnostics panel is on the top of the operator information panel.


To access the light path diagnostics panel, slide the blue release button on the operator information panel to the left. Pull forward on the operator information panel until the hinge of the panel is free of the server chassis. Then pull down on the operator information panel, so that you can view the light path diagnostics panel information.



Note:

1. For optimum fan speed, do not run the server for more than 10 minutes while the light path diagnostics panel is pulled out of the server.
2. Light path diagnostics LEDs remain lit only while the server is connected to power.

The following illustration shows the controls and LEDs on the light path diagnostics panel.



- **Remind button:** This button places the system-error LED on the front panel into Remind mode. In Remind mode, the system-error LED flashes once every 2 seconds until the problem is corrected, the server is restarted, or a new problem occurs.

By placing the system-error LED indicator in Remind mode, you acknowledge that you are aware of the last failure but will not take immediate action to correct the problem. The remind function is controlled by the IMM.


- **NMI button:** Press this button to force a nonmaskable interrupt to the microprocessor, if you are directed by IBM service.
- **Reset button:** Press this button to reset the server and run the power-on self-test (POST). You might have to use a pen or the end of a straightened paper clip to press the button. The reset button is in the lower-right corner of the light path diagnostics panel.

Rear view

This topic provides an illustration that shows the connectors on the rear of the server.

The following illustration shows the connectors on the rear of the server.

A thumbscrew is in this position only when a 2-node lock bracket is installed (2-node Scalability Kit Option)



Power-cord connector: Connect the power cord to this connector.

System-management Ethernet connector: Use this connector to connect the server integrated management module (IMM) to a network. The IMM is used for systems-management and information control. This connector is used only by the IMM.

QPI ports 1 - 4: In a single-node configuration, use these connectors to insert either a QPI wrap card or a filler panel. The QPI wrap cards enable increased performance in certain models. In a two-node configuration, insert the QPI cables in these ports to connect another server or a memory expansion module to your server. See the documentation that came with your QPI cable kit for detailed cabling instructions.

USB connectors: Connect USB devices, such as a USB mouse or keyboard, to these connectors.

Video connector: Connect a monitor to this connector. In a two-node configuration, connect the monitor to the primary server to see standard system output.


Serial connector: Connect a 9-pin serial device to this connector. The serial port is shared with the integrated management module (IMM). The IMM can take control of the shared serial port to perform text console redirection and to redirect serial traffic, using Serial over LAN (SOL).

Gigabit Ethernet 1 and 2 connectors: Use these connectors to connect the server to a network.

Rear view LEDs

This topic provides an illustration and descriptions of the LEDs on the rear of the server.

The following illustration shows the LEDs on the rear of the server.



AC power LED: Each hot-swap power supply has an ac power LED and a dc power LED. When the ac power LED is lit, it indicates that sufficient power is coming into the power supply through the power cord. During typical operation, both the ac and dc power LEDs are lit.

DC power LED: Each hot-swap power supply has a dc power LED and an ac power LED. When the dc power LED is lit, it indicates that the power supply is supplying sufficient dc power to the system. During typical operation, both the ac and dc power LEDs are lit.

Error LED: When the power-supply error LED is lit, it indicates a problem with the power supply.

QPI Link LEDs 1 - 4: When the QuickPath Interconnect (QPI) link LEDs are lit, they indicate that the QPI links are fully established.

Table 4. QPI link LEDs

Link LEDs	Number of Nodes	QPI wrap card or cable status
Off	1	None installed
On	1	Wrap card installed, working
Off at failing port	1	Wrap card installed, not working
Off	1 with four microprocessors	None installed
On	2	Cables installed, working
Off at failing port	2	Cables installed, not working

Table 4. QPI link LEDs (continued)

Link LEDs	Number of Nodes	QPI wrap card or cable status
Blinking	1 to 4	Server(s) operating at reduced capacity

Locator LED: Use this LED to visually locate the server among other servers. You can use IBM Systems Director to light this LED remotely.

In a two-node configuration, this LED is lit on the primary server and flashes on the secondary server during POST.

You can press the locator button on the operator information panel on the front of the server or use an IPMI command to turn this LED on or off.

System-error LED: When this LED is lit, it indicates that a system error has occurred. An LED on the light path diagnostics panel is also lit to help isolate the error. (See “Light path diagnostics panel” on page 15 for information about the location and using the light path diagnostics panel.)

Power-on LED: See “Operator information panel” on page 14 for the various states of the power-on LED.

The following table describes the problems that are indicated by various combinations of the power-supply LEDs and the power-on LED on the operator information panel and suggested actions to correct the detected problems.

Table 5. Power-supply LEDs

Power-supply LEDs			Description	Action	Notes
AC	DC	Error			
Off	Off	Off	No ac power to either power supply or a problem with the ac power source	<ol style="list-style-type: none"> 1. Check the ac power to the server. 2. Make sure that the power cord is connected to a functioning power source and is securely connected to the server. 3. Turn the server off and then turn the server back on. 4. Replace the power cord. 5. Check the power supply settings. 6. If the problem remains, replace the power supply. 	This is a normal condition when no ac power is present.
Off	Off	On	No ac power to the server or a problem with the ac power source and the power supply had detected an internal problem	<ol style="list-style-type: none"> 1. Replace the power supply. 2. Make sure that the power cord is connected to a functioning power source. 	This happens only when a second power supply is providing power to the server.

Table 5. Power-supply LEDs (continued)

Power-supply LEDs			Description	Action	Notes
AC	DC	Error			
On	Off	Off	Power supply not fully seated, faulty system board, or faulty power supply	<ol style="list-style-type: none"> 1. Reseat the power supply. 2. If the system-board error LED is off, replace the power supply. 3. (Trained service technician only) If the system-board error LED is lit, replace the system board. 	This typically indicates that a power supply is not fully seated.
On	Off or Flashing	On	Faulty power supply	Replace the power supply.	
On	On	Off	Normal operation		
On	On	On	Power supply is faulty but still operational	Replace the power supply.	

Server power features

This topic provides guidelines for server power features.

When the server is connected to an ac power source but is not turned on, the operating system does not run, and all core logic except for the service processor is shut down; however, the server can respond to requests from the service processor, such as a remote request to turn on the server. The power-on LED flashes to indicate that the server is connected to ac power but not turned on.

In a two-node configuration, connect both servers to an ac power source as close to the same time as possible to ensure optimum operation.

Turning on the server

This topic provides instructions for how to turn on the server.

A scaled system takes longer to power-on than a stand alone system. Approximately 30 seconds for a stand alone server, or up to 8 minutes in a 2-node configuration, after the server is connected to ac power, the power-control button becomes active, and one or more fans might start running to provide cooling while the server is connected to power. You can turn on the server and all nodes in the partition and start the operating system by pressing the power-control button.

Note: Do not power the server off when b:b/0:0 is flashing on the front panel. This indicates that setup/configuration is in process.

If you are restarting a two-node server after it has been turned off, you must allow extra time for the hardware to synchronize before you turn on the server again.

The server can also be turned on in any of the following ways:

- If a power failure occurs while the server is turned on, the server will restart automatically when power is restored.
- The systems-management software can turn on the server remotely.
- If your operating system supports the Wake on LAN feature, the Wake on LAN feature can turn on the server.

Note: Some memory is reserved for various system resources and is unavailable to the operating system. The amount of memory that is reserved for system resources depends on the operating system, the configuration of the server, and the configured PCI options.

Turning off the server

This topic provides instructions and guidelines for turning off the server.

When you turn off the server and leave it connected to ac power, the server can respond to requests from the IMM, such as a remote request to turn on the server. While the server remains connected to ac power, one or more fans might continue to run. To remove all power from the server, you must disconnect it from the power source.

Important: To view the error LEDs on the system board, leave the server connected to a power source.


Some operating systems require an orderly shutdown before you turn off the server. See your operating-system documentation for information about shutting down the operating system.

Statement 5



CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



The server can be turned off in any of the following ways:

- You can turn off the server from the operating system, if your operating system supports this feature. After an orderly shutdown of the operating system, the server will be turned off automatically.
- You can press the power-control button to start an orderly shutdown of the operating system and turn off the server, if your operating system supports this feature.
- If the operating system stops functioning, you can press and hold the power-control button for more than 4 seconds to turn off the server.
- The IMM can turn off the server as an automatic response to a critical system failure.
- You can turn off the server through a request from the IMM.

Internal LEDs, connectors, and jumpers


This topic provides general information about internal LEDs, connectors, and jumpers.

The following illustrations show the connectors, LEDs, and jumpers on the internal boards. The illustrations might differ slightly from your hardware.

Memory-card DIMM connectors

This topic provides an illustration that shows the DIMM connectors on a memory card.

The following illustration shows the DIMM connectors on a memory card.



Memory-card LEDs and button

This topic provides an illustration that shows the LEDs on a memory card.

The following illustration shows the LEDs on a memory card.

Note: If the memory card is removed from the server, you must press the light path diagnostics button to light the LED.





Table 6. Memory-card LEDs and button

LED	Description
Light path diagnostics button power LED	When this LED is lit, it indicates that the capacitor is charged and is able to light other LEDs.
Light path diagnostics button	Press this button to relight the error LED that had previously been lit.
Memory card/DIMM error LED	When this LED is lit, it indicates that an error has occurred in one of the DIMMs on the memory card or that there is a problem with the memory card.
Memory card only error LED	When this LED is lit, it indicates that an error has occurred on the memory card itself.
DIMM 1 - 8 error LEDs	When one of these LEDs is lit, it indicates that an error has occurred in the associated DIMM.

Microprocessor-board connectors

This topic provides an illustration of the connectors on the microprocessor board.


The following illustration shows the connectors on the microprocessor board.



Microprocessor-board LEDs

This topic provides illustrations and descriptions of the microprocessor-board LEDs.

The following illustration shows the LEDs on the microprocessor board.



“Microprocessor-board LEDs” on page 24 describes the function of each status LED.


Table 7. Microprocessor board non-light-path-diagnostics status LEDs

LED	Description
System management heartbeat LED	When this LED is flashing at a constant rate of once every 2 seconds, it indicates normal operation of the IMM. Note: If this LED is not lit, do the following. <ol style="list-style-type: none"> 1. Reseat the system. 2. See “Confirm and recover IMM boot image failure” on page 75. 3. Replace the microprocessor-board assembly (trained service technician only, see “Removing the microprocessor-board assembly” on page 171 and “Replacing the microprocessor-board assembly” on page 173. 4.
Microprocessor 1 - 4 error LEDs	When one of these LEDs is lit, it indicates that an error has occurred in the associated microprocessor. Note: You must remove the top cover bracket before you can see these LEDs.
Microprocessor-board error LED	When this LED is lit, it indicates that an error has occurred on the microprocessor board. Note: You must remove the memory card or memory card filler from memory card connector 7 before you can see this LED.

I/O-board connectors

This topic provides an illustration that shows the connectors on the I/O board.

The following illustration shows the connectors on the I/O board.




Note: Slot 2 is electrically only x4.

I/O-board LEDs

This topic provides an illustration that shows the LEDs on the I/O board.

The following illustration shows the LEDs on the I/O board.



“I/O-board LEDs” on page 26 describes the function of each non-light path diagnostics status LED.


Table 8. I/O-board non-light-path-diagnostics status LEDs

LED	Description
Slot 1 - 7 error LEDs	When one of these LEDs is lit, it indicates that an error has occurred in the associated I/O slot.
I/O board error LED	When this LED is lit, it indicates that an error has occurred on the I/O board. Note: You must look at the server at an angle from the front to see this LED.

I/O-board jumpers

This topic provides an illustration that shows the jumpers on the I/O board.

The following illustration shows the jumpers on the I/O board.



“I/O-board jumpers” on page 27 describes the function of each jumper block.


Table 9. I/O-board jumper blocks

Jumper name	Description
Wake on LAN bypass (J31)	The default position is pins 1 and 2. Move the jumper to pins 2 and 3 to prevent a Wake on LAN packet from waking the system when the system is in the powered-off state.
Password override (J29)	<p>When you change the position of this jumper, the server bypasses the power-on password check. The next time you turn on the server, the Setup Utility starts and you can change or delete the power-on password. You do not need to move the jumper back to the default position (pins 1 and 2) after the password is overridden.</p> <p>Changing the position of this jumper does not affect the administrator password check if an administrator password is set. If you forget the administrator password, you must replace the I/O board. (Replacement of the I/O board for this reason is not covered by the warranty.)</p> <p>For more information about passwords, see “Passwords” on page 207.</p>
Boot recovery (J22)	The default position is pins 1 and 2 (to use the primary page during startup). Move the jumper to pins 2 and 3 to use the secondary page during startup.

SAS-backplane connectors

This topic provides an illustration that shows the connectors on the SAS backplane.

The following illustration shows the connectors on the SAS backplane.



Memory expansion module features and specifications

This topic provides a table with all of the memory expansion module features and specifications.

The following table contains a summary of the features and specifications of the IBM MAX5 for System X memory expansion module.

Table 10. Memory expansion module features and operating specifications

<ul style="list-style-type: none"> • Intel 7500 or 7510 scalable memory buffer (depending on your model) with eight memory ports (four DIMMs on each port) • Xcellerated Memory Technology • EXA5 chip set • QuickPath Interconnect (QPI) architecture technology: <ul style="list-style-type: none"> – Four 6.4 gigatransfers (GT) per second QuickPath Interconnect links (for up to 2 microprocessors) – Three 10.0 GT per second EXA5 scalability links • Scalability: <ul style="list-style-type: none"> – Connects to the (4U) rack servers using QPI cables – Connects to other memory expansion modules, using EXA5 link cables – Scales up to 2 nodes (two memory expansion modules + two servers) 	<p>DIMMs:</p> <ul style="list-style-type: none"> • Minimum: 2 DIMMs, 4 GB • Maximum: 32 DIMM slots (up to 512 GB, 1 TB when 32 GB DIMMs are available, of memory, depending on the DIMM size) • Type of DIMMs: PC3-10600R-999, 1067 MHz, ECC, DDR3 registered SDRAM dual inline memory modules (DIMMs) • Supports 2 GB, 4 GB, 8 GB, and 16 GB DIMMs (32 GB DIMMs when available) <p>Fans:</p> <ul style="list-style-type: none"> • Five hot-swap 40 mm fans 	<p>Power supply:</p> <ul style="list-style-type: none"> • One 675-watt (110 - 220 V ac auto-sensing) standard • Supports up to two 675-watt (110 - 220 V ac auto-sensing) hot-swap power supplies with built-in fans for redundancy support <p>Light path diagnostics LEDs:</p> <ul style="list-style-type: none"> • Board • Configuration • Fan • Link(for QPI and EXA5 links) • Locate • Memory • Power-on • Power supply
---	--	---

Table 10. Memory expansion module features and operating specifications (continued)

<p>Acoustical noise emissions: For maximum system configurations (32 DIMMs installed)</p> <ul style="list-style-type: none"> • Sound power (idling): 6.2 bels • Sound power (operating): 6.8 bels <p>Size:</p> <ul style="list-style-type: none"> • Height: 4.4 cm (1.73 in.) • Depth: 72.4 cm (28.5 in.) • Width: 48.3 cm (19.0 in.) • Weight: approximately 12.8 kg (28.2 lb) for a standard unit; when fully configured, 15.4 kg (33.9 lb) 	<p>Environment:</p> <ul style="list-style-type: none"> • Air temperature: <ul style="list-style-type: none"> – Enclosure on: 10° to 35°C (50° to 95°F); altitude: 0 to 914.4 m (3000 ft). Decreased system temperature by 0.75° for every 1000 ft increase in altitude. – Enclosure off: 5° to 45°C (41° to 113°F) – Shipment: -40°C to +60°C (-40°F to 140°F) • Humidity: <ul style="list-style-type: none"> – Enclosure on: 20% to 80%; maximum dew point: 21°C (70°F) – Enclosure off: 8% to 80%; maximum dew point: 27°C (80°F) – Shipment: 5% to 100% • Particulate contamination: <p>Attention: Airborne particulates and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the server. For information about the limits for particulates and gases, see “Particulate contamination” on page 1033.</p> 	<p>Heat output:</p> <p>Approximate heat output:</p> <ul style="list-style-type: none"> • Minimum configuration: 314 Btu per hour (92 watts) • Maximum configuration 2048 Btu per hour (600 watts) <p>Electrical input:</p> <ul style="list-style-type: none"> • Sine-wave input (50 - 60 Hz) required • Input voltage low range: <ul style="list-style-type: none"> – Minimum: 90 V ac – Maximum: 136 V ac • Input voltage high range: <ul style="list-style-type: none"> – Minimum: 198 V ac – Maximum: 264 V ac • Approximate input kilovolt-amperes (kVA): <ul style="list-style-type: none"> – Minimum: 0.1 kVA – Maximum: 0.6 kVA <p>Note:</p> <ol style="list-style-type: none"> 1. Power consumption and heat output vary depending on the number and type of optional features that are installed and the power-management optional features that are in use. 2. These levels were measured in controlled acoustical environments according to the procedures specified by the American National Standards Institute (ANSI) S12.10 and ISO 7779 and are reported in accordance with ISO 9296. Actual sound-pressure levels in a given location might exceed the average stated values because of room reflections and other nearby noise sources. The declared sound-power levels indicate an upper limit, below which a large number of computers will operate.
---	--	--

Memory expansion module indicators, LEDs, and power

This topic discusses memory expansion module indicators, LEDs, and power.


This section describes the indicators and light-emitting diodes (LEDs) on the front and rear of the IBM MAX5 for System x memory expansion module.

Front view

This topic provides an illustration that shows the indicators on the front of the memory expansion module.

The following illustration shows the indicators on the front of the memory expansion module. All of the LEDs are controlled by the server integrated management module (IMM).

Note: The memory expansion module does not have a power-on button. The memory expansion module and all other functions are controlled by the server to which it is connected.




- **Operator information panel:** This panel contains the indicators for the memory expansion module.
 - **Power-on LED:** When this green LED is lit, it indicates that the memory expansion module is powered on.
 - **Locate LED:** Use this blue LED to locate the memory expansion module. The locate LED also has a button that you can press to light up other servers or other memory expansion modules to which the memory expansion module is connected.
 - **Power supply fault (error) LED:** When this amber LED is lit, it indicates a faulty hot-swap power-supply.
 - **Memory error LED:** When this amber LED is lit, it indicates a DIMM problem.
 - **Link error LED:** When this amber LED is lit, indicates that a QPI link fault or a EXA link fault has occurred. The port LED for the link that has been disconnected will not be lit on the rear of the memory expansion module. EXA link LEDs are on the rear of the memory expansion module and the QPI link LEDs are on the server to which the memory expansion module is connected.
 - **Fan error LED:** When this amber LED is lit, it indicates a fan error.
 - **System board error LED:** When this amber LED is lit, it indicates a memory expansion module system-board tray error.
 - **Configuration error LED:** When this amber LED is lit, it indicates a configuration error. The memory error LED might be lit to indicate a memory configuration error.

Rear view

This topic discusses the indicators on the rear of the IBM MAX5 for System x memory expansion module,

The following illustration shows the indicators on the rear of the IBM MAX5 for System x memory expansion module:



- **Power-on LED:** When this green LED is lit, it indicates that the memory expansion module is powered on. This LED is functionally equivalent to the power-on LED on the front of the memory expansion module.
- **Locate LED:** When this blue LED is lit, it indicates that the command from the server IMM to the memory expansion module is complete. Use this blue LED to locate the memory expansion module. The front locate LED also has a button that you can press to locate other servers or other memory expansion modules to which the memory expansion module is connected. This LED is functionally equivalent to the locate LED on the front of the memory expansion module.
- **System error LED:** When this LED is lit, it indicates that a system error has occurred.
- **QPI ports:** Insert either a QPI cable or a filler panel in each of these connectors.

Note: When you handle the QPI cables, take precautions to avoid damaging the high density interface. Dropping or incorrectly connecting the QPI cables can damage the high density interface. Store the protective covers that come on the end of the QPI cables for reuse when you perform maintenance on the server or memory expansion module or when you remove the cables of any reason.

- **Power connector:** Connect the power cord to this connector.
- **AC power LED:** Each hot-swap power supply has an ac power LED and a dc power LED. When the ac power LED is lit, it indicates that sufficient power is coming into the power supply through the power cord. During typical operation, both the ac and dc power LEDs are lit.
- **DC power LED:** Each hot-swap power supply has a dc power LED and an ac power LED. When the dc power LED is lit, it indicates that the power supply is supplying adequate dc power to the memory expansion module. During normal operation, both the ac and dc power LEDs are lit.
- **EXA link LED:** When this green LED is lit, it indicates that a EXA link is functioning.

Turning the memory expansion module on and off

This topic explains how to turn the memory expansion module on and off.


Because the memory expansion module is controlled by the server, turning on the memory expansion module refers to connecting the memory expansion module power cord into the power source and pressing the power-control button on a host server that is connected to the memory expansion module and is configured to identify the expansion module. Normally, the operating system on the server starts, and the server issues a power-on request to the memory expansion module. The memory expansion module is turned off only if the connected server issues a power-off request, and you have disconnected the memory expansion module power cord from the power source. You cannot turn off the memory expansion module manually.

Statement 5



CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.




You can disconnect the memory expansion module power cords from the power source to shut off all power immediately without damaging the memory expansion module, but it might cause an unrecoverable error and loss of data on the connected server.

Memory expansion module internal connectors and buttons

This section provides illustrations showing the internal connectors and buttons on the memory expansion module system-board tray.

The illustrations in this section show the internal connectors and buttons on the memory expansion module system-board tray. The illustrations might differ slightly from your hardware.



Chapter 3. Diagnostics

This topic provides general information about diagnostic tools to help resolve issues with the server.

This chapter describes the diagnostic tools that are available to help you solve problems that might occur in the server.

If you cannot diagnose and correct a problem by using the information in this chapter, see Appendix D, “Getting help and technical assistance,” on page 1027 for more information.

Diagnostic tools

This topic provides a list of tools to help you diagnose and resolve issues with the server.

The following tools are available to help you diagnose and solve hardware-related problems:

- **Light path diagnostics**

Use light path diagnostics to diagnose system errors quickly. See “Light path diagnostics” on page 57 for more information.

- **IBM Dynamic System Analysis**

IBM Dynamic System Analysis (DSA) collects and analyzes system information to aid in diagnosing server problems. DSA collects the following information about the server:

- Drive health information
- Event logs for service processors
- Hardware inventory, including PCI and USB information
- Installed applications and hot fixes
- Kernel modules
- Light path diagnostics status
- Network interfaces and settings
- Service processor (integrated management module) status and configuration
- System configuration
- Vital product data and firmware information

DSA creates a DSA log, which is a chronologically ordered merge of the system-event log (as the IPMI event log), the integrated management module (IMM) chassis-event log (as the ASM event log), and the operating-system event logs. You can send the DSA log as a file to IBM service to aid in problem determination or view the information as a text file or HTML file.

Note: Use the latest available version of DSA to make sure that you are using the most recent configuration data.

- **Troubleshooting tables**

These tables list problem symptoms and actions to correct the problems. See “Troubleshooting tables” on page 42.

- **IBM Electronic Service Agent**

IBM Electronic Service Agent is a software tool that monitors the server for hardware error events and automatically submits electronic service requests to

IBM service. Also, it can collect and transmit system configuration information on a scheduled basis so that the information is available to you and your support representative. It uses minimal system resources, is available free of charge, and can be downloaded from the web. For more information and to download Electronic Service Agent, go to <http://www.ibm.com/support/electronic/>.

- **POST error codes and error logs**

The power-on self-test (POST) generates messages to indicate successful test completion or the detection of a problem. See Appendix C, “UEFI/POST error codes,” on page 1013 for more information.

Event logs

This topic provides details about the error codes and messages that display in various types of event logs.

Error codes and messages are displayed in the following types of event logs:

- **POST event log:** This log contains the three most recent error codes and messages that were generated during POST. You can view the POST event log from the Setup utility.
- **System-event log:** This log contains POST and system management interrupt (SMI) events and all events that are generated by the BMC that is embedded in the IMM. You can view the system-event log through the Setup utility and through the Dynamic System Analysis (DSA) program (as IPMI event log).

The system-event log is limited in size. When it is full, new entries will not overwrite existing entries; therefore, you must periodically save and clear the system-event log through the Setup utility. When you are troubleshooting, you might have to save and then clear the system-event log to make the most recent events available for analysis.

Messages are listed on the left side of the screen, and details about the selected message are displayed on the right side of the screen. To move from one entry to the next, use the Up Arrow (↑) and Down Arrow (↓) keys or the Page Up and Page Down keys.

Some IMM sensors cause assertion events to be logged when their setpoints are reached. When a setpoint condition no longer exists, a corresponding deassertion event is logged. However, not all events are assertion-type events.

- **Integrated management module (IMM) event log:** This log contains a filtered subset of all IMM, POST, and system management interrupt (SMI) events. you can view the IMM event log through the IMM Web interface and through the Dynamic System Analysis (DSA) program (as the ASM event log).
- **DSA log:** This log is generated by the Dynamic System Analysis (DSA) program, and it is a chronologically ordered merge of the system-event log (as the IPMI event log), the IMM chassis-event log (as the ASM event log), and the operating-system event logs. You can view the DSA log through the DSA program.

Note: In a two-node configuration, many critical events and their recovery events are forwarded to the primary server. For a complete listing of all the events, go to each node to view the logs.

Viewing event logs through the Setup utility

This topic provides instructions on how to view event logs using the Setup utility.

About this task

To view the POST event log or system-event log, complete the following steps:

Procedure

1. Turn on the server.
2. When the prompt <F1> Setup is displayed, press F1. If you have set both a password and an administrator password, you must type the administrator password to view the event logs.
3. System Event Logs
 - To view the POST event log, select **POST Event Viewer**.
 - To view the system-event log, select **System Event Log**.

Viewing event logs without restarting the server

This topic provides instructions on viewing event logs without having to restart the server.

About this task

If the server is not hung, methods are available for you to view one or more event logs without having to restart the server.

If you have executed Dynamic System Analysis (DSA) Portable, you can use it to view the system-event log (as the IPMI event log), the IMM event log (as the ASM event log), the operating-system event logs, or the merged DSA log. You can also use DSA Preboot to view these logs, although you must restart the server to use DSA Preboot. To download DSA Portable, update DSA Preboot, or to download a DSA Preboot CD image, go to <http://www.ibm.com/systems/support/supportsite.wss/docdisplay?lnodocid=SERV-DSA&brandind=5000008>.

Results

If IPMItool is installed in the server, you can use it to view the system-event log. Most recent versions of the Linux operating system come with a current version of IPMItool. For an overview of IPMI, go to <http://www.ibm.com/developerworks/linux/blueprints/> and click **Using Intelligent Platform Management Interface (IPMI) on IBM Linux platforms**.

Note: Changes are made periodically to the IBM web site. The actual procedure might vary slightly from what is described in this document.

You can view the IMM event log through the **Event Log** link in the IMM web interface.

The following table describes the methods that you can use to view the event logs, depending on the condition of the server. The first two conditions generally do not require that you restart the server.

Table 11. Methods for viewing event logs

Condition	Action
The server is not hung and is connected to a network.	Use any of the following methods: <ul style="list-style-type: none"> • Run DSA Portable to view the event logs or create an output file that you can send to IBM service. • In a web browser, type the IP address of the IMM and go to the Event Log page. • Use IPMItool to view the system-event log.
The server is not hung and is not connected to a network.	Use IPMItool locally to view the system-event log.
The server is hung.	<ul style="list-style-type: none"> • Restart the server and press F2 to start DSA Preboot and view the event logs. • Alternatively, you can restart the server and press F1 to start the Setup utility and view the POST event log or system-event log. For more information, see “Viewing event logs through the Setup utility” on page 39.

Checkout procedures

This topic provides details about the checkout procedure used to diagnose problems with the server.

The checkout procedure is the sequence of tasks that you should follow to diagnose a problem in the server.

About the checkout procedure

This topic provides important safety and general information to review before you perform the checkout procedure.

Before you perform the checkout procedure for diagnosing hardware problems, review the following information:

- Read the safety information that begins with “Safety” on page v.
- IBM Dynamic System Analysis (DSA) provides the primary method of testing the major components of the server, such as the microprocessor board, Ethernet controller, DIMMs, memory controller, optical drives, and hard disk drives. You can also use them to test some external devices. If you are not sure whether a problem is caused by the hardware or by the software, you can use DSA to confirm that the hardware is working correctly.
- When you run DSA, a single problem might cause more than one error message. When this happens, correct the cause of the first error message. The other error messages usually will not occur the next time you run DSA.

Exception: If multiple error codes or light path diagnostics LEDs indicate a microprocessor error, the error might be in a microprocessor or in a

microprocessor socket. See “Microprocessor problems” on page 49 for information about diagnosing microprocessor problems.

- Before you run the diagnostic programs, you must determine whether the failing server is part of a shared hard disk drive cluster (two or more servers sharing external storage devices). If it is part of a cluster, you can run all diagnostic programs except the ones that test the storage unit (that is, a hard disk drive in the storage unit) or the storage adapter that is attached to the storage unit. The failing server might be part of a cluster if any of the following conditions is true:
 - You have identified the failing server as part of a cluster (two or more servers sharing external storage devices).
 - One or more external storage units are attached to the failing server and at least one of the attached storage units is also attached to another server or unidentifiable device.
 - One or more servers are located near the failing server.

Important: If the server is part of a shared hard disk drive cluster, run one test at a time. Do not run any suite of tests, such as “quick” or “normal” tests, because this might enable the hard disk drive diagnostic tests.

- In a two-node configuration, be sure to check the LEDs and view the logs on both servers to determine whether the error occurred on the primary or secondary server.
- If the server is halted and a POST error code is displayed, see Appendix C, “UEFI/POST error codes,” on page 1013. If the server is halted and no error message is displayed, see “Troubleshooting tables” on page 42 and “Solving undetermined problems” on page 77.
- For information about power-supply problems, see “Power problems” on page 53 and “Power-supply LEDs” on page 69.
- For intermittent problems, check the event logs; see “Event logs” on page 38 and “IBM Dynamic System Analysis” on page 71.

Performing the checkout procedure

This topic provides instructions on how to perform the checkout procedure to diagnose problems with the server.

About this task

To perform the checkout procedure, complete the following steps:

Procedure

1. Is the server part of a cluster?
 - **No:** Go to step “Performing the checkout procedure.”
 - **Yes:** Shut down all failing servers that are related to the cluster. Go to step “Performing the checkout procedure.”
2. Complete the following steps:
 - a. Check the power-supply LEDs (see “Power-supply LEDs” on page 69).
 - b. Turn off the server and all external devices.
 - c. Check all internal and external devices for compatibility (see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for additional information).
 - d. Check all cables and power cords.
 - e. Set all monitor controls to the middle positions.

- f. Turn on all external devices.
 - g. Turn on the server. If the server does not start, see “Troubleshooting tables.”
 - h. Check the system-error LED on the operator information panel. If it is flashing, check the light path diagnostics LEDs (see “Light path diagnostics” on page 57).
 - i. Check for the following results:
 - Successful completion of POST
 - Successful completion of startup, which is indicated by a readable display of the operating-system desktop
3. Is there a readable image on the monitor screen?
- **No:** Find the failure symptom in “Troubleshooting tables”; if necessary, see “Solving undetermined problems” on page 77.
 - **Yes:** Run DSA (see “IBM Dynamic System Analysis” on page 71).
 - If DSA reports an error, follow the instructions in Appendix A, “DSA diagnostic test results,” on page 227.
 - If DSA does not report an error but you still suspect a problem, see “Solving undetermined problems” on page 77.

Troubleshooting tables

This topic contains troubleshooting tables to help find solutions to problems with symptoms.

About this task

Use the troubleshooting tables to find solutions to problems that have identifiable symptoms.

If you cannot find a problem in these tables, see “IBM Dynamic System Analysis” on page 71 for information about testing the server.

If you have just added new software or a new optional device and the server is not working, complete the following steps before you use the troubleshooting tables:

Procedure

1. Check the light path diagnostics LEDs on the operator information panel (see “Light path diagnostics” on page 57).
2. Remove the software or device that you just added.
3. Run IBM Dynamic System Analysis (DSA) to determine whether the server is running correctly (for information about using DSA, see “IBM Dynamic System Analysis” on page 71).
4. Reinstall the new software or new device.

Results

CD or DVD drive problems

This topic provides a list of suggested actions to take when you have problems with the CD or DVD drive.

About this task

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
The CD or DVD drive is not recognized.	<ol style="list-style-type: none"> 1. Make sure that: <ul style="list-style-type: none"> • The IDE or SATA channel to which the CD or DVD drive is attached (primary or secondary) is enabled in the Setup utility. • The signal cable and connector are not damaged and the connector pins are not bent. • All cables and jumpers are installed correctly. • The correct device driver is installed for the CD or DVD drive. 2. Run the CD or DVD drive diagnostic programs (see “IBM Dynamic System Analysis” on page 71). 3. Reseat the following components: <ol style="list-style-type: none"> a. CD or DVD drive (see “Removing the DVD drive” on page 115 and “Replacing the DVD drive” on page 116) b. CD or DVD drive cable c. I/O-board assembly (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144) 4. Replace the components listed in step “CD or DVD drive problems” one at a time, in the order shown, restarting the server each time.
A CD or DVD is not working correctly.	<ol style="list-style-type: none"> 1. Clean the CD or DVD. 2. Use a different CD or DVD in the drive. 3. Run the CD or DVD drive diagnostic programs (see “IBM Dynamic System Analysis” on page 71). 4. Check the connector and signal cable for bent pins or damage. 5. Reseat the CD or DVD drive (see “Removing the DVD drive” on page 115 and “Replacing the DVD drive” on page 116). 6. Replace the CD or DVD drive.
The CD or DVD drive tray is not working or opening.	<ol style="list-style-type: none"> 1. Make sure that the server is turned on. 2. Insert the end of a straightened paper clip into the manual tray-release opening. 3. Reseat the CD or DVD drive (see “Removing the DVD drive” on page 115 and “Replacing the DVD drive” on page 116). 4. Replace the CD or DVD drive.

Embedded hypervisor problems

This topic provides suggested actions for correcting problems with the embedded hypervisor.

About this task

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
An embedded hypervisor device is not listed in the expected boot order, or is not in the list of boot devices, or a similar problem has occurred.	<ol style="list-style-type: none">1. Make sure the embedded hypervisor device is selected in the boot menu (in the Setup utility and in Select Boot Device).2. If the embedded hypervisor is on an internal flash memory device, make sure that the internal flash memory device is seated in the connector correctly (see “Removing the internal flash memory” on page 140 and “Replacing the internal flash memory” on page 141).3. See the documentation that comes with the embedded hypervisor for setup and configuration information.4. Make sure that other software works on the server.

General problems

This topic provides solutions for general problems with the server.

About this task

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
An LED is not working or a similar problem has occurred.	If the part is a CRU, replace it. If the part is a FRU, the part must be replaced by a trained service technician (see “Replaceable server components” on page 83 to determine whether the part is a CRU or a FRU).
Power LED blinks quickly or system can't be powered on.	<ol style="list-style-type: none">1. Reseat the system.2. See “Confirm and recover IMM boot image failure” on page 75.

Hard disk drive problems

This topic provides a list of suggested actions for problems with the hard disk drive.

About this task

<ul style="list-style-type: none"> Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. See Chapter 4, "Parts listing, Types 7145, 7146, 7143, and 7191," on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). If an action step is preceded by "(Trained service technician only)," that step must be performed only by a trained service technician. 	
Symptom	Action
Not all drives are recognized by the DSA hard disk drive diagnostic test.	Remove the drive that is indicated by DSA (see "Removing a hot-swap hard disk drive" on page 117); then, run the hard disk drive diagnostic test again (see "IBM Dynamic System Analysis" on page 71). If the remaining drives are recognized, replace the drive that you removed with a new one.
The server stops responding during the hard disk drive diagnostic test.	Remove the hard disk drive that was being tested when the server stopped responding (see "Removing a hot-swap hard disk drive" on page 117), and run the diagnostic test again (see "IBM Dynamic System Analysis" on page 71). If the hard disk drive diagnostic test runs successfully, replace the drive that you removed with a new one (see "Replacing a hot-swap hard disk drive" on page 118).
A hard disk drive was not detected while the operating system was being started.	Reseat all hard disk drives and cables; then, run the DSA hard disk drive diagnostic test again (see "IBM Dynamic System Analysis" on page 71).
A hard disk drive passes the DSA hard disk drive diagnostic test but the problem remains.	Run the diagnostic SAS Fixed Disk Test (see "IBM Dynamic System Analysis" on page 71). Note: This test is not available to servers that use RAID or servers with IDE or SATA hard disk drives.

Intermittent problems

This topic provides possible solutions to problems that occur occasionally and are difficult to diagnose.

About this task

<ul style="list-style-type: none"> Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. See Chapter 4, "Parts listing, Types 7145, 7146, 7143, and 7191," on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). If an action step is preceded by "(Trained service technician only)," that step must be performed only by a trained service technician. 	
Symptom	Action
A problem occurs only occasionally and is difficult to diagnose.	<ol style="list-style-type: none"> Make sure that: <ul style="list-style-type: none"> All cables and cords are connected securely to the rear of the server and attached devices. When the server is turned on, air is flowing from the fan grill. If there is no airflow, the fan is not working. This can cause the server to overheat and shut down. Check the event logs (see "Event logs" on page 38). See "Solving undetermined problems" on page 77.

USB keyboard, mouse, or pointing-device problems

This topic provides suggested actions to resolve problems with the USB keyboard, mouse, or pointing device attached to the server.

About this task

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
All or some keys on the keyboard do not work.	<ol style="list-style-type: none"> 1. If you have installed a USB keyboard, run the Setup utility and enable keyboardless operation to prevent the POST error message 301 from being displayed during startup. 2. See for information about keyboard compatibility. 3. Make sure that: <ul style="list-style-type: none"> • The keyboard cable is securely connected. • The server and the monitor are turned on. 4. Reseat the following components: <ol style="list-style-type: none"> a. Keyboard b. I/O-board assembly (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144) 5. Replace the components listed in step “USB keyboard, mouse, or pointing-device problems” one at a time, in the order shown, restarting the server each time.
The USB mouse or USB pointing device does not work.	<ol style="list-style-type: none"> 1. See for information about mouse compatibility. 2. Make sure that: <ul style="list-style-type: none"> • The mouse or pointing-device USB cable is securely connected to the server, and the device drivers are installed correctly. • The server and the monitor are turned on. • Keyboardless operation is enabled in the Setup utility. 3. If you are using a USB hub, disconnect the USB device from the hub and connect it directly to the server. 4. Reseat the following components: <ol style="list-style-type: none"> a. Mouse or pointing device b. I/O-board assembly (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144) 5. Replace the components listed in step “USB keyboard, mouse, or pointing-device problems” one at a time, in the order shown, restarting the server each time.

Memory problems

This topic provides a list of suggestion actions to help resolve problems with memory that is displayed on the server.

About this task

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
<p>The amount of system memory that is displayed is less than the amount of installed physical memory.</p>	<p>Note: If you change the memory, you must update the memory configuration in the Setup utility.</p> <ol style="list-style-type: none"> 1. Make sure that: <ul style="list-style-type: none"> • No error LEDs are lit on the operator information panel, the memory card, or on the memory expansion module. • Memory mirroring does not account for the discrepancy. • Scalability does not account for the discrepancy. Note: Each node in a multi-node configuration uses 256 MB of system memory. • In a two-node configuration, make sure that both nodes have started and all the devices between the two nodes have been counted. • The memory modules are seated correctly (see “Removing a DIMM” on page 137 and “Replacing a DIMM” on page 138). • You have installed the correct type of memory. • If you changed the memory, you updated the memory configuration in the Setup utility. • All banks of memory are enabled. The server might have automatically disabled a memory bank when it detected a problem, or a memory bank might have been manually disabled. 2. Check the POST event log for error message 289. If a DIMM was disabled, run the Setup utility and enable the DIMM. See Chapter 6, “Configuration information and instructions,” on page 201. 3. Run memory diagnostics (see “IBM Dynamic System Analysis” on page 71). 4. Make sure that there is no memory mismatch when the server is at the minimum memory configuration (two 1 GB DIMMs). 5. Reinstall the removed DIMMs, one pair at a time, in the memory cards and the memory expansion module, making sure that the DIMMs in each pair match. 6. Reinstall the removed memory cards one memory card at a time (see “Removing a memory card” on page 136 and “Replacing a memory card” on page 137), making sure that the DIMMs on each card match. 7. Reseat the following components: <ol style="list-style-type: none"> a. DIMM b. Memory card 8. Replace the components listed in step “Memory problems” on page 47 one at a time, in the order shown, restarting the server each time. 9. If the DIMM was disabled, run the Setup utility and enable the DIMM. See Chapter 6, “Configuration information and instructions,” on page 201. <p>For additional information about memory, see the <i>IBM eX5 Portfolio Overview IBM System x3850 X5, x3950 X5, and BladeCenter HX5</i> at http://www.redbooks.ibm.com/abstracts/tips0054.html.</p>

Microprocessor problems

This topic explores a list of possible solutions for problems with the primary microprocessor on the server.

About this task

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
The server does not function after replacing the primary microprocessor or the primary microprocessor error LED is lit.	<ol style="list-style-type: none"> 1. Correct any errors that are indicated by the light path diagnostics LEDs (see “Light path diagnostics” on page 57). 2. Make sure that the server supports all the microprocessors and that the microprocessors match in speed and cache size. 3. Reseat the following components: <ol style="list-style-type: none"> a. Microprocessor 1 (see “Removing a microprocessor and heat sink” on page 161) b. (Trained service technician only) Microprocessor board (see “Removing the microprocessor-board assembly” on page 171 and “Replacing the microprocessor-board assembly” on page 173) 4. (Trained service technician only) If there is no indication of which microprocessor has failed, isolate the error by testing with one microprocessor at a time. 5. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. (Trained service technician only) Microprocessor 1 b. (Trained service technician only) Microprocessor board 6. (Trained service technician only) If multiple error codes or light path diagnostics LEDs indicate a microprocessor error, reverse the locations of two microprocessors to determine whether the error is associated with a microprocessor or with a microprocessor socket. <ul style="list-style-type: none"> • (Trained service technician only) If the error is associated with a microprocessor, replace the microprocessor. • (Trained service technician only) If the error is associated with a microprocessor socket, replace the microprocessor board.

Monitor or video problems

This topic provides possible symptoms and solutions for problems with the monitor.

About this task

If you suspect a problem with your monitor, see the documentation that comes with the monitor for instructions for testing and adjusting the monitor. If you cannot diagnose the problem, call for service.

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
Testing the monitor.	<ol style="list-style-type: none"> 1. Make sure that the monitor cables are firmly connected. 2. In a two-node configuration, make sure that the monitor is connected to the primary server. 3. Try using a different monitor on the server, or try testing the monitor on a different server. 4. Replace the I/O-board shuttle.
The screen is blank.	<ol style="list-style-type: none"> 1. If the server is attached to a KVM switch, bypass the KVM switch to eliminate it as a possible cause of the problem: connect the monitor cable directly to the correct connector on the rear of the server. 2. Make sure that: <ul style="list-style-type: none"> • The server is turned on. If there is no power to the server, see “Power problems” on page 53. • The monitor cables are connected correctly. • The monitor is turned on and the brightness and contrast controls are adjusted correctly. 3. Make sure that the correct server is controlling the monitor, if applicable. 4. Make sure that damaged server firmware is not affecting the video; see “Recovering the server firmware” on page 73 for information about recovering from server firmware failure. 5. Observe the checkpoint code display on the light path diagnostics panel; if the codes are changing, go to the next step. 6. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. Monitor b. Video adapter (if one is installed) c. Replace the I/O-board shuttle. 7. See “Solving undetermined problems” on page 77 for information about solving undetermined problems.
The monitor works when you turn on the server, but the screen goes blank when you start some application programs.	<p>Make sure that:</p> <ul style="list-style-type: none"> • The application program is not setting a display mode that is higher than the capability of the monitor. • You installed the necessary device drivers for the application.

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
<p>The monitor has screen jitter, or the screen image is wavy, unreadable, rolling, or distorted.</p>	<ol style="list-style-type: none"> 1. If the monitor self-tests show that the monitor is working correctly, consider the location of the monitor. Magnetic fields around other devices (such as transformers, appliances, fluorescent lights, and other monitors) can cause screen jitter or wavy, unreadable, rolling, or distorted screen images. If this happens, turn off the monitor. Attention: Moving a color monitor while it is turned on might cause screen discoloration. Move the device and the monitor at least 305 mm (12 in.) apart, and turn on the monitor. Note: <ol style="list-style-type: none"> a. To prevent diskette drive read/write errors, make sure that the distance between the monitor and any external diskette drive is at least 76 mm (3 in.). b. Non-IBM monitor cables might cause unpredictable problems. 2. Reseat the monitor cable 3. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. Monitor cable b. Monitor c. I/O-board shuttle
<p>Wrong characters appear on the screen.</p>	<ol style="list-style-type: none"> 1. If the wrong language is displayed, update the server firmware with the correct language. 2. Reseat the monitor cable. 3. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. Monitor b. I/O-board shuttle

Optional-device problems

This topic provides a list of symptoms and suggestions for resolving problems with optional devices.

About this task

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
An IBM optional device that was just installed does not work.	<ol style="list-style-type: none"> 1. Make sure that: <ul style="list-style-type: none"> • The device is designed for the server (see). • You followed the installation instructions that came with the device and the device is installed correctly. • You have not loosened any other installed devices or cables. • You updated the configuration information in the Setup utility. Whenever memory or any other device is changed, you must update the configuration. 2. Reseat the device that you just installed. 3. Replace the device that you just installed.
An IBM optional device that used to work does not work now.	<ol style="list-style-type: none"> 1. Make sure that all of the hardware and cable connections for the device are secure. 2. If the device comes with test instructions, use those instructions to test the device. 3. If the failing device is a SCSI device, make sure that: <ul style="list-style-type: none"> • The cables for all external SCSI devices are connected correctly. • The last device in each SCSI chain, or the end of the SCSI cable, is terminated correctly. • Any external SCSI device is turned on. You must turn on an external SCSI device before turning on the server. 4. Reseat the failing device. 5. Replace the failing device.
POST reports the following PCI event: Redundant PCI Host Bridge IB Link Failed. Slot Number = NA. Bus Number = NA. Device ID = 0xffff. Vendor ID = 0xffff	<ol style="list-style-type: none"> 1. Check for bent pins between the I/O-board shuttle and the microprocessor board. 2. Replace the failing device.

Power problems

This topic provides possible solutions to problems with the power or power button on the server.

About this task

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
<p>The power-control button does not work, and the reset button does not work (the server does not start).</p> <p>Note: The power-control button will not function for up to 3 minutes after the server has been connected to ac power.</p>	<ol style="list-style-type: none"> 1. Check the light path to determine whether any LEDs are lit. If they are, follow the instructions for correcting light path errors (see “Light path diagnostics LEDs” on page 63). 2. Make sure that the operator information panel power-control button is working correctly: <ol style="list-style-type: none"> a. Disconnect the ac power cord for 20 seconds; then, reconnect the ac power cord and restart the server. b. Reseat the operator information panel cables, and then repeat step a. <ul style="list-style-type: none"> • If the server starts, reseat the operator information panel (see “Removing the operator information panel assembly” on page 118 and “Replacing the operator information panel assembly” on page 120). If the problem remains, replace the operator information panel. • If the server does not start, reseat the operator information panel. If the problem remains, replace the operator information panel. 3. Make sure that the reset button is working correctly: <ol style="list-style-type: none"> a. Disconnect the server power cords. b. Reconnect the power cords. c. Reseat the light path diagnostics panel cable (the operator information panel ribbon cable), and then repeat steps a and b. <ul style="list-style-type: none"> • If the server starts, replace the operator information panel (see “Removing the operator information panel assembly” on page 118 and “Replacing the operator information panel assembly” on page 120). • If the server does not start, go to step a and b. 4. Make sure that: <ul style="list-style-type: none"> • The power cords are correctly connected to the server and to a working electrical outlet. • The type of memory that is installed is correct. • The memory card is fully seated. • The LEDs on the power supply do not indicate a problem. • The microprocessors are installed in the correct sequence. • The firmware levels in the server and the memory expansion module are all the same. • The microprocessor types in the server and the memory expansion module are all the same. <p>(Continued on the next page)</p>

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
(continued)	<ol style="list-style-type: none"> 1. Reseat the following components: <ol style="list-style-type: none"> a. Memory card (see “Removing a memory card” on page 136 and “Removing the memory-card cage” on page 175) b. Operator information panel (see “Removing the operator information panel assembly” on page 118 and “Replacing the operator information panel assembly” on page 120) c. (Trained service technician only) Microprocessor board (see “Removing the microprocessor-board assembly” on page 171 and “Replacing the microprocessor-board assembly” on page 173) 2. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. Memory card b. Operator information panel c. (Trained service technician only) Microprocessor board 3. If you just installed an optional device, remove it, and restart the server. If the server now starts, you might have installed more devices than the power supply supports. 4. See “Power-supply LEDs” on page 69. 5. See “Solving undetermined problems” on page 77.
The server does not turn off.	<ol style="list-style-type: none"> 1. Determine whether you are using an Advanced Configuration and Power Management (ACPI) or a non-ACPI operating system. If you are using a non-ACPI operating system, complete the following steps: <ol style="list-style-type: none"> a. Press Ctrl+Alt+Delete. b. Turn off the server by holding the power-control button for 5 seconds. c. Restart the server. d. If the server fails POST and the power-control button does not work, disconnect the ac power cord for 20 seconds; then, reconnect the ac power cord and restart the server. 2. If the problem remains or if you are using an ACPI-aware operating system, suspect the microprocessor board.
The server unexpectedly shuts down, and the LEDs on the operator information panel are not lit.	See “Solving undetermined problems” on page 77.

Serial-device problems

This topic provides suggested actions to take to solve problems with serial devices.

About this task

<ul style="list-style-type: none"> Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
The number of serial ports that are identified by the operating system is less than the number of installed serial ports.	<ol style="list-style-type: none"> Make sure that: <ul style="list-style-type: none"> Each port is assigned a unique address in the Setup utility and none of the serial ports is disabled. The serial-port adapter (if one is present) is seated correctly. Reseat the serial port adapter (see “Removing an adapter” on page 110 and “Replacing an adapter” on page 111). Replace the serial port adapter.
A serial device does not work.	<ol style="list-style-type: none"> Make sure that: <ul style="list-style-type: none"> The device is compatible with the server. The serial port is enabled and is assigned a unique address. The device is connected to the correct connector (see “Internal LEDs, connectors, and jumpers” on page 22). Reseat the following components: <ol style="list-style-type: none"> Failing serial device Serial cable I/O-board assembly (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144) Replace the components listed in step 2, one at a time, in the order shown, restarting the server each time.

ServerGuide problems

This topic provides possible solutions to problems with the ServerGuide program.

About this task

<ul style="list-style-type: none"> Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
The <i>ServerGuide Setup and Installation</i> CD will not start.	<ol style="list-style-type: none"> Make sure that the server supports the ServerGuide program and has a startable (bootable) CD or DVD drive. If the startup (boot) sequence settings have been changed, make sure that the CD or DVD drive is first in the startup sequence. If more than one CD or DVD drive is installed, make sure that only one drive is set as the primary drive. Start the CD from the primary drive.

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
The operating-system installation program continuously loops.	Make more space available on the hard disk.
The ServerGuide program will not start the operating-system CD.	Make sure that the operating-system CD is supported by the ServerGuide program. See the <i>ServerGuide Setup and Installation</i> CD label for a list of supported operating-system versions.
The operating system cannot be installed; the option is not available.	Make sure that the server supports the operating system. If it does, either no logical drive is defined (SCSI RAID systems), or the ServerGuide System Partition is not present. Run the ServerGuide program and make sure that setup is complete.

Software problems

This topic provides possible solutions to problems with software installed on the server.

About this task

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 	
Symptom	Action
You suspect a software problem.	<ol style="list-style-type: none"> 1. To determine whether the problem is caused by the software, make sure that: <ul style="list-style-type: none"> • The server has the minimum memory that is needed to use the software. For memory requirements, see the information that comes with the software. If you have just installed an adapter, the server might have an adapter-address conflict. • The software is designed to operate on the server. • Other software works on the server. • The software works on another server. 2. If you receive any error messages while you use the software, see the information that comes with the software for a description of the messages and suggested solutions to the problem. 3. Contact your place of purchase of the software.

Universal Serial Bus (USB) port problems

This topic provides possible solutions to problems with USB devices.

About this task

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Symptom	Action
A USB device does not work.	<ol style="list-style-type: none">1. Run USB diagnostics (see “IBM Dynamic System Analysis” on page 71).2. Make sure that:<ul style="list-style-type: none">• The correct USB device driver is installed.• The operating system supports USB devices.3. Make sure that the USB configuration options are set correctly in the Setup utility (see “Configuring the server” on page 202 for more information).4. If you are using a USB hub, disconnect the USB device from the hub and connect it directly to the server.

Video problems

About this task

See “Monitor or video problems” on page 50.

Light path diagnostics

This topic provides information about light path diagnostics.

Light path diagnostics is a system of LEDs on various external and internal components of the server. When an error occurs, LEDs are lit throughout the server. By viewing the LEDs in a particular order, you can often identify the source of the error.

The server is designed so that LEDs remain lit when the server is connected to an ac power source but is not turned on, provided that the power supply is operating correctly. This feature helps you to isolate the problem when the operating system is shut down.

Any memory-card LED can be lit while the memory card is removed from the server so that you can isolate a problem. After ac power has been removed from the server, power remains available to these LEDs for up to 24 hours.

To view the memory card LEDs, press and hold the light path diagnostics button on the memory card to light the error LEDs. The LEDs that were lit while the server was turned on will be lit again while the button is pressed.


Many errors are first indicated by a lit information LED or system-error LED on the operator information panel on the front of the server. If one or both of these LEDs are lit, one or more LEDs elsewhere in the server might also be lit and can direct you to the source of the error.

Before you work inside the server to view light path diagnostics LEDs, read the safety information that begins with “Safety” on page v and “Handling static-sensitive devices” on page 100.


If an error occurs, view the light path diagnostics LEDs in the following order:

1. Check the operator information panel on the front of the server.
 - If the information LED is lit, it indicates that there is a suboptimal condition in the server.
 - If the system-error LED is lit, it indicates that an error has occurred.

The following illustration shows the operator information panel.



2. To view the light path diagnostics panel, press the release latch on the front of the operator information panel to the left; then, slide it forward. This reveals the light path diagnostics panel. Lit LEDs on this panel indicate the type of error that has occurred.




Note: (Trained service technician only) The NMI button is used for operating-system debugging purposes and will cause the server to reset if it is pressed.

Look at the system service label on the top of the server, which gives an overview of internal components that correspond to the LEDs on the light path diagnostics panel. This information and the information in “Light path diagnostics LEDs” on page 63 can often provide enough information to correct the error.

3. Remove the server cover and look inside the server for lit LEDs. Certain components inside the server have LEDs that will be lit to indicate the location of a problem. For example, a microprocessor error will light the LED next to the failing microprocessor on the microprocessor board.

The following illustration shows the LEDs on the microprocessor board.




Note:


- a. You must remove the memory card or memory card filler from memory card connector 7 before you can see the microprocessor board error LED.
- b. You must remove the top cover bracket before you can see the microprocessor error LEDs 1-4.

The following illustration shows the LEDs on a memory card.

Note: You can view the LED on top of the memory card while the card is in the server. When you remove the memory card from the server, you must press the light path diagnostics button on the card to relight the LEDs to identify the error.



The following illustration shows the LEDs on the I/O board.




Remind button

This topic provides a description of the Remind button.

You can use the remind button on the light path diagnostics panel to put the system-error LED on the operator information panel into Remind mode.

The following illustration shows the operator information panel.



When you press the remind button, you acknowledge the error but indicate that you will not take immediate action. The system-error LED flashes while it is in Remind mode and stays in Remind mode until one of the following conditions occurs:

- All known errors or suboptimal conditions are corrected.
- The server is powered back on.
- A new error or suboptimal condition occurs, causing the system-error LED to be lit again.

You can also use the remind button to turn off the LOG LED on the light path diagnostics panel and the information LED.

In multi-node configurations, you can also press this button during startup to start the server as a stand-alone server.

Light path diagnostics LEDs

This topic provides a table that describes the LEDs on the light path diagnostics panel.

The following table describes the LEDs on the light path diagnostics panel. If the information LED or system-error LED on the front of the server is lit, determine whether any LEDs on the light path diagnostics panel are lit, and then refer to this table for the suggested action to correct the detected problem.

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 		
Light path diagnostics LED	Description	Action
All LEDs are off (only the power LED is lit or flashing).		No action is necessary.
All LEDs are off (the power LED is lit or flashing and the system-error LED is lit).	A machine check has occurred. The server is identifying the machine check, the server was interrupted while identifying the machine check, or the server was unable to identify the machine check.	<ol style="list-style-type: none"> 1. Wait several minutes for the server to identify the machine check, and the server will restart. 2. (Trained service technician only) Extract the machine check data, which will be used to identify the machine check.
OVERSPEC	There is insufficient power to power the system. The LOG LED might also be lit.	<ol style="list-style-type: none"> 1. Add a power supply if only one power supply is installed. 2. Use 220 V ac instead of 110 V ac. 3. Reseat the power supply (see “Removing a hot-swap power supply” on page 123 and “Replacing the hot-swap power supply” on page 127). 4. Remove optional devices. 5. Replace the power supply.
LOG	Information is present in the system-event log.	<ol style="list-style-type: none"> 1. Check the log for possible errors. 2. Save the log if necessary and clear it.

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Light path diagnostics LED	Description	Action
LINK	<p>There is a fault in a QPI port or the QPI scalability cables.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. This LED remains lit until the problem is solved and the server is turned off and restarted. 2. If a fault occurs, the SMP Expansion Port link LED on the failed port is off. 	<ol style="list-style-type: none"> 1. If the CNFG LED is also lit, make sure that your QPI wrap cards or QPI scalability cables are installed and in the proper sequence. 2. If a memory expansion module is attached to the server, check to determine whether the front LINK error LED is lit on the memory expansion module or the server. The LED that is lit determines which device you should troubleshoot. 3. Check the QPI port link LEDs to find the failing port or cable. (The rear LED on the failing port or cable is off.) 4. Reseat the QPI wrap cards or the QPI scalability cables (if installed). Attention: Do not disconnect or connect any of the cables when the server or memory expansion module is connected to power. 5. Replace the QPI wrap cards or the QPI scalability cables (if installed). Attention: Do not disconnect or connect any of the cables when the server or memory expansion module is connected to power. 6. (Trained service technician only) Replace the I/O board (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144).
PS	<p>A power supply has failed or has been removed.</p> <p>Note: In a redundant power configuration, the dc power LED on one power supply might be off.</p>	<ol style="list-style-type: none"> 1. If a memory expansion module is attached to the server, check to determine whether the front PS error LED is lit on the memory expansion module or the server. The LED that is lit determines which device you should troubleshoot. 2. Reinstall the removed power supply (see “Replacing the hot-swap power supply” on page 127). 3. Check the individual power-supply LEDs to find the failing power supply (see “Rear view LEDs” on page 17). 4. Reseat the failing power supply (see “Removing a hot-swap power supply” on page 123 and “Replacing the hot-swap power supply” on page 127). 5. Make sure that the power cord is fully seated in the power-supply inlet and the ac power source. 6. Replace the power supply.

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Light path diagnostics LED	Description	Action
PCI	<p>A PCI adapter has failed.</p> <p>Note: The error LED next to the failing adapter on the I/O-board shuttle is also lit.</p>	<ol style="list-style-type: none"> 1. See the system-event log (see “Event logs” on page 38). 2. Reseat the following components: <ol style="list-style-type: none"> a. Failing adapter (see “Removing an adapter” on page 110 and “Replacing an adapter” on page 111) b. The I/O board assembly (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144) 3. Replace the components listed in step 2, one at a time, in the order shown, restarting the server each time.
FAN	<p>A fan has failed or has been removed.</p> <p>Note: A failing or missing fan can also cause the TEMP LED to be lit.</p>	<ol style="list-style-type: none"> 1. If a memory expansion module is attached to the server, check to determine whether the front FAN error LED is lit on the memory expansion module or the server. The LED that is lit determines which device you should troubleshoot. 2. Reinstall the removed fan (see “Replacing the front hot-swap fans” on page 122). 3. If an individual fan LED is lit, replace the fan. Note: A failing fan might not cause the fan LED to be lit. 4. (Trained service technician only) Reseat the microprocessor board (see “Removing the microprocessor-board assembly” on page 171 and “Replacing the microprocessor-board assembly” on page 173). 5. (Trained service technician only) Replace the microprocessor board.
TEMP	<p>A system temperature or component has exceeded thermal specifications.</p> <p>Note: A fan LED might also be lit.</p>	<ol style="list-style-type: none"> 1. See the system-event log for the source of the fault (see “Event logs” on page 38). 2. Make sure that the airflow of the server is not blocked. 3. If a fan LED is lit, reseat the fan (see “Removing the front hot-swap fans” on page 120 and “Replacing the front hot-swap fans” on page 122). 4. Replace the fan for which the LED is lit. 5. Make sure that the room is neither too hot nor too cold (see “Environment” in “Server features and specifications” on page 7).

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Light path diagnostics LED	Description	Action
MEM	Memory failure.	Check the logs (either System Event Log or IMM/AMM Log), see “Event logs” on page 38 for applicable memory events; then, follow the steps as indicated in the POST error code section (see Appendix C, “UEFI/POST error codes,” on page 1013) or IMM error messages section (see Appendix B, “Integrated management module error messages,” on page 367).
NMI	A hardware error has been reported to the operating system. Note: The PCI or MEM LED might also be lit.	<ol style="list-style-type: none"> 1. See the system-error log (see “Event logs” on page 38). 2. If the PCI LED is lit, follow the instructions for that LED. 3. If the MEM LED is lit, follow the instructions for that LED. 4. Restart the server.
CNFG	A configuration error has occurred.	<ol style="list-style-type: none"> 1. If a memory expansion module is attached to the server, check to determine whether the front CNFG error LED is lit on the memory expansion module or the server. The LED that is lit determines which device you should troubleshoot. 2. Make sure that the memory cards all have the same memory controller level. 3. Find the failing or missing component by checking the other light path diagnostic LEDs on the operator information panel. Make sure that the microprocessors match each other (speed and cache). Also make sure that the installed microprocessors and memory cards are supported for your machine type or multi-node configuration. 4. Make sure that the fans, power supplies, expansion and scaling cables, microprocessors, and memory cards are correctly installed and in the correct sequence.

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Light path diagnostics LED	Description	Action
CPU	A microprocessor has failed, is missing, or has been incorrectly installed.	<ol style="list-style-type: none"> 1. If the CNFG light is lit, make sure that the microprocessors are installed in the correct sequence; see “Microprocessor” on page 160 and make sure the microprocessors match each other (speed and cache). Also make sure that the microprocessors are supported by your server machine type or multi-node configuration. 2. Check the system-event log to determine the reason for the lit LED (see “Event logs” on page 38). 3. If PCI Express adapters are installed in slots 1, 2, 3, or 4, make sure that the microprocessors are correctly installed in sockets 3 and 4. If the server is configured for only two microprocessors, make sure that the second microprocessor is installed in socket 3 or 4 (see the <i>Installation and User’s Guide</i> for additional information). The CONFIG LED is also lit. 4. Find the failing, missing, or mismatched microprocessor by checking the LEDs on the microprocessor board. 5. Reseat the following components: <ol style="list-style-type: none"> a. (Trained service technician only) Failing microprocessor (see “Microprocessor” on page 160) b. (Trained service technician only) Microprocessor board (see “Removing the microprocessor-board assembly” on page 171 and “Replacing the microprocessor-board assembly” on page 173) 6. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. (Trained service technician only) Failing microprocessor b. (Trained service technician only) Microprocessor board
VRM	Reserved	

- Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved.
- See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU).
- If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician.

Light path diagnostics LED	Description	Action
DASD	<p>A hard disk drive has failed or has been removed.</p> <p>Note: The error LED on the failing hard disk drive is also lit.</p>	<ol style="list-style-type: none"> 1. Reinstall the removed drive. 2. Reseat the following components: <ol style="list-style-type: none"> a. Suspected hard disk drive (see “Removing a hot-swap hard disk drive” on page 117 and “Replacing a hot-swap hard disk drive” on page 118) b. SAS hard disk drive backplane (see “Removing the SAS hard disk drive backplane assembly” on page 153 and “Replacing the SAS hard disk drive backplane assembly” on page 155) c. SAS signal cable d. The I/O board assembly (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144) 3. Replace the components listed in step 2, one at a time, in the order shown, restarting the server each time.
RAID	Reserved	
BOARD	The I/O-board shuttle or microprocessor board has failed.	<ol style="list-style-type: none"> 1. Find the suspected board by checking the LEDs on the I/O-board shuttle and microprocessor board. 2. If the I/O board LED is lit, reseat the I/O board (see “Removing the I/O-board shuttle” on page 143 and “Replacing the I/O-board shuttle” on page 144). If the I/O board LED remains lit, replace the I/O board. 3. If the I/O board LED is not lit, remove memory card 7 to see if the microprocessor-board LED is lit (see “Removing a memory card” on page 136). 4. (Trained service technician only) If the microprocessor-board LED is lit, reseat the microprocessor board (see “Removing the microprocessor-board assembly” on page 171 and “Replacing the microprocessor-board assembly” on page 173). If the microprocessor-board LED remains lit, replace the microprocessor board.

Power-supply LEDs

This topic provides information about power-supply LEDs.

The following minimum configuration is required for the dc LEDs on the power supply to be lit:


- AC power source
- Power cord connected
- Power supply with ac power present LED on
- I/O board with power supply connections
- Microprocessor board

The following minimum configuration is required for the server to start:

- AC Power source
- Power cord
- Power supply
- I/O board
- Microprocessor board
- One microprocessor
- Two DIMMs on one memory card
- Operator information panel

If the a memory expansion module is connected to the server, two 2 GB DIMMs on the memory expansion module.

The following illustration shows the locations of the power-supply LEDs.



The following table describes the problems that are indicated by various combinations of the power-supply LEDs and the power-on LED on the operator information panel and suggested actions to correct the detected problems.

Power-supply LEDs			Operator information panel power-on LED	Description	Action
AC	DC	Error			
Off	Off	Off	Off	No ac power to the server, or a problem with the ac power source.	<ol style="list-style-type: none"> 1. Check the ac power to the server. 2. Make sure that the power cord is connected to a functioning power source. 3. Make sure that the power cord is fully seated in the power-supply inlet.
On	Off	Off	Off	DC source power problem or system error.	<ol style="list-style-type: none"> 1. Reseat one power supply at a time (see "Removing a hot-swap power supply" on page 123 and "Replacing the hot-swap power supply" on page 127). 2. View the system-event log (see "Event logs" on page 38).
On	On	Off	Off	The server is turned off or standby power problem.	<ol style="list-style-type: none"> 1. Press the power-control button on the operator information panel. 2. View the system-error log (see "Event logs" on page 38). 3. Remove one power supply at a time (see "Removing a hot-swap power supply" on page 123 and "Replacing the hot-swap power supply" on page 127).
On	On	Off	Flashing	Normal standby state.	No action.

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 					
Power-supply LEDs			Operator information panel power-on LED	Description	Action
AC	DC	Error			
On	On or off	On	On or off	There is an internal power supply fault (for example, a thermal fault or an over voltage or under voltage condition).	<ol style="list-style-type: none"> 1. View the system-event log (see “Event logs” on page 38). 2. Replace the power supply (see “Removing a hot-swap power supply” on page 123 and “Replacing the hot-swap power supply” on page 127).
On	On	Off	On	The power is good and the server is running.	No action.

IBM Dynamic System Analysis

This topic provides general information about IBM Dynamic System Analysis.

IBM Dynamic System Analysis (DSA) collects and analyzes system information to aid in diagnosing server problems. DSA collects the following information about the server:

- System Bus information, including memory (SMI), microprocessor, and scaling (QPI or EXA)
- Drive health information
- Event logs for ServeRAID controllers and service processors
- Hardware inventory, including PCI and USB information
- Installed applications and hot fixes
- Light path diagnostics status
- Network interfaces and settings
- Performance data and details about processes that are running
- RAID and controller configuration
- Service processor (integrated management module) status and configuration
- System configuration
- Vital product data and firmware information

For system-specific information about the action that you should take as a result of a message that DSA generates, see Appendix A, “DSA diagnostic test results,” on page 227.

If you cannot find a problem by using DSA, see “Solving undetermined problems” on page 77 for information about testing the server.

Note:

1. In a multi-node environment, each server has a unique DSA interface. You can view server-specific information, such as error logs, from these unique DSA interfaces.
2. Before using DSA in a multi-node configuration, you must disable extended Apic (X2apic). (To disable Apic, go to the UEFI Setup, select **System Settings** → **Processors** → **Extended Apic** → **Disable**.)
3. DSA Preboot might appear to be unresponsive when you start the program. This is normal operation while the program loads.

To obtain DSA code and the *Dynamic System Analysis Installation and User's Guide*, go to <http://www.ibm.com/support/entry/portal/docdisplay?indocid=SERV-DSA> or complete the following steps.

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

1. Go to <http://www.ibm.com/supportportal/>.
2. Under **IBM Systems support**, click **System x**.
3. Under **Related downloads**, click **Dynamic System Analysis (DSA)**.

DSA editions

This topic provides information about the two DSA editions available.

Two editions of Dynamic System Analysis are available:

- **DSA Portable**

DSA Portable Edition runs within the operating system; you do not have to restart the server to run it. It is packaged as a self-extracting file that you download from the Web. When you run the file, it self-extracts to a temporary folder and performs comprehensive collection of hardware and operating-system information. After it runs, it automatically deletes the temporary files and folder and leaves the results of the data collection and diagnostics on the server.

If you are able to start the server, use DSA Portable.

- **DSA Preboot**

DSA Preboot runs outside of the operating system; you must restart the server to run it. It is packaged as an ISO image that you download from the Web, or it is provided in flash memory on the server. In addition to the capabilities of the other editions of DSA, DSA Preboot includes diagnostic routines that would be disruptive to run within the operating-system environment (such as resetting devices and causing loss of network connectivity). It has a graphical user interface that you can use to specify which diagnostics to run and to view the diagnostic and data collection results.

DSA Preboot provides diagnostics for the following system components, if they are installed:

- Broadcom network adapter
- Optical devices (CD or DVD)
- Tape drives (SCSI)
- Memory
- Microprocessor
- Checkpoint panel
- I2C bus
- SAS/SATA drives

If you are unable to restart the server or if you need comprehensive diagnostics, use DSA Preboot.

Running DSA Preboot

This topic provides steps for how to run DSA Preboot.

To run DSA Preboot, complete the following steps:

1. If the server is running, turn off the server and all attached devices.
2. Turn on all attached devices; then, turn on the server.
3. When the prompt <F2> Diagnostics is displayed, press F2.

Note: DSA Preboot might appear to be unresponsive for an unusual length of time when you start the program. This is normal operation while the program loads.

4. (Optional) Select **Quit to DSA** to exit from the stand-alone memory diagnostic program.

Note: After you exit from the stand-alone memory diagnostic environment, you must restart the server to access the stand-alone memory diagnostic environment again.

5. Select **gui** to display the graphical user interface, or select **cmd** to display the DSA interactive menu.
6. Follow the instructions on the screen to select the diagnostic test to run. If the diagnostic tests do not detect any hardware errors but the problem remains during normal server operation, a software error might be the cause. If you suspect a software problem, see the information that comes with your software.

Recovering the server firmware

This topic provides general information about recovering the server firmware.

The flash memory in the server consists of a primary bank and a backup bank. You must maintain a bootable IBM UEFI firmware image in the backup bank. If the UEFI firmware in the primary bank has become corrupted, such as from a power failure during an update, you can recover the UEFI firmware in either of two ways:

- **In-band method:** Through the automatic boot recovery function (automatic) or using the boot recovery jumper and an IBM Flash UEFI Update (manual)
- **Out-of-band method:** Using the IMM web interface and an IBM Flash UEFI Update

You can obtain an IBM Flash UEFI Update package from <http://www.ibm.com/supportportal/> or from your IBM service representative.

In-band automatic recovery method

This topic provides information about the in-band automatic recovery method, as well as instructions for how to recover the UEFI firmware and restore the server operation to the primary bank.

If the integrated management module (IMM) detects a problem with the UEFI firmware in the primary bank, the automatic boot recovery function starts the server from the backup bank so that you can restore the UEFI firmware in the primary bank. Use this method if the BRD LED on the light path diagnostics panel is lit and there is an event log entry or if Booting Backup Image is displayed on the firmware splash screen; otherwise, use the in-band manual recovery method.

To recover the UEFI firmware and restore the server operation to the primary bank, complete the following steps:

1. Boot the server to an operating system that is supported by the IBM Flash UEFI Update package that you downloaded.
2. Install the IBM Flash UEFI Update package, following the instructions in the readme file that comes with the update package.
3. Restart the server.
4. When the prompt Press F3 to restore to primary is displayed, press F3 to start the server from the primary bank.

In-band manual recovery method

This topic provides steps to recover the UEFI firmware and restore the server operation to the primary bank.

To recover the UEFI firmware and restore the server operation to the primary bank, complete the following steps:

1. Turn off the server, and disconnect all power cords and external cables.
2. Remove the server top cover. See "Removing and replacing consumable parts and Tier 1 CRUs" on page 105 for more information.
3. Locate the boot recovery jumper (J22) on the I/O board.
4. Move the jumper from pins 1 and 2 to pins 2 and 3 to enable the UEFI firmware recovery mode.
5. Reinstall the server cover; then, reconnect all power cords.
6. Restart the server. The power-on self-test (POST) starts.
7. Boot the server to an operating system that is supported by the firmware update package that you downloaded.
8. Perform the firmware update by following the instructions that are in the firmware update package readme file.
9. Copy the downloaded firmware update package into a directory.
10. From a command line, type *filename-s*, where *filename* is the name of the executable file that you downloaded with the firmware update package.
11. Turn off the server and disconnect all power cords and external cables, and then remove the server cover.
12. Move the boot recovery jumper back to the primary position (pins 1 and 2).
13. Reinstall the server cover, and then reconnect all the power cables.
14. Restart the server.

Out-of-band method

For information about using the IMM web interface to recover the UEFI firmware, see the IMM documentation.

Nx boot failure

This topic provides information about Nx boot failure.

Configuration changes, such as added devices or adapter firmware updates, and firmware or application code problems can cause the server to fail POST (the power-on self test). If this occurs, the server responds in either of the following ways:

- The server restarts automatically and attempts POST again.
- The server hangs, and you must manually restart the server for the server to attempt POST again.

After a specified number of consecutive attempts (auto or manual), the Nx boot failure feature causes the server to revert to the default UEFI configuration and start the Setup utility so that you can make the necessary corrections to the configuration and restart the server. If the server is unable to successfully complete POST with the default configuration, there might be a problem with the system board.

To specify the number of consecutive restart attempts that will trigger the Nx boot feature, in the Setup utility, click **Settings > POST Attempt Limit**. The available options are 3, 6, 9, and 255 (disable Nx boot failure).

Confirm and recover IMM boot image failure

This topic provides instructions for how to confirm and recover IMM boot image failure.

Check the system management heartbeat LED to confirm whether the uBoot fails to boot. Normally, system management heartbeat LED on the planar will start blinking rapidly when the ac cord is plugged to the system. It will then turn to slow blink after some time (usually within 5 minutes). This indicates IMM system has started up and firmware application is starting to load. It will usually grant power permission to the server system within 1 minute after the heart beat LED slows down. Be careful here, this system management heartbeat LED is not the power button. It's a LED locates on the system board which you may need to remove the cover to check. The location of x3850X5 system management heartbeat LED is CR33 (Refer to the "Microprocessor board non-light-path-diagnostics status LEDs" table, see "Microprocessor-board LEDs" on page 24).

If the system management heartbeat LED doesn't blink, it confirms that Uboot fails to boot. In this case, try the following method to recover Uboot.

1. Power off the system, unplug the power cord.
2. Remove the cover and close the Backup Uboot jumper J75-A5.
3. Plug the power cord and start to boot the IMM from backup uBoot code.
4. If IMM is back running normally and accessible, update latest IMM firmware through in-band or out-of-band method.
5. Power off the server, disconnect the power cord from the server. Remove the cover and open the hardware jumper.

6. Connect the power cord to the server and check if the IMM is recovered.

System-event log

This topic provides information about the types of messages contained in the system-event log.

The system-event log contains messages of three types:

Information

Information messages do not require action; they record significant system-level events, such as when the server is started.

Warning

Warning messages do not require immediate action; they indicate possible problems, such as when the recommended maximum ambient temperature is exceeded.

Error Error messages might require action; they indicate system errors, such as when a fan is not detected.

Each message contains date and time information, and it indicates the source of the message (POST or the IMM).

Solving Ethernet controller problems

This topic provides troubleshooting procedures to try when solving Ethernet controller problems.

The method that you use to test the Ethernet controller depends on which operating system and which switch you are using. See the operating-system and switch documentation for information about Ethernet controllers, and see the Ethernet controller device-driver readme file.

Try the following procedures:

- Make sure that the correct device drivers, which come with the server, are installed and that they are at the latest level.
- Make sure that the Ethernet cable is installed correctly.
 - The cable must be securely attached at all connections. If the cable is attached but the problem remains, try a different cable.
 - If the Ethernet controller is set to operate at 100 Mbps, you must use Category 5 cabling.
- Determine whether the switch supports auto-negotiation. For auto-negotiation problem determination procedures, see the switch documentation. If the switch does not support auto-negotiation, try configuring the integrated Ethernet controller manually to match the speed and duplex mode of the switch.
- Check the Ethernet controller LEDs on the rear panel of the server. These LEDs indicate whether there is a problem with the connector, cable, or switch.
 - The Ethernet link status LED is lit when the Ethernet controller receives a link pulse from the switch. If the LED is off, there might be a defective connector or cable or a problem with the switch.
 - The Ethernet transmit/receive activity LED is lit when the Ethernet controller sends or receives data over the Ethernet network. If the Ethernet transmit/receive activity light is off, make sure that the switch and network are operating and that the correct device drivers are installed.

- Check the LAN activity LED on the rear of the server. The LAN activity LED is lit when data is active on the Ethernet network. If the LAN activity LED is off, make sure that the hub and network are operating and that the correct device drivers are installed.
- Check for operating-system-specific causes of the problem.
- Make sure that the device drivers on the client and server are using the same protocol.

If the Ethernet controller still cannot connect to the network but the hardware appears to be working, the network administrator must investigate other possible causes of the error.

Solving undetermined problems

This topic provides instructions for how to solve undetermined problems if the diagnostics tests do not diagnose the failure.

If the diagnostic tests did not diagnose the failure or if the server is inoperative, use the information in this section.

If you suspect that a software problem is causing failures (continuous or intermittent), see “Software problems” on page 56.

Damaged data in CMOS memory or damaged IBM UEFI firmware can cause undetermined problems. To reset the CMOS data, turn off the server and remove the battery for two minutes.

Damaged memory-card connector pins or incorrectly installed memory cards can prevent the server from starting or might cause a POST checkpoint halt. For example, a memory card that is not completely installed or has bent connector pins might cause the server to continually restart or display an F2 checkpoint halt. Remove and inspect all memory-card connector pins for bent or damaged interface pins (see “Removing a memory card” on page 136 and “Replacing a memory card” on page 137). Replace all memory cards that have damaged pins and make sure that each card is completely latched into place.

Check the LEDs on all the power supplies (see “Power-supply LEDs” on page 69). If the LEDs indicate that the power supplies are working correctly, complete the following steps:

1. Turn off the server.
2. Make sure that the server is cabled correctly.
3. Remove or disconnect the following devices, one at a time, until you find the failure. Turn on the server and reconfigure it each time.
 - Any external devices.
 - Surge-suppressor device (on the server).
 - Modem, printer, mouse, and non-IBM devices.
 - Each adapter (see “Removing an adapter” on page 110 and “Replacing an adapter” on page 111).
 - Hard disk drives (see “Removing a hot-swap hard disk drive” on page 117 and “Replacing a hot-swap hard disk drive” on page 118).
 - Memory modules. The minimum configuration requirement is 2 GB (two 1 GB DIMMs). (See “Removing a DIMM” on page 137 and “Replacing a DIMM” on page 138.)

The following minimum configuration is required for the server to turn on:

- I/O board
- Power supply

- Power cord
 - Microprocessor board
 - One microprocessor
 - Two 1 GB DIMMs on one memory card (If a memory expansion module is connected to the server, two 2 GB DIMMs on the memory expansion module.)
4. Turn on the server. If the problem remains, suspect the following components in the following order:
- a. Memory card
 - b. Microprocessor board

If the problem is solved when you remove an adapter from the server but the problem recurs when you reinstall the same adapter, suspect the adapter; if the problem recurs when you replace the adapter with a different one, suspect the I/O board.

If you suspect a networking problem and the server passes all the system tests, suspect a network cabling problem that is external to the server.

Problem determination tips

This topic provides problem determination tips.

Because of the variety of hardware and software combinations that you can encounter, use the following information to assist you in problem determination. If possible, have this information available when you request assistance from IBM.

- Machine type and model
- Microprocessor and hard disk drive upgrades
- Failure symptoms
 - Does the server fail the Dynamic System Analysis diagnostic tests?
 - What occurs? When? Where?
 - Does the failure occur on a single server or on multiple servers?
 - Is the failure repeatable?
 - Has this configuration ever worked?
 - What changes, if any, were made before the configuration failed?
 - Is this the original reported failure?
- Diagnostic program type and version level
- Hardware configuration (print screen of the system summary)
- FPGA firmware level
- UEFI firmware level
- Operating-system type and version level

You can solve some problems by comparing the configuration and software setups between working and nonworking servers. When you compare servers to each other for diagnostic purposes, consider them identical only if all the following factors are exactly the same in all the servers:

- Machine type and model
- FPGA firmware level
- UEFI firmware level
- Adapters and attachments, in the same locations
- Address jumpers, terminators, and cabling


- Software versions and levels
- Diagnostic program type and version level
- Configuration option settings
- Operating-system control-file setup

See Appendix D, “Getting help and technical assistance,” on page 1027 for information about calling IBM for service.

Chapter 4. Parts listing, Types 7145, 7146, 7143, and 7191

This topic provides information about parts for Types 7145, 7146, 7143, and 7191.

The following replaceable components are available for the System x3850 X5 and x3950 X5 Types 7145, 7146, 7143, and 7191 except as specified otherwise in “Replaceable server components” on page 83. For an updated parts listing, go to <http://www.ibm.com/supportportal/>.



Replaceable server components

This topic provides a parts listing for all removable server components.

Replaceable components are of four types:

- **Consumable part:** Purchase and replacement of consumable parts (components, such as batteries and printer cartridges, that have depletable life) is your responsibility. If IBM acquires or installs a consumable part at your request, you will be charged for the service.
- **Tier 1 customer replaceable unit (CRU):** Replacement of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request with no service agreement, you will be charged for the installation.
- **Tier 2 customer replaceable unit:** You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service that is designated for your server.
- **Field replaceable unit (FRU):** FRUs must be installed only by trained service technicians.

Table 12. Parts listing, Types 7143, 7145, 7146, and 7191

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
1	Top cover (all models)	59Y4815		
2	QPI wrap card filler (see Filler Kit)			
3	QPI wrap card (models D1x, D3x, D4x, D2x, H2x, HBx)	00D0561		
4	Power supply filler (see Filler Kit)			
5	Power supply, 1975 Watt	69Y5945		
	Power supply, 675 Watt	69Y5943		
6	Emulex 10GbE Custom Adapter for IBM System x (all models)	49Y4202		
7	I/O-board shuttle (Types 7143 and 7191)		88Y5422	
7	I/O-board shuttle (Types 7145 and 7146)		69Y1851	
7a	PCI latch kit for the I/O-board shuttle assembly		59Y4983	
8	Chassis assembly (all models)			59Y4814
9	Hard disk drive backplane filler (see Filler Kit)			
10	Hard disk drive backplane (all models except 4Fx, 5Dx, 5Gx, ARx)		43V7070	
11	Hard disk drive backplane carrier (see Miscellaneous hardware parts kit)			
12	Hard disk drive backplane power cables and carrier (see Cabling Kit)			
13	RAID card carrier (see Miscellaneous hardware parts kit)			
14	ServeRAID-BR10i SAS/SATA Controller (all 7145/7191 models except 4Fx, 5Dx, 5Gx)		44E8690	
14	ServeRAID-M5015 SAS/SATA Controller (models D4x, H1x, H2x, H3x)		46M0851	
15	Hard disk drive, 200 GB SSD (models 4Fx, 5Gx, D1x, D2x)	40K6897		
15	Hard disk drive, 200 GB SSD (models D3x, D4x)	49Y6120		

Table 12. Parts listing, Types 7143, 7145, 7146, and 7191 (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
15	Hard disk drive, SATA MultiBurner (models H1x H2x)	44W3256		
15	Hard disk drive, 600 GB 10K, 2.5-inch SAS (models H1x, H2x, H3x)	49Y2004		
15	Hard disk drive, 300 GB 10K, 2.5-inch SAS (optional)	42D0638		
15	Hard disk drive, 73 GB 15K, 2.5-inch SAS (optional)	42D0673		
15	Hard disk drive, 146 GB 15K, 2.5-inch SAS (optional)	42D0678		
15	Hard disk drive, 146 GB (optional)	42D0633		
16	Hard disk drive filler (see Filler Kit)			
17	Operator information panel (all models)	46M0059		
18	200 Gb SATA 1.8 inch MLC SSD (models 4Fx, 5Gx)	40K6897		
18	50 Gb SATA SSD (optional)	43W7717		
19	1.8 inch SSD backplane and cage (models 4Fx, 5Dx, 5Gx, D1x, D2x, D3x, D4x)		59Y6222	
20	1.8 inch SSD filler blank (model 5Dx)	49Y4936		
21	Front bezel (all models)	59Y4818		
22	DVD SAP HANA v 1.5.53-5	46W8273		
22	DVD SAP HANA v 1.6.60-6	00AK712		
22	DVD/CD-RW SATA drive (some models only)	44W3254		
22	DVD/CD multi-burner SATA drive (some models only)	44W3256		
22	DVD UltraSlim Enhanced SATA drive (optional)	44W3254		
23	Battery tray (see Miscellaneous hardware parts kit)			
24	Front fans (120 mm) (all models)	59Y4813		
25	Memory card cage (included in chassis assembly)			
26	Middle fans (dual 60 mm) (all models)	59Y4812		
27	Memory card filler (see Filler Kit)			
28	CPU card			47C2444
28	Memory card			47C2450
28	Memory card (Types 7143 and 7191)			69Y1742
28	Memory card (Types 7145 and 7146)	46M0001		
28	Memory board	47C2433		
29	DIMM, 1 GB (optional)	44T1490		
29	DIMM, 2 GB (all)	44T1491		
29	DIMM, 2 GB	49Y1423		
29	DIMM, 2 GB (all models)	49Y1443		
29	DIMM, 4 GB (models 1Rx, 2Rx, 2Sx, 3Rx, 4Dx, 4Fx, 4Rx, 4Sx, 5Dx, 5Gx, 5Rx, 5Sx)	46C7452		
29	DIMM, 8 GB (optional)	46C7488		
29	DIMM, 16 GB (optional)	46C7489		
29	DIMM, 8 GB (optional)	49Y1381		

Table 12. Parts listing, Types 7143, 7145, 7146, and 7191 (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
29	DIMM, 16 GB (optional)	49Y1382		
29	DIMM, 4 GB (1.35V) PC3L-10600R-999 CL9 DDR3 ECC (Types 7143 and 7191)	49Y1425		
29	DIMM, 8 GB (1.35V) PC3L-8500R-777 CL7 DDR3 ECC (Types 7143 and 7191)	49Y1417		
29	DIMM, 16 GB (1.35V) PC3L-8500R-777 CL7 DDR3 ECC (Types 7143 and 7191) (models H1x, H2x, H3x)	49Y1418		
29	DIMM, 32 GB (4Gb, 4Rx4, 1.35V) PC3-8500 DDR3-1066 LP RDIMM (optional)	90Y3103		
30	Microprocessor board (Types 7145 and 7146)			69Y1811
30	Microprocessor board Types (7143 and 7193)			88Y5351
31	Microprocessor (Intel Xeon E7520 1.86 GHz, 18M 4-core), insertion tool, and heat sink (models 1Rx, ARx)			59Y6230
31	Microprocessor (Intel Xeon E7530 1.86 GHz, 12M, 6-core), insertion tool, and heat sink (models 2Rx, 2Sx)			59Y6229
31	Microprocessor (Intel Xeon L7545 1.86 GHz, 18M, 6-core), insertion tool, and heat sink (optional)			59Y6226
31	Microprocessor (Intel Xeon L7555 1.86 GHz, 24M, 8-core), insertion tool, and heat sink (optional)			59Y6224
31	Microprocessor (Intel Xeon E7540 2.00 GHz, 18M, 6-core), insertion tool, and heat sink (model 3Rx)			59Y6228
31	Microprocessor (Intel Xeon X7550 2.00 GHz, 18M, 8-core), insertion tool, and heat sink (models 4Dx, 4Fx, 4Rx, 4Sx)			59Y6225
31	Microprocessor (Intel Xeon X7560 2.26 GHz, 24M, 8-core), insertion tool, and heat sink (models 4Rx, 5Dx, 5Gx, 5Rx, 5Sx)			59Y6223
31	Microprocessor (Intel Xeon X7542 2.67 GHz, 18M, 6-core), insertion tool, and heat sink (optional)			59Y6227
31	Microprocessor (Intel Xeon E7-4807 1.86 GHz, 18M, 6-core, 95W - 4 socket) Types 7143 and 7191 (models B1x, B8x, B9x)			69Y1877
31	Microprocessor (Intel Xeon E7-4820 2.00 GHz, 18M, 8-core, 105W - 4 socket) Types 7143 and 7191 (model B2x)			69Y1878
31	Microprocessor (Intel Xeon E7-4830 2.13 GHz, 24M, 8-core, 105W - 4 socket) Types 7143 and 7191 (model B3x)			69Y1879
31	Microprocessor (Intel Xeon E7-4850 2.26 GHz, 24M, 10-core, 130W - 4 socket) Types 7143 and 7191 (models B6x, D2x, D3x, D4x, F1x, F2x)			69Y1880
31	Microprocessor (Intel Xeon E7-4860 2.40 GHz, 30M, 10-core, 130W - 4 socket) Types 7143 and 7191 (model B7x)			69Y1881
31	Microprocessor (Intel Xeon E7-8837 2.67 GHz, 24M, 8-core, 130W - 8 socket) Types 7143 and 7191 (optional)			69Y1882
31	Microprocessor (Intel Xeon E7-8830 2.13 GHz, 24M, 8-core, 105W - 8 socket) Types 7143 and 7191 (optional)			69Y1884

Table 12. Parts listing, Types 7143, 7145, 7146, and 7191 (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
31	Microprocessor (Intel Xeon E7-8867L 2.13 GHz, 30M, 10-core, 105W - 8 socket) Types 7143 and 7191 (optional)			69Y1885
31	Microprocessor (Intel Xeon E7-8860 2.26 GHz, 24M, 10-core, 130W - 8 socket) Types 7143 and 7191 (model C2x)			69Y1886
31	Microprocessor (Intel Xeon E7-8870 2.40 GHz, 30M, 10-core, 130W - 8 socket) Types 7143 and 7191 (models C3x, H1x, H2x, H3x)			69Y1887
31	Microprocessor (Intel Xeon E7-8850 2.00 GHz, 24M, 10-core, 130W - 8 socket) Types 7143 and 7191 (model C1x)			88Y5402
31	Microprocessor (Intel Xeon E7-4850 2.00 GHz, 24M, 10-core, 30W - 4 socket) Types 7143 and 7191 (model D1x)			88Y5404
32	Heat sink (all models)			68Y7257
33	Heat sink filler (see Filler Kit)			
34	Top cover bracket (all models)	59Y4816		
35	IBM 2-Node x3850 X5 and x3950 X5 Scalability Cable (Kit) Types 7143 and 7191 (model D1x) Types 7145 and 7146 (optional)	59Y4826		
36	IBM MAX5 to x3850 X5 Cable (Kit) (models 2Sx, 4Ds, 4Sx, 5Sx)	40K6750		
	2 node mechanical support (models 2Sx, 4Sx, 5Sx, 4Dx, 4Fx, 5Gx, B8x, B9x, F1x, F2x)	59Y4931		
	2 GB 1Rx8 2 Gb PC3-10600R-999 DDR3-1333 LP RDIMM (optional)	44T1582		
	ServeRAID-M1015 adapter with battery (optional)	46M0918		
	ServeRAID-M1015 adapter without battery (model B7x)	46M0861		
	4 Gb PS PCI-E single port FC adapter (optional)	00Y5626		
	4 Gb FC PCI-E dual port FC adapter (optional)	00Y5627		
	4 Gb PCI-E single port FC adapter (optional)	43W7510		
	4 Gb PCI-E dual port FC adapter (optional)	43W7512		
	6 Gb SSD HBA card assembly (model 5Gx)	46M0913		
	8 Gb PCI-E single port adapter (optional)	42D0491		
	8 Gb FC dual port HBA adapter (optional)	42D0500		
	8 Gb QLogic FC single port HBA adapter (optional)	00Y5628		
	8 Gb QLogic FC single port HBA adapter (optional)	00Y5629		
	10 Gb QLogic GB CNA adapter (optional)	42C1802		
	10 Gb FCoCEE dual port HBA adapter (optional)	42C1822		
	10 Gbe SW SFP+ Module (models H1x, H2x, H3x)		49Y8579	
	320 Gb DuoSLC SSD PCIe (model 5Gx)	81Y4521		
	320 SSD PCIe (models 5Gx, D1x, H1x)	81Y4521		
	1000 Express Ethernet adapter (optional)	39Y6070		

Table 12. Parts listing, Types 7143, 7145, 7146, and 7191 (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
	3800 NVIDIA Quadro FX 3PCI-Ex 16 adapter (optional)	43V5894		
	1.28 TB IOPS MLC duo adapter for IBM System x	81Y4529		
	640 GB High IOPS MLC adapter for IBM System x	81Y4533		
	320 GB High IOPS SLC adapter for IBM System x	81Y4537		
	640 GB High IOPS SLC duo adapter for IBM System x	81Y4541		
	640 SSD PCIe adapter (models H2x, H3x)	81Y4518		
	Ethernet quad adapter (models H1x, H2x, H3x)	49Y4242		
	Emulex 10 GbE Adapter (models B2x, B3x, B5x, B6x, B7x, C1x, C2x, C3x, D1x, D2x, H1x, H2x, H3x)	49Y7942		
	IBM MAX5 MB2 for System x	88Y6530		
	4 bay backplane filler (all models)	69Y2286		
	B5015 SSD controller (model 4Fx)	46M0970		
	Battery, 3.0 volt	15F8409		
	Cable, Mini SAS 750 mm (29.5 inches) (models 4Fx, 5Dx, 5Gx, D1x, D2x, D3x, D4x)		59Y4915	
	Cable, VGA power N3800 (optional)		59Y3455	
	Cable kit, SSD (models 4Fx, 5Dx, 5Gx, D1x, D2x, D3x, D4x)		59Y4914	
	CMA	68Y7213		
	HBA 3U card (models D1x, D2x, D3x, D4x)	90Y4356		
	NetXtreme II 1000 Express Dual Port adapter (optional)	49Y4205		
	NetXtreme II 1000 Express Quad Port adapter (optional)	49Y4222		
	M5000 battery (models H1x, H2x, H3x)	81Y4451		
	M5000 feature key (optional)	46M0931		
	Microprocessor insertion tool (optional)	68Y7268		
	PRO/1000 PT dual port adapter (optional)	39Y6128		
	PRO/1000 PT quad port adapter (optional)	39Y6138		
	PRO/1000 PF server adapter (optional)	42C1752		
	Rack latch kit (all models)	59Y4972		
	ServRAID Superkey (model D4x)	81Y4427		
	Slide rail kit	68Y7226		
	DVD/CD-RW optical drive filler (see Filler Kit)			
	PCI full high adapter filler (see Filler Kit)			
	Cable kit (SAS power, USB, SATA signal, fan) (all models except 4Fx, 5Dx, 5Gx)		59Y4827	
	Filler Kit (microprocessor heat sink, memory card, 2.5" hard disk drive, optical, hard disk drive backplane, QPI wrap card, and full high PCI adapter) (all models except 4Dx, 4Fx, 5Dx, 5Gx)	59Y4824		
	Shipping bracket kit (all models)		59Y4821	
	Cable management arm (all models)	59Y4822		

Table 12. Parts listing, Types 7143, 7145, 7146, and 7191 (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
	SAS signal cable (all models except ARx, 5Dx)	46C4124		
	Latches, EIA 5U (models 2Sx, 4Dx, 4Fx, 4Sx, 5Gx, 5Sx) (for servers connected to a memory expansion module only)		40K6765	
	Line cord (all models)	39M5377		
	Miscellaneous hardware parts kit (all models) <ul style="list-style-type: none"> • Assembly, backplane carrier (1) • Bracket, DVD retention (1) • Bracket, HDD backplane (1) • Bracket, RAID battery (1) • Handle, RAID card (1) • Screw, M5x16 black (2) • Screw, M6 hex head (4) 	59Y4823		
	2 GB USB Key (all models)		42D0545	
	3U 6 GB Performance Optimized Host Bus Adapter, with 3U Bracket (models D1x, D3x, D2x)	46C8937		
	Label kit (system service, FRU, chassis sheet) (Types 7145 and 7146)	59Y4825		
	Label kit (system service, FRU, chassis sheet) (Types 7143 and 7191)	88Y5406		
	Screw kit (all models)	59Y4922		
	System service label (models 2Sx, 4Dx, 4Fx, 4Sx, 5Gx, 5Sx)	40K6763		
	Thermal grease			41Y9292
	Alcohol wipe, Canada			41Y8746
	Alcohol wipe, Brazil/Mexico			41Y8747
	Alcohol wipe, Taiwan/Japan			41Y8748
	Alcohol wipe, China/Malaysia			41Y8749
	Alcohol wipe, Australia/UK			41Y8750
	Alcohol wipe, Korea			41Y8751
	Alcohol wipe, Hungary			41Y8753
	Alcohol wipe, Latin America			41Y8754
	Alcohol wipe, China			41Y8757
	Alcohol wipe, Hong Kong			41Y8758
	Alcohol wipe, India			41Y8759
	Alcohol wipe, Singapore			41Y8760
	Alcohol wipe, other countries			41Y8752

Consumable parts are not covered by the IBM Statement of Limited Warranty. The following consumable parts are available for purchase from the retail store.

Table 13. Consumable parts

Description	Part number
ServeRAID SAS controller battery	43W4342

To order a consumable part, complete the following steps:

1. Go to <http://www.ibm.com>.
2. From **Products** menu, click **Upgrades, accessories & parts**.
3. Click **Obtain maintenance parts**; then, follow the instructions to order the component from the retail store.

If you need help with your order, call the toll-free number that is listed on the retail parts page, or contact your local IBM representative for assistance.

Replaceable memory expansion module components

This topic provides a table that lists the replaceable components for the IBM MAX5 for System x memory expansion module.

The following replaceable components are available for the IBM MAX5 for System x memory expansion module.

The following illustration shows the major components in the memory expansion module.




Table 14. Parts listing, memory expansion module

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
1	Chassis assembly (without the front bezel) (models 2Sx, 4Dx, 4Fx, 4Sx, 5Gx, 5Sx, B8x, B9x, F1x, F2x)			40K6743
2	Memory, 2 GB PC3-10600R-999 DDR3 ECC	44T1491		

Table 14. Parts listing, memory expansion module (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
2	Memory, 4 GB PC3-10600R-999 DDR3 ECC (models 2Sx, 4Sx, 4Dx, 5Sx)	44T1598		
2	Memory, 4 GB (1.35V) PC3L-10600R-999 CL9 DDR3 ECC (for memory expansion modules with Intel 7510 scalable memory buffer)	49Y1425		
2	Memory, 4 GB PC3-8500-777 DDR3 ECC (models 1Rx, 2Rx, 2Sx, 3Rx, 4Dx, 4Fx, 4Rx, 4Sx, 5Dx, 5Gx, 5Rx, 5Sx,)	46C7452		
2	Memory, 8GB (1.35V) PC3L-8500R-777 CL7 DDR3 ECC (for memory expansion modules with Intel 7510 scalable memory buffer)	49Y1417		
2	Memory, 8 GB PC3-8500-777 DDR3 ECC	46C7488		
2	Memory, 16 GB (1.35V) PC3L-8500R-777 CL7 DDR3 ECC (for memory expansion modules with Intel 7510 scalable memory buffer)	49Y1418		
2	Memory, 16 GB PC3-8500-777 DDR3 ECC	46C7489		
3	Cable assembly, five-drop fan (models B8x, B9x, F1x, F2x)	40K6746		
4	Fan assembly, hot-swap (models 2Sx, 4Sx, 5Sx, 4Dx, 4Fx, 5Gx B8x, B9x, F1x, F2x)	40K6745		
5	Bezel (models 2Sx, 4Sx, 4Dx, 5Sx, B8x, B9x, F1x, F2x)	40K6747		
6	Information panel assembly	68Y9656		
7	Air baffle (models 2Sx, 4Sx, 5Sx, B8x, B9x, F1x, F2x)	40K6748		
8	System-board tray assembly (models 2Sx, 4Sx, 4Dx, 5Sx, B8x, B9x, F1x, F2x) <ul style="list-style-type: none"> • Intel 7500 scalable memory buffer • Use in memory expansion module models that attach to machine types 7145 and 7146 		40K6744	
8	System-board tray assembly (models B8x, F1x, F2x) <ul style="list-style-type: none"> • Intel 7510 scalable memory buffer • Use in memory expansion module models that attach to machine types 7143 and 7191 		40K6774	
9	Power supply, 675 Watt hot-swap Types 7143 and 7191 (models B8x, B9x, F1x, F2x) Types 7145 and 7146 (models 2Sx, 4Sx, 4Dx, 5Sx)	39Y7218		
10	Power supply filler (see Filler Kit)	49Y5331		
11	EXA filter	68Y9703		
12	DIMM filler (models B8x, B9x, F1x, F2x)	44V8227		

Table 14. Parts listing, memory expansion module (continued)

Index	Description	CRU part number (Tier 1)	CRU part number (Tier 2)	FRU part number
	Cable, EXA scalability (optional)	40K6752		
	CMA (models F1x, F2x, B8x, B9x)	49Y4817		
	EIA latches (models 2Sx 4Sx 5Sx 4Dx 4Fx 5Gx F1x F2x B8x B9x)		40K6765	
	Filler kit (models 2Sx 4Sx 5Sx 4Dx 4Fx 5Gx F1x F2x B8x B9x) <ul style="list-style-type: none"> • EXA filler assembly • MK QPI bracket 	40K6764		
	MK cables (models 2Sx, 4Sx, 5Sx, 4Dx, 4Fx, 5Gx, B8x B9x, F1x, F2x)	40K6746		
	OPI cable (models 2Sx, 4Sx, 5Sx, 4Dx, 4Fx, 5Gx, B8x B9x, F1x, F2x)	40K6750		
	Service label (models B8x, B9x, F1x, F2x)	40K6775		
	Slide kit (models B8x, B9x, F1x, F2x)	60Y0328		
	SVC label (models 2Sx 4Sx 5Sx 4Dx 4Fx 5Gx F1x F2x B8x B9x)	40K6763		

Power cords

This topic provides information about power cords, as well as a table listing the IBM power cords by country and region.

For your safety, IBM provides a power cord with a grounded attachment plug to use with this IBM product. To avoid electrical shock, always use the power cord and plug with a properly grounded outlet.

IBM power cords used in the United States and Canada are listed by Underwriter's Laboratories (UL) and certified by the Canadian Standards Association (CSA).

For units intended to be operated at 115 volts: Use a UL-listed and CSA-certified cord set consisting of a minimum 16 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a parallel blade, grounding-type attachment plug rated 15 amperes, 125 volts.

For units intended to be operated at 230 volts (U.S. use): Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a tandem blade, grounding-type attachment plug rated 15 amperes, 250 volts.

For units intended to be operated at 230 volts (outside the U.S.): Use a cord set with a grounding-type attachment plug. The cord set should have the appropriate safety approvals for the country in which the equipment will be installed.

IBM power cords for a specific country or region are usually available only in that country or region.

IBM power cord part number	Used in these countries and regions
39M5206	China
39M5102	Australia, Fiji, Kiribati, Nauru, New Zealand, Papua New Guinea
39M5123	Afghanistan, Albania, Algeria, Andorra, Angola, Armenia, Austria, Azerbaijan, Belarus, Belgium, Benin, Bosnia and Herzegovina, Bulgaria, Burkina Faso, Burundi, Cambodia, Cameroon, Cape Verde, Central African Republic, Chad, Comoros, Congo (Democratic Republic of), Congo (Republic of), Cote D'Ivoire (Ivory Coast), Croatia (Republic of), Czech Republic, Dahomey, Djibouti, Egypt, Equatorial Guinea, Eritrea, Estonia, Ethiopia, Finland, France, French Guyana, French Polynesia, Germany, Greece, Guadeloupe, Guinea, Guinea Bissau, Hungary, Iceland, Indonesia, Iran, Kazakhstan, Kyrgyzstan, Laos (People's Democratic Republic of), Latvia, Lebanon, Lithuania, Luxembourg, Macedonia (former Yugoslav Republic of), Madagascar, Mali, Martinique, Mauritania, Mauritius, Mayotte, Moldova (Republic of), Monaco, Mongolia, Morocco, Mozambique, Netherlands, New Caledonia, Niger, Norway, Poland, Portugal, Reunion, Romania, Russian Federation, Rwanda, Sao Tome and Principe, Saudi Arabia, Senegal, Serbia, Slovakia, Slovenia (Republic of), Somalia, Spain, Suriname, Sweden, Syrian Arab Republic, Tajikistan, Tahiti, Togo, Tunisia, Turkey, Turkmenistan, Ukraine, Upper Volta, Uzbekistan, Vanuatu, Vietnam, Wallis and Futuna, Yugoslavia (Federal Republic of), Zaire
39M5130	Denmark
39M5144	Bangladesh, Lesotho, Macao, Maldives, Namibia, Nepal, Pakistan, Samoa, South Africa, Sri Lanka, Swaziland, Uganda
39M5151	Abu Dhabi, Bahrain, Botswana, Brunei Darussalam, Channel Islands, China (Hong Kong S.A.R.), Cyprus, Dominica, Gambia, Ghana, Grenada, Iraq, Ireland, Jordan, Kenya, Kuwait, Liberia, Malawi, Malaysia, Malta, Myanmar (Burma), Nigeria, Oman, Polynesia, Qatar, Saint Kitts and Nevis, Saint Lucia, Saint Vincent and the Grenadines, Seychelles, Sierra Leone, Singapore, Sudan, Tanzania (United Republic of), Trinidad and Tobago, United Arab Emirates (Dubai), United Kingdom, Yemen, Zambia, Zimbabwe
39M5158	Liechtenstein, Switzerland
39M5165	Chile, Italy, Libyan Arab Jamahiriya
39M5172	Israel
39M5095	220 - 240 V Antigua and Barbuda, Aruba, Bahamas, Barbados, Belize, Bermuda, Bolivia, Brazil, Caicos Islands, Canada, Cayman Islands, Colombia, Costa Rica, Cuba, Dominican Republic, Ecuador, El Salvador, Guam, Guatemala, Haiti, Honduras, Jamaica, Japan, Mexico, Micronesia (Federal States of), Netherlands Antilles, Nicaragua, Panama, Peru, Philippines, Taiwan, United States of America, Venezuela
39M5513	110 - 120 V Antigua and Barbuda, Aruba, Bahamas, Barbados, Belize, Bermuda, Bolivia, Caicos Islands, Canada, Cayman Islands, Colombia, Costa Rica, Cuba, Dominican Republic, Ecuador, El Salvador, Guam, Guatemala, Haiti, Honduras, Jamaica, Mexico, Micronesia (Federal States of), Netherlands Antilles, Nicaragua, Panama, Peru, Philippines, Saudi Arabia, Thailand, Taiwan, United States of America, Venezuela
39M5219	Korea (Democratic People's Republic of), Korea (Republic of)

IBM power cord part number	Used in these countries and regions
39M5199	Japan
39M5068	Argentina, Paraguay, Uruguay
39M5226	India
39M5240	Brazil

Product recovery CDs

This topic provides a list of product recovery CDs.

Table 15 describes the product recovery CD CRUs.

Table 15. Product recovery CDs

Description	CRU part number
Microsoft Windows Server 2008 R2 Datacenter 32/64 bit, multilingual	49Y0222
Microsoft Windows Server 2008 Datacenter 32/64 bit, Simplified Chinese	49Y0223
Microsoft Windows Server 2008 Datacenter 32/64 bit, Traditional, Chinese	49Y0224
Microsoft Windows Server 2008 Standard Edition 32/64 bit 1-4 microprocessors, multilingual	49Y0892
Microsoft Windows Server 2008 Standard Edition 32/64 bit 1-4 microprocessors, Simplified Chinese	49Y0893
Microsoft Windows Server 2008 Standard Edition 32/64 bit 1-4 microprocessors, Traditional, Chinese	49Y0894
Microsoft Windows Server 2008 Enterprise Edition 32/64 bit 1-8 microprocessors, multilingual	49Y0895
Microsoft Windows Server 2008 SP2 Enterprise Edition 32/64 bit 1-8 microprocessors, Simplified Chinese	49Y0896
Microsoft Windows Server 2008 Enterprise Edition 32/64 bit 1-8 microprocessors, Traditional, Chinese	49Y0897
Microsoft Windows Server 2008 Datacenter R2, multilingual	59Y7332
Microsoft Windows Server 2008 Datacenter R2, Simplified Chinese	59Y7333
Microsoft Windows Server 2008 Datacenter R2, Traditional, Chinese	59Y7334
Microsoft Windows Server 2008 Datacenter SP2 32/64 bit, multilingual	60Y1760
Microsoft Windows Server 2008 HPC ROK, US English	68Y9455
Microsoft Windows Server 2008 HPC ROK, Japanese	68Y9456
Microsoft Windows Server 2008 HPC ROK, Simplified Chinese	68Y9457
Microsoft Windows Server 2008 R2 Foundation, US English	81Y2001
Microsoft Windows Server 2008 R2 Foundation, French	81Y2002
Microsoft Windows Server 2008 R2 Foundation, German	81Y2003
Microsoft Windows Server 2008 R2 Foundation, Spanish	81Y2004
Microsoft Windows Server 2008 R2 Foundation, Italian	81Y2005
Microsoft Windows Server 2008 R2 Foundation, Brazilian	81Y2006
Microsoft Windows Server 2008 R2 Foundation, Polish	81Y2007
Microsoft Windows Server 2008 R2 Foundation, Russian	81Y2008

Table 15. Product recovery CDs (continued)

Description	CRU part number
Microsoft Windows Server 2008 R2 Foundation, Turkish	81Y2009
Microsoft Windows Server 2008 R2 Foundation, Japanese	81Y2010
Microsoft Windows Server 2008 R2 Foundation, Simplified Chinese	81Y2011
Microsoft Windows Server 2008 R2 Foundation, Traditional, Chinese	81Y2012
Microsoft Windows Server 2008 R2 Foundation, Korean	81Y2013
Microsoft Windows Server 2008 R2 Foundation, Czech	81Y2014
Microsoft Windows 2008 Server R2 Standard Edition 1-4 microprocessors, multilingual	81Y2015
Microsoft Windows 2008 Server R2 Standard Edition 1-4 microprocessors, Simplified Chinese	81Y2016
Microsoft Windows 2008 Server R2 Standard Edition 1-4 microprocessors, Traditional, Chinese	81Y2017
Microsoft Windows 2008 Server R2 Enterprise Edition 1-8 microprocessors, multilingual	81Y2018
Microsoft Windows 2008 Server R2 Enterprise Edition 1-8 microprocessors, Simplified Chinese	81Y2019
Microsoft Windows 2008 Server R2 Enterprise Edition 1-8 microprocessors, Traditional, Chinese	81Y2020
Microsoft Windows Server 2008 R2 Enterprise Edition 1-8 microprocessors, multilingual	81Y2021
Microsoft Windows 2008 Server R2 Enterprise Edition 1-8 microprocessors, Simplified Chinese	81Y2022
Microsoft Windows 2008 Server R2 Enterprise Edition 1-8 microprocessors, Traditional, Chinese	81Y2023

VMware ESXi recovery CDs (Type 7145)

This topic provides a table that list VMware ESXi recovery CDs (Type 7145).

“VMware ESXi recovery CDs (Type 7145)” describes the VMware ESXi recovery CD CRUs.

Table 16. VMware ESXi recovery CDs

Description	CRU part number
VMware ESX Server 3i version 3.5	46D0762
VMware ESX Server 3i v 3.5 Update 2	46M9236
VMware ESX Server 3i v 3.5 Update 3	46M9237
VMware ESX Server 3i v 3.5 Update 4	46M9238
VMware ESX Server 3i v 3.5 Update 5	68Y9633
VMware ESXi 4	49Y8747
VMware ESXi 4.0 U1	68Y9634
VMware vSphere ESXi 4.1 without flash memory USB key	81Y2028

Chapter 5. Removing and replacing components

Replaceable components are of four types:

- **Consumable part:** Purchase and replacement of consumable parts (components, such as batteries and printer cartridges, that have depletable life) is your responsibility. If IBM acquires or installs a consumable part at your request, you will be charged for the service.
- **Tier 1 customer replaceable unit (CRU):** Replacement of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation.
- **Tier 2 customer replaceable unit:** You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service that is designated for your server.
- **Field replaceable unit (FRU):** FRUs must be installed only by trained service technicians.

See Chapter 4, “Parts listing, Types 7145, 7146, 7143, and 7191,” on page 81 to determine whether a component is a Tier 1 CRU, Tier 2 CRU, or FRU.

For information about the terms of the warranty and getting service and assistance, see the *Warranty Information* document that came with your server.

Installation guidelines

This topic guidelines that should be read before removing or replacing a component.

Before you remove or replace a component, read the following information:

- Read the safety information that begins with “Safety” on page v, “Working inside the server with the power on” on page 99, and “Handling static-sensitive devices” on page 100. This information will help you work safely.
- When you install your new server, take the opportunity to download and apply the most recent firmware updates. This step will help to ensure that any known issues are addressed and that your server is ready to function at maximum levels of performance. To download firmware updates for your server, go to <http://www.ibm.com/supportportal/>.

For additional information about tools for updating, managing, and deploying firmware, see the ToolsCenter for System x and BladeCenter at <http://publib.boulder.ibm.com/infocenter/toolsctr/v1r0/index.jsp>.

- Before you install optional hardware devices, make sure that the server is working correctly. Start the server, and make sure that the operating system starts, if an operating system is installed, or that a 19990305 error code is displayed, indicating that an operating system was not found but the server is otherwise working correctly. If the server is not working correctly, see Chapter 3, “Diagnostics,” on page 37 for information about how to run diagnostics.
- In a two-node configuration, you must remove the QPI cables to separately debug the servers.
- If the server is connected to a memory expansion modules, see the documentation for the QPI or EXA cabling kit for important cabling information when disconnecting or connecting QPI or EXA cables.

- Observe good housekeeping in the area where you are working. Place removed covers and other parts in a safe place.
- If you must start the server while the cover is removed, make sure that no one is near the server and that no tools or other objects have been left inside the server.
- Do not attempt to lift an object that you think is too heavy for you. If you have to lift a heavy object, observe the following precautions:
 - Make sure that you can stand safely without slipping.
 - Distribute the weight of the object equally between your feet.
 - Use a slow lifting force. Never move suddenly or twist when you lift a heavy object.
 - To avoid straining the muscles in your back, lift by standing or by pushing up with your leg muscles.
- Make sure that you have an adequate number of properly grounded electrical outlets for the server, monitor, and other devices.
- Back up all important data before you make changes to disk drives.
- Have a small flat-blade screwdriver available.
- To view the error LEDs on the system board and internal components, leave the server connected to power.
- You do not have to turn off the server to install or replace hot-swap power supplies, hot-swap fans, or hot-plug Universal Serial Bus (USB) devices. However, you must turn off the server before you perform any steps that involve removing or installing adapter cables.
- Blue on a component indicates touch points, where you can grip the component to remove it from or install it in the server, open or close a latch, and so on.
- Orange on a component or an orange label on or near a component indicates that the component can be hot-swapped, which means that if the server and operating system support hot-swap capability, you can remove or install the component while the server is running. (Orange can also indicate touch points on hot-swap components.) See the instructions for removing or installing a specific hot-swap component for any additional procedures that you might have to perform before you remove or install the component.
- When you are finished working on the server, reinstall all safety shields, guards, labels, and ground wires.
- For a list of supported optional devices for the server, see <http://www-03.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

A single-power-supply server operating at 208 V ac

This topic discusses a single-power-supply server operating at 208 V ac.

One power supply operating at 208 V ac supports a fully populated server, but it does not support power or cooling redundancy.

System reliability guidelines

This topic provides a list of requirements to help ensure proper cooling and system reliability.

To help ensure proper cooling and system reliability, make sure that the following requirements are met:

- Each of the drive bays has a drive or a filler installed in it.
- There is adequate space around the server to allow the server cooling system to work properly. Leave approximately 50 mm (2 in.) of open space around the front and rear of the server. Do not place objects in front of the fans. For proper cooling and airflow, replace the server cover before you turn on the server. Operating the server for extended periods of time (more than 30 minutes) with the server cover removed might damage server components.
- You have followed the cabling instructions that come with optional adapters.
- You have replaced a failed fan within 48 hours.
- You have replaced a hot-swap drive within 2 minutes of removal.
- For redundant and hot-swappable power supply operation, the power supplies are connected to 200-240 V ac.
- Microprocessor sockets 1 - 4 each always contain either a heat-sink blank or a microprocessor and heat sink.

Note: Microprocessor temperature, hard disk drive temperature, and planar voltage sensing is not supported.

Working inside the server with the power on

This topic provides guidelines about working inside the server with the power on.

Attention: Static electricity that is released to internal server components when the server is powered on might cause the server to halt, which might result in the loss of data. To avoid this potential problem, always use an electrostatic-discharge wrist strap or other grounding system when you work inside the server with the power on. You can connect the wrist strap to a connector on the front of the server (see “Front view” on page 13 for the location of the electrostatic-discharge connector).

The server supports hot-swap devices and is designed to operate safely while it is turned on and the cover is removed. Follow these guidelines when you work inside a server that is turned on:

- Avoid wearing loose-fitting clothing on your forearms. Button long-sleeved shirts before working inside the server; do not wear cuff links while you are working inside the server.
- Do not allow your necktie or scarf to hang inside the server.
- Remove jewelry, such as bracelets, necklaces, rings, and loose-fitting wrist watches.
- Remove items from your shirt pocket, such as pens and pencils, that might fall into the server as you lean over it.

- Avoid dropping any metallic objects, such as paper clips, hairpins, and screws, into the server.

Handling static-sensitive devices

This topic provides instructions for how to handle static-sensitive devices.

Attention: Static electricity can damage the server and other electronic devices. To avoid damage, keep static-sensitive devices in their static-protective packages until you are ready to install them.

To reduce the possibility of damage from electrostatic discharge, observe the following precautions:

- Limit your movement. Movement can cause static electricity to build up around you.
- Wear an electrostatic-discharge wrist strap, if one is available.
- Handle the device carefully, holding it by its edges or its frame.
- Do not touch solder joints, pins, or exposed circuitry.
- Do not leave the device where others can handle and damage it.
- While the device is still in its static-protective package, touch it to an *unpainted* metal surface on the outside of the server for at least 2 seconds. This drains static electricity from the package and from your body.
- Remove the device from its package and install it directly into the server without setting down the device. If it is necessary to set down the device, put it back into its static-protective package. Do not place the device on the server cover or on a metal surface.
- Take additional care when you handle devices during cold weather. Heating reduces indoor humidity and increases static electricity.

Servicing multi-node systems

This topic provides general information about servicing multi-node systems.

Note: Before you pull the servers out of the rack, make sure that the rack tip plate is installed.

If you are servicing a QPI two-node scaled configuration, you can slide both units out of the rack at the same time to access components in the top node. To access the components in the bottom node, you must disconnect the QPI cables in the rear of the server and unlatch the two-node bracket from the top node in the rear.


If you are servicing components in a server to which a memory expansion module is attached, slide the server and memory expansion module out of the rack together, as one unit.

Internal cable routing and connectors


This topic provides illustrations of the internal cable routing and connectors.

About this task


The following illustration shows the routing of the DVD power, fans 1 and 2, scalability LED, and operator information cables.



The following illustration shows the routing of the USB and DVD signal cables.



The following illustration shows the cable routing of the SAS signal cables from the solid state drive backplane to the ServeRAID adapter.



Returning a device or component

This topic provides information for returning a device..

If you are instructed to return a device or component, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Connecting the cables

This topic provides illustrations that show the locations of the input and output connectors on the server.


See the documentation that comes with optional devices for additional cabling instructions. It might be easier for you to route cables before you install certain devices.

You can install one or more optional EXA Scaling kits, when available, to interconnect the SMP Expansion ports of two servers.


The following illustrations show the locations of the input and output connectors on the server. Detailed cabling instructions are in the *Rack Installation Instructions* that come with the server and the *Rack and Cable Installation Instructions* that come with the QPI cable kits.

Rear view

A thumbscrew is in this position only when a 2-node lock bracket is installed (2-node Scalability Kit Option)



Front view



Removing and replacing server components

This topic provides information about the four types of replaceable server components.

Replaceable components are of four types:

- **Consumable part:** Purchase and replacement of consumable parts (components, such as batteries and printer cartridges, that have depletable life) is your responsibility. If IBM acquires or installs a consumable part at your request, you will be charged for the service.
- **Tier 1 customer replaceable unit (CRU):** Replacement of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation.
- **Tier 2 customer replaceable unit:** You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service that is designated for your server.
- **Field replaceable unit (FRU):** FRUs must be installed only by trained service technicians.

Removing and replacing consumable parts and Tier 1 CRUs

This topic provides general information about removing and replacing consumable parts and Tier 1 CRUs.

Replacement of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation.

The illustrations in this document might differ slightly from your hardware.


Removing the top cover

This topic provides instructions for how to remove the top cover.

About this task

Attention: Operating the server for more than 2 minutes with the top cover removed might damage server components. For proper cooling and airflow, replace the top cover before you turn on the server.

To remove the top cover, complete the following steps.



Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. If you are installing or replacing a non-hot-swap component, turn off the server and all peripheral devices, and disconnect the power cords and all external cables.
3. Slide the server out of the rack until the slide rails lock into place.
4. Press the button and rotate the cover-release latch. The cover slides to the rear approximately 13 mm (0.5 inch). Lift the cover off the server.
5. If you are instructed to return the cover, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the top cover

This topic provides instructions for how to install the top cover.

About this task

To install the top cover, complete the following steps:

Procedure

1. Make sure that all internal cables are correctly routed.
2. Set the cover on top of the server so that approximately 13 mm (0.5 inch) extends from the rear.
3. Make sure that the cover-release latch is up.
4. Slide the top cover forward and into position, pressing the release latch closed.
5. If necessary, reconnect the power cords and all external cables, and then turn on the server.
6. Slide the server into the rack.

Removing the top-cover bracket

This topic provides instructions for how to remove the top-cover bracket.


About this task

To remove the top-cover bracket, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. If you are installing or replacing a non-hot-swap component, turn off the server and all peripheral devices, and disconnect the power cords and all external cables.
3. Slide the server out of the rack until the slide rails lock into place.
4. Remove the top cover.
5. Slide the blue latches on the top-cover bracket toward the center of the server.
6. Tilt and lift the top-cover bracket out of the server.
7. If you are instructed to return the top-cover bracket, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Results



Replacing the top-cover bracket

This topic provides instructions for how to replace the top-cover bracket.

About this task

To replace the top-cover bracket, complete the following steps:


Procedure

1. Make sure that all internal cables are correctly routed.
2. Align the top-cover bracket on top of the server so that the metal tabs line up correctly on the chassis, and then rotate it into place.
3. Slide the blue latches on the top cover bracket toward the outside of the server to lock it in place.

Removing the front bezel

This topic provides instructions for how to remove the front bezel.

About this task



Note: You do not have to remove the top cover before you remove the bezel.

To remove the bezel, complete the following steps:

Procedure


1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Press on the bezel retention tabs at the sides of the bezel, and pull the bezel from the server.
3. If you are instructed to return the bezel, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the front bezel

This topic provides instructions for how to install the front bezel.

About this task

To install the bezel, align the studs with the matching holes on all four corners; then, push in and snap the bezel into place.




Removing an adapter

This topic provides instructions for how to remove a PCI Express adapter.

About this task

To remove a PCI Express adapter, complete the following steps.



Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to remove the adapter.

3. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
4. Disconnect any cables from the adapter.
5. Lift the blue adapter retention latch up away from the server and open the tab.
6. Carefully grasp the adapter by its top edge or upper corners, and pull the adapter from the server.
7. If you are instructed to return the adapter, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing an adapter

This topic provides instructions for how to install a replacement PCI Express adapter.

About this task

Note: If you are replacing a ServeRAID adapter that has a battery, you must install the adapter in a full-length slot. You must also leave an empty expansion slot on each side of the adapter.

To install a replacement PCI Express adapter, complete the following steps:

Procedure

1. See the documentation that comes with the adapter for instructions for setting jumpers or switches and for cabling.

Note: Route adapter cables before you install the adapter.

2. Carefully grasp the adapter by its top edge or upper corners, and align it with the connector on the I/O board.
3. Press the adapter firmly into the adapter connector.
4. Rotate the latch closed and push it down on the blue latch until it clicks into place, securing the adapter.
5. Connect any required cables to the adapter.
6. Install the top cover (see “Replacing the top cover” on page 107).
7. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
8. Turn on all attached devices and the server.

Removing the battery

This topic provides instructions for how to remove the battery.


About this task

To remove the battery, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).
4. Locate the battery (see "I/O-board connectors" on page 26).
5. If any PCI adapters are blocking access to the battery, remove them (see "Removing an adapter" on page 110).

6. Remove the battery:
 - a. Use one finger to push the battery horizontally out of its housing.
 - b. Lift the battery from the socket.



7. Dispose of the battery as required by local ordinances or regulations.

Replacing the battery

This topic provides instructions for how to install the replacement battery.

About this task

The following notes describe information that you must consider when you replace the battery in the server:

- You must replace the battery with a lithium battery of the same type from the same manufacturer.
- After you replace the battery, you must reconfigure the server and reset the system date and time.
- To avoid possible danger, read and follow the following safety statement.

Statement 2



CAUTION:

When replacing the lithium battery, use only IBM Part Number 15F8409 or an equivalent type battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- **Throw or immerse into water**
- **Heat to more than 100°C (212°F)**
- **Repair or disassemble**


Dispose of the battery as required by local ordinances or regulations.

To install the replacement battery, complete the following steps:

Procedure

1. Follow any special handling and installation instructions that come with the replacement battery.
2. Locate the battery connector (see “I/O-board connectors” on page 26).

3. Insert the new battery:
 - a. Position the battery so that the positive (+) symbol is facing you.
 - b. Place the battery into its socket, and press the battery toward the housing until it snaps into place.



4. Install the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
5. Reconnect the external cables; then, reconnect the power cords and turn on the peripheral devices and the server.

Note: You must wait approximately 3 minutes after you connect the power cord of the server to an electrical outlet before the power-control button becomes active.

6. Start the Setup utility and reset the configuration:
 - Set the system date and time.
 - Set the power-on password.
 - Reconfigure the server.

See “Configuring the server” on page 202 for details.

Removing the DVD drive


This topic provides instructions for how to remove the DVD drive.

About this task


To remove the DVD drive, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the front bezel.



4. Push in and hold the blue release button while you pull the DVD drive out of the server.



5. Remove the DVD bracket from the drive.
6. If you are instructed to return the DVD drive, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the DVD drive

This topic provides instructions for how to install the replacement DVD drive.

About this task

To install the replacement DVD drive, complete the following steps:

Procedure

1. Install the DVD bracket on the side of the new DVD drive.
2. Slide the DVD drive into the server until it engages the SATA cable.
3. Install the front bezel (see “Replacing the front bezel” on page 109).
4. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
5. Turn on all attached devices and the server.

Removing a 1.8-inch solid state drive


This topic provides instructions on how to remove a solid state drive.

About this task

To remove a solid state drive, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Remove the drive cage filler panel.
3. Slide the drive release latch to the right and rotate the handle to the open



- position.
4. Slide the solid state drive out of the server.

Replacing a 1.8-inch solid state drive

This topic provides instructions on how to install the replacement solid state drive.

About this task

To install the replacement solid state drive, complete the following steps:

Procedure

1. Remove the drive cage filler panel.
2. Slide the drive release latch to the right and rotate the handle to the open position.
3. Push the solid state drive all the way until it clicks in the backplane.
4. Rotate the handle until the latch clicks closed.
5. Reinstall the drive cage filler panel.
6. Install the drive ID label on the server front bezel.

Removing a hot-swap hard disk drive


This topic provides instructions for how to remove the hot-swap hard disk drive.

About this task

Important: Before you remove a hot-swap hard disk drive from the server, take the following precautions to save data, firmware, and configuration data:

- Before you make changes to disk drives, disk drive controllers (including controllers that are integrated on the system board), disk drive backplanes, or disk drive cables, back up all important data that is stored on hard disks.
- Before you remove any component of a RAID array, back up all RAID configuration information.

To remove the hot-swap hard disk drive, complete the following steps.



Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Be sure to save the data on your drive, especially if it is part of a RAID array, before you remove it from the server.
3. Push the latch on the handle to the left, then open the drive handle and pull the hard disk drive assembly out of the server.
4. If you are instructed to return the hot-swap hard disk drive, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a hot-swap hard disk drive

This topic provides instructions for replacing a hot-swap hard disk drive.

About this task

To install the replacement hot-swap hard disk drive, complete the following steps:

Procedure


1. Touch the static-protective package that contains the hard disk drive to any unpainted surface on the outside of the server; then, remove the hard disk drive from the package.
2. Make sure that the tray handle is open; then, slide the hard disk drive into the hot-swap bay.
3. Close the handle until it latches closed.
4. Check the hard disk drive status LEDs to make sure that the hard disk drive is operating correctly.
5. Restore the RAID configuration information that you backed up before you removed the hot-swap hard disk drive.

Removing the operator information panel assembly

This topic provides instructions for how to remove the operator information panel assembly.

About this task

To remove the operator information panel assembly, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the front bezel and the top cover (see “Removing the front bezel” on page 108 and “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
4. Remove the memory cards or fillers from slots 5, 6, 7, and 8 (see “Removing a memory card” on page 136).
5. Disconnect the operator information panel (front panel) cable from the microprocessor board, see “Microprocessor-board connectors” on page 24.
6. Press the blue release button above the assembly and carefully pull the assembly out of the server. Make sure that you do not damage the cable as you remove the assembly from the server.
7. Disconnect the cable from the rear of the operator information panel.
8. If you are instructed to return the operator information panel assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the operator information panel assembly

This topic provides instructions for how to install the replacement operator information panel assembly.

About this task

To install the replacement operator information panel assembly, complete the following steps:

Procedure

1. Connect the operator information panel cable to the rear of the new operator information panel.
2. Thread the operator information panel cable into the operator information panel bay and insert the assembly into the server from the front.
3. Connect the cable to the microprocessor board.
4. Install the memory cards or fillers in slots 5, 6, 7, and 8 (see "Replacing a memory card" on page 137).
5. Install the front bezel and the top cover (see "Replacing the front bezel" on page 109 and "Replacing the top cover" on page 107).
6. Connect the cables and power cords (see "Connecting the cables" on page 104 for cabling instructions).
7. Turn on all attached devices and the server and check the server for normal operation.

Removing the front hot-swap fans


This topic provides instructions for how to remove a front hot-swap fan.

About this task


To remove a front hot-swap fan, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Remove the front bezel.



3. Open the fan-release handle by pushing the orange release latch down.



4. Pull out on the free end of the handle to slide the fan out of the server.
5. If you are instructed to return the fan, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the front hot-swap fans

This topic provides instructions for installing a replacement hot-swap fan.

About this task

To install a replacement hot-swap fan, complete the following steps:

Procedure


1. Open the fan-release handle to 90° on the replacement fan.
2. Slide the fan into the server, and close the handle to the locked position.
3. Make sure that the fan error LED on the replacement fan is off.
4. Install the front bezel (see “Replacing the front bezel” on page 109).

Removing the middle hot-swap fan

This topic provides instructions for how to remove the middle hot-swap fan.

About this task

To remove the middle hot-swap fan, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).

Attention: To ensure proper cooling and airflow, do not operate the server for more than 2 minutes with the top cover removed.

3. Squeeze the fan handles together, and then lift the fan out of the server.

Attention: The server cannot run for more than 30 seconds when this fan is removed. The server will shut down automatically if the fan is missing for 30 seconds or longer.

4. If you are instructed to return the fan, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the middle hot-swap fan

This topic provides instructions for how to install the replacement middle hot-swap fan.

About this task

To install the replacement middle hot-swap fan, complete the following steps:

Procedure

1. Lower the fan into the socket, and push it downward until it clicks into place.
2. Make sure that the fan error LED on the replacement fan is off.
3. Install the top cover (see “Replacing the top cover” on page 107).

Removing a hot-swap power supply

This topic provides precautions for removing or installing a hot-swap power supply.

About this task

Note: Two power supplies must be installed in the server for either power supply to be considered hot-swap.

When you remove or install a hot-swap power supply, observe the following precautions.

Statement 8



CAUTION:


Never remove the cover on a power supply or any part that has the following label attached.



Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

Removing a hot-swap power supply in a single-node server: About this task

To remove a hot-swap power supply in a single-node server, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97

Note: If your server has only one power supply, you must turn off the server before you remove the power supply.


2. If only one power supply is installed, turn off the server.
3. Disconnect the power cord from the connector on the back of the power supply.
4. Slide the orange release latch on the handle to the right and lift the handle up to the open position.
5. Pull the power supply out of the bay.
6. If you are instructed to return the hot-swap power supply, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Removing a hot-swap power supply in a 2-node server:


This topic provides instructions for how to remove a hot-swap power supply in a 2-node server.

About this task

To remove a hot-swap power supply in a 2-node server, complete the following steps.



Right power supply



Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97

Note: If your server has only one power supply, you must turn off the server before you remove the power supply.

2. If only one power supply is installed, turn off the server.
3. Disconnect the power cord from the connector on the back of the power supply.
4. Separate the cables to access the power supply
5. Slide the orange release latch on the handle to the right and lift the handle up to the open position.
6. Pull the power supply out of the bay.
7. If you are instructed to return the hot-swap power supply, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the hot-swap power supply

This topic provides instructions for how to install the replacement hot-swap power supply.

About this task

To install the replacement hot-swap power supply, complete the following steps:


Procedure

1. Touch the static-protective package that contains the power supply to any unpainted surface on the outside of the server; then, remove it from the package.
2. Press the orange release latch on the handle to the right and pull the handle up to the open position if it is not already in the open position.
3. Push the power supply into the bay, slide the latch to the right, and push the handle down to lock it.
4. Connect one end of the power cord for the new power supply into the ac inlet on the back of the power supply, and connect the other end of the power cord into a properly grounded electrical outlet.
5. Route the cable through the retention hook on the back of the power supply.
6. If the server is turned off, turn on the server.
7. Make sure that the ac and dc power LED on the power supply is lit, indicating that the power supply is operating correctly.

Removing a QPI wrap card

This topic provides instructions for how to remove a QPI wrap card from the server.

About this task



To remove a QPI wrap card from the server, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary.
3. Rotate the blue release latch on the handle and pull the handle to the open position.
4. Slide the wrap card out of the server.
5. If you are instructed to return the wrap card, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a QPI wrap card

This topic provides steps to install the replacement QPI wrap card.

About this task

To install the replacement QPI wrap card, complete the following steps:


Procedure

1. Rotate the blue release latch on the handle and pull the handle to the open position.
2. Push the wrap card into the bay, and slide the handle to the locked position.
3. Connect the cables and power cords (see "Connecting the cables" on page 104 for cabling instructions).
4. Turn on all attached devices and the server.

Removing a ServeRAID SAS controller battery

This topic provides instructions for how to remove a ServeRAID SAS controller battery from the adapter.

About this task



To remove a ServeRAID SAS controller battery from the adapter, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary.
3. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).

4. If you are removing the battery from a ServeRAID SAS controller in one of the rear I/O connectors, see “Removing an adapter” on page 110 for controller removal instructions.
5. If you are removing the battery from the ServeRAID SAS controller behind the hard disk drives, see “Removing the RAID adapter carrier and the RAID adapter assembly” on page 146 for controller removal instructions.
6. Disconnect the cable that connects the battery to the battery carrier.
7. Remove the battery from the adapter.
8. If you are instructed to return the battery, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a ServeRAID SAS controller battery

This topic provides steps for replacing a ServeRAID SAS controller battery.

About this task

To replace a ServeRAID SAS controller battery, complete the following steps:

Procedure

1. Install the battery on the ServeRAID adapter.
2. Connect the cable from the battery to the battery carrier.
3. If you are installing a ServeRAID SAS controller in one of the rear I/O connectors, see “Replacing an adapter” on page 111 for controller installation instructions.
4. If you are installing the ServeRAID SAS controller behind the hard disk drives, see “Replacing the RAID adapter carrier and the RAID adapter assembly” on page 149 for controller installation instructions.

Memory cards and memory modules (DIMM)

This topic provides information about memory cards and memory modules (DIMM).


About this task

The following notes describe the types of dual inline memory modules (DIMMs) that the server supports and other information that you must consider when you install DIMMs:

- To confirm that the server supports the memory modules that you are installing, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.
- All server machine types that are described in this document support 240-pin, double-data-rate (DDR) III, registered synchronous dynamic random-access memory (SDRAM) with error correcting code (ECC) DIMMs. These DIMMs must be compatible with the latest PC3-10600 or PC3-8500 SDRAM registered DIMM specifications.
 - All machine types support 1.5 V DIMMs; machine types 7143 and 7191 also support 1.35 V DIMMs.
 - All machine types support 2 GB PC3-10600 DIMMs and 4 GB, 8 GB, 16 GB, and 32 GB (when available) PC3-8500 DIMMs; machine types 7145 and 7146 also support 1 GB DIMMs.
- The server supports up to eight memory cards. Each memory card holds up to eight DIMMs.
- The Intel 7500 Scalable Memory Buffer and the Intel 7510 Scalable Memory Buffer are not interchangeable and cannot be used in the same server. To verify


that your server supports the memory card that you are installing, look at the label on the top of the memory card. If the label does not state that the memory card can be used only in machine types 7143 and 7191, the memory card can be used only in machine types 7145 and 7146.

- The server supports an additional 512 GB of memory when the 32-DIMM optional IBM MAX5 for System x memory expansion module is attached to the server.
- The server supports memory sparing. Memory sparing reserves memory capacity for failover in the event of a DIMM failure, and the reserved capacity is subtracted from the total available memory. Memory sparing provides less redundancy than memory mirroring does. If a predetermined threshold of correctable errors is reached the contents of the failing DIMM are copied to the spare memory, and the failing DIMM or rank is disabled. To enable memory sparing through the Setup utility, select System Settings > Memory. (You cannot use memory mirroring and memory sparing at the same time.)
- At least one memory card with one pair of DIMMs must be installed for the server to operate.
- When you install additional DIMMs on a memory card, be sure to install them in pairs. The DIMMs in each pair must match each other.
- You do not have to save new configuration information to the IMM when you install or remove DIMMs. The only exception is if you replace a DIMM that was designated as disabled in the Setup utility **Memory Settings** menu. In this case, you must re-enable the row in the Setup utility or reload the default memory settings.
- When you restart the server after you add or remove a DIMM, the server displays a message that the memory configuration has changed.
- Memory cards in connectors 1 and 2 support microprocessor 1, memory cards in connectors 3 and 4 support microprocessor 2, memory cards in connectors 5 and 6 support microprocessor 3, and memory cards in connectors 7 and 8 support microprocessor 4.
- There are four memory power buses, which are split among the eight memory cards.
- Populate the memory-card connectors to match the microprocessor installation, in the following order: 1, 7, 3, 5, 2, 8, 4, 6. (Microprocessors must be installed in the following order: 1, 4, 2, and 3.) The following illustration shows the locations of the memory-card and microprocessor connectors.



Front of server

- The following illustration shows the DIMM connectors on a memory card.



- In a low-cost and low-power DIMM installation, install the DIMMs on each memory card in the order shown in the following tables. The goal in a low-cost and low-power configuration is to completely fill each memory card before you install the next memory card.

Table 17. Low-cost and low-power DIMM installation sequence

DIMM pair installation order	Memory-card connector number	DIMM-connector numbers	Installed microprocessors
First	1	1 and 8	1 and 4
Second	7	1 and 8	
Third	1	3 and 6	
Fourth	7	3 and 6	
Fifth	1	2 and 7	
Sixth	7	2 and 7	
Seventh	1	4 and 5	
Eighth	7	4 and 5	

If you plan to install additional memory cards in the low-cost installation sequence, follow the DIMM installation sequence in “Memory cards and memory modules (DIMM)” on page 129 for each memory card. Install the memory cards in the installation sequence shown in “Memory cards and memory modules (DIMM)” on page 129.

Table 18. Low-cost and low-power memory-card installation sequence

Memory card pairs	Memory-card connector number	Installed microprocessors
First	1 and 7	1 and 4
Second	2 and 8	
Third	3 and 5	2 and 3
Fourth	4 and 6	

In a high-performance DIMM installation, install the DIMMs on each memory card in the order shown in the following table. You must install at least one pair of DIMMs on each memory card.

Table 19. High-performance memory-card installation sequence

DIMM pair installation order	Memory-card connector number	DIMM connector numbers
First	1	1 and 8
Second	7	1 and 8
Third	3	1 and 8
Fourth	5	1 and 8
Fifth	2	1 and 8
Sixth	8	1 and 8
Seventh	4	1 and 8
Eighth	6	1 and 8
Ninth	1	3 and 6
Tenth	7	3 and 6
Eleventh	3	3 and 6
Twelfth	5	3 and 6
Thirteenth	2	3 and 6
Fourteenth	8	3 and 6

Table 19. High-performance memory-card installation sequence (continued)

DIMM pair installation order	Memory-card connector number	DIMM connector numbers
Fifteenth	4	3 and 6
Sixteenth	6	3 and 6
Seventeenth	1	2 and 7
Eighteenth	7	2 and 7
Nineteenth	3	2 and 7
Twentieth	5	2 and 7
Twenty-first	2	2 and 7
Twenty-second	8	2 and 7
Twenty-third	4	2 and 7
Twenty-fourth	6	2 and 7
Twenty-fifth	1	4 and 5
Twenty-sixth	7	4 and 5
Twenty-seventh	3	4 and 5
Twenty-eighth	5	4 and 5
Twenty-ninth	2	4 and 5
Thirtieth	8	4 and 5
Thirty-first	4	4 and 5
Thirty-second	6	4 and 5

To enable memory mirroring, you must install DIMMs in sets of four, one pair in each memory card. All DIMMs in each set must be the same size and type. Memory cards 1 and 2 mirror each other, cards 3 and 4 mirror each other, memory cards 5 and 6 mirror each other, and cards 7 and 8 mirror each other. Install DIMMs in the sequence shown in the following table.

Table 20. Memory-card installation sequence for memory-mirroring configuration


DIMM quad installation order	Memory-card connector number	DIMM connector numbers
First	1	1 and 8
	2	1 and 8
Second	7	1 and 8
	8	1 and 8
Third	3	1 and 8
	4	1 and 8
Fourth	5	1 and 8
	6	1 and 8
Fifth	1	3 and 6
	2	3 and 6
Sixth	7	3 and 6
	8	3 and 6
Seventh	3	3 and 6
	4	3 and 6

Table 20. Memory-card installation sequence for memory-mirroring configuration (continued)

DIMM quad installation order	Memory-card connector number	DIMM connector numbers
Eighth	5	3 and 6
	6	3 and 6
Ninth	1	2 and 7
	2	2 and 7
Tenth	7	2 and 7
	8	2 and 7
Eleventh	3	2 and 7
	4	2 and 7
Twelfth	5	2 and 7
	6	2 and 7
Thirteenth	1	4 and 5
	2	4 and 5
Fourteenth	7	4 and 5
	8	4 and 5
Fifteenth	3	4 and 5
	4	4 and 5
Sixteenth	5	4 and 5
	6	4 and 5

- If a problem with a DIMM is detected, light path diagnostics lights the system-error LED on the front of the server, indicating that there is a problem and guiding you to the defective DIMM. When this occurs, first identify the defective DIMM; then, remove and replace the DIMM.

The following illustration shows the LEDs that are on a memory card.



Memory card/DIMM error LED: When this LED is lit, it indicates that a memory card or DIMM has failed.

Memory card only error LED: When this LED is lit, it indicates that a memory card has failed.

DIMM 1 - 8 error LED: When one of these LEDs is lit, it indicates that DIMM has failed.

Light path diagnostics button power LED: When this LED is lit, it indicates that the capacitor is charged and error LEDs can be lit as necessary.

Light path diagnostics button: Press this button to relight the error LED that had previously been lit.


Removing a memory card:

This topic provides instructions for how to remove a memory card.

About this task

At least one memory card with one pair of DIMMs must be installed for the server to operate correctly.

To remove a memory card, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
Attention: To ensure proper cooling and airflow, do not operate the server for more than 2 minutes with the top cover removed.
3. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
4. Slide the blue release lever to the unlocked position (toward the rear of the server) and open the retention levers; then, lift the memory card out of the server.
5. If necessary, remove all DIMMs.


6. If you are instructed to return the memory card, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a memory card:

This topic provides instructions to install a replacement memory card.

About this task

The Intel 7500 Scalable Memory Buffer memory card and the Intel 7510 Scalable Memory Buffer memory card are not interchangeable and cannot be used in the same server. To verify that your server supports the memory card that you are installing, look at the label on the top of the memory card. If the label does not state that the memory card can be used only in machine types 7143 and 7191, the memory card can be used only in machine type 7145 and 7146.



To install a replacement memory card, complete the following steps:

Procedure

1. Make sure that the memory card that you are installing is supported by your server by verifying the machine types listed on the label on top of the memory card.
2. Insert the memory card into the memory-card connector. Press the memory card into the connector and the retention latch down onto the top of the memory card.
3. Slide the blue release latch toward the front of the server, into the locked position.
4. Install the top cover (see “Replacing the top cover” on page 107).


Removing a DIMM:

This topic provides instructions for how to remove a DIMM.

About this task

DIMMs must be installed in pairs of the same type and speed. To use the memory-mirroring feature, all the DIMMs that are installed in the server must be of the same type and speed, and the operating system must support memory mirroring.

To remove a DIMM, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary.
3. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
4. Remove the memory card (see “Removing a memory card” on page 136).
5. Place the memory card on a flat, static-protective surface, with the DIMM connectors facing up.
Attention: To avoid breaking the DIMM retaining clips or damaging the DIMM connectors, open and close the clips gently.
6. Open the retaining clip simultaneously on each end of the DIMM connector and remove the DIMM from the connector.
7. If you are instructed to return the DIMM, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a DIMM:


This topic provides instructions for how to install the replacement DIMM.

About this task

To install the replacement DIMM, complete the following steps:

Procedure

1. Open the retaining clip on each end of the DIMM connector.
2. Touch the static-protective package that contains the DIMM to any unpainted metal surface on the server. Then, remove the DIMM from the package.
3. Turn the DIMM so that the DIMM keys align correctly with the connector.



4. Insert the DIMM into the connector by aligning the edges of the DIMM with the slots at the ends of the DIMM connector. Firmly press both ends of the DIMM straight down into the connector. The retaining clips snap into the locked position when the DIMM is seated in the connector.

Note: If there is a gap between the DIMM and the retaining clips, the DIMM has not been correctly inserted; open the retaining clips, remove the DIMM, and then reinsert it.

5. Reinstall the memory card (see “Replacing a memory card” on page 137).
6. Install the top cover (see “Replacing the top cover” on page 107).
7. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
8. Turn on all attached devices and the server.

Removing and replacing Tier 2 CRUs

This topic provides general information about removing and replacing Tier 2 CRUs

You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service that is designated for your server.

The illustrations in this document might differ slightly from your hardware.

Removing the internal flash memory


This topic provides instructions for how to remove the internal flash memory (or hypervisor key).

About this task

To remove the internal flash memory (or hypervisor key), complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Disconnect the power cable and remove the power supply that is closest to the flash drive you plan to replace.
3. Reach through the empty power-supply bay and locate the internal flash memory. Push the locking collar on the connector down to the unlocked position.



4. Lift the internal flash memory out of the connector.

5. If you are instructed to return the internal flash memory, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the internal flash memory

This topic provides instructions for how to install the replacement internal flash memory (or hypervisor key).

About this task

To install the replacement internal flash memory (or hypervisor key), complete the following steps:

Procedure


1. Reach through the power-supply bay and insert the internal flash memory into the connector.
2. Pull up on the locking collar to lock the internal flash memory in place.
3. Reinstall the power supply (see “Replacing the hot-swap power supply” on page 127) and reconnect the power cable.

Removing the front USB assembly

This topic provides instructions for how to remove the front USB assembly.

About this task

To remove the front USB assembly, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).

4. Remove the top cover bracket (see “Removing the top-cover bracket” on page 107).
5. Remove the middle fan (see “Removing the middle hot-swap fan” on page 122).
6. Remove the memory cards and memory card fillers (see “Removing a memory card” on page 136).
7. Disconnect the SAS cables from the RAID card controller.
8. Remove the RAID card controller (see “Removing the RAID adapter carrier and the RAID adapter assembly” on page 146).
9. Remove the memory-card cage (see “Removing the memory-card cage” on page 175).
10. Press on the release latches on the front side of the USB mounting bracket and push the mounting bracket into the server.
11. Pull the USB assembly through the opening and remove it from the server.
12. If you are instructed to return the front USB assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the front USB assembly

This topic provides instructions for replacing the front USB assembly.

About this task

To install the replacement front USB assembly, complete the following steps:

Procedure


1. Insert the USB assembly into the opening from inside the server and push it in until it clicks into place.
2. Route the USB assembly cable under the hard disk drive backplane to the outside of the RAID PCI Express connector.
3. Install the memory-card cage assembly (see “Replacing the memory-card cage” on page 176).
4. Connect the SAS cables to the RAID card controller.
5. Install the RAID card controller (“Replacing the RAID adapter carrier and the RAID adapter assembly” on page 149).
6. Install the middle fan (see “Replacing the middle hot-swap fan” on page 123).
7. Install the memory cards and memory card fillers (see “Replacing a memory card” on page 137).
8. Install the top cover bracket (see “Replacing the top-cover bracket” on page 108).
9. Install the top cover (see “Replacing the top cover” on page 107) and the front bezel (see “Replacing the front bezel” on page 109).
10. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
11. Turn on all attached devices and the server.

Removing the I/O-board shuttle

This topic provides instructions for how to remove the rear I/O-board shuttle.

About this task

To remove the rear I/O-board shuttle, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see “Removing the top cover” on page 106).
4. Remove the top cover bracket (see “Removing the top-cover bracket” on page 107).
5. Remove any installed adapters (see “Removing an adapter” on page 110).
6. Remove the power supplies or power-supply fillers from the rear of the server (see “Removing a hot-swap power supply” on page 123).
7. Pull out the blue release pin to unlatch the shuttle, and then rotate the shuttle handle up.
8. Disconnect the front USB cable and the DVD signal cable from the connectors on the shuttle.
9. Pull up on the handle to remove the I/O-board shuttle assembly from the server and place it on a clean, flat surface to avoid damage to the connectors on the underside of the board.
10. If you are instructed to return the I/O-board shuttle, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the I/O-board shuttle


This topic provides instructions for how to install the replacement rear I/O-board shuttle.

About this task

To install the replacement rear I/O-board shuttle, complete the following steps:

Procedure

1. Align the I/O-board shuttle over the server so that the pins on the side of the chassis can slide into the slots on the side of the server.



2. Carefully lower the shuttle into the chassis, leaving the handle in the vertical position.
3. Thread the USB and DVD drive cables into the shuttle.
4. Connect the USB cable and the optical drive cable to the connectors on the I/O shuttle.
5. Rotate the handle to the closed and locked position until the pin locks into the handle.
6. Reinstall the power supplies and power supply filler (see "Replacing the hot-swap power supply" on page 127).
7. Reinstall the adapters (see "Replacing an adapter" on page 111).
8. Reinstall the top cover bracket (see "Replacing the top-cover bracket" on page 108).
9. Install the top cover (see "Replacing the top cover" on page 107).
10. Connect the power cords and external cables (see "Connecting the cables" on page 104 for cabling instructions).
11. Turn on all attached devices and the server.

12. Restore the RAID configuration information that you backed up before you removed the I/O-board shuttle.


Removing the DVD cable

About this task

To remove the DVD cable, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the front bezel (see “Removing the front bezel” on page 108).
4. Push in the release button on the DVD drive and pull the drive out of the server.
5. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
6. Remove the top cover bracket (see “Removing the top-cover bracket” on page 107).
7. Remove the middle fan (see “Removing the middle hot-swap fan” on page 122).
8. Disconnect the SAS cables and remove the ServeRAID card from the dedicated PCI connector (see “Removing the RAID adapter carrier and the RAID adapter assembly” on page 146).
9. Remove the memory cards and memory card fillers (see “Removing a memory card” on page 136).
10. Remove the memory cage (see “Removing the memory-card cage” on page 175).
11. Disconnect the cable from the rear of the DVD housing.



12. Disconnect the cables from the I/O board.
13. Remove the cables from the server.

Replacing the DVD cable

This topic provides instructions for how to install the replacement DVD cable.

About this task

To install the replacement DVD cable, complete the following steps:

Procedure

1. Route the DVD cable in the server and connect it to the I/O board; then, connect the other end of the cable to the rear of the DVD housing (see “Internal cable routing and connectors” on page 101).
2. Install the memory-card cage (see “Replacing the memory-card cage” on page 176).
3. Install the RAID adapter and connect the SAS cable to the RAID adapter (see “Replacing the RAID adapter carrier and the RAID adapter assembly” on page 149).
4. Install the memory cards and memory card fillers (see “Replacing a memory card” on page 137).
5. Install the middle fan (see “Replacing the middle hot-swap fan” on page 123).
6. Install the top cover bracket (see “Replacing the top-cover bracket” on page 108).
7. Install the server top cover (see “Replacing the top cover” on page 107).
8. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
9. Turn on all attached devices and the server.

Removing the RAID adapter carrier and the RAID adapter assembly


This topic provides instructions for how to remove the RAID adapter carrier and RAID adapter assembly.

About this task

Important: Before you remove the RAID adapter carrier and the RAID adapter assembly from the server, take the following precautions to save data, firmware, and configuration data:


- Before you make changes to disk drives, disk drive controllers (including controllers that are integrated on the system board), disk drive backplanes, or disk drive cables, back up all important data that is stored on hard disks.
- Before you remove any component of a RAID array, back up all RAID configuration information.

To remove the RAID adapter carrier and RAID adapter assembly, complete the following steps.




Procedure

1. Read the safety information that begins with "Safety" on page v, "Installation guidelines" on page 97, and "Handling static-sensitive devices" on page 100.
2. Save the system configuration.
3. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
4. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).
5. Remove the top cover bracket (see "Removing the top-cover bracket" on page 107).
6. Pull the blue handle on the RAID adapter carrier up to remove it from the server.
7. Disconnect the SAS cables from the RAID adapter.
8. Press the release latch and remove the RAID adapter from the carrier.



9. If a battery is installed on the RAID adapter, remove the battery carrier card and the battery from the RAID adapter. You must remove the three screws to separate them.



10. If you are instructed to return the RAID adapter assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the RAID adapter carrier and the RAID adapter assembly


This topic provides steps to replace the RAID adapter carrier and RAID adapter assembly.

About this task

To replace the RAID adapter carrier and RAID adapter assembly, complete the following steps:

Procedure


1. If you removed a battery carrier and battery from the former RAID adapter, use the three screws and install it on the new RAID adapter.
2. Install the replacement RAID adapter onto the RAID adapter carrier.




3. Connect the SAS cables to the RAID adapter.

Note: Attach the SAS cable from port 0 to the lower backplane and the SAS cable from port 1 to the upper backplane (if one is installed).


ServeRAID M5015 controller



ServeRAID BR10i controller



4. Slide the RAID adapter carrier and RAID adapter assembly into the slot on the side of the server. Make sure that the carrier is flat against the side wall of the server so that the adapter is installed in the connector correctly.



5. Install the top cover bracket (see "Replacing the top-cover bracket" on page 108).
6. Install the top cover (see "Replacing the top cover" on page 107).
7. Connect the cables and power cords (see "Connecting the cables" on page 104 for cabling instructions).
8. Turn on all attached devices and the server.
9. Restore the RAID configuration information that you backed up before you removed the RAID card carrier and the RAID card assembly.

Removing the hard disk drive backplane and cable assembly


This topic provides instructions for how to remove the hard disk drive backplane cable assembly.

About this task

Important: Before you remove the hard disk drive backplane cable assembly from the server, take the following precautions to save data, firmware, and configuration data:

- Before you make changes to disk drives, disk drive controllers (including controllers that are integrated on the system board), disk drive backplanes, or disk drive cables, back up all important data that is stored on hard disks.
- Before you remove any component of a RAID array, back up all RAID configuration information.

To remove the hard disk drive backplane cable assembly, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
4. Pull the hard disk drives and fillers out of the server slightly to disengage them from the SAS backplane. If you remove the drives from the server, be sure to note the location of each drive so that you will be able to reinstall it in the correct drive bay.
5. Slide the latch on top of the backplane assembly while you pull the blue handle on the backplane cable assembly up to remove it from the server. The cables are attached to the assembly.
6. Disconnect the power and configuration cables from the hard disk drive backplane.
7. If you are instructed to return the hard disk drive backplane cable assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the hard disk drive backplane and cable assembly

This topic provides instructions for how to replace the hard disk drive backplane cable assembly.

About this task

To replace the hard disk drive backplane cable assembly, complete the following steps.

Procedure

1. Connect the power and configuration cables to the cable connectors on the backplane.
2. Slide the backplane and cable assembly into the server behind the hard disk drive bays.
3. Install the top cover (see “Replacing the top cover” on page 107).
4. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
5. Reinstall the hard disk drives and hard disk drive fillers into the server (see “Replacing a hot-swap hard disk drive” on page 118).
6. Turn on all attached devices and the server.
7. Restore the RAID configuration information that you backed up before you removed the hard disk drive backplane cable assembly.

Removing the SAS hard disk drive backplane assembly


This topic provides instructions for how to remove the SAS hard disk drive backplane assembly.

About this task

Important: Before you remove the SAS hard disk drive backplane assembly from the server, take the following precautions to save data, firmware, and configuration data:


- Before you make changes to disk drives, disk drive controllers (including controllers that are integrated on the system board), disk drive backplanes, or disk drive cables, back up all important data that is stored on hard disks.
- Before you remove any component of a RAID array, back up all RAID configuration information.

To remove the SAS hard disk drive backplane assembly, complete the following steps.



Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).
4. Pull the hard disk drives and fillers out of the server slightly to disengage them from the SAS backplane. If you remove the drives from the server, be sure to note the location of each drive so that you will be able to reinstall it in the correct drive bay.
5. Push the release tab toward the rear of the server to release the assembly; then, pull the assembly up from the server. At the same time, pull the power and configuration cables (hard disk drive backplane cable assembly) out of the server.
6. Disconnect the SAS signal cable and SAS power and configuration cables from the backplane.
7. Push the latches on the backplane carrier outward to disengage and remove the backplane from the carrier.



8. If you are instructed to return the SAS hard disk drive backplane assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the SAS hard disk drive backplane assembly

This topic provides instructions for how to install the replacement SAS hard disk drive backplane assembly.

About this task

To install the replacement SAS hard disk drive backplane assembly, complete the following steps:

Procedure

1. Install the backplane onto the carrier.
 - a. Line up the notch on the backplane with the bottom-right corner of the carrier.
 - b. Push the backplane onto the carrier until it snaps into place.
2. Slide the assembly into the card guides and pull the release tab toward the front of the server to engage the assembly.
3. Reconnect the SAS signal cable and SAS power cable to the backplane.
4. Slide the hard disk drive backplane cable assembly into the server.
5. Reinstall the hard disk drives and drive fillers.
6. Install the top cover (see “Replacing the top cover” on page 107).
7. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
8. Turn on all attached devices and the server.
9. Restore the RAID configuration information that you backed up before you removed the hard disk drive backplane.


Removing the eXFlash 1.8-inch drive cage and backplane assembly

This topic provides instructions to remove the eXFlash drive backplane assembly.

About this task

Important: Before you remove the eXFlash 1.8-inch backplane assembly from the server, take the following precautions to save data, firmware, and configuration data:

- Before you make changes to disk drives, disk drive controllers (including controllers that are integrated on the system board), disk drive backplanes, or disk drive cables, back up all important data that is stored on hard disks.
- Before you remove any component of a RAID array, back up all RAID configuration information.




To remove the eXFlash drive backplane assembly, complete the following steps.


Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).
4. Remove the filler panel.


5. Pull the drives out of the cage assembly and install them in the same positions in the new cage assembly.




6. If you have 2.5-inch hard disk drives installed below the 1.8-inch cage, pull the drives and fillers out of the server.



- Slide the backplane retention release tab forward and slightly lift the hard disk drive backplane carrier to disconnect the cables from the rear of the 1.8-inch backplane and cage assembly.



- Disconnect the signal cable and power and configuration cables from the backplane.
- Slide the backplane retention release tab forward and pull the solid state drive backplane cage assembly out of the server.



- If you are instructed to return the solid state drive backplane cage assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the eXFlash 1.8-inch drive cage and backplane assembly


This topic provides instructions for how to replace the eXFlash 1.8-inch drive cage and backplane assembly.

About this task

To install the replacement eXFlash drive cage and backplane, complete the following steps:

Procedure

1. Slide the assembly into the front of the server until it clicks into place.
2. Slide the backplane cable assembly into the server.
3. If you have 2.5-inch hard disk drives installed below the 1.8-inch cage, slightly pull the drives and fillers out from the server, slide the backplane retention release tab forward, and slightly lift up the hard disk drive backplane carrier to reconnect the power, signal, and configuration cables to the backplane.
4. Reinstall the solid state drives.



5. Install the drive filler panel over the drives.
6. Install the top cover (see "Replacing the top cover" on page 107).
7. Connect the cables and power cords (see "Connecting the cables" on page 104 for cabling instructions).
8. Turn on all attached devices and the server.
9. Restore the RAID configuration information that you backed up before you removed the hard disk drive backplane.

Removing and replacing FRUs

This topic provides information about FRUs.

About this task

FRUs must be installed only by trained service technicians.

Microprocessor


This topic provides notes that describe the types of microprocessor that the server supports and other information that you must consider when you replace a microprocessor.

About this task

The following notes describe the type of microprocessor that the server supports and other information that you must consider when you replace a microprocessor:

- The optional microprocessors that IBM supports are limited by the capacity and capability of the server. Any microprocessors that you install must have the same specifications as the microprocessors that came with the server.
- For a list of supported optional devices for the server, see .
- The server supports up to four Intel Xeon microprocessors. If you are installing two or more microprocessors, they must be the same cache size and type, and the same clock speed. The server does not support mixing types of microprocessors.
- If you are using a two-microprocessor configuration, you must install the microprocessors in sockets 1 and 4 for PCI Express slots 1 - 4 to be functional.
- The server can operate as a symmetric multiprocessing (SMP) server. With SMP, certain operating systems and application programs can distribute the processing load among the microprocessors. This enhances performance for database and point-of-sale applications, integrated manufacturing solutions, and other applications.
- Read the documentation that comes with the microprocessor to determine whether you have to update the UEFI firmware. To download the most current level of server firmware, go to .
- Obtain an SMP-capable operating system. For a list of supported operating systems, see .
- You can use the Setup utility to determine the specific type of microprocessor in the server.
- Each microprocessor socket must always contain either a heat-sink blank or a microprocessor and heat sink.

The following illustration of the microprocessor board shows the locations of the microprocessor sockets.



Removing a microprocessor and heat sink:


This topic provides instructions for how to remove a microprocessor and heat sink.

About this task

Microprocessors are to be removed only by trained service technicians.

Attention:


- Do not allow the thermal grease on the microprocessor and heat sink to come in contact with anything. Contact with any surface can compromise the thermal grease and the microprocessor socket.
- Dropping the microprocessor during installation or removal can damage the contacts.
- Do not touch the microprocessor contacts; handle the microprocessor by the edges only. Contaminants on the microprocessor contacts, such as oil from your skin, can cause connection failures between the contacts and the socket.
- Use the microprocessor installation tool that comes with the new microprocessor to remove and install the microprocessor from the server.




To remove a microprocessor and heat sink, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v, "Handling static-sensitive devices" on page 100, and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices and disconnect the power cord and all external cables.
3. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).
4. Remove the top cover bracket (see "Removing the top-cover bracket" on page 107).
5. Rotate the heat-sink release lever **1** to the fully open position.




6. Lift the heat sink **2** out of the server. If the heat sink sticks to the microprocessor, slightly twist the heat sink back and forth to break the seal. After removal, place the heat sink on its side on a clean, flat surface.
7. Open the microprocessor release latch **1** by pressing down on the end, moving it to the side, and releasing it in the open (up) position. Swing open the microprocessor load plate **2**.




8. Place the microprocessor installation tool (which comes with the new microprocessor) down over the microprocessor **1**, aligning the holes on the tool with the screws on the microprocessor bracket. Twist the handle clockwise **2** to lock the microprocessor in the tool.


Note: The microprocessor installation tool is recessed to prevent damage to the microprocessor grease.



Note: If you are removing E7 series microprocessors, you must use the microprocessor installation tool with the text “X7500 + E7” on the bottom of the tool (see the following illustration). Tools that do not have this text on the bottom will not work correctly with the E7 series microprocessors.



9. Carefully lift the microprocessor straight up and out of the socket, and then turn the tool upside down so that the microprocessor is facing up. Twist the tool handle counterclockwise to unlock the microprocessor, and then lift the microprocessor out of the tool.



10. If you are instructed to return the microprocessor, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Installing a microprocessor and heat sink:

This topic provides instructions and guidelines for installing a microprocessor and heat sink.

About this task

For important information about the type of microprocessors that the server supports, microprocessor population order and how it affects server performance and operation, and other information that you must consider when you install a microprocessor, see the *Installation and User's Guide* on the IBM Documentation CD.

Read the documentation that comes with the microprocessor to determine whether you must update the UEFI firmware. To download the most current level of server firmware, go to .


Results

Important:

- A startup (boot) microprocessor must always be installed in microprocessor socket 1 on the microprocessor board.
- To ensure correct server operation, be sure to use microprocessors that are compatible and install a memory card and an additional DIMM for microprocessor 2. Compatible microprocessors must have the same QuickPath Interconnect (QPI) link speed, integrated memory controller frequency, core frequency, power segment, cache size, and type.
- Do not mix Intel Xeon EX versions of the 6000 and 7000 Series microprocessors and the E7 Series microprocessors in the same server, it is not supported. In addition:
 - Intel Xeon versions of the 6000 and 7000 Series microprocessors are supported only on machine types 7145 and 7146.
 - Intel Xeon EX E7 Series microprocessors are supported only on machine types 7143 and 7191.
- Microprocessors with different stepping levels are supported in this server. If you install microprocessors with different stepping levels, it does not matter which microprocessor is installed in microprocessor socket 1 or socket 2.
- If you are installing a microprocessor that has been removed, make sure that it is paired with its original heat sink or a new replacement heat sink. Do not reuse a heat sink from another microprocessor; the thermal grease distribution might be different and might affect conductivity.
- If you are installing a new heat sink, remove the protective backing from the thermal material that is on the underside of the new heat sink.
- If you are installing a new heat-sink assembly that did not come with thermal grease, see “Thermal grease” on page 170 for instructions for applying thermal grease; then, continue with step “Installing a microprocessor and heat sink” on page 165 of this procedure.
- If you are installing a heat sink that has contaminated thermal grease, see “Thermal grease” on page 170 for instructions for replacing the thermal grease; then, continue with step “Installing a microprocessor and heat sink” on page 165 of the following procedure.

To install a new or replacement microprocessor, complete the following steps:


1. The microprocessor is shipped in a static-protective package and foam. Remove the static-protective package and foam from the shipping carton and remove the foam from around the static-protective package.
2. Touch the static-protective package that contains the microprocessor to any unpainted metal surface on the server. Then, remove the microprocessor from the package.
3. If there is a plastic protective cover on the bottom of the microprocessor, carefully remove it.



4. Place the microprocessor, with the contacts facing down, on the foam pad in the shipping carton.
5. Open the microprocessor release latch **1** by pressing down on the end, moving it to the side, and releasing it to the open (up) position. Swing open the microprocessor retainer bracket **2**.


Attention:

- Handle the microprocessor carefully. Dropping the microprocessor during installation or removal can damage the contacts.
- Do not touch the microprocessor contact; handle the microprocessor with the tool only. Contaminants on the microprocessor contacts, such as oil from your skin, can cause connection failures between the contacts and the socket.
- Do not use excessive force when you press the microprocessor into the socket.
- Make sure that the microprocessor is oriented and aligned and positioned in the socket before you try to close the lever.




6. Install the replacement microprocessor into the microprocessor installation tool:
 - a. Touch the static-protective package that contains the new microprocessor to any unpainted metal surface on the outside of the server.
 - b. Twist the handle of the installation tool counterclockwise so that it is in the open position.

Note: If you are installing E7 series microprocessors in your server, you must use the microprocessor installation tool with the text "X7500 + E7" on the bottom of the tool (see the following illustration). Tools that do not have this text on the bottom will not work correctly with the E7 series microprocessors




- c. Using the triangle on the microprocessor to align it with the installation tool, place the microprocessor on the underside of the tool.
- d. Twist the handle of the installation tool clockwise to secure the microprocessor in the tool.

Note: You can pick up or release the microprocessor by twisting the microprocessor installation tool handle clockwise.



7. Carefully position the microprocessor with the microprocessor tool over the microprocessor socket. Twist the microprocessor installation tool counterclockwise to insert the microprocessor into the socket.


Note: The microprocessor fits only one way in the socket.



8. Close the load plate and then rotate the microprocessor-release latch to secure the microprocessor.
9. Remove the heat sink from its package.
10. Install the heat sink.

Attention: Do not touch the thermal grease on the bottom of the heat sink or set down the heat sink after you remove the plastic cover. Touching the thermal grease will contaminate it.

- a. Make sure that the heat-sink release lever **1** is in the fully open position.
- b. Remove the plastic protective cover from the bottom of the heat sink.



- c. Position the heat sink above the microprocessor with the thermal grease side down, and align the clips of the heat sink with the tabs next to the microprocessor socket.
 - d. Press down firmly on the heat sink **2** until it is seated securely.
 - e. Rotate the heat-sink release lever **3** to the closed and locked position.
11. Replace the top cover bracket (see "Replacing the top-cover bracket" on page 108).

12. Install the top cover (see “Replacing the top cover” on page 107).
13. Slide the server into the rack.
14. Reconnect the external cables; then, reconnect the power cords and turn on the peripheral devices and the server.

Thermal grease:

This topic provides instructions for how to replace damaged or contaminated thermal grease on the microprocessor and heat sink.


The thermal grease must be replaced whenever debris is found in the grease.

To replace damaged or contaminated thermal grease on the microprocessor and heat sink, complete the following steps:


1. Place the heat sink on a clean work surface.
2. Remove the alcohol wipe from its package and unfold it completely.
3. Use the alcohol wipe to clean the thermal grease from the bottom of the heat sink.

Note: Make sure that all of the thermal grease is removed.

4. Use a clean area of the alcohol wipe to clean the thermal grease from the microprocessor; then, dispose of the alcohol wipe after all of the thermal grease is removed.



5. Use the thermal-grease syringe to place 9 uniformly spaced dots of 0.02 mL each on the top of the microprocessor. The outermost dots must be within 5 mm of the edge.



Note: 0.01 mL is one tick mark on the syringe. If the grease is properly applied, approximately half of the grease will remain in the syringe.

6. Install the heat sink onto the microprocessor as described in “Installing a microprocessor and heat sink” on page 165.

Removing the microprocessor-board assembly


This topic provides instructions for how to remove the microprocessor-board assembly.

About this task

Important: This procedure is to be performed only by trained service technicians. Before you remove the microprocessor-board assembly from the server, take the following precautions to save data, firmware, and configuration data:

- Record all system configuration information, such as IMM IP addresses, vital product data, and the machine type, model number, and serial number of the server.
- Using the IBM Advanced Settings Utility (ASU), save the system configuration to external media.
- Save the system-event log to external media.
- Before you attach a memory expansion module to the server and try to use it, you must update the UEFI firmware with the latest level of firmware code. If you attach and try to use the memory expansion module without updating the UEFI firmware, you might get unexpected system behavior, or the server might not power on. For special instructions to follow before you attach the memory expansion module to the server, go to .

To remove the microprocessor-board assembly, complete the following steps.




Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.


3. Remove the top cover (see "Removing and replacing consumable parts and Tier 1 CRUs" on page 105).
4. Remove the top-cover bracket (see "Removing the top-cover bracket" on page 107).
5. Remove the power supplies (see "Removing a hot-swap power supply" on page 123).
6. Remove the I/O-board shuttle from the microprocessor-board assembly (see "Removing the I/O-board shuttle" on page 143).
7. Remove the memory cards and memory-card fillers (see "Removing the I/O-board shuttle" on page 143).
8. Disconnect the signal cables from the ServeRAID adapter and remove the adapter from the server (see "Removing the RAID adapter carrier and the RAID adapter assembly" on page 146).
9. Remove the middle fan (see "Removing the middle hot-swap fan" on page 122).
10. Remove the memory-card cage (see "Removing the memory-card cage" on page 175).
11. Disconnect the following cables: front fan, scalability LED, operator information panel, hard disk drive backplane, and CD/DVD power.
12. If you have a single-node server without a memory expansion module attached, remove the QPI wrap cards or fillers (see "Removing a QPI wrap card" on page 127). If you have a two-node server or a server that is connected to a memory expansion module, disconnect the QPI cables from each end and set them aside in a safe place. Be sure to protect the ends of the QPI cables.
13. (Trained service technician only) Remove the microprocessors (see "Removing a microprocessor and heat sink" on page 161).
14. Loosen the thumbscrews on the rear of the server. If you have a two-node server, you might have four thumbscrews on the rear of the server. One thumbscrew is used to connect the two-node bracket.
15. Slide the assembly slightly toward the front of the server; then, using the microprocessor-board handle on the left side, lift the assembly out at an angle.
16. Remove the microprocessor socket covers from the new microprocessor-board assembly and set them aside.
17. Remove microprocessors from the sockets of the old microprocessor board and install them into the sockets on the new board using the microprocessor installation tool.

Note:

- a. If you are removing E7 series microprocessors, you must use the microprocessor installation tool with the text "X7500 + E7" on the bottom of the tool (see the following illustration). Tools that do not have this text on the bottom will not work correctly with the E7 series microprocessors.
- b. Be sure to keep the heat sink and microprocessor from each microprocessor socket of the old microprocessor board together so that you can install them on the new microprocessor board together. For example, when you remove the heat sink and microprocessor from microprocessor socket 1 of the old microprocessor board, install them both on the same socket on the new microprocessor board.
- c. Use an alcohol wipe to remove any thermal grease from the tabs on the microprocessor load plate on the old microprocessor board.



I



18. Install microprocessor socket covers on the empty microprocessor sockets on the old microprocessor board before you pack the board for shipping.
19. If you are instructed to return the microprocessor-board assembly, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the microprocessor-board assembly

About this task

To install the replacement microprocessor-board assembly, complete the following steps:

Procedure

1. Before you attach a memory expansion module to the server and try to use it, you must update the UEFI firmware with the latest level of firmware code. If you attach and try to use the memory expansion module without updating the UEFI firmware, you might get unexpected system behavior, or the server might not power on. For special instructions to follow before you attach the memory expansion module to the server, go to .
2. Insert the microprocessor-board assembly in the server at an angle; then, slide the assembly toward the back of the server. Make sure that all the cables are clear of the assembly as you install it in the server.
3. Tighten the thumbscrews on the rear of the server. The second hole from the left side, rear view is for mounting the two-node lock bracket when you add a second two-node system attachment. If you have a two-node server, reinstall this lock bracket.


4. If you have a single-node server without a memory expansion module attached, install the QPI wrap cards or fillers. If you have a two-node server or if your server is connected to a memory expansion module, reconnect the QPI cables.
5. Connect the following cables: front fan, scalability LED, operator information panel, hard disk drive backplane, and CD/DVD power.
6. Route the front USB and DVD/CD signal cables behind the hard disk drive backplane and to the side of the ServeRAID adapter connector (see “Internal cable routing and connectors” on page 101).
7. (Trained service technician only) Reinstall the microprocessors (see “Installing a microprocessor and heat sink” on page 165).
8. Install the memory-card cage (see “Replacing the memory-card cage” on page 176). Make sure that all the cables are clear of the cage as you install it in the server.
9. Install the middle fan (see “Replacing the middle hot-swap fan” on page 123).
10. Connect the signal cables to the ServeRAID adapter and install the adapter in the server (see “Replacing the RAID adapter carrier and the RAID adapter assembly” on page 149).
11. Install the memory cards and memory-card fillers (see “Replacing a memory card” on page 137).
12. Install the I/O-board shuttle (see “Replacing the I/O-board shuttle” on page 144). Be sure to thread the USB and DVD/CD signal cables through the server and connect them to the I/O-board shuttle.
13. Install the top cover bracket (see “Replacing the top-cover bracket” on page 108).
14. Install the power supplies (see “Replacing the hot-swap power supply” on page 127).
15. Install the top cover (see “Replacing the top cover” on page 107).
16. Connect the cables and power cords (see “Connecting the cables” on page 104 for cabling instructions).
17. Turn on all attached devices and the server.
18. Using the Advanced Settings Utility (ASU), restore the system configuration, such as the IMM IP addresses, vital product data, and the machine type, model number, and serial number of the server.
19. Using the ASU, restore the system configuration to the new microprocessor board.

Removing the memory-card cage

This topic provides instructions for how to remove the memory-card cage.

About this task

To remove the memory-card cage, complete the following steps.



Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables as necessary to replace the device.
3. Remove the top cover (see “Removing and replacing consumable parts and Tier 1 CRUs” on page 105).
4. Remove the top cover bracket (see “Removing the top-cover bracket” on page 107).
5. Remove the memory cards and memory card fillers (see “Removing a memory card” on page 136).
6. Remove the middle fan (see “Removing the middle hot-swap fan” on page 122).
7. Disconnect the SAS cables from the ServeRAID adapter.
8. Remove the ServeRAID adapter (see “Removing the RAID adapter carrier and the RAID adapter assembly” on page 146).
9. Slide the locking latches to the unlocked positions.
10. Loosen the two thumbscrews.
11. Pull the cage out of the server.
12. If you are instructed to return the memory-card shuttle, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the memory-card cage

About this task

To replace the memory-card cage, complete the following steps:

Procedure

1. Move any cables out of the way and then set the replacement memory card cage into the server.
2. Tighten the two thumbscrews.
3. Slide the locking latches to the locked positions.
4. Install the memory cards and memory card fillers (see “Replacing a memory card” on page 137).
5. Install the middle fan (see “Replacing the middle hot-swap fan” on page 123).
6. Connect the SAS cables to the ServeRAID adapter.
7. Install the ServeRAID adapter (see “Replacing the RAID adapter carrier and the RAID adapter assembly” on page 149).
8. Reinstall the top cover bracket (see “Replacing the top-cover bracket” on page 108).
9. Reinstall the top cover (see “Replacing the top cover” on page 107).
10. Connect the power cords and external cables (see “Connecting the cables” on page 104 for cabling instructions).
11. Turn on all attached devices and the server.

Removing and replacing the memory expansion module components

This topic provides information about removing and replacing the memory expansion module components.

The following sections provide information about removing and replacing components in the optional IBM MAX5 for System x memory expansion module.

Removing and replacing memory expansion module Tier 1 CRUs

This topic provides general information about removing and replacing memory expansion module Tier 1 CRUs.

Replacement of Tier 1 CRUs is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation.

The illustrations in this document might differ slightly from your hardware.

Removing the memory expansion module bezel

This topic provides instructions for how to remove the memory expansion module bezel.


About this task

To remove the memory expansion module bezel, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.

2. Press in on the release tabs on both ends of the bezel and pull it off of the chassis.




Replacing the memory expansion module bezel

About this task

To replace the memory expansion module bezel, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Align the bezel alignment tabs with the chassis and press the bezel onto the chassis until it snaps into place.



Removing the memory expansion module air baffle


This topic provides instructions for how to remove the air baffle in the memory expansion module.

About this task

To remove the air baffle in the memory expansion module, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the host server (see “Turning off the server” on page 21) and all attached peripheral devices. Disconnect all power cords from the memory expansion module; then, disconnect all external cables from the memory expansion module as necessary to replace the device.
3. Remove the bezel (see “Removing the memory expansion module bezel” on page 177).
4. Remove the system-board tray (see “Removing the memory expansion module system-board tray assembly” on page 197).
5. Press the air baffle release tab in and lift the air baffle out of the slot on the system-board tray wall (near the rear of DIMM 1) to release it; then, push the air baffle forward slightly to unhook it from the system board and set it aside.



Replacing the memory expansion module air baffle


This topic provides instructions for how to replace the memory expansion module air baffle.

About this task

To replace the memory expansion module air baffle, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Align the air baffle next to DIMM 1 and hook the hinge on the air baffle underneath the system board; then, insert the tab on the other end of the air baffle into the tab slot on the system-board wall until it is firmly in place.



3. Replace the system-board tray (see "Removing the memory expansion module system-board tray assembly" on page 197).
4. Reinstall the bezel (see "Replacing the memory expansion module bezel" on page 178).

Removing the memory expansion module information panel assembly


This topic provides instructions for how to remove the memory expansion module information panel assembly.

About this task


To remove the information panel assembly, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the host server (see "Turning off the server" on page 21) and all attached peripheral devices. Disconnect all power cords from the memory expansion module; then, disconnect all external cables from the memory expansion module as necessary to replace the device.
3. Remove the bezel (see "Removing the memory expansion module bezel" on page 177).
4. Grasp the blue release latches on the system-board tray handles and pull the latches in opposite directions; then, rotate the handles to the open position.



5. Grasp the handles and pull the system-board tray out until it stops.
6. Disconnect the information panel assembly cable from the connector on the system board tray.
7. Press the information panel release tab to the left and hold it while you pull the right side of the information panel assembly out of the slot on the system-board tray.



8. Grasp the left side of the information panel assembly and pull the tab out of the hole on the system-board tray and remove the assembly from the tray.
9. If you are instructed to return the information panel, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the memory expansion module information panel assembly


This topic provides instructions for how to replace the memory expansion module information panel assembly.

About this task


To replace the memory expansion module information panel assembly, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. From the front of the memory expansion module system-board tray, insert the cable end of the information panel assembly through the information panel slot.
3. Insert the tab on the left side of the information panel assembly into the hole on the system-board tray and hold the information panel assembly release latch while you rotate the right side of the assembly toward the system-board tray.



4. Push the information panel assembly release latch in firmly to snap the release latch into place and secure the information panel assembly.
5. Connect the information panel assembly cable to the connector on the system board.
6. Slide the system-board tray forward until the tabs at the bottom of the handles touch the chassis; then, close the release latches firmly (they will snap into the locked position).



7. Reinstall the bezel (see “Replacing the memory expansion module bezel” on page 178).
8. Reconnect the power cords to the memory expansion module; then, connect all external cables to the memory expansion module.
9. Turn on the peripheral devices and the host server.

Removing a memory expansion module hot-swap fan


This topic provides instructions for how to remove a hot-swap fan from the memory expansion module.

About this task

To remove a hot-swap fan from the memory expansion module, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Remove the bezel (see “Removing the memory expansion module bezel” on page 177).
3. Squeeze both fan latches on the fan toward each other and slide the fan out of the slot.



4. If you are instructed to return the fan, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a memory expansion module hot-swap fan


This topic provides instructions for how to replace a hot-swap fan in the memory expansion module.

About this task

To replace a hot-swap fan in the memory expansion module, complete the following steps:

Procedure

1. Align the new fan with the slot in the fan cage.
2. Slide the fan into the fan slot until it snaps into the connector firmly.



3. Reinstall the bezel (see “Replacing the memory expansion module bezel” on page 178).

Removing a memory expansion module DIMM


This topic provides instructions for how to remove a DIMM from the memory expansion module.

About this task

To remove a DIMM from the memory expansion module, complete the following steps:


Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.
2. Turn off the host server (see “Turning off the server” on page 21) and all attached peripheral devices. Disconnect all power cords from the memory expansion module; then, disconnect all external cables from the memory expansion module as necessary to replace the device.
3. Remove the bezel (see “Removing the memory expansion module bezel” on page 177).
4. Grasp the blue release tabs on the system-board tray latches and pull the latches in opposite directions to release the tray from the chassis.



5. Pull the system-board tray out until it stops; then, press the blue tabs on both sides of the system-board tray and pull the tray out of the chassis.
6. Carefully open both retaining clips on each end of the DIMM connector and remove the DIMM from the connector.

Attention: To avoid breaking the retaining clips or damaging the DIMM connectors, open and close the clips gently.



7. If you are instructed to return the DIMM, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a memory expansion module DIMM

This topic provides information about the types of DIMMs, as well as instructions for how to replace a memory expansion module DIMM.

About this task

The following notes describe the types of DIMMs that the memory expansion module supports and other information that you must consider when you install DIMMs:

- The memory expansion module supports a maximum of 32 DIMMs (single-rank, dual-rank, or quad-rank).

Note: To determine the type of a DIMM, see the label on the DIMM. The information on the label is in the format `xxxxx nRxxx PC3-xxxxx-xx-xx-xxx`. The numeral in the sixth numerical position indicates whether the DIMM is single-rank ($n=1$) or dual-rank ($n=2$).

- The DIMM options that are available for the memory expansion module are 2 GB, 4 GB, 8 GB, 16 GB, and 32 GB.
- If you install 32 GB DIMMs in the memory expansion module, all of the DIMMs must be 32 GB capacity DIMMs. You cannot mix 32 GB DIMMs with other capacity DIMMs in the system.
- The memory expansion module supports a minimum of 4 GB and a maximum of 1 TB of system memory.
- The memory expansion module supports 1.35-volt (low-voltage) and 1.5-volt DIMMs. In addition:
 - The memory expansion module supports low-voltage (1.35-volt) DIMMs at capacities of 4 GB, 8 GB, and 16 GB only.
 - When you mix 1.35-volt and 1.5-volt DIMMs in the memory expansion module, it will operate at the 1.5-volt rate.
 - You can enable all the DIMMs (1.35-volt and 1.5-volt) to operate at 1.5-volt in the Setup utility through the host server.

- Double-device data correction support is only available when 16 GB x4 DRAM technology DIMMs are installed in the memory expansion module and the memory expansion module is connected to a host server.
- The memory expansion module supports memory sparing through the host server. Memory sparing reserves memory capacity for failover in the event of a DIMM failure, and the reserved capacity is subtracted from the total available memory. When the memory sparing threshold of correctable errors is reached, the contents of the failing DIMM are copied to the spare memory, and the failing DIMM or rank is disabled. To enable memory sparing through the Setup utility, select **System Settings > Memory**.
- When you populate DIMMs in the memory expansion module, populate the larger capacity DIMMs first, then the smaller capacity DIMMs. See “Replacing a memory expansion module DIMM” on page 186 for non-mirroring mode DIMM population sequence and “Removing a memory expansion module DIMM” on page 185 for memory-mirroring mode DIMM population sequence.
- The memory expansion module provides eight memory ports (memory channels), and each memory port supports up to four DIMMs. Do not mix DIMMs with x4 technology (DIMMs with DRAMs that are organized with 4 data lanes) and x8 technology (DIMMs with DRAMs that are organized with 8 data lanes) in the same memory port. The following table shows the DIMM connectors on the eight memory ports.

Table 21. DIMM connectors on each memory port

Memory ports	DIMM connectors
1	1, 2, 7, and 8
2	3, 4, 5, and 6
3	9, 10, 15, and 16
4	11, 12, 13, and 14
5	17, 18, 23, and 24
6	19, 20, 21, and 22
7	25, 26, 31, and 32
8	27, 28, 29, and 30
Note: 2 GB, 4 GB, and 8 GB DIMMs are x4 technology DIMMs. 16 GB and 32 GB DIMMs are x8 technology DIMMs.	

- Do not mix DIMMs with 1 Gb (gigabit) DRAM technology, 2 Gb DRAM technology, or other gigabit DRAM technologies in banks of eight DIMMs on memory ports that are on the same memory controller. This is not supported in the memory expansion module. The following table lists the DIMM connectors for each bank of eight DIMMs that are on the memory ports within the same memory controller.

Table 22. DIMM connectors on memory ports with the same memory controller

Bank of DIMMs	DIMM connectors
1st bank of DIMMs	1, 2, 3, 4, 5, 6, 7, and 8
2nd bank of DIMMs	9, 10, 11, 12, 13, 14, 15, and 16
3rd bank of DIMMs	17, 18, 19, 20, 21, 22, 23, and 24
4th bank of DIMMs	25, 26, 27, 28, 29, 30, 31, and 32

- DIMMs must be installed in pairs for non-mirroring mode and in sets of four for memory-mirroring.

- A minimum of two DIMMs must be installed in the memory expansion module for each microprocessor in the host server.
- The maximum operating speed of the memory expansion module is determined by the slowest DIMM installed in the memory expansion module.
- The memory expansion module does not come with any DIMMs installed when you purchase it as a option. When you install DIMMs, install them in the order shown in the following tables to optimize system performance.
- The server supports non-mirroring mode and memory-mirroring mode.
 - **Non-mirroring mode.** When you use the non-mirroring mode, install DIMMs as indicated in the following table.

Table 23. Non-mirroring mode DIMM population sequence for the memory expansion module

Pairs of DIMMs	DIMM connector population sequence
Pair 1	28, 29
Pair 2	9, 16
Pair 3	1, 8
Pair 4	20, 21
Pair 5	26, 31
Pair 6	11, 14
Pair 7	3, 6
Pair 8	18, 23
Pair 9	27, 30
Pair 10	10, 15
Pair 11	2, 7
Pair 12	19, 22
Pair 13	25, 32
Pair 14	12, 13
Pair 15	4, 5
Pair 16	17, 24

Note: When you populate DIMMs in the memory expansion module, populate the larger capacity DIMMs first, then the smaller capacity DIMMs.

- **Memory-mirroring mode.** When you use the mirroring mode feature, consider the following information:
 - Memory-mirroring mode replicates and stores data on sets of four DIMMs simultaneously. If a failure occurs, the memory controller switches from the primary set of memory DIMMs to the backup set of DIMMs. To enable memory mirroring through the Setup utility, select **System Settings** → **Memory**. For more information, see “Configuring the server” on page 202.
 - DIMMs must be installed in sets of four. The DIMMs in each set must be the same size and type. This is applicable also when the memory expansion module is attached to a host server and the host server has an optional memory tray installed in the server. You must install DIMMs in sets of four DIMMs for memory-mirroring mode in each (server, memory tray, and the memory expansion module).
 - The maximum available memory is reduced to half of the installed memory when memory mirroring is enabled. For example, if the memory expansion

module has 64 GB of memory installed, only 32 GB of addressable memory is available when you use memory mirroring.


- The following table lists the DIMM installation sequence for memory-mirroring mode.

Table 24. Memory-mirroring mode DIMM population sequence for the memory expansion module

Sets of 4 DIMMs	DIMM connector population sequence
Set 1	9, 16, 28, 29
Set 2	1, 8, 20, 21
Set 3	11, 14, 26, 31
Set 4	3, 6, 18, 23
Set 5	10, 15, 27, 30
Set 6	2, 7, 19, 22
Set 7	12, 13, 25, 32
Set 8	4, 5, 17, 24

Note: When you populate DIMMs in the memory expansion module, populate the larger capacity DIMMs first, then the smaller capacity DIMMs.

The following illustration shows the locations of the DIMM connectors on the memory expansion module system-board tray.




To install a memory module in the memory expansion module, complete the following steps.

Note: The memory expansion module might come with DIMM fillers on DIMM connectors that are not populated. Remove them before you install DIMMs in those connectors.

Procedure

1. Touch the static-protective package that contains the new DIMM to any unpainted metal surface on the outside of the memory expansion module; then, remove the DIMM from the package.
2. Turn the DIMM so that the DIMM keys align correctly with the connector.
3. Insert the DIMM into the connector by aligning the edges of the DIMM with the slots at the ends of the DIMM connector.



4. Firmly press the DIMM straight down into the connector by applying pressure on both ends of the DIMM simultaneously. The retaining clips snap into the locked position when the DIMM is firmly seated in the connector.

Note: If there is a gap between the DIMM and the retaining clips, the DIMM has not been correctly inserted; open the retaining clips, remove the DIMM, and then reinsert it.

5. Grasp the system-board tray on both sides (near the stop-tabs) and align the system-board tray with the chassis.
6. Slide the system-board tray forward until the tabs at the bottom of the handles touch the chassis; then, close the handles and press firmly on the release latches to snap them into the locked position.
7. Reinstall the bezel (see “Replacing the memory expansion module bezel” on page 178).
8. Reconnect the power cords to the memory expansion module; then, connect all external cables to the memory expansion module.
9. Turn on the peripheral devices and the host server.

Removing a memory expansion module hot-swap power supply

This topic provides precautions, as well as instructions for how to remove or install a hot-swap power supply.

About this task


When you remove or install a hot-swap power supply, observe the following precautions.

Statement 5



CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



Statement 8



CAUTION:

Never remove the cover on a power supply or any part that has the following label attached.




Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

To remove a hot-swap power supply from the memory expansion module, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.

2. If only one power supply is installed, turn off the host server and peripheral devices and disconnect the memory expansion module power cords.
3. If the memory expansion module is in a rack, at the back of the memory expansion module, pull back the cable management arm to gain access to the rear of the memory expansion module and the power supply.
4. Press and hold the orange release tab to the left. Grasp the handle and pull the power supply out of the memory expansion module.



5. If you are instructed to return the power supply, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing a memory expansion module hot-swap power supply

This topic provides instructions for how to install a hot-swap power supply in the memory expansion module.

About this task

The following notes describe the type of power supply that the memory expansion module supports and other information that you must consider when you install a power supply:

- The server comes with one 675-watt hot-swap 12-volt output power supply. The input voltage is 110 V ac or 220 V ac auto-sensing.

Note: You cannot mix 110 V ac and 220 V ac power supplies in the memory expansion module; it is not supported.


- These power supplies are designed for parallel operation. In the event of a power-supply failure, the redundant power supply continues to power the server. The memory expansion module supports a maximum of two power supplies, which is the requirement for redundancy support.

To install a hot-swap power supply in the memory expansion module, complete the following steps:

Procedure

1. Read the safety information that begins with “Safety” on page v and “Installation guidelines” on page 97.

2. Touch the static-protective package that contains the hot-swap power supply to any unpainted metal surface on the memory expansion module; then, remove the power supply from the package and place it on a static-protective surface.
3. If you are installing a hot-swap power supply into an empty bay, remove the power-supply filler panel from the power-supply bay.



4. Grasp the handle on the rear of the power supply and slide the power supply forward into the power-supply bay until it clicks. Make sure that the power supply connects firmly into the power-supply connector.
5. Route the power cord through the cable retention clip on the rear of the server so that it does not accidentally become disconnected.
6. Connect the power cord to the power-cord connector on the new power supply.
7. Connect the other end of the power cord to a properly grounded electrical outlet.
8. Make sure that the ac power LED and the dc power LED on the power supply are lit, indicating that the power supply is operating correctly. The two green LEDs are to the right of the power-cord connector.

Removing the memory expansion module five-drop fan cable assembly

This topic provides instructions for how to remove the five-drop fan cable assembly.


About this task

To remove the five-drop fan cable assembly, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Turn off the host server (see "Turning off the server" on page 21) and all attached peripheral devices. Disconnect all power cords from the memory expansion module; then, disconnect all external cables from the memory expansion module as necessary to replace the device.
3. Remove the bezel (see "Removing the memory expansion module bezel" on page 177).

4. Remove the system-board tray (see “Removing the memory expansion module system-board tray assembly” on page 197).
5. Remove the fans (see “Removing a memory expansion module hot-swap fan” on page 183).
6. From the inside of the system-board tray, remove the fan cable connectors from the system-board tray, starting with the connector that is farthest from the operator information panel.
7. Disconnect the five-drop fan cable from the system-board.
8. Grasp the tab on the cable connector on the rear of the fan and push the connector to the right to release the fan connector from the system-board tray; then, remove the cable for that fan from the clamp. Repeat this for each fan connector until you have removed all five fan connectors from the fan connectors in the fan cage.



9. Lift the five-drop fan cable from the system-board tray.
10. If you are instructed to return the fan cable, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the memory expansion module five-drop fan cable assembly


This topic provides instructions for how to install the five-drop fan cable assembly.

About this task

To install the five-drop fan cable assembly, complete the following steps:

Procedure

1. Read the safety information that begins with "Safety" on page v and "Installation guidelines" on page 97.
2. Connect the five-drop fan cable connectors to the rear of the fans, starting with the fan that is farthest from the operator information panel.
3. Insert the fan cable connector into the connector on the system-board tray and push it to the left to lock it in place; then route that fan cable through the cable clamp next to that fan. Repeat this for each fan connector until you have connected all five fan connectors to the fan connectors in the fan cage and the cable is routed through the clamps.



4. Connect the five-drop fan cable to the connector on the system board.
5. Replace the fans (see "Replacing a memory expansion module hot-swap fan" on page 184).
6. Replace the system-board tray (see "Removing the memory expansion module system-board tray assembly" on page 197).
7. Replace the bezel (see "Replacing the memory expansion module bezel" on page 178).
8. Reconnect the power cords to the memory expansion module; then, connect all external cables to the memory expansion module.
9. Turn on the peripheral devices and the host server.

Removing and replacing memory expansion module Tier 2 CRUs

This topic provides general information about removing and replacing memory expansion module Tier 2 CRUs.

About this task

You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge, under the type of warranty service that is designated for your memory expansion module.

Removing the memory expansion module system-board tray assembly

This topic provides instructions for how to remove the memory expansion module system-board tray assembly.


About this task

To remove the system-board tray, complete the following steps:

Note: When you replace the system-board tray, make sure that the host UEFI firmware is at the latest level.

Procedure

1. Before you attach a memory expansion module to the server and try to use it, you must update the UEFI firmware with the latest level of firmware code. If you attach and try to use the memory expansion module without updating the UEFI firmware, you might get unexpected system behavior, or the server might not power on. For special instructions to follow before you attach the memory expansion module to the server, go to .
2. Read the safety information that begins with Safety and “Installation guidelines” on page 97.
3. Turn off the host server (see Turning off the server) and all attached peripheral devices. Disconnect all power cords; then, disconnect all external cables from the server. Disconnect all power cords from the memory expansion module; then, disconnect all external cables from the memory expansion module. (Do not bend or nick the scalability cables while working with the cables.)
4. Remove the bezel (see “Removing the memory expansion module bezel” on page 177).
5. Grasp the blue release latches on the system-board tray handles and press the release latches in opposite directions and rotate the handles to the fully open position.



6. Grasp the handles and pull the system-board tray out until it stops; then, press inward on the stop-tabs on both sides of the system-board tray and pull the tray out of the chassis.
7. Remove the air baffle (see “Replacing the memory expansion module air baffle” on page 180).
8. Remove the DIMMs (see “Removing a memory expansion module DIMM” on page 185).
9. Remove all hot-swap fans (see “Removing a memory expansion module hot-swap fan” on page 183).
10. If you are instructed to return the system-board tray, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

Replacing the memory expansion module system-board tray assembly

This topic provides instructions for how to replace the system-board tray.

About this task

Note:


1. When you replace the system-board tray in the memory expansion module, be sure to order the correct system-board tray for your model. A label comes on models of the memory expansion module that contain the Intel 7510 scalable memory buffer. The label is located on top of the system-board tray. A note on the label states "This MAX5 contains Intel 7510 scalable memory buffer". In addition, models of the memory expansion module that contain the Intel 7510 scalable memory buffer will have a label attached inside of the memory expansion module chassis. To locate the label, remove the front bezel. The label is attached to the left side of the chassis and states "7510 SMP". See the parts listing table in “Replaceable memory expansion module components” on page 90 for more information about the correct system-board tray for your model.
2. When you reassemble the components in the memory expansion module, be sure to route all cables carefully so that they are not exposed to excessive pressure.
3. When you replace the system-board tray, make sure that the host UEFI firmware is at the latest level (see “Updating the firmware” on page 201).

4. Before you attach a memory expansion module to the server and try to use it, you must update the UEFI firmware with the latest level of firmware code. If you attach and try to use the memory expansion module without updating the UEFI firmware, you might get unexpected system behavior, or the server might not power on. For special instructions to follow before you attach the memory expansion module to the server, go to

To replace the system-board tray, complete the following steps:

Procedure

1. Reinstall the DIMMs (see “Replacing a memory expansion module DIMM” on page 186).
2. Reinstall the air baffle (see “Replacing the memory expansion module air baffle” on page 180).
3. Reinstall the hot-swap fans (see “Removing a memory expansion module hot-swap fan” on page 183).
4. Grasp the system-board tray on both sides (near the stop-tabs) and align the system-board tray with the chassis.



5. Slide the system-board tray forward until the tabs at the bottom of the handles touch the chassis; then, close the handles and press firmly on the release latches to snap them into the locked position.
6. Reinstall the bezel (see “Replacing the memory expansion module bezel” on page 178).
7. Reconnect the power cords to the memory expansion module; then, connect all external cables to the memory expansion module.
8. Turn on the peripheral devices and the host server.

Chapter 6. Configuration information and instructions

This topic provides general information about the configuration.

This chapter provides information about updating the firmware and using the configuration utilities.

Updating the firmware

This topic provides instructions for updating the firmware.

Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

Before you attach a memory expansion module to the server and try to use it, you must update the UEFI firmware and FPGA firmware with the latest level of firmware code. If you attach and try to use the memory expansion module without updating the UEFI firmware and FPGA firmware, you might get unexpected system behavior, or the server might not power on. For special instructions to follow before you attach the memory expansion module to the server, go to .

The firmware for the server is periodically updated and is available for download from the web. To check for the latest level of firmware, such as UEFI firmware, FPGA firmware, vital product data (VPD) code, device drivers, and integrated management module firmware, go to .

Attention: Before you update the firmware, be sure to back up any keys that are stored in the Trusted Platform Module (TPM), in case any of the TPM characteristics are changed by the new firmware. For instructions, see your encryption software documentation.

Download the latest firmware for the server; then, install the firmware, using the instructions that are included with the downloaded files.

In a two-node configuration, make sure that the UEFI firmware, FPGA firmware, and IMM code are at the same levels on all nodes.

When you replace a device in the server, you might have to update the firmware that is stored in memory on the device or restore the pre-existing firmware from a diskette or CD image.

- FPGA firmware is stored in ROM on the system board.
- UEFI firmware is stored in ROM on the system board.
- IMM firmware is stored in ROM on the IMM on the system board.
- Ethernet firmware is stored in ROM on the Ethernet controller.
- ServeRAID firmware is stored in ROM on the ServeRAID adapter.
- SATA firmware is stored in ROM on the integrated SATA controller.
- SAS/SATA firmware is stored in ROM on the SAS/SATA controller on the system board.

Configuring the server

This topic provides instructions on how to configure the server.

The following configuration programs come with the server:

- **Setup utility**

The Setup utility (formerly called the Configuration/Setup Utility program) is part of the IBM UEFI firmware. Use it to perform configuration tasks such as changing the startup-device sequence, setting the date and time, and setting passwords. For information about using this program, see “Configuring the server.”

- **Boot Selection Menu program**

The Boot Selection Menu program is part of the UEFI firmware. Use it to override the startup sequence that is set in the Setup utility and temporarily assign a device to be first in the startup sequence. For more information about using this program, see “Using the Boot Selection Menu program” on page 208.

- **IBM ServerGuide Setup and Installation CD**

The ServerGuide program provides software-setup tools and installation tools that are designed for the server. Use this CD during the installation of the server to configure basic hardware features, such as an integrated SAS controller with RAID capabilities, and to simplify the installation of your operating system. For information about obtaining and using this CD, see “Using the ServerGuide Setup and Installation CD” on page 209.

- **Integrated management module**

Use the integrated management module (IMM) for configuration, to update the firmware and sensor data record/field replaceable unit (SDR/FRU) data, and to remotely manage the server. For information about using the IMM, see “Using the integrated management module” on page 211.

- **VMware ESXi embedded hypervisor**

An USB flash device with VMware ESXi embedded hypervisor software is included with some server models and available for purchase for other models. Hypervisor is virtualization software that enables multiple operating systems to run on a host system at the same time. The USB embedded hypervisor flash device installs in either of the I/O board internal USB ports. For more information about using the embedded hypervisor, see “Using the embedded hypervisor” on page 214.

- **Remote presence and blue-screen capture features**

The remote presence feature provides the following functions:

- Remotely viewing video with graphics resolutions up to 1280 x 1024 at 75 Hz, regardless of the system state
- Remotely accessing the server, using the keyboard and mouse from a remote client
- Mapping the CD or DVD drive, diskette drive, and USB flash drive on a remote client, and mapping ISO and diskette image files as virtual drives that are available for use by the server
- Uploading a diskette image to the IMM memory and mapping it to the server as a virtual drive

The blue-screen capture feature captures the video display contents before the IMM restarts the server when the IMM detects an operating-system hang condition. A system administrator can use the blue-screen capture feature to assist in determining the cause of the hang condition.

For more information, see “Using the remote presence capability and blue-screen capture” on page 215

- **Ethernet controller configuration**

For information about configuring the Ethernet controller, see “Configuring the Broadcom Gigabit Ethernet controller” on page 216.

- **IBM Advanced Settings Utility (ASU) program**

Use this program as an alternative to the Setup utility for modifying UEFI settings and IMM settings. Use the ASU program online or out of band to modify UEFI settings from the command line without the need to restart the server to run the Setup utility. For information about using this program, see “IBM Advanced Settings Utility program” on page 217.

Setup utility menu choices

This topic provides descriptions of the Setup utility menu choices.

The following choices are on the Setup utility main menu. Depending on the version of the IBM UEFI firmware, some menu choices might differ slightly from these descriptions.

- **System Information**

Select this choice to view information about the server. When you make changes through other choices in the Setup utility, some of those changes are reflected in the system information; you cannot change settings directly in the system information.

This choice is on the full Setup utility menu only.

- **System Summary**

Select this choice to view configuration information, including the ID, speed, and cache size of the microprocessors; machine type and model of the server; the serial number; the system UUID; and the amount of installed memory.

When you make configuration changes through other choices in the Setup utility, the changes are reflected in the system summary; you cannot change settings directly in the system summary.

- **Product Data**

Select this choice to view the system-board identifier and the revision level or issue date of the server firmware, integrated management module, and diagnostics code.

- **System Settings**

Select this choice to view or change the server component settings. This choice is on the full Setup utility menu only.

- **Adapters and UEFI Drivers**

Select this choice to view information about the adapters and device drivers in the server that are compliant with EFI 1.10 and UEFI 2.0.

- **Processors**

Select this choice to view or change the processor settings.

- **Memory**

Select this choice to view or change the memory settings. To configure memory mirroring, select **System Settings** → **Memory** → **Memory Mirroring Mode** → **Mirrored**.

- **Devices and I/O Ports**
Select this choice to view or change assignments for devices and input/output (I/O) ports. You can configure the serial ports; configure remote console redirection; enable or disable integrated Ethernet controllers, the SAS/SATA controller, SATA optical drive channels, and PCI slots; and view the system Ethernet MAC addresses. If you disable a device, it cannot be configured, and the operating system will not be able to detect it (this is equivalent to disconnecting the device).
- **Power**
Select this choice to view or change power settings.
 - **Active Energy Manager**
Select this choice to enable or disable power capping. If you enable power capping, the Active Energy Manager program will limit the maximum power that is consumed by the server.
 - **Power Restore Policy**
Select this choice to determine the mode of operation to which the server will be restored after a power outage occurs. You can select **Always on**, **Always off**, or **Restore** to restore the server the state it was in at the time of the power outage.
- **Operating Modes**
Select this choice to select the memory speed or to specify a preset operating mode to configure the server for maximum power savings, maximum efficiency, or maximum performance.
 - **Efficiency mode**
Select this choice to maintain the optimal balance between performance and power consumption. The server generally produces the best performance per watt while it is in this mode.
 - **Acoustic mode**
Select this choice to configure the server to draw the minimum amount of power and generate the least noise. Server performance might be degraded depending on the application that you are running.
 - **Performance mode**
Select this choice to achieve the highest absolute performance for most server applications. The power consumption in this mode is often higher than in the Efficiency or Acoustics mode.
 - **Custom mode**
Select this choice only if you understand the functions of the low-level IMM settings. This is the only choice that enables you to change the low-level IMM settings that affect the performance and power consumption of the server.
- **Integrated Management Module**
Select this choice to view or change the settings for the integrated management module.
 - **POST Watchdog Timer**
Select this choice to view or enable the POST watchdog timer.
 - **POST Watchdog Timer Value**
Select this choice to view or set the POST loader watchdog timer value.
 - **Reboot System on NMI**
Enable or disable restarting the server whenever a nonmaskable interrupt (NMI) occurs. **Disabled** is the default.

- **Commands on USB Interface Preference**
Enable or disable the Ethernet over USB interface on IMM.
- **Network Configuration**
Select this choice to view and select the system management network interface port, the IMM MAC address, the current IMM IP address, and host name; define the static IMM IP address, subnet mask, and gateway address; specify whether to use the static IP address or have DHCP assign the IMM IP address; save the network changes; and reset the IMM.
- **Reset IMM to Defaults**
Select this choice to view or reset the IMM to the default settings.
- **Reset IMM**
Select this choice to reset the IMM settings.
- **Legacy Support**
Select this choice to view or set legacy support.
 - **Force Legacy Video on Boot**
Select this choice to force INT video support, if the operating system does not support UEFI video output standards.
 - **Rehook INT**
Select this choice to enable or disable devices from taking control of the boot process. The default is **Disable**.
 - **Legacy Thunk Support**
Select this choice to enable or disable UEFI to interact with PCI mass storage devices that are not UEFI compliant.
 - **Network**
Select this choice to view or configure optional network devices, such as iSCSI, PXE, and network devices. There might be additional configuration choices for optional network devices that are compliant with UEFI 2.1 and later.
- **Date and Time**
Select this choice to set the date and time in the server, in 24-hour format (*hour:minute:second*).
This choice is on the full Setup utility menu only.
- **Start Options**
Select this choice to view or change the start options, including the startup sequence, keyboard NumLock state, PXE boot option, and PCI device boot priority. Changes in the startup options take effect when you restart the server.
The startup sequence specifies the order in which the server checks devices to find a boot record. The server starts from the first boot record that it finds. If the server has Wake on LAN hardware and software and the operating system supports Wake on LAN functions, you can specify a startup sequence for the Wake on LAN functions. For example, you can define a startup sequence that checks for a disc in the CD-RW/DVD drive, then checks the hard disk drive, and then checks a network adapter.
This choice is on the full Setup utility menu only.
- **Boot Manager**
Select this choice to view, add, or change the device boot priority, boot from a file, select a one-time boot, or reset the boot order to the default setting.
- **System Event Logs**

Select this choice to access the System Event Manager, where you can view the POST event log and the system-event log.

The POST event log contains the three most recent error codes and messages that were generated during POST.

The system-event log contains POST and system management interrupt (SMI) events and all events that are generated by the baseboard management controller that is embedded in the integrated management module.

Important: If the system-error LED on the front of the server is lit but there are no other error indications, clear the system-event log. Also, after you complete a repair or correct an error, clear the system-event log to turn off the system-error LED on the front of the server.

- **POST Event Viewer**

Select this choice to access the POST event viewer to view the POST event log.

- **System Event Log**

Select this choice to view the system-event log.

- **Clear System Event Log**

Select this choice to clear the system-event log.

- **User Security**

Select this choice to set, change, or clear passwords. For information about passwords, see “Passwords” on page 207.

This choice is on the full and limited Setup utility menu.

- **Set Power-on Password**

Select this choice to set or change a power-on password. For more information, see “Power-on password” on page 207.

- **Clear Power-on Password**

Select this choice to clear a power-on password.

- **Set Administrator Password**

Select this choice to set or change an administrator password. An administrator password is intended to be used by a system administrator; it limits access to the full Setup utility menu. If an administrator password is set, the full Setup utility menu is available only if you type the administrator password at the password prompt. For more information, see “Administrator password” on page 208.

- **Clear Administrator Password**

Select this choice to clear an administrator password.

- **Save Settings**

Select this choice to save the changes that you have made in the settings.

- **Restore Settings**

Select this choice to cancel the changes that you have made in the settings and restore the previous settings.

- **Load Default Settings**

Select this choice to cancel the changes that you have made in the settings and restore the factory settings.

- **Exit Setup**

Select this choice to exit from the Setup utility. If you have not saved the changes that you have made in the settings, you are asked whether you want to save the changes or exit without saving them.

Passwords

This topic provides general information about passwords.

From the **User Security** menu choice, you can set, change, and delete a power-on password and an administrator password. The **User Security** choice is on the full Setup utility menu only.

If you set only a power-on password, you must type the power-on password to complete the system startup and to have access to the full Setup utility menu.

An administrator password is intended to be used by a system administrator; it limits access to the full Setup utility menu. If you set only an administrator password, you do not have to type a password to complete the system startup, but you must type the administrator password to access the Setup utility menu.

If you set a power-on password for a user and an administrator password for a system administrator, you can type either password to complete the system startup. A system administrator who types the administrator password has access to the full Setup utility menu; the system administrator can give the user authority to set, change, and delete the power-on password. A user who types the power-on password has access to only the limited Setup utility menu; the user can set, change, and delete the power-on password, if the system administrator has given the user that authority.

Power-on password

This topic provides information about the power-on password.

If a power-on password is set, when you turn on the server, you must type the power-on password to complete the system startup. You can use any combination of 6-20 printable ASCII characters for the password.

If a power-on password is set, you can enable the Unattended Start mode, in which the keyboard and mouse remain locked but the operating system can start. You can unlock the keyboard and mouse by typing the power-on password.

If you forget the power-on password, you can regain access to the server in any of the following ways:

- If an administrator password is set, type the administrator password at the password prompt. Start the Setup utility and reset the power-on password.
- Remove the battery from the server and then reinstall it. For instructions for removing the battery, see “Removing the battery” on page 112.
Attention: Before you change any switch settings or move any jumpers, turn off the server; then, disconnect all power cords and external cables. See the safety information that begins with “Safety” on page v. Do not change settings or move jumpers on any system-board switch or jumper blocks that are not shown in this document.
- Change the position of the power-on password override jumper to bypass the power-on password (see “I/O-board jumpers” on page 27 for more information). The default for the Password override jumper (J29) is pins 1 and 2. When the server is turned off, move the jumper to another position (for example pins 2 and 3) to enable the power-on password override. The power-on password prompt bypasses only once after moving the jumper. Start the Setup utility and reset or clear the power-on password.

You do not have to return the jumper to the previous position.

The power-on password override jumper does not affect the administrator password.

Attention: Before you move any jumpers, turn off the server; then, disconnect all power cords and external cables. See the safety information that begins with "Safety" on page v. Do not change settings or move jumpers on any system-board switch or jumper blocks that are not shown in this document.

Administrator password

This topic provides general information about the administrator password.

If an administrator password is set, you must type the administrator password for access to the full Setup utility menu. You can use any combination of 6-20 printable ASCII characters for the password.

Attention: If you set an administrator password and then forget it, there is no way to change, override, or remove it. You must replace the I/O board.

Using the Boot Selection Menu program

This topic provides instructions for using the Boot Selection Menu program.

About this task

The Boot Selection Menu is used to temporarily redefine the first startup device without changing boot options or settings in the Setup Utility.

To use the Boot Selection Menu program, complete the following steps:

Procedure

1. Turn off the server.
2. Restart the server.
3. When the prompt <F12> Select Boot Device is displayed, press F12. If a bootable USB mass storage device is installed, a submenu item (**USB Key/Disk**) is displayed.
4. Use the Up Arrow and Down Arrow keys to select an item from the menu and press Enter.

Results

The next time the server starts, it returns to the startup sequence that is set in the Setup Utility.

Starting the backup UEFI firmware

This topic provides general information about starting the backup UEFI firmware.

About this task

The system board contains a backup copy area for the UEFI firmware. This is a secondary copy of the UEFI firmware that you update only during the process of updating the UEFI firmware. If the primary copy of the UEFI firmware becomes damaged, use this backup copy.

To force the server to start from the backup copy of the UEFI firmware, turn off the server; then, move the UEFI boot recovery J22 jumper to the backup position (pins 2 and 3).

Use the backup copy of the UEFI firmware until the primary copy is restored. After the primary copy is restored, turn off the server; then, move the UEFI boot recovery J22 jumper back to the primary position (pins 1 and 2).

Using the ServerGuide Setup and Installation CD

This topic provides information about using the *ServerGuide Setup and Installation* CD.

The *ServerGuide Setup and Installation* CD provides software setup tools and installation tools that are designed for your server. The ServerGuide program detects the server model and optional hardware devices that are installed and uses that information during setup to configure the hardware. The ServerGuide program simplifies operating-system installations by providing updated device drivers and, in some cases, installing them automatically.

You can download a free image of the *ServerGuide Setup and Installation* CD or purchase the CD from the ServerGuide fulfillment website at <http://www.ibm.com/systems/management/serverguide/sub.html>. To download the free image, click **IBM Service and Support Site**.

Note: Changes are made periodically to the IBM website. The actual procedure might vary slightly from what is described in this document.

The ServerGuide program requires a supported IBM server with an enabled startable (bootable) CD drive. In addition to the *ServerGuide Setup and Installation* CD, you must have your operating-system CD to install the operating system.

To start the *ServerGuide Setup and Installation* CD, complete the following steps:

1. Insert the CD, and restart the server. If the CD does not start, see "ServerGuide problems" in the *Problem Determination and Service Guide* on the IBM Documentation CD.
2. Follow the instructions on the screen to complete the following tasks:
 - a. Select your language.
 - b. Select your keyboard layout and country.
 - c. View the overview to learn about ServerGuide features.
 - d. View the readme file to review installation tips for your operating system and adapter.
 - e. Start the operating-system installation. you will need your operating-system CD.

ServerGuide features

Features and functions can vary slightly with different versions of the ServerGuide program. To learn more about the version that you have, start the *ServerGuide Setup and Installation* CD and view the online overview. Not all features are supported on all server models.

The ServerGuide program has the following features:

- An easy-to-use interface
- Diskette-free setup, and configuration programs that are based on detected hardware
- Device drivers that are provided for the server model and detected hardware
- Operating-system partition size and file-system type that are selectable during setup

The ServerGuide program performs the following tasks:

- Sets system date and time
- Detects the RAID adapter or controller and runs the SAS RAID configuration program (with LSI chip sets for ServeRAID adapters only)
- Checks the microcode (firmware) levels of a ServeRAID adapter and determines whether a later level is available from the CD
- Detects installed optional hardware devices and provides updated device drivers for most adapters and devices
- Provides diskette-free installation for supported Windows operating systems
- Includes an online readme file with links to tips for hardware and operating-system installation

Setup and configuration overview

This topic provides general information about using the *ServerGuide Setup and Installation* CD.

When you use the *ServerGuide Setup and Installation* CD, you do not need setup diskettes. You can use the CD to configure any supported IBM server model. The setup program provides a list of tasks that are required to set up your server model. On a server with a ServeRAID adapter or integrated SCSI controller with RAID capabilities, you can run the SCSI RAID configuration program to create logical drives.

Note: Features and functions can vary slightly with different versions of the ServerGuide program.

Typical operating-system installation

This topic provides instructions for a typical operating-system installation.

The ServerGuide program can reduce the time it takes to install an operating system. It provides the device drivers that are required for your hardware and for the operating system that you are installing. This section describes a typical ServerGuide operating-system installation.

Note: Features and functions can vary slightly with different versions of the ServerGuide program.

1. After you have completed the setup process, the operating-system installation program starts. (You will need your operating-system CD to complete the installation.)
2. The ServerGuide program stores information about the server model, service processor, hard disk drive controllers, and network adapters. Then, the program checks the CD for newer device drivers. This information is stored and then passed to the operating-system installation program.
3. The ServerGuide program presents operating-system partition options that are based on your operating-system selection and the installed hard disk drives.
4. The ServerGuide program prompts you to insert your operating-system CD and restart the server. At this point, the installation program for the operating system takes control to complete the installation.

Installing your operating system without using ServerGuide

This topic provides general information about installing your operating system without using ServerGuide.

About this task

If you have already configured the server hardware and you are not using the ServerGuide program to install your operating system, you can download the latest operating-system installation instructions for the server from .

Using the integrated management module

This topic provides general information about using the integrated management module.

The integrated management module (IMM) is a second generation of the functions that were formerly provided by the baseboard management controller hardware. It combines service processor functions, video controller, and remote presence function in a single chip.

The IMM supports the following basic systems-management features:

- Active Energy Manager.
- Alerts (in-band and out-of-band alerting, PET traps - IPMI style, SNMP, e-mail).
- Auto Boot Failure Recovery.
- Automatic Server Restart (ASR) when POST is not complete or the operating system hangs and the operating-system watchdog timer times out. The IMM might be configured to watch for the operating-system watchdog timer and restart the server after a timeout, if the ASR feature is enabled. Otherwise, the IMM allows the administrator to generate an NMI by pressing a nonmaskable interrupt button on the information panel for an operating-system memory dump. ASR is supported by Intelligent Peripheral management Interface (IPMI).

- Boot sequence manipulation.
- Command-line interface.
- Configuration save and restore.
- DIMM error assistance. The Unified Extensible Firmware Interface (UEFI) disables a failing DIMM that is detected during POST, and the IMM lights the associated system-error LED and the failing DIMM error LED.
- Environmental monitor with fan speed control for temperature, voltages, fan failure, and power supply failure.
- Intelligent Platform Management Interface (IPMI) Specification V2.0 and Intelligent Platform Management Bus (IPMB) support.
- Invalid system configuration (CNFG) LED support.
- Light path diagnostics LEDs to report errors that occur with fans, power supplies, microprocessor, hard disk drives, and system errors.
- Nonmaskable interrupt (NMI) detection and reporting.
- Operating-system failure blue screen capture.
- PCI configuration data.
- PECI 2 support.
- Power/reset control (power-on, hard and soft shutdown, hard and soft reset, schedule power control).
- Query power-supply input power.
- ROM-based IMM firmware flash updates.
- Serial over LAN (SOL).
- Serial port redirection over Telnet or SSH.
- System-event log.
- When one of the two microprocessors reports an internal error, the server disables the defective microprocessor and restarts with the one good microprocessor.

The IMM also provides the following remote server management capabilities through the OSA SMBridge management utility program:

- **Command-line interface (IPMI Shell)**

The command-line interface provides direct access to server management functions through the IPMI 2.0 protocol. Use the command-line interface to issue commands to control the server power, view system information, and identify the server. You can also save one or more commands as a text file and run the file as a script.

- **Serial over LAN**

Establish a Serial over LAN (SOL) connection to manage servers from a remote location. You can remotely view and change the UEFI settings, restart the server, identify the server, and perform other management functions. Any standard Telnet client application can access the SOL connection.

Obtaining the IP address for the Web interface access

This topic provides instruction for obtaining the IP address for the Web interface access.

The IMM MAC address tag is tied to the rear of the server. The hostname of the IMM is "IMM-" plus the last twelve characters of the MAC address. Because the default setting of the IMM is DHCP, after the IMM Ethernet port is connected to a management network, it can obtain an IP address from the network and it is difficult to identify on the network. Viewing the tag is one way to find the IMM after the server is connected to the network.

To access the Web interface, you need the IP address of the IMM which you can obtain through the Setup utility. To obtain the IP address, complete the following steps:

1. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1. If you have set both a power-on password and an administrator password, you must type the administrator password to access the full Setup utility menu.
3. Select **System Settings** → **Integrated Management Module** → **Network Configuration**.
4. Locate the IP address.
5. Exit from the Setup utility.

Logging on to the IMM web interface

This topic provide steps to log on to the IMM web interface.

About this task

To log on to the IMM web interface, complete the following steps:

Procedure

1. Open a web browser and in the **Address** or **URL** field, type the IP address or host name of the IMM to which you want to connect.

Note: If you are logging on to the IMM for the first time after installation, the IMM defaults to DHCP. If a DHCP host is not available, the IMM assigns a static IP address of 192.168.70.125. The MAC address tag provides the default hostname of the IMM and does not require you to start the server.

2. On the Login page, type the user name and password. If you are using the IMM for the first time, you can obtain the user name and password from your system administrator. All login attempts are documented in the system-event log.

Note: The IMM is set initially with a user name of USERID and password of PASSWORD (with a zero, not the letter O). You have read/write access. You must change this default password the first time you log on.

3. On the Welcome page, type a timeout value (in minutes) in the field that is provided. The IMM will log you off the web interface if your browser is inactive for the number of minutes that you entered for the timeout value.
4. Click **Continue** to start the session. The System Status page provides a quick view of the server status.


Using the embedded hypervisor

This topic provides instructions for using the embedded hypervisor.

About this task

The VMware ESXi embedded hypervisor software is available on the IBM USB flash device with embedded hypervisor. The USB flash device can be installed in either of the I/O board internal USB ports (see the following illustration). Hypervisor is virtualization software that enables multiple operating systems to run on a host system at the same time. The USB flash device is required to activate the hypervisor functions.

Note: When you add an optional memory expansion module to your server configuration and you plan to use the optional USB flash device with VMware ESXi embedded hypervisor software, see the documentation that comes with the USB flash device and the operation system installation instructions for installing VMware ESXi (or ESX, depending on your environment) on your server at the IBM website at <http://www.ibm.com/supportportal/>. The documentation provides additional installation and configuration information that you must follow before you use the memory expansion module.



To start using the embedded hypervisor functions, you must add the USB flash device to the startup sequence in the Setup utility.

To add the USB flash device to the startup sequence, complete the following steps:

Procedure

1. Turn on the server.

Note: Approximately 1 to 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1.
3. From the Setup utility main menu, select **Boot Manager**.
4. Select **Add Boot Option**; then, select **USB Storage**. Press Enter, and then select Esc.
5. Select **Change Boot Order** and then select **Commit Changes**; then, press Enter.
6. Select **Save Settings** and then select **Exit Setup**.

Results

If the embedded hypervisor flash device image becomes corrupted, you can use the *VMware Recovery* CD that comes with the server to recover the flash device image. To recover the flash device image, complete the following steps:

1. Turn on the server.

Note: Approximately 1 to 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. Insert the VMware Recovery CD into the CD or DVD drive.
3. Follow the instructions on the screen.

For additional information and instructions, see the *VMware ESXi Server 31 Embedded Setup Guide* at http://www.vmware.com/pdf/vi3_35/esx_3i_e/r35/vi3_35_25_3i_setup.pdf

Using the remote presence capability and blue-screen capture

This topic provides instructions for using the remote presence capability and blue-screen capture.

About this task

The remote presence and blue-screen capture features are integrated functions of the integrated management module (IMM).

The remote presence feature provides the following functions:

- Remotely viewing video with graphics resolutions up to 1600 x 1200 at 85 Hz, regardless of the system state
- Remotely accessing the server, using the keyboard and mouse from a remote client
- Mapping the CD or DVD drive, diskette drive, and USB flash drive on a remote client, and mapping ISO and diskette image files as virtual drives that are available for use by the server
- Uploading a diskette image to the IMM memory and mapping it to the server as a virtual drive

The blue-screen capture feature captures the video display contents before the IMM restarts the server when the IMM detects an operating-system hang condition. A system administrator can use the blue-screen capture to assist in determining the cause of the hang condition.

Enabling the Broadcom Gigabit Ethernet Utility program

This topic provides general information about enabling the Broadcom Gigabit Ethernet Utility program.

You can configure the Broadcom Gigabit ports as a startable device, and can be customized in the startup sequence. Enable, disable, and customize the startup sequence of the Broadcom Gigabit Ethernet ports from the Setup Utility.

Configuring the Broadcom Gigabit Ethernet controller

This topic provides information about configuring the Broadcom Gigabit Ethernet controller.

The Ethernet controllers are integrated on the system board. They provide an interface for connecting to a 10 Mbps, 100 Mbps, or 1 Gbps network and provide full-duplex (FDX) capability, which enables simultaneous transmission and reception of data on the network. If the Ethernet ports in the server support auto-negotiation, the controllers detect the data-transfer rate (10BASE-T, 100BASE-TX, or 1000BASE-T) and duplex mode (full-duplex or half-duplex) of the network and automatically operate at that rate and mode.

You do not have to set any jumpers or configure the controllers. However, you must install a device driver to enable the operating system to address the controllers. For device drivers and information about configuring the Ethernet controllers, see the *Broadcom NetXtreme II Gigabit Ethernet Software* CD. To find updated information about configuring the controllers, go to .

Configuring RAID arrays

This topic provides instructions for configuring RAID arrays.

About this task

Through the Setup utility, you can access utilities to configure RAID arrays. The specific procedure for configuring arrays depends on the RAID controller that you are using. For details, see the documentation for your RAID controller. To access the utility for your RAID controller, complete the following steps:

Procedure

1. Turn on the server.

Note: Approximately 1 to 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1. If you have set an administrator password, you must type the administrator password to access the full Setup utility menu. If you do not type the administrator password, a limited Setup utility menu is available.
3. Select **System Settings** → **Adapters and UEFI drivers**.
4. Press Enter to refresh the list of device drivers.
5. Select the device driver for your RAID controller and press Enter.
6. Follow the instructions in the documentation for your RAID controllers.

Results

For more information about RAID arrays, see the IBM Redbooks® publications about RAID arrays at <http://www.redbooks.ibm.com/abstracts/tips0054.html>.

IBM Advanced Settings Utility program

This topic provides information about the IBM Advanced Settings Utility program.

The IBM Advanced Settings Utility (ASU) program is an alternative to the Setup utility for modifying UEFI settings. Use the ASU program online or out of band to modify UEFI settings from the command line without the need to restart the server to access the Setup utility.

You can also use the ASU program to configure the optional remote presence feature or other IMM settings. The remote presence feature provides enhanced systems-management capabilities.

In addition, the ASU program provides limited settings for configuring the IPMI function in the IMM through the command-line interface.

Use the command-line interface to issue setup commands. You can save any of the settings as a file and run the file as a script. The ASU program supports scripting environments through a batch-processing mode.

For more information and to download the ASU program, go to <http://www.ibm.com/support/entry/portal/docdisplay?lnidocid=TOOL-ASU> or complete the following steps.

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Product support**, click **System x**.
3. On the left side of the page, click **Systems Management software**.
4. Under **Configuration**, click **Advanced Settings Utility**.

Updating IBM Systems Director

This topic provides instructions for updating IBM Systems Director.

About this task

If you plan to use IBM Systems Director to manage the server, you must check for the latest applicable IBM Systems Director updates and interim fixes.

Note: Changes are made periodically to the IBM website. The actual procedure might vary slightly from what is described in this document.

To locate and install a newer version of IBM Systems Director, complete the following steps:

Procedure

1. Check for the latest version of IBM Systems Director:
 - a. Go to <http://www.ibm.com/systems/management/director/downloads.html>.

- b. If a newer version of IBM Systems Director than what comes with the server is shown in the drop-down list, follow the instructions on the web page to download the latest version.
2. Install the IBM Systems Director program.

Results

If your management server is connected to the Internet, to locate and install updates and interim fixes, complete the following steps:

1. Make sure that you have run the Discovery and Inventory collection tasks.
2. On the Welcome page of the IBM Systems Director web interface, click **View updates**.
3. Click **Check for updates**. The available updates are displayed in a table.
4. Select the updates that you want to install, and click **Install** to start the installation wizard.

If your management server is not connected to the Internet, to locate and install updates and interim fixes, complete the following steps:

1. Make sure that you have run the Discovery and Inventory collection tasks.
2. On a system that is connected to the Internet, go to <http://www.ibm.com/eserver/support/fixes/fixcentral/>.
3. From the **Product family** list, select **IBM Systems Director**.
4. From the **Product** list, select **IBM Systems Director**.
5. From the **Installed version** list, select the latest version, and click **Continue**.
6. Download the available updates.
7. Copy the downloaded files to the management server.
8. On the management server, on the Welcome page of the IBM Systems Director web interface, click the **Manage** tab, and click **Update Manager**.
9. Click **Import updates** and specify the location of the downloaded files that you copied to the management server.
10. Return to the Welcome page of the web interface, and click **View updates**.
11. Select the updates that you want to install, and click **Install** to start the installation wizard.

Configuring an EXA multi-node system


This topic provides information about configuring an EXA multi-node system.

About this task

Note:

1. The EXA scalability feature is supported only in memory expansion modules that contain the Intel 7510 Scalable Memory Buffer.
2. Do not use the IMM Scalable Partition Web Interface to configure a QPI multi-node system.

This feature requires scalability cables and firmware that supports X-Architecture scalability from one memory expansion module to another memory expansion module. In a 2-node EXA scaled configuration, each memory expansion module is connected to an x3850 X5 or x3950 X5 server, and the memory expansion modules are connected to each other through the EXA scalability cables. (For detailed installation instructions, see the documentation that came with the EXA cables.)



The Scalable Partition web interface is an extension of the IMM web interface and is used to create, delete, control, and view scalable partitions. The Scalable Partition web interface firmware is in the IMM.

A multi-node configuration interconnects multiple servers or scalable partitions. When two servers with memory expansion module configurations are connected through EXA cables, you can merge this multi-node configuration to form a single logical server or partition it into multiple stand-alone servers without removing any cables. This capability to partition a multi-node server into several individual servers without removing any cables is referred to as IBM FlexNode Technology.

As a single logical server, the server is able to use resources from all scalable partitions. The server uses a single, contiguous memory space and provides access to all associated adapters, hard disk drives, and USB devices (including the mouse and keyboard). PCI slot numbering starts with the primary node and continues with the secondary nodes, in numeric order of the logical node IDs. The internal optical drive and VGA connection on the secondary node are disabled, and the server cannot use them.

Note: When the server is configured as a single logical server, if there is an ac system power failure to one of the nodes (partitions), the remaining good node powers itself down and remains off until the failing node recovers from the ac power loss. Remote users will not receive any warning or error messages that the partition has failed, but local users will see a 00.bb blinking sequence on the front panel checkpoint display. After the power is restored, both nodes will automatically turn on and boot as a two-node partition. If you replace the I/O card in the server, follow the instructions for creating an EXA multi-node system.

In a stand-alone server, each scalable partition supports an independent operating-system installation. In addition, each scalable partition uses its own individual resources (one server and the associated memory expansion module) as an independent system. One stand-alone server cannot boot an operating system on another stand-alone server.

Creating an EXA multi-node system

This topic provides information about creating an EXA multi-node system.

About this task

The following information provides instructions for creating an EXA multi-node system from multiple servers and configuring it as a single logical 8-socket server.

Note: To check for the latest firmware levels and to download firmware updates, go to <http://www.ibm.com/supportportal/>.

Before you create an EXA multi-node system, make sure that all the nodes in the multi-node configuration contain the following software and hardware:

- The current level of UEFI firmware, SAS UEFI code, IMM firmware, and FPGA firmware (all nodes must be at the same level)
- Microprocessors that are the same cache size, type, and clock speed

Note: All the nodes must have all the microprocessor sockets and memory connectors populated.

To create a scalable partition, complete the following steps:

1. Connect the EXA cables. For detailed instructions, see the documentation that comes with your cables.
2. Connect all nodes to an ac power source and make sure that they are not running an operating system.

Note: All nodes that are part of an existing partition and are connected through EXA cables must be in Standalone mode (part of the partition but operating independently). To enable Standalone mode, on the Scalable Complex Management page, click **Standalone Boot**, and then click **Force**.

3. Connect and log in to the IMM web interface.

Note: For instructions for creating, modifying, and controlling partitions through the IMM Telnet interface, see “Using the IMM Telnet interface” on page 223.

The screenshot displays the IBM Integrated Management Module (IMM) web interface for System X. The main content area is titled "Scalable Complex Management" and features several sections:

- Partition Control:** Includes buttons for Start, Reset, and Stop.
- Standalone Boot:** Includes buttons for Force and Undo.
- Partition Configure:** Includes buttons for Auto, Create, Custom, and Delete.
- Reset Defaults:** Includes a Reset button.
- Partition Reorder:** Includes a dropdown menu for Top System (SN# 2314636) and a Redraw button.

On the right side, there is a "System Partition Mode" table:

Started	Valid	Multinode
Started	Valid	Multinode
Started	Valid	Multinode

The interface also shows a diagram of two chassis (SN# 2314636 and SN# 2315994) with their respective ports (Port 1, Port 2, Port 3) connected via EXA cables.

4. In the navigation pane, click **Scalable Partitioning**, and then click **Manage Partition(s)**. Use the Scalable Complex Management page to create, delete, control, and view scalable partitions. Select the primary node; then, automatically or manually create a scalable partition:
 - To automatically create a single partition that uses all nodes in the multi-node configuration, click **Partition Configure**, and then click **Auto**.
 - To manually assign nodes to the partition, click **Partition Configure**, select the nodes you want to include as members of the partition, and then click **Create**.

Note: To reorder the sequence in which the nodes appear in the diagram on the page, click **Redraw**. For example, you can reorder the diagram to reflect the order in which the nodes are physically installed in a rack. The nodes are reordered according to the QPI or EXA cabling, with the node that you select in the top position.

Partitioning an EXA multi-node system

This topic provides information about partitioning an EXA multi-node system.

About this task


There are two ways to partition an EXA multi-node system into stand-alone servers: deleting the partition configuration and forcing a stand-alone boot. Both methods are performed through the IMM web interface from the Manage Partition(s) page, through the IMM in either server. The benefit of forcing a stand-alone boot is that you can restore the original partition information by clicking **Undo**.

Note: For instructions for creating, modifying, and controlling partitions through the IMM Telnet interface, see “Using the IMM Telnet interface” on page 223.


To partition an EXA multi-node system, complete the following steps:

1. Connect and log in to the IMM web interface.
2. Make sure that the scaled system is powered off. In the navigation pane, expand **Scalable Partitioning**, and click **Manage Partition(s)**. Both nodes should be indicated as stopped.

3. Select the chassis that you are connected to through the IMM. The interface control for the other chassis should be disabled.



4. Determine which method you plan to use to partition the multi-node server:
 - To delete the partition, click **Partition Configuration**, and then click **Delete**.
 - To force a stand-alone boot, click **Standalone Boot**, and then click **Force**.
5. Make sure that each chassis is in Standalone mode, which indicates that the system is now partitioned into two independent systems.



Using the IMM Telnet interface

This topic provides information about the IMM Telnet interface.

About this task

You can create, modify, and control partitions through the IMM Telnet interface. To use the IMM Telnet interface, log in to the IMM Telnet interface on either node and use the **scale** command for multi-node control and configuration.

To display scale information, in the IMM Telnet interface, type `scale` at the system prompt. Information similar to the following example is displayed.

```
Node UUID: 92CF1100F19111DF8000E41F13E455FC
Node ID: 3c0d
Node SN:
Node Power State: off
Node Partition ID: na
Node Logical ID: na
Node Primary: na
Node Mode: na
```

```
Node UUID: C7C92400EE7011DF8000E41F13E454E4
Node ID: 8bb9
Node SN:
Node Power State: off
Node Partition ID: na
Node Logical ID: na
Node Primary: na
Node Mode: na
```

Creating a partition by using the IMM Telnet interface:

This topic provides information about creating a partition by using the IMM Telnet interface.

About this task

Note: Before you create a partition, make sure that the nodes that you intend to include in the partition are powered off and are not in any active partition.

You can create partitions through the IMM Telnet interface by using the **auto** command (`scale -auto primarynodeid`) or the **create** command (`scale -create primarynodeid, nodeid`) command.

You can use the **auto** command to create a partition that includes all the nodes in the complex and specify the node that is to be the primary node. For example, if the EXA system contains only two nodes, 3c0d and 8bb9, to create a 2-node partition with node 3c0d as the primary node, type `scale -auto 3c0d`.

You can use the **create** command to specify the nodes in the complex that are to be included in the partition. The first node ID in the argument is the primary

node. For example, if the EXA system includes nodes 3c0d and 8bb9, to create a 2-node partition with node 3c0d as the primary node, type `scale -create 3c0d, 8bb9`.

After you use either method to create the partition, the scale information is updated with the node partition ID assigned to the partition for future partition operation. When you type `scale` at the system prompt, information similar to the following example is displayed.

```
Node UUID: 92CF1100F19111DF8000E41F13E455FC
Node ID: 3c0d
Node SN:
Node Power State: off
Node Partition ID: 1
Node Logical ID: 0
Node Primary: yes
Node Mode: partition
```

```
Node UUID: C7C92400EE7011DF8000E41F13E454E4
Node ID: 8bb9
Node SN:
Node Power State: off
Node Partition ID: 1
Node Logical ID: 1
Node Primary: no
Node Mode: partition
```

Deleting a partition by using the IMM Telnet interface:

This topic provides information about deleting a partition by using the IMM Telnet interface.

About this task

Note: Before you delete a partition, make sure that all the nodes in the partition are powered off.

You can delete partitions through the IMM Telnet interface by using the **delete** command (`scale -delete`) command or the **delete -partid** command (`scale -delete -partid id`) command.

You can use the **delete** command to delete all partitions in the complex.

You can use the **delete -partid** command to delete a specific partition. For example, to delete partition 1, type `scale -delete -partid 1`.

Toggle partitions by using the IMM Telnet interface:

This topic provides information about toggling partitions by using the IMM Telnet interface.

About this task

Note: Before you toggle a partition to Standalone mode, make sure that all the nodes in the partition are powered off.

A partition can be in either of two modes: Standalone and Partition. When the partition is in Standalone mode, each node operates independently. When the partition is in Partition mode, all the nodes in the partition boot as a single system.

The command to toggle the partition is `scale -mode standalone|partition -partid id`.

For example, to set partition 1 in Standalone mode, type `scale -mode standalone -partid 1`.

Starting, stopping, and resetting by using the IMM Telnet interface:

This topic provides information about starting, stopping, and resetting by using the IMM Telnet interface.

About this task

There are three additional partition commands that you can use with the IMM Telnet interface: **start**, **stop**, and **reset**.

You can use the **start** command (`scale -start {-partid id | -node nodeid}`) to start a partition or node. When you use this command, if the node is in a partition and the partition is not in Standalone mode, all the nodes in the partition will power on. For example, to start partition 1, type `scale -start -partid 1`.

Use the **reset** command (`scale -reset {-partid id | -node nodeid}`) to reset a partition or node. When you use this command, if the node is in a partition and the partition is not in Standalone mode, all the nodes in the partition will be reset.

Use the **stop** command (`scale -stop {-partid id | -node nodeid}`) to shut down a partition or node. When you use this command, if the node is in a partition and the partition is in Standalone mode, all the nodes in the partition will power off. For example, to stop node 8bb9, type `scale -stop -node 8bb9`.

Configuring a QPI multi-node system

This topic provides information about configuring a QPI multi-node system.

About this task

A multi-node configuration interconnects multiple servers or multiple partitions. This configuration requires 8 microprocessors and 16 memory cards (4 microprocessors and 8 memory cards per node). See the documentation that came with your QPI cables to set up your QPI multi-node configuration.

Note: Do not use the IMM Scalable Partition Web Interface to configure a QPI multi-node system.

Before you create scalable partitions, make sure that all the nodes in the multi-node configuration contain the following software and hardware:

- The current level of UEFI code, SAS UEFI code, IMM firmware, and FPGA firmware

Note: To check for the latest firmware levels and to download firmware updates, go to <http://www.ibm.com/supportportal/>.

- Microprocessor that are the same cache size and type, and the same clock speed

Note: The nodes can vary in the number of microprocessors and the amount of memory each contains, above the minimum.

Appendix A. DSA diagnostic test results

After running the DSA diagnostic tests, use this information to resolve any issues that were found.

DSA Broadcom network test results

The following messages are generated when you run the Broadcom network test.

405-000-000 BRCM:TestControlRegisters Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-001-000 BRCM:TestMIIRegisters Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-002-000 BRCM:TestEEPROM Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-003-000 BRCM:TestInternalMemory Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-004-000 BRCM:TestInterrupt Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-005-000 BRCM:TestLoopbackMAC Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-006-000 BRCM:TestLoopbackPhysical Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-007-000 BRCM:TestLEDs Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-800-000 BRCM:TestControlRegisters Test Aborted

Explanation: The control registers test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-801-000 BRCM:TestMIIRegisters Test Aborted

Explanation: The MII register test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-802-000 BRCM:TestEEPROM Test Aborted

Explanation: The EEPROM test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-803-000 BRCM:TestInternalMemory Test Aborted

Explanation: The internal memory test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-804-000 BRCM:TestInterrupt Test Aborted

Explanation: The interrupt test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-805-000 BRCM:TestLoopbackMAC Test Aborted

Explanation: Loopback testing at the MAC layer was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-806-000 BRCM:TestLoopbackPhysical Test Aborted

Explanation: Loopback testing at the physical layer was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-807-000 BRCM:TestLEDs Test Aborted

Explanation: Verification of status LEDs was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-900-000 BRCM:TestControlRegisters Test Failed

Explanation: A failure was detected while testing internal MAC registers

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-901-000 BRCM:TestMIRegisters Test Failed

Explanation: A failure was detected while testing internal PHY registers.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-902-000 BRCM:TestEEPROM Test Failed

Explanation: A failure was detected while testing non-volatile RAM.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-903-000 BRCM:TestInternalMemory Test Failed

Explanation: A failure was detected while testing internal memory.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

405-904-000 BRCM:TestInterrupt Test Failed

Explanation: A failure was detected while testing interrupts.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-905-000 BRCM:TestLoopbackMAC Test Failed

Explanation: BRCM:TestLoopbackMAC Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-906-000 BRCM:TestLoopbackPhysical Test Failed

Explanation: A failure was detected during the loopback test at the physical layer.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

405-907-000 BRCM:TestLEDs Test Failed

Explanation: A failure was detected while verifying operation of the status LEDs.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

DSA Brocade test results

The following messages are generated when you run the Brocade test.

218-000-000 Brocade:MemoryTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-001-000 Brocade:ExternalLoopbackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-002-000 Brocade:SerdesLoopbackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-003-000 Brocade:PCILoopbackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-004-000 Brocade:ExternalEthLoopbackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

218-005-000 Brocade:SerdesEthLoopbackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

218-006-000 Brocade:InternalLoopbackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-800-000 Brocade:MemoryTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-801-000 Brocade:ExternalLoopbackTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-802-000 Brocade:SerdesLoopbackTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-803-000 Brocade:PCILoopbackTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

218-804-000 Brocade:ExternalEthLoopbackTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

218-805-000 Brocade:SerdesEthLoopbackTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-806-000 Brocade:InternalLoopbackTest Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-900-000 Brocade:MemoryTest Failed

Explanation: A failure was detected while testing the adapter memory.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Rerun the test.
2. Verify whether the firmware is at proper level.
3. Rerun the test.
4. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-901-000 Brocade:ExternalLoopbackTest Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check cable connections.
2. Rerun the test.
3. Verify whether the firmware is at proper level.
4. Rerun the test.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-902-000 Brocade:SerdesLoopbackTest Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Rerun the test.
2. Verify whether the firmware is at proper level.
3. Rerun the test.
4. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

218-903-000 Brocade:PCILoopbackTest Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Rerun the test.
2. Verify whether the firmware is at proper level.
3. Rerun the test.
4. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-904-000 Brocade:ExternalEthLoopbackTest Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check or replace SFP/cable.
2. Rerun the test.
3. Verify whether the firmware is at proper level.
4. Rerun the test.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-905-000 Brocade:SerdesEthLoopbackTest Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Rerun the test.
2. Verify whether the firmware is at proper level.
3. Rerun the test.
4. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

218-906-000 Brocade:InternalLoopbackTest Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Rerun the test.
2. Verify whether the firmware is at proper level.
3. Rerun the test.
4. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

DSA checkpoint panel test results

The following messages are generated when you run the checkpoint panel test.

180-000-000 Check-point Panel Test Passed

Explanation: Check-point Panel Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

180-801-000 Check-point Panel Test Aborted

Explanation: Check-point Panel Test Aborted. BMC is unable to verify that the operator information panel cable is connected.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Inspect and reseal operator information panel cable at both ends.
2. Verify that the Baseboard Management Controller (BMC) is working.
3. Run the test again.
4. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

180-901-000 Check-point Panel Test Failed

Explanation: Check-point Panel Test Failed. Operator reported incorrect display.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check the operator information panel cabling for loose or broken connections at both ends or damage to the cable.
2. Replace the information panel cable if damage is present.
3. Run the test again.
4. Replace the operator information panel assembly.
5. Run the test again.
6. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

DSA CPU stress test results

The following messages are generated when you run the CPU stress test.

089-000-000 CPU Stress Test Passed

Explanation: CPU Stress Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

089-801-000 CPU Stress Test Aborted

Explanation: CPU Stress Test Aborted. Internal Program Error.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Turn off and restart the system.
2. Make sure that the DSA Diagnostic code is at the latest level.
3. Run the test again.
4. Check system firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component. The latest level firmware for this component can be found in reference to this system type at the IBM Support website.
5. Run the test again.
6. If the system has stopped responding, turn off and restart the system and then run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

089-802-000 CPU Stress Test Aborted

Explanation: CPU Stress Test Aborted. System resource unavailability error.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Turn off and restart the system.
2. Make sure that the DSA Diagnostic code is at the latest level.
3. Run the test again.
4. Check system firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
5. Run the test again.
6. If the system has stopped responding, turn off and restart the system and then run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

089-803-000 CPU Stress Test Aborted

Explanation: CPU Stress Test Aborted. Memory size is insufficient to run the test. At least 1GB is required.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

089-804-000 CPU Stress Test Aborted

Explanation: CPU Stress Test Aborted. User pressed Ctrl-C.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

089-901-000 CPU Stress Test Failed

Explanation: CPU Stress Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. If the system has stopped responding, turn off and restart the system and then run the test again.
2. Make sure that the DSA Diagnostic code is at the latest level.
3. Run the test again.
4. Check system firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
5. Run the test again.
6. If the system has stopped responding, turn off and restart the system and then run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA Emulex adapter test results

The following messages are generated when you run the Emulex adapter test.

516-000-000 ELXUCNA: NIC MAC LoopBackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

516-001-000 ELXUCNA: NIC PHY LoopBackTest Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

516-002-000 ELXUCNA: ELXUCNA: NIC LED(Beacon)Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

516-800-000 ELXUCNA: NIC MAC LoopBackTest Aborted

Explanation: Loopback testing at the MAC layer was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

516-801-000 ELXUCNA: NIC PHY LoopBackTest Aborted

Explanation: Loopback testing at the physical layer was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

516-802-000 ELXUCNA: ELXUCNA: NIC LED(Beacon)Test Aborted

Explanation: Verification of status LEDs was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

516-900-000 ELXUCNA: NIC MAC LoopBackTest Failed

Explanation: A failure was detected during the loopback test at the MAC layer.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

516-901-000 ELXUCNA: NIC PHY LoopBackTest Failed

Explanation: A failure was detected during the loopback test at the physical layer.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

516-902-000 ELXUCNA: ELXUCNA: NIC LED(Beacon)Test Failed

Explanation: A failure was detected while verifying operation of the status LEDs.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA EXA port ping test results

The following messages are generated when you run the EXA port ping test.

401-000-000 EXA Port Ping Test Passed

Explanation: EXA Port Ping Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

401-801-000 EXA Port Ping Test Aborted

Explanation: EXA Port Ping Test Aborted. Unable to get device base address.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Remove power cables, wait for 45 seconds, reconnect and rerun the test.
2. Make sure that the scalability cable connections are as per specification.
3. Make sure that DSA and BIOS/uEFI are at the latest level.
4. If the problem remains, contact your technical-service representative.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

401-802-000 EXA Port Ping Test Aborted

Explanation: EXA Port Ping Test Aborted. Port connections may not be correct.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Remove power cables, wait for 45 seconds, reconnect and rerun the test.
2. Make sure that the scalability cable connections are as per specification.
3. Make sure that DSA and BIOS/uEFI are at the latest level.
4. If the problem remains, contact your technical-service representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

401-901-001 EXA Port Ping Test Failed

Explanation: EXA Port Ping Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Remove power cables, wait for 45 seconds, reconnect and rerun the test.
2. Make sure that the scalability cable connections are as per specification.
3. Check scalability cables for loose connections.
4. Replace the scalability cable(s) for specified port(s).
5. If the problem remains, contact your technical-service representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA hard drive test results

The following messages are generated when you run the hard drive test.

217-000-000 HDD Test Passed

Explanation: HDD Stress Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

217-800-000 HDD Test Aborted

Explanation: HDD Test Aborted. The test was canceled.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check cable connections.
2. Rerun the test.
3. Verify that Hard drive supports self test and self test logging.
4. If the problem remains, contact your technical-support representative.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

217-900-000 HDD Test Failed

Explanation: HDD Test Failed. The hard drive self-test detected a failure.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check cable connections.
2. Rerun the test.
3. Verify the firmware is at the latest level.
4. Rerun the test.
5. If the problem remains, contact your technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA Intel network test results

The following messages are generated when you run the Intel network test.

406-000-000 IANet:Registers Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

406-001-000 IANet:EEPROM Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

406-002-000 IANet:FIFO Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-003-000 IANet:Interrupts Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

406-004-000 IANet:Loopback Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

406-800-000 IANet:Registers Test Aborted

Explanation: Registers test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-801-000 IANet:EEPROM Test Aborted

Explanation: EEPROM test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-802-000 IANet:FIFO Test Aborted

Explanation: FIFO test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-803-000 IANet:Interrupts Test Aborted

Explanation: Interrupt test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-804-000 IANet:Loopback Test Aborted

Explanation: Loopback test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

406-900-000 IANet:Registers Test Failed

Explanation: A failure was detected during the Registers test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

406-901-000 IANet:EEPROM Test Failed

Explanation: A failure was detected during the EEPROM test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-902-000 IANet:FIFO Test Failed

Explanation: A failure was detected during the FIFO test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-903-000 IANet:Interrupts Test Failed

Explanation: A failure was detected during the Interrupt test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
2. Rerun the test.
3. Check interrupt assignments in the PCI Hardware section of the DSA Diagnostic Log. If the ethernet device is sharing interrupts, if possible modify the interrupt assignments using F1 Setup to assign a unique interrupt to the device.
4. Rerun the test.
5. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

406-904-000 IANet:Loopback Test Failed

Explanation: A failure was detected during the Loopback test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check the Ethernet cable for damage and ensure correct cable type and attachment.
2. Check component firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
3. Rerun the test.
4. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

DSA LSI hard drive test results

The following messages are generated when you run the LSI hard drive test.

407-000-000 LSIESG:DiskDefaultDiagnostic Test Passed

Explanation: The test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

407-800-000 LSIESG:DiskDefaultDiagnostic Test Aborted

Explanation: The test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

407-900-000 LSIESG:DiskDefaultDiagnostic Test Failed

Explanation: The hard drive self-test detected a failure.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check cable connections.
2. Rerun the test.
3. Verify whether the firmware is at the latest level.
4. Rerun the test.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA Mellanox adapter test results

The following messages are generated when you run the Mellanox adapter test.

408-000-000 MLNX:MLNX_DiagnosticTestEthernetPort Test Passed

Explanation: Port Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

408-001-000 MLNX:MLNX_DiagnosticTestIBPort Test Passed

Explanation: Port Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

408-800-000 MLNX:MLNX_DiagnosticTestEthernetPort Test Aborted

Explanation: Port Test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

408-801-000 MLNX:MLNX_DiagnosticTestIBPort Test Aborted

Explanation: Port Test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

408-900-000 MLNX:MLNX_DiagnosticTestEthernetPort Test Failed

Explanation: Port Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Make sure that the physical link of the port under test in the active state.
2. If these condition was met but the test keeps failing the port's adapter might be faulty.
3. Try replacing the adapter and repeating the test.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

408-901-000 MLNX:MLNX_DiagnosticTestIBPort Test Failed

Explanation: Port Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Make sure that the physical link of the port under test in the active state and a subnet manager running on the fabric to which the port is attached.
2. If these condition was met but the test keeps failing the port's adapter might be faulty.
3. Try replacing the adapter and repeating the test.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA memory isolation test results

The following messages are generated when you run the memory isolation test.

201-000-000 Standalone Memory Test Passed

Explanation: Quick/Full Memory Test All CPUs Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-000-001 Standalone Memory Test Passed

Explanation: Quick/Full Memory Test CPU 1 Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-000-002 Standalone Memory Test Passed

Explanation: Quick/Full Memory Test CPU 2 Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-000-003 Standalone Memory Test Passed

Explanation: Quick/Full Memory Test CPU 3 Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-000-004 Standalone Memory Test Passed

Explanation: Quick/Full Memory Test CPU 4 Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-811-000 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-811-001 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-811-002 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-811-003 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-812-000 Standalone Memory Test Aborted

Explanation: Memory test is not supported for this system.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-812-001 Standalone Memory Test Aborted

Explanation: Memory test is not supported for this system.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-812-002 Standalone Memory Test Aborted

Explanation: Memory test is not supported for this system.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-812-003 Standalone Memory Test Aborted

Explanation: Memory test is not supported for this system.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-813-000 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not turn OFF ECC error reporting in CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-813-001 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not turn OFF ECC error reporting in CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-813-002 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not turn OFF ECC error reporting in CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-813-003 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not turn OFF ECC error reporting in CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-814-000 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not disable Scubbing feature for CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-814-001 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not disable Scubbing feature for CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-814-002 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not disable Scubbing feature for CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-814-003 Standalone Memory Test Aborted

Explanation: Chipset Error: Can not disable Scubbing feature for CPU.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-815-000 Standalone Memory Test Aborted

Explanation: Program Error with Quick Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-815-001 Standalone Memory Test Aborted

Explanation: Program Error with Quick Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-815-002 Standalone Memory Test Aborted

Explanation: Program Error with Quick Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-815-003 Standalone Memory Test Aborted

Explanation: Program Error with Quick Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-816-000 Standalone Memory Test Aborted

Explanation: Program Error with Full Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-816-001 Standalone Memory Test Aborted

Explanation: Program Error with Full Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-816-002 Standalone Memory Test Aborted

Explanation: Program Error with Full Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-816-003 Standalone Memory Test Aborted

Explanation: Program Error with Full Memory Menu Option Selection.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-818-000 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-818-001 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-818-002 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-818-003 Standalone Memory Test Aborted

Explanation: Unable to Locate SMBIOS key "_SM_".

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-819-000 Standalone Memory Test Aborted

Explanation: The start-end address ranges in the restricted area of the memory.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-819-001 Standalone Memory Test Aborted

Explanation: The start-end address ranges in the restricted area of the memory.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-819-002 Standalone Memory Test Aborted

Explanation: The start-end address ranges in the restricted area of the memory.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-819-003 Standalone Memory Test Aborted

Explanation: The start-end address ranges in the restricted area of the memory.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-820-000 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-820-001 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-820-002 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-820-003 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-821-000 Standalone Memory Test Aborted

Explanation: Variable range MTRR registers are larger than fixed range MTRR registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-821-001 Standalone Memory Test Aborted

Explanation: Variable range MTRR registers are larger than fixed range MTRR registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-821-002 Standalone Memory Test Aborted

Explanation: Variable range MTRR registers are larger than fixed range MTRR registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-821-003 Standalone Memory Test Aborted

Explanation: Variable range MTRR registers are larger than fixed range MTRR registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-822-000 Standalone Memory Test Aborted

Explanation: Invalid MTRR service request.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-822-001 Standalone Memory Test Aborted

Explanation: Invalid MTRR service request.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-822-002 Standalone Memory Test Aborted

Explanation: Invalid MTRR service request.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-822-003 Standalone Memory Test Aborted

Explanation: Invalid MTRR service request.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-824-000 Standalone Memory Test Aborted

Explanation: Node Interleave feature must be OFF. Go to Setup and disable Node Interleave option and then re-run the test.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-824-001 Standalone Memory Test Aborted

Explanation: Node Interleave feature must be OFF. Go to Setup and disable Node Interleave option and then re-run the test.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-824-002 Standalone Memory Test Aborted

Explanation: Node Interleave feature must be OFF. Go to Setup and disable Node Interleave option and then re-run the test.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-824-003 Standalone Memory Test Aborted

Explanation: Node Interleave feature must be OFF. Go to Setup and disable Node Interleave option and then re-run the test.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-826-000 Standalone Memory Test Aborted

Explanation: BIOS: Memory Controller has been disabled. Go to Setup and Enable Memory Controller.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-826-001 Standalone Memory Test Aborted

Explanation: BIOS: Memory Controller has been disabled. Go to Setup and Enable Memory Controller.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-826-002 Standalone Memory Test Aborted

Explanation: BIOS: Memory Controller has been disabled. Go to Setup and Enable Memory Controller.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-826-003 Standalone Memory Test Aborted

Explanation: BIOS: Memory Controller has been disabled. Go to Setup and Enable Memory Controller.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-827-000 Standalone Memory Test Aborted

Explanation: BIOS: ECC function has been disabled by BIOS. Go to Setup and enable ECC generation.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-827-001 Standalone Memory Test Aborted

Explanation: BIOS: ECC function has been disabled by BIOS. Go to Setup and enable ECC generation.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-827-002 Standalone Memory Test Aborted

Explanation: BIOS: ECC function has been disabled by BIOS. Go to Setup and enable ECC generation.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-827-003 Standalone Memory Test Aborted

Explanation: BIOS: ECC function has been disabled by BIOS. Go to Setup and enable ECC generation.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-844-000 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem in masking MSR machine check control MASK registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-844-001 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem in masking MSR machine check control MASK registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-844-002 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem in masking MSR machine check control MASK registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-844-003 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem in masking MSR machine check control MASK registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-845-000 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem clearing MSR machine check control registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-845-001 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem clearing MSR machine check control registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-845-002 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem clearing MSR machine check control registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-845-003 Standalone Memory Test Aborted

Explanation: Chipset Error: Problem clearing MSR machine check control registers.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-859-000 Standalone Memory Test Aborted

Explanation: INVALID XSECSRAT type.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-859-001 Standalone Memory Test Aborted

Explanation: INVALID XSECSRAT type.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-859-002 Standalone Memory Test Aborted

Explanation: INVALID XSECSRAT type.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-859-003 Standalone Memory Test Aborted

Explanation: INVALID XSECSRAT type.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-860-000 Standalone Memory Test Aborted

Explanation: No OEM0 type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-860-001 Standalone Memory Test Aborted

Explanation: No OEM0 type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-860-002 Standalone Memory Test Aborted

Explanation: No OEM0 type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-860-003 Standalone Memory Test Aborted

Explanation: No OEM0 type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-861-000 Standalone Memory Test Aborted

Explanation: No SRAT type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-861-001 Standalone Memory Test Aborted

Explanation: No SRAT type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-861-002 Standalone Memory Test Aborted

Explanation: No SRAT type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-861-003 Standalone Memory Test Aborted

Explanation: No SRAT type 1 found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-862-000 Standalone Memory Test Aborted

Explanation: No OEM1 structure found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-862-001 Standalone Memory Test Aborted

Explanation: No OEM1 structure found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-862-002 Standalone Memory Test Aborted

Explanation: No OEM1 structure found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-862-003 Standalone Memory Test Aborted

Explanation: No OEM1 structure found.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-863-000 Standalone Memory Test Aborted

Explanation: No IBMERROR key in OEM1 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-863-001 Standalone Memory Test Aborted

Explanation: No IBMERROR key in OEM1 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-863-002 Standalone Memory Test Aborted

Explanation: No IBMERROR key in OEM1 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-863-003 Standalone Memory Test Aborted

Explanation: No IBMERROR key in OEM1 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-864-000 Standalone Memory Test Aborted

Explanation: No GAS located in OEM1.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-864-001 Standalone Memory Test Aborted

Explanation: No GAS located in OEM1.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-864-002 Standalone Memory Test Aborted

Explanation: No GAS located in OEM1.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-864-003 Standalone Memory Test Aborted

Explanation: No GAS located in OEM1.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-865-000 Standalone Memory Test Aborted

Explanation: No XSECSRAT key in OEM0 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-865-001 Standalone Memory Test Aborted

Explanation: No XSECSRAT key in OEM0 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-865-002 Standalone Memory Test Aborted

Explanation: No XSECSRAT key in OEM0 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-865-003 Standalone Memory Test Aborted

Explanation: No XSECSRAT key in OEM0 structure.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-866-000 Standalone Memory Test Aborted

Explanation: EFI-SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-866-001 Standalone Memory Test Aborted

Explanation: EFI-SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-866-002 Standalone Memory Test Aborted

Explanation: EFI-SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-866-003 Standalone Memory Test Aborted

Explanation: EFI-SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-867-000 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer not allocated.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-867-001 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer not allocated.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-867-002 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer not allocated.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-867-003 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer not allocated.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-868-000 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer allocated in GetMemoryMap too small.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-868-001 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer allocated in GetMemoryMap too small.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-868-002 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer allocated in GetMemoryMap too small.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-868-003 Standalone Memory Test Aborted

Explanation: EFI/SAL: Buffer allocated in GetMemoryMap too small.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-869-000 Standalone Memory Test Aborted

Explanation: EFI/SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-869-001 Standalone Memory Test Aborted

Explanation: EFI/SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-869-002 Standalone Memory Test Aborted

Explanation: EFI/SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-869-003 Standalone Memory Test Aborted

Explanation: EFI/SAL Invalid parameter from GetMemoryMap function.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-870-000 Standalone Memory Test Aborted

Explanation: CPU Doamin in ACPI not valid.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-870-001 Standalone Memory Test Aborted

Explanation: CPU Doamin in ACPI not valid.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-870-002 Standalone Memory Test Aborted

Explanation: CPU Doamin in ACPI not valid.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-870-003 Standalone Memory Test Aborted

Explanation: CPU Doamin in ACPI not valid.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-871-000 Standalone Memory Test Aborted

Explanation: Data Mis-compare encountered.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-871-001 Standalone Memory Test Aborted

Explanation: Data Mis-compare encountered.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-871-002 Standalone Memory Test Aborted

Explanation: Data Mis-compare encountered.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-871-003 Standalone Memory Test Aborted

Explanation: Data Mis-compare encountered.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-877-000 Standalone Memory Test Aborted

Explanation: BIOS: Sparing in Extended PCI reg. must be OFF. Go to setup and disable sparing.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-877-001 Standalone Memory Test Aborted

Explanation: BIOS: Sparing in Extended PCI reg. must be OFF. Go to setup and disable sparing.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-877-002 Standalone Memory Test Aborted

Explanation: BIOS: Sparing in Extended PCI reg. must be OFF. Go to setup and disable sparing.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-877-003 Standalone Memory Test Aborted

Explanation: BIOS: Sparing in Extended PCI reg. must be OFF. Go to setup and disable sparing.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-878-000 Standalone Memory Test Aborted

Explanation: Sparing feature must be turned OFF. Go to setup and turn the sparing feature OFF.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-878-001 Standalone Memory Test Aborted

Explanation: Sparing feature must be turned OFF. Go to setup and turn the sparing feature OFF.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-878-002 Standalone Memory Test Aborted

Explanation: Sparing feature must be turned OFF. Go to setup and turn the sparing feature OFF.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-878-003 Standalone Memory Test Aborted

Explanation: Sparing feature must be turned OFF. Go to setup and turn the sparing feature OFF.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-885-000 Standalone Memory Test Aborted

Explanation: Processor does not support MTRR register manipulation. Can not write to memory without cache.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-885-001 Standalone Memory Test Aborted

Explanation: Processor does not support MTRR register manipulation. Can not write to memory without cache.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-885-002 Standalone Memory Test Aborted

Explanation: Processor does not support MTRR register manipulation. Can not write to memory without cache.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-885-003 Standalone Memory Test Aborted

Explanation: Processor does not support MTRR register manipulation. Can not write to memory without cache.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-886-000 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-886-001 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-886-002 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-886-003 Standalone Memory Test Aborted

Explanation: Memory Upper limit is less than 16 Mbytes.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-899-000 Standalone Memory Test Aborted

Explanation: Memory Diagnostics Test Aborted by user.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-899-001 Standalone Memory Test Aborted

Explanation: Memory Diagnostics Test Aborted by user.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-899-002 Standalone Memory Test Aborted

Explanation: Memory Diagnostics Test Aborted by user.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-899-003 Standalone Memory Test Aborted

Explanation: Memory Diagnostics Test Aborted by user.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

201-901-000 Standalone Memory Test Failed

Explanation: Memory Diagnostics Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.
5. Replace any DIMMS(s) mentioned in error, one by one.
6. Make sure that all DIMMs are enabled in the Configuration/Setup Utility program.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-901-001 Standalone Memory Test Failed

Explanation: Memory Diagnostics Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.
5. Replace any DIMMS(s) mentioned in error, one by one.
6. Make sure that all DIMMs are enabled in the Configuration/Setup Utility program.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-901-002 Standalone Memory Test Failed

Explanation: Memory Diagnostics Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.
5. Replace any DIMMS(s) mentioned in error, one by one.
6. Make sure that all DIMMs are enabled in the Configuration/Setup Utility program.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

201-901-003 Standalone Memory Test Failed

Explanation: Memory Diagnostics Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Perform the actions mentioned one at a time and try the test after each action.
2. If the problem remains, contact your technical-service representative.
3. Turn off the system and disconnect it from power. Wait for 45 seconds. Reseat DIMM(s). Reconnect it to power.
4. Make sure that DSA and BIOS/uEFI are at the latest level.
5. Replace any DIMMS(s) mentioned in error, one by one.
6. Make sure that all DIMMs are enabled in the Configuration/Setup Utility program.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA memory stress test results

The following messages are generated when you run the memory stress test.

202-000-000 MemStr Test Passed

Explanation: Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

202-801-000 MemStr Test Aborted

Explanation: Internal program error.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Turn off and restart the system.
2. Make sure that the DSA Diagnostic code is at the latest level.
3. Run the test again.
4. If the system has stopped responding, turn off and restart the system.
5. Check the system firmware level and upgrade if necessary.
6. Run the memory diagnostic to identify the specific failing DIMM.
7. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

202-802-000 MemStr Test Aborted

Explanation: Memory size is insufficient to run the test. At least 1 GB is required.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

202-803-000 MemStr Test Aborted

Explanation: User pressed Ctrl-C.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

202-901-000 MemStr Test Failed

Explanation: Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Execute the standard DSA memory diagnostics to validate all memory.
2. Make sure that the DSA Diagnostic code is at the latest level.
3. Turn off the system and disconnect it from power.
4. Reseat the memory cards and DIMMs.
5. Reconnect the system to power and turn the system on.
6. Run the test again.
7. Execute the standard DSA memory diagnostics to validate all memory.
8. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

202-902-000 MemStr Test Failed

Explanation: Memory size is insufficient to run the test.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Ensure that all memory is enabled by checking the "Available System Memory" in the "Resource Utilization" section of the DSA Diagnostic Event log.
2. If necessary, access the Configuration/Setup Utility program by pressing F1 during system boot and enable all memory.
3. Make sure that the DSA Diagnostic code is at the latest level.
4. Run the test again.
5. Execute the standard DSA memory diagnostics to validate all memory.
6. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA Nvidia GPU test results

The following messages are generated when you run the Nvidia GPU test.

409-000-000 NVIDIA User Diagnostic Test Passed

Explanation: NVIDIA User Diagnostic test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-003-000 Nvidia::DiagnosticServiceProvider::Bandwidth Test Passed

Explanation: Nvidia GPU Bandwidth test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

409-004-000 Nvidia::DiagnosticServiceProvider::Query Test Passed

Explanation: Nvidia GPU Query test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

409-005-000 Nvidia::DiagnosticServiceProvider::Matrix Test Passed

Explanation: Nvidia GPU Matrix test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-006-000 Nvidia::DiagnosticServiceProvider::Binomial Test Passed

Explanation: Nvidia GPU Binomial test passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-800-000 NVIDIA User Diagnostic Test Aborted

Explanation: NVIDIA User Diagnostic test was canceled.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-803-000 Nvidia::DiagnosticServiceProvider::Bandwidth Test Aborted

Explanation: Nvidia GPU Bandwidth test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-804-000 Nvidia::DiagnosticServiceProvider::Query Test Aborted

Explanation: Nvidia GPU Query test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

409-805-000 Nvidia::DiagnosticServiceProvider::Matrix Test Aborted

Explanation: Nvidia GPU Matrix test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

409-806-000 Nvidia::DiagnosticServiceProvider::Binomial Test Aborted

Explanation: Nvidia GPU Binomial test was canceled.

Severity: Warning

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-900-000 NVIDIA User Diagnostic Test Failed

Explanation: NVIDIA User Diagnostic Test Failed.

Severity: Event

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Verify that the GPU is seated in the PCIe slot correctly by reseating the GPU. Then power cycle the system.
2. Verify that the power connectors to the GPU are connected firmly. Then power cycle the system.
3. Run `nvidia-smi -q` In some cases this will report a poorly connected power cable.
4. Rerun the diagnostics, using the same GPU, on system that is known to be working. A variety of system issues can cause diagnostic failure.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-903-000 Nvidia::DiagnosticServiceProvider::Bandwidth Test Failed

Explanation: Nvidia GPU Bandwidth Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Verify that the GPU is seated in the PCIe slot correctly by reseating the GPU. Then power cycle the system.
2. Verify that the power connectors to the GPU are connected firmly. Then power cycle the system.
3. Run `nvidia-smi -q` In some cases this will report a poorly connected power cable.
4. Rerun the diagnostics, using the same GPU, on system that is known to be working. A variety of system issues can cause diagnostic failure.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-904-000 Nvidia::DiagnosticServiceProvider::Query Test Failed

Explanation: Nvidia GPU Query Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Verify that the GPU is seated in the PCIe slot correctly by reseating the GPU. Then power cycle the system.
2. Verify that the power connectors to the GPU are connected firmly. Then power cycle the system.
3. Run `nvidia-smi -q` In some cases this will report a poorly connected power cable.
4. Rerun the diagnostics, using the same GPU, on system that is known to be working. A variety of system issues can cause diagnostic failure.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

409-905-000 Nvidia::DiagnosticServiceProvider::Matrix Test Failed

Explanation: Nvidia GPU Matrix Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Verify that the GPU is seated in the PCIe slot correctly by reseating the GPU. Then power cycle the system.
2. Verify that the power connectors to the GPU are connected firmly. Then power cycle the system.
3. Run `nvidia-smi -q` In some cases this will report a poorly connected power cable.
4. Rerun the diagnostics, using the same GPU, on system that is known to be working. A variety of system issues can cause diagnostic failure.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

409-906-000 Nvidia::DiagnosticServiceProvider::Binomial Test Failed

Explanation: Nvidia GPU Binomial Test Failed.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Verify that the GPU is seated in the PCIe slot correctly by reseating the GPU. Then power cycle the system.
2. Verify that the power connectors to the GPU are connected firmly. Then power cycle the system.
3. Run `nvidia-smi -q` In some cases this will report a poorly connected power cable.
4. Rerun the diagnostics, using the same GPU, on system that is known to be working. A variety of system issues can cause diagnostic failure.
5. If the problem remains, contact your IBM technical-support representative.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA optical drive test results

The following messages are generated when you run the optical drive test.

215-000-000 Optical Drive Test Passed

Explanation: Optical Drive Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

215-801-000 Optical Drive Test Aborted

Explanation: Optical Drive Test Aborted. Unable to communicate with driver.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Make sure that the DSA Diagnostic code is at the latest level.
2. Run the test again.
3. Check the drive cabling for loose or broken connections at both ends or damage to the cable. Replace the cable if damage is present.
4. Run the test again.
5. Check system firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
6. Run the test again.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

215-802-000 Optical Drive Test Aborted

Explanation: Optical Drive Test Aborted. A read error was encountered.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Insert a new CD or DVD into the drive and wait for 15 seconds for the media to be recognized. Rerun the test.
2. Check the drive cabling for loose or broken connections at both ends or damage to the cable. Replace the cable if damage is present.
3. Run the test again.
4. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

215-803-000 Optical Drive Test Failed

Explanation: Optical Drive Test Failed. Disk may be in use by the operating system.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Wait for the system activity to cease
2. Run the test again
3. Turn off and restart the system.
4. Run the test again.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

215-804-000 Optical Drive Test Aborted

Explanation: Optical Drive Test Aborted. The media tray is open.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Close the media tray and wait for 15 seconds for the media to be recognized. Run the test again.
2. Insert a new CD or DVD into the drive and wait for 15 seconds for the media to be recognized. Rerun the test.
3. Check the drive cabling for loose or broken connections at both ends or damage to the cable. Replace the cable if damage is present.
4. Run the test again.
5. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

215-901-000 Optical Drive Test Aborted

Explanation: Optical Drive Test Aborted. Drive media is not detected.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Insert a new CD or DVD into the drive and wait for 15 seconds for the media to be recognized. Rerun the test.
2. Check the drive cabling for loose or broken connections at both ends or damage to the cable. Replace the cable if damage is present.
3. Run the test again.
4. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

215-902-000 Optical Drive Test Failed

Explanation: Optical Drive Test Failed. Read miscompare.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Insert a new CD or DVD into the drive and wait for 15 seconds for the media to be recognized. Rerun the test.
2. Check the drive cabling for loose or broken connections at both ends or damage to the cable. Replace the cable if damage is present.
3. Run the test again.
4. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

215-903-000 Optical Drive Test Aborted

Explanation: Optical Drive Test Aborted. Could not access the device.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Insert a new CD or DVD into the drive and wait for 15 seconds for the media to be recognized. Rerun the test.
2. Check the drive cabling for loose or broken connections at both ends or damage to the cable. Replace the cable if damage is present.
3. Run the test again.
4. Check system firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
5. Run the test again.
6. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA system management test results

The following messages are generated when you run the system management test.

166-000-001 IMM I2C Test Passed

Explanation: IMM I2C Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-801-001 IMM I2C Test Aborted

Explanation: IMM returned incorrect response length.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-802-001 IMM I2C Test Aborted

Explanation: Test cannot be completed for unknown reason.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-803-001 IMM I2C Test Aborted

Explanation: Node Busy. Try later.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-804-001 IMM I2C Test Aborted

Explanation: Invalid Command.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-805-001 IMM I2C Test Aborted

Explanation: Invalid Command for given LUN.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-806-001 IMM I2C Test Aborted

Explanation: Timeout while processing command.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-807-001 IMM I2C Test Aborted

Explanation: Out of space.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-808-001 IMM I2C Test Aborted

Explanation: Reservation Canceled or Invalid Reservation ID.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-809-001 IMM I2C Test Aborted

Explanation: Request data truncated.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-810-001 IMM I2C Test Aborted

Explanation: Request data length invalid.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-811-001 IMM I2C Test Aborted

Explanation: Request data field length limit exceeded.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-812-001 IMM I2C Test Aborted

Explanation: Parameter out of range.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-813-001 IMM I2C Test Aborted

Explanation: Cannot return number of requested data bytes.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-814-001 IMM I2C Test Aborted

Explanation: Requested Sensor, data, or record not present.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-815-001 IMM I2C Test Aborted

Explanation: Invalid data field in Request.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-816-001 IMM I2C Test Aborted

Explanation: Command illegal for specified sensor or record type.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-817-001 IMM I2C Test Aborted

Explanation: Command response could not be provided.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-818-001 IMM I2C Test Aborted

Explanation: Cannot execute duplicated request.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-819-001 IMM I2C Test Aborted

Explanation: Command response could not be provided. SDR Repository in?update mode.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-820-001 IMM I2C Test Aborted

Explanation: Command response could not be provided. Device in firmware update mode.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-821-001 IMM I2C Test Aborted

Explanation: Command response could not be provided. BMC initialization in progress.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-822-001 IMM I2C Test Aborted

Explanation: Destination unavailable.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-823-001 IMM I2C Test Aborted

Explanation: Cannot execute command. Insufficient privilege level.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-824-001 IMM I2C Test Aborted

Explanation: Cannot execute command.

Severity: Warning

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-901-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in Host bus (BUS 0).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the CPU card.
4. Run the test again.
5. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-902-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in CPU, PCI, Lightpath bus (BUS 1).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat lightpath card.
4. Reseat PCI cards in slots.
5. Reseat PCIe/power card.
6. Reseat CPU(s).
7. Reseat CPU card.
8. Run the test again.
9. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-903-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in memory Bus (BUS 2).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat lightpath card.
4. Reseat PCI cards in slots.
5. Reseat PCIe/power card.
6. Reseat CPU(s).
7. Reseat CPU card.
8. Run the test again.
9. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-904-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in Power Supply bus (BUS 3).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat power supply backplane.
4. Reseat PCIe/power card.
5. Reseat the CPU card.
6. Run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-905-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in SAS bus (BUS 4).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the SAS Backplane.
4. Reseat the CPU card.
5. Run the test again.
6. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-906-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in the config bus (BUS 5).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat PCIe/power card.
4. Reseat the CPU card.
5. Run the test again.
6. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-909-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in the VPD bus (Memory Drawer BUS 0).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the Memory Drawer.
4. Reseat PCIe/power card.
5. Reseat the CPU card.
6. Run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-910-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in the Voltage Regulator bus (Memory Drawer BUS 1).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the Memory Drawer.
4. Reseat PCIe/power card.
5. Reseat the CPU card.
6. Run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-911-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in the Voltage Regulator bus (Memory Drawer BUS 2).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the Memory Drawer.
4. Reseat PCIe/power card.
5. Reseat the CPU card.
6. Run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

166-912-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in the Clock bus (Memory Drawer BUS 3).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the Memory Drawer.
4. Reseat PCIe/power card.
5. Reseat the CPU card.
6. Run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

166-913-001 IMM I2C Test Failed

Explanation: IMM Indicates failure in the Power Supply bus (Memory Drawer BUS 4).

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Perform the actions mentioned one at a time and try the test after each action:

1. Turn off the system and disconnect it from power. Wait for 45 seconds. Reconnect it to power.
2. Make sure that DSA and BMC/IMM are at the latest level.
3. Reseat the Memory Drawer.
4. Reseat PCIe/power card.
5. Reseat the CPU card.
6. Run the test again.
7. If failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

DSA tape drive test results

The following messages are generated when you run the tape drive test.

264-000-000 Tape Test Passed

Explanation: Tape Test Passed.

Severity: Event

Serviceable: No

Recoverable: No

Automatically notify Support: No

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

264-901-000 Tape Test Failed

Explanation: An error was found in the tape alert log.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Clean the tape drive using the appropriate cleaning media and install new media.
2. Run the test again.
3. Clear the error log.
4. Run the test again.
5. Make sure that the drive firmware is at the latest level.
6. Rerun the test after upgrading to the latest firmware level.
7. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

264-902-000 Tape Test Failed

Explanation: Tape Test Failed. Media is not detected.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Clean the tape drive using the appropriate cleaning media and install new media.
2. Run the test again.
3. Make sure that the drive firmware is at the latest level.
4. Rerun the test after upgrading to the latest firmware level.
5. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

264-903-000 Tape Test Failed

Explanation: Tape Test Failed. Media is not detected.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Clean the tape drive using the appropriate cleaning media and install new media.
2. Run the test again.
3. Make sure that the drive firmware is at the latest level.
4. Rerun the test after upgrading to the latest firmware level.
5. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

264-904-000 Tape Test Failed

Explanation: Tape Test Failed. Drive hardware error.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Check the tape drive cabling for loose or broken connections or damage to the cable. Replace the cable if damage is present.
2. Clean the tape drive using the appropriate cleaning media and install new media.
3. Run the test again.
4. Make sure that the drive firmware is at the latest level.
5. Rerun the test after upgrading to the latest firmware level.
6. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

264-905-000 Tape Test Failed

Explanation: Tape Test Failed. Software error: invalid request.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. If the system has stopped responding, turn off and restart the system.
2. Check the system firmware level and upgrade if necessary. The installed firmware level can be found in the DSA Diagnostic Event Log within the Firmware/VPD section for this component.
3. Run the test again.
4. If the system has stopped responding, turn off and restart the system.
5. Make sure that the drive firmware is at the latest level.
6. Run the test again.
7. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
 - Latest level of DSA
 - Latest level of BMC/IMM
-

264-906-000 Tape Test Failed

Explanation: Tape Test Failed. Unrecognized error.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Clean the tape drive using the appropriate cleaning media and install new media.
2. Run the test again.
3. Make sure that the drive firmware is at the latest level.
4. Rerun the test after upgrading to the latest firmware level.
5. Make sure that the DSA Diagnostic code is at the latest level.
6. Run the test again.
7. Check the system firmware level and upgrade if necessary.
8. Run the test again.
9. If the failure remains, refer to "Troubleshooting by symptom" in the system "Installation and Service Guide" for the next corrective action.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

264-907-000 Tape Test Failed

Explanation: An error was found in the block address somewhere.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Clean the tape drive using the appropriate cleaning media and install new media.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

264-908-000 Tape Test Failed

Explanation: An error was found in getting tape capacity.

Severity: Error

Serviceable: Yes

Recoverable: No

Automatically notify Support: No

User response: Complete the following steps:

1. Make sure that medium is present.
2. Clean the tape drive using the appropriate cleaning media and install new media.

Related Links:

- IBM Support Website
- Latest level of DSA
- Latest level of BMC/IMM

Appendix B. Integrated management module error messages

This topic provides descriptions of integrated management module error messages.

The IMM messages are displayed in the integrated management module (IMM) event log. You can view the IMM event log through the IMM Web interface and through IBM Dynamic System Analysis (as the ASM event log). For more information about IMM, see the *Integrated Management Module User's Guide* at <http://www.ibm.com/support/entry/portal/docdisplay?lnocid=MIGR-5079770>

IMM Events that automatically notify Support

You can configure the Integrated Management Module II (IMM2) to automatically notify Support (also known as *call home*) if certain types of errors are encountered. If you have configured this function, see the table for a list of events that automatically notify Support.

Table 25. Events that automatically notify Support

Event ID	Message String	Automatically Notify Support
80010202-0701ffff	Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.	Yes
80010202-2801ffff	Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.	Yes
80010902-0701ffff	Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted.	Yes
80010b03-1500ffff	Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has asserted.	Yes
80070608-2201ffff	Sensor [SensorElementName] has transitioned to non-recoverable.	Yes
806f0021-0b04ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes
806f0021-0b05ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes
806f0021-0b06ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes
806f0021-0b07ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes
806f0021-0b08ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes

Table 25. Events that automatically notify Support (continued)

Event ID	Message String	Automatically Notify Support
806f0021-2201ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes
806f0021-2582ffff	Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].	Yes
806f0108-0a01ffff	[PowerSupplyElementName] has Failed.	Yes
806f0108-0a02ffff	[PowerSupplyElementName] has Failed.	Yes
806f010c-2581ffff	Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].	Yes
806f010d-0400ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0401ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0402ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0403ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0404ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0405ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0406ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0407ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0408ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-0409ffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-040affff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-040bffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-040cffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-040dffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-040effff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f010d-040fffff	The Drive [StorageVolumeElementName] has been disabled due to a detected fault.	Yes
806f011b-0701ffff	The connector [PhysicalConnectorElementName] has encountered a configuration error.	Yes

Table 25. Events that automatically notify Support (continued)

Event ID	Message String	Automatically Notify Support
806f0207-0301ffff	[ProcessorElementName] has Failed with FRB1/BIST condition.	Yes
806f0207-0302ffff	[ProcessorElementName] has Failed with FRB1/BIST condition.	Yes
806f0207-0303ffff	[ProcessorElementName] has Failed with FRB1/BIST condition.	Yes
806f0207-0304ffff	[ProcessorElementName] has Failed with FRB1/BIST condition.	Yes
806f020d-0400ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0401ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0402ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0403ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0404ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0405ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0406ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0407ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0408ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-0409ffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-040affff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-040bffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-040cffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes

Table 25. Events that automatically notify Support (continued)

Event ID	Message String	Automatically Notify Support
806f020d-040dffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-040effff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f020d-040fffff	Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].	Yes
806f050c-2581ffff	Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].	Yes
806f060d-0400ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0401ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0402ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0403ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0404ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0405ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0406ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0407ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0408ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-0409ffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-040affff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-040bffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-040cffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-040dffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-040effff	Array in system [ComputerSystemElementName] has failed.	Yes
806f060d-040fffff	Array in system [ComputerSystemElementName] has failed.	Yes
806f0813-2581ffff	A Uncorrectable Bus Error has occurred on system [ComputerSystemElementName].	Yes

Table 25. Events that automatically notify Support (continued)

Event ID	Message String	Automatically Notify Support
806f0813-2582ffff	A Uncorrectable Bus Error has occurred on system [ComputerSystemElementName].	Yes

40000001-00000000 Management Controller [arg1] Network Initialization Complete.

Explanation: The IMM network subsystem initialization has completed.

May also be shown as 4000000100000000 or 0x4000000100000000

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: IMM and ID: 0001

SNMP Trap ID: 37

Automatically notify Support: No

User response: Information only; no action is required.

40000002-00000000 Certificate Authority [arg1] has detected a [arg2] Certificate Error.

Explanation: A problem has occurred with the SSL Server, SSL Client, or SSL Trusted CA certificate that has been imported into the IMM. The imported certificate must contain a public key that corresponds to the key pair that was previously generated by the **Generate a New Key and Certificate Signing Request** link.

May also be shown as 4000000200000000 or 0x4000000200000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0002

SNMP Trap ID:

Automatically notify Support: No

User response: Make sure that the certificate that you are importing is correct and properly generated.

40000003-00000000 Ethernet Data Rate modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the Ethernet data rate of the Integrated Management Module external network interface to the specified value.

May also be shown as 4000000300000000 or 0x4000000300000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0003

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000004-00000000 • 40000006-00000000

40000004-00000000 Ethernet Duplex setting modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the Ethernet duplex setting of the Integrated Management Module external network interface to the specified value.

May also be shown as 4000000400000000 or 0x4000000400000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0004

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000005-00000000 Ethernet MTU setting modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the Ethernet maximum transmission unit (MTU) setting of the Integrated Management Module external network interface to the specified value.

May also be shown as 4000000500000000 or 0x4000000500000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0005

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000006-00000000 Ethernet locally administered MAC address modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the Ethernet locally administered MAC address of the Integrated Management Module external network interface to the specified value

May also be shown as 4000000600000000 or 0x4000000600000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0006

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000007-00000000 Ethernet interface [arg1] by user [arg2].

Explanation: The specified user has enabled or disabled the Ethernet interface.

May also be shown as 4000000700000000 or 0x4000000700000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0007

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000008-00000000 Hostname set to [arg1] by user [arg2].

Explanation: The specified user has changed the Integrated Management Module host name.

May also be shown as 4000000800000000 or 0x4000000800000000

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: IMM and ID: 0008

SNMP Trap ID: 37

Automatically notify Support: No

User response: Information only; no action is required.

40000009-00000000 IP address of network interface modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the IP address of the Integrated Management Module external network interface to the specified value.

May also be shown as 4000000900000000 or 0x4000000900000000

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: IMM and ID: 0009

SNMP Trap ID: 37

Automatically notify Support: No

User response: Information only; no action is required.

4000000a-00000000 • 4000000c-00000000

4000000a-00000000 IP subnet mask of network interface modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the subnet mask of the Integrated Management Module external network interface to the specified value.

May also be shown as 4000000a00000000 or 0x4000000a00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0010

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000000b-00000000 IP address of default gateway modified from [arg1] to [arg2] by user [arg3].

Explanation: The specified user has changed the gateway address of the Integrated Management Module external network interface to the specified value.

May also be shown as 4000000b00000000 or 0x4000000b00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0011

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000000c-00000000 OS Watchdog response [arg1] by [arg2] .

Explanation: This message is for the use case where an OS Watchdog has been enabled or disabled by a user.

May also be shown as 4000000c00000000 or 0x4000000c00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0012

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000000d-00000000 DHCP[[arg1]] failure, no IP address assigned.

Explanation: A DHCP server has failed to assign an IP address to the IMM.

May also be shown as 4000000d00000000 or 0x4000000d00000000

Severity: Warning

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0013

SNMP Trap ID:

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Make sure that the IMM network cable is connected.
2. Make sure that there is a DHCP server on the network that can assign an IP address to the IMM.

4000000e-00000000 Remote Login Successful. Login ID: [arg1] from [arg2] at IP address [arg3].

Explanation: The specified user has logged in to the Integrated Management Module.

May also be shown as 4000000e00000000 or 0x4000000e00000000

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: IMM and ID: 0014

SNMP Trap ID: 30

Automatically notify Support: No

User response: Information only; no action is required.

4000000f-00000000 Attempting to [arg1] server [arg2] by user [arg3].

Explanation: This message is for the use case where a user is using the Management Controller to perform a power function on the system.

May also be shown as 4000000f00000000 or 0x4000000f00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0015

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000010-00000000 • 40000012-00000000

40000010-00000000 Security: Userid: [arg1] had [arg2] login failures from WEB client at IP address [arg3].

Explanation: A user has exceeded the maximum allowed number of unsuccessful login attempts from a web browser and has been prevented from logging in for the lockout period.

May also be shown as 4000001000000000 or 0x4000001000000000

Severity: Warning

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0016

SNMP Trap ID: 30

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Make sure that the correct login ID and password are being used.
2. Have the system administrator reset the login ID or password.

40000011-00000000 Security: Login ID: [arg1] had [arg2] login failures from CLI at [arg3].

Explanation: A user has exceeded the maximum allowed number of unsuccessful login attempts from the command-line interface and has been prevented from logging in for the lockout period.

May also be shown as 4000001100000000 or 0x4000001100000000

Severity: Warning

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0017

SNMP Trap ID: 30

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Make sure that the correct login ID and password are being used.
2. Have the system administrator reset the login ID or password.

40000012-00000000 Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from WEB browser at IP address [arg2].

Explanation: A user has attempted to log in from a web browser by using an invalid login ID or password.

May also be shown as 4000001200000000 or 0x4000001200000000

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0018

SNMP Trap ID: 30

Automatically notify Support: No

User response: Make sure that the correct login ID and password are being used.

40000013-00000000 Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from TELNET client at IP address [arg2].

Explanation: A user has attempted to log in from a Telnet session by using an invalid login ID or password.

May also be shown as 4000001300000000 or 0x4000001300000000

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0019

SNMP Trap ID: 30

Automatically notify Support: No

User response: Make sure that the correct login ID and password are being used.

40000014-00000000 The [arg1] on system [arg2] cleared by user [arg3].

Explanation: The specified user has deleted system log events or audit log events.

May also be shown as 4000001400000000 or 0x4000001400000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0020

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000015-00000000 Management Controller [arg1] reset was initiated by user [arg2].

Explanation: The Integrated Management Module has been reset. The logs provide additional details.

May also be shown as 4000001500000000 or 0x4000001500000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0021

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000016-00000000 • 40000018-00000000

40000016-00000000 ENET[[arg1]] DHCP-HSTN=[arg2], DN=[arg3], IP@[arg4], SN=[arg5], GW@[arg6], DNS1@[arg7] .

Explanation: The DHCP server has assigned an IMM IP address and configuration.

May also be shown as 4000001600000000 or 0x4000001600000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0022

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000017-00000000 ENET[[arg1]] IP-Cfg:HstName=[arg2], IP@[arg3] ,NetMsk=[arg4], GW@[arg5] .

Explanation: An IMM IP address and configuration have been assigned using client data.

May also be shown as 4000001700000000 or 0x4000001700000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0023

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000018-00000000 LAN: Ethernet[[arg1]] interface is no longer active.

Explanation: The IMM Ethernet interface has been disabled.

May also be shown as 4000001800000000 or 0x4000001800000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0024

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000019-00000000 LAN: Ethernet[[arg1]] interface is now active.

Explanation: The IMM Ethernet interface has been enabled.

May also be shown as 4000001900000000 or 0x4000001900000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0025

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000001a-00000000 DHCP setting changed to [arg1] by user [arg2].

Explanation: The specified user has changed the DHCP setting of the Integrated Management Module external network interface.

May also be shown as 4000001a00000000 or 0x4000001a00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0026

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000001b-00000000 Management Controller [arg1]: Configuration restored from a file by user [arg2].

Explanation: The specified user has restored the Integrated Management Module (IMM) configuration from a previously saved configuration file. Some configuration settings might require that the IMM be restarted before they take effect.

May also be shown as 4000001b00000000 or 0x4000001b00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0027

SNMP Trap ID:

Automatically notify Support: N

User response: Information only; no action is required.

4000001c-00000000 Watchdog [arg1] Screen Capture Occurred .

Explanation: An operating-system error has occurred, and the screen capture was successful.

May also be shown as 4000001c00000000 or 0x4000001c00000000

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: IMM and **ID:** 0028

SNMP Trap ID: 22

Automatically notify Support: No

User response: If there was no operating-system error, complete the following steps until the problem is solved:

1. Reconfigure the watchdog timer to a higher value.
2. Make sure that the IMM Ethernet-over-USB interface is enabled.
3. Reinstall the RNDIS or cdc_ether device driver for the operating system.
4. Disable the watchdog.

If there was an operating-system error, check the integrity of the installed operating system.

4000001d-00000000 Watchdog [arg1] Failed to Capture Screen.

Explanation: An operating-system error has occurred, and the screen capture failed.

May also be shown as 4000001d00000000 or 0x4000001d00000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and **ID:** 0029

SNMP Trap ID: 22

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Reconfigure the watchdog timer to a higher value.
2. Make sure that the IMM Ethernet over USB interface is enabled.
3. Reinstall the RNDIS or cdc_ether device driver for the operating system.
4. Disable the watchdog.
5. Check the integrity of the installed operating system.
6. Update the IMM firmware. **Important:** Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

4000001e-00000000 Running the backup Management Controller [arg1] main application.

Explanation: The IMM was unable to run the primary IMM image and has resorted to running the backup image.

May also be shown as 4000001e00000000 or 0x4000001e00000000

Severity: Warning

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0030

SNMP Trap ID: 22

Automatically notify Support: No

User response: Update the IMM firmware. **Important:** Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

4000001f-00000000 Please ensure that the Management Controller [arg1] is flashed with the correct firmware. The Management Controller is unable to match its firmware to the server.

Explanation: The server does not support the installed IMM firmware version.

May also be shown as 4000001f00000000 or 0x4000001f00000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0031

SNMP Trap ID: 22

Automatically notify Support: No

User response: Update the IMM firmware to a version that the server supports. **Important:** Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

40000020-00000000 Management Controller [arg1] Reset was caused by restoring default values.

Explanation: The default configuration has been restored to the Integrated Management Module.

May also be shown as 4000002000000000 or 0x4000002000000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0032

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000021-00000000 • 40000023-00000000

40000021-00000000 Management Controller [arg1] clock has been set from NTP server [arg2].

Explanation: The IMM clock has been set to the date and time that are provided by the Network Time Protocol server.

May also be shown as 4000002100000000 or 0x4000002100000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0033

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000022-00000000 SSL data in the Management Controller [arg1] configuration data is invalid. Clearing configuration data region and disabling SSL.

Explanation: There is a problem with the certificate that has been imported into the IMM. The imported certificate must contain a public key that corresponds to the key pair that was previously generated through the "Generate a New Key and Certificate Signing Request" link.

May also be shown as 4000002200000000 or 0x4000002200000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0034

SNMP Trap ID: 22

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Make sure that the certificate that you are importing is correct.
 2. Try to import the certificate again.
-

40000023-00000000 Flash of [arg1] from [arg2] succeeded for user [arg3] .

Explanation: The specified firmware update has been completed.

May also be shown as 4000002300000000 or 0x4000002300000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0035

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000024-00000000 Flash of [arg1] from [arg2] failed for user [arg3].

Explanation: The specified firmware has not been updated.

May also be shown as 4000002400000000 or 0x4000002400000000

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0036

SNMP Trap ID: 22

Automatically notify Support: No

User response: Information only; no action is required.

40000025-00000000 The [arg1] on system [arg2] is 75% full.

Explanation: The IMM event log is 75% full. When the event log is completely full, the new entries will overwrite the oldest entries. To avoid losing older log entries, save the log as a text file and clear the log.

May also be shown as 4000002500000000 or 0x4000002500000000

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: IMM and ID: 0037

SNMP Trap ID: 35

Automatically notify Support: No

User response: Information only; no action is required.

40000026-00000000 The [arg1] on system [arg2] is 100% full.

Explanation: The IMM event log is full. New entries in the log will overwrite the oldest entries. To avoid losing older log entries, save the log as a text file and clear the log.

May also be shown as 4000002600000000 or 0x4000002600000000

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0038

SNMP Trap ID: 22

Automatically notify Support: No

User response: To avoid losing older log entries, save the log as a text file and clear the log.

40000027-00000000 • 40000029-00000000

40000027-00000000 Platform Watchdog Timer expired for [arg1].

Explanation: A “Platform Watchdog Timer Expired” event has occurred.

May also be shown as 4000002700000000 or 0x4000002700000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0039

SNMP Trap ID: 21

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Reconfigure the watchdog timer to a higher value.
 2. Make sure that the IMM Ethernet-over-USB interface is enabled.
 3. Reinstall the RNDIS or cdc_ether device driver for the operating system.
 4. Disable the watchdog.
 5. Check the integrity of the installed operating system.
-

40000028-00000000 Management Controller Test Alert Generated by [arg1].

Explanation: The Integrated Management Module has sent a test message to help verify connectivity.

May also be shown as 4000002800000000 or 0x4000002800000000

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: IMM and ID: 0040

SNMP Trap ID: 22

Automatically notify Support: No

User response: Information only; no action is required.

40000029-00000000 Security: Userid: [arg1] had [arg2] login failures from an SSH client at IP address [arg3].

Explanation: A user has exceeded the maximum number of unsuccessful login attempts from SSH and has been prevented from logging in for the lockout period.

May also be shown as 4000002900000000 or 0x4000002900000000

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0041

SNMP Trap ID: 30

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Make sure that the correct login ID and password are being used.
2. Have the system administrator reset the login ID or password.

4000002a-00000000 [arg1] firmware mismatch internal to system [arg2]. Please attempt to flash the [arg3] firmware.

Explanation: A specific type of firmware mismatch has been detected.

May also be shown as 4000002a00000000 or 0x4000002a00000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0042

SNMP Trap ID: 22

Automatically notify Support: No

User response: Reflash the IMM firmware to the latest version.

4000002b-00000000 Domain name set to [arg1].

Explanation: Domain name set by user

May also be shown as 4000002b00000000 or 0x4000002b00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0043

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000002c-00000000 Domain Source changed to [arg1] by user [arg2].

Explanation: Domain source changed by user

May also be shown as 4000002c00000000 or 0x4000002c00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0044

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000002d-00000000 • 4000002f-00000000

4000002d-00000000 DDNS setting changed to [arg1] by user [arg2].

Explanation: DDNS setting changed by user

May also be shown as 4000002d00000000 or 0x4000002d00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0045

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000002e-00000000 DDNS registration successful. The domain name is [arg1].

Explanation: The DDNS registration was successful.

May also be shown as 4000002e00000000 or 0x4000002e00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0046

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000002f-00000000 IPv6 enabled by user [arg1] .

Explanation: The specified user has enabled IPv6 support on the Integrated Management Module.

May also be shown as 4000002f00000000 or 0x4000002f00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0047

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000030-00000000 IPv6 disabled by user [arg1] .

Explanation: The specified user has disabled IPv6 support on the Integrated Management Module.

May also be shown as 4000003000000000 or 0x4000003000000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0048

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000031-00000000 IPv6 static IP configuration enabled by user [arg1].

Explanation: The specified user has enabled IPv6 static address assignment on the Integrated Management Module.

May also be shown as 4000003100000000 or 0x4000003100000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0049

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000032-00000000 IPv6 DHCP enabled by user [arg1].

Explanation: The specified user has enabled DHCPv6 on the Integrated Management Module.

May also be shown as 4000003200000000 or 0x4000003200000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0050

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000033-00000000 • 40000035-00000000

40000033-00000000 IPv6 stateless auto-configuration enabled by user [arg1].

Explanation: IPv6 stateless address auto-configuration has been enabled on the Integrated Management Module by the specified user.

May also be shown as 4000003300000000 or 0x4000003300000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0051

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000034-00000000 IPv6 static IP configuration disabled by user [arg1].

Explanation: The specified user has disabled IPv6 static address assignment on the Integrated Management Module.

May also be shown as 4000003400000000 or 0x4000003400000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0052

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000035-00000000 IPv6 DHCP disabled by user [arg1].

Explanation: The specified user has disabled DHCPv6 on the Integrated Management Module.

May also be shown as 4000003500000000 or 0x4000003500000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0053

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000036-00000000 IPv6 stateless auto-configuration disabled by user [arg1].

Explanation: IPv6 stateless address auto-configuration has been disabled on the Integrated Management Module by the specified user.

May also be shown as 4000003600000000 or 0x4000003600000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0054

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000037-00000000 ENET[[arg1]] IPv6-LinkLocal:HstName=[arg2], IP@[arg3] ,Pref=[arg4] .

Explanation: The IPv6 link-local address is active.

May also be shown as 4000003700000000 or 0x4000003700000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0055

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000038-00000000 ENET[[arg1]] IPv6-Static:HstName=[arg2], IP@[arg3] ,Pref=[arg4], GW@[arg5] .

Explanation: The IPv6 static address is active.

May also be shown as 4000003800000000 or 0x4000003800000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0056

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

40000039-00000000 • 4000003b-00000000

40000039-00000000 ENET[[arg1]] DHCPv6-HSTN=[arg2], DN=[arg3], IP@[arg4], Pref=[arg5].

Explanation: The IPv6 DHCP-assigned address is active.

May also be shown as 4000003900000000 or 0x4000003900000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0057

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000003a-00000000 IPv6 static address of network interface modified from [arg1] to [arg2] by user [arg3].

Explanation: A user modifies the IPv6 static address of a Management Controller

May also be shown as 4000003a00000000 or 0x4000003a00000000

Severity: Info

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0058

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

4000003b-00000000

Explanation: The DHCPv6 server has failed to assign an IP address to a management controller.

May also be shown as 4000003b00000000 or 0x4000003b00000000

Severity: Warning

Alert Category: none

Serviceable: No

CIM Information: Prefix: IMM and ID: 0059

SNMP Trap ID:

Automatically notify Support: No

User response: Complete the following steps until the problem is solved:

1. Make sure that the IMM network cable is connected.
2. Make sure that there is a DHCP6 server on the network that can assign an IP address to the IMM.

4000003c-00000000 Platform Watchdog Timer expired for [arg1].

Explanation: IMM has detected an OS did not start in the expected amount of time.

May also be shown as 4000003c00000000 or 0x4000003c00000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0060

SNMP Trap ID: 26

Automatically notify Support: No

User response:

1. Reconfigure the watchdog timer to a higher value.
2. Make sure that the IMM Ethernet over USB interface is enabled.
3. Reinstall the RNDIS or cdc_ether device driver for the operating system.
4. Disable the watchdog.
5. Check the integrity of the installed operating system

40000084-00000000 IMM firmware mismatch between nodes [arg1] and [arg2]. Please attempt to flash the IMM firmware to the same level on all nodes.

Explanation: A mismatch of IMM firmware between nodes has been detected.

May also be shown as 4000008400000000 or 0x4000008400000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0132

SNMP Trap ID: 22

Automatically notify Support: No

User response: Attempt to flash the IMM firmware to the same level on all nodes.

40000085-00000000 FPGA firmware mismatch between nodes [arg1] and [arg2]. Please attempt to flash the FPGA firmware to the same level on all nodes.

Explanation: A mismatch of FPGA firmware between nodes has been detected.

May also be shown as 4000008500000000 or 0x4000008500000000

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: IMM and ID: 0133

SNMP Trap ID: 22

Automatically notify Support: No

User response: Attempt to flash the FPGA firmware to the same level on all nodes.

80010002-2801ffff • 80010202-2801ffff

80010002-2801ffff Numeric sensor [NumericSensorElementName] going low (lower non-critical) has asserted.

Explanation: The CMOS battery voltage has dropped below its specified threshold.

May also be shown as 800100022801ffff or 0x800100022801ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0476

SNMP Trap ID: 13

Automatically notify Support: No

User response: Replace the CMOS battery.

80010202-0701ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: A Voltage has dropped below its specified threshold (sensor Planar 12V, Planar 3.3V, or Planar 5V).

May also be shown as 800102020701ffff or 0x800102020701ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 1

Automatically notify Support: Yes

User response:

- (Trained service technician only) If the specified sensor is Planar 3.3V or Planar 5V, replace the I/O board.
 - If the specified sensor is Planar 12V, check the IMM event log for power-supply-related issues, and resolve those issues. If the problem remains, (trained service technician only) replace the I/O board.
-

80010202-2801ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: The CMOS battery voltage has dropped below its specified threshold.

May also be shown as 800102022801ffff or 0x800102022801ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 1

Automatically notify Support: Yes

User response: Replace the CMOS battery.

80010204-1d01ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of Fan 1 (Fan 1A Tach or Fan 1B Tach) has gone low.

May also be shown as 800102041d01ffff or 0x800102041d01ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d02ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of Fan 2 (Fan 2A Tach or Fan 2B Tach) has gone low.

May also be shown as 800102041d02ffff or 0x800102041d02ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d03ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of Fan 3 (Fan 3A Tach or Fan 3B Tach) has gone low.

May also be shown as 800102041d03ffff or 0x800102041d03ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d04ffff • 80010204-1d06ffff

80010204-1d04ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of Fan 4 (Fan 4A Tach or Fan 4B Tach) has gone low.

May also be shown as 800102041d04ffff or 0x800102041d04ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d05ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of Fan 5 (Fan 5A Tach or Fan 5B Tach) has gone low.

May also be shown as 800102041d05ffff or 0x800102041d05ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d06ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of MEU Fan 1 has gone low.

May also be shown as 800102041d06ffff or 0x800102041d06ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d07ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of MEU Fan 2 has gone low.

May also be shown as 800102041d07ffff or 0x800102041d07ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d08ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of MEU Fan 3 has gone low.

May also be shown as 800102041d08ffff or 0x800102041d08ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d09ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of MEU Fan 4 has gone low.

May also be shown as 800102041d09ffff or 0x800102041d09ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010204-1d0affff • 80010701-1801ffff

80010204-1d0affff Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.

Explanation: IMM has detected the speed of a Fan (MEU Fan 5 Tach) has gone low.

May also be shown as 800102041d0affff or 0x800102041d0affff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0480

SNMP Trap ID: 11

Automatically notify Support: No

User response:

- Reseat the failing fan indicated by the lit LED on the fan.
- Replace Fan.

80010701-0c01ffff Numeric sensor [NumericSensorElementName] going high (upper non-critical) has asserted.

Explanation: An upper non-critical sensor going high has asserted.

May also be shown as 800107010c01ffff or 0x800107010c01ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0490

SNMP Trap ID: 12

Automatically notify Support: No

User response: No action, warning of increased temperature.

80010701-1801ffff Numeric sensor [NumericSensorElementName] going high (upper non-critical) has asserted.

Explanation: An upper non-critical sensor going high has asserted.

May also be shown as 800107011801ffff or 0x800107011801ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0490

SNMP Trap ID: 12

Automatically notify Support: No

User response: No action, warning of increased temperature.

80010703-1500ffff Numeric sensor [NumericSensorElementName] going high (upper non-critical) has asserted.

Explanation: An upper non-critical current sensor going high has asserted.

May also be shown as 800107031500ffff or 0x800107031500ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0490

SNMP Trap ID: 164

Automatically notify Support: No

User response: No action, warning of increased temperature.

80010901-0c01ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted.

Explanation: An upper critical sensor going high has asserted.

May also be shown as 800109010c01ffff or 0x800109010c01ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0494

SNMP Trap ID: 0

Automatically notify Support: No

User response: Reduce the ambient temperature.

80010901-1801ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted.

Explanation: An upper critical sensor going high has asserted.

May also be shown as 800109011801ffff or 0x800109011801ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0494

SNMP Trap ID: 0

Automatically notify Support: No

User response: Reduce the ambient temperature.

80010902-0701ffff • 80010b01-0c01ffff

80010902-0701ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted.

Explanation: A voltage has risen above its specified threshold (sensor Planar 12V, Planar 3.3V, or Planar 5V).

May also be shown as 800109020701ffff or 0x800109020701ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0494

SNMP Trap ID: 1

Automatically notify Support: Yes

User response:

- (Trained service technician only) If the specified sensor is Planar 3.3V or Planar 5V, replace the I/O board.
- If the specified sensor is Planar 12V, check the IMM Web event log for power-supply-related issues, and resolve those issues.: If the problem remains, (trained service technician only) replace the I/O board.

80010903-1500ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted.

Explanation: A current has risen above its specified threshold.

May also be shown as 800109031500ffff or 0x800109031500ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0494

SNMP Trap ID: 4

Automatically notify Support: No

User response: Check the IMM Web event log for power-supply-related issues, and resolve those issues. If the problem remains, (trained service technician only) replace the I/O board.

80010b01-0c01ffff Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has asserted.

Explanation: An upper non-recoverable sensor going high has asserted.

May also be shown as 80010b010c01ffff or 0x80010b010c01ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0498

SNMP Trap ID: 0

Automatically notify Support: No

User response: Reduce the ambient temperature.

80010b01-1801ffff Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has asserted.

Explanation: An upper non-recoverable sensor going high has asserted.

May also be shown as 80010b011801ffff or 0x80010b011801ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0498

SNMP Trap ID: 0

Automatically notify Support: No

User response: Reduce the ambient temperature.

80010b03-1500ffff Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has asserted.

Explanation: An upper non-recoverable current sensor going high has asserted.

May also be shown as 80010b031500ffff or 0x80010b031500ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0498

SNMP Trap ID: 4

Automatically notify Support: Yes

User response: Replace the power supply.

80030108-1381ffff Sensor [SensorElementName] has asserted.

Explanation: AC restore has asserted

May also be shown as 800301081381ffff or 0x800301081381ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-1881ffff • 8003010c-2582ffff

8003010c-1881ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel on the memory expansion module has occurred.

May also be shown as 8003010c1881ffff or 0x8003010c1881ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2581ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 1 has occurred.

May also be shown as 8003010c2581ffff or 0x8003010c2581ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2582ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 2 has occurred.

May also be shown as 8003010c2582ffff or 0x8003010c2582ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2583ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 3 has occurred.

May also be shown as 8003010c2583ffff or 0x8003010c2583ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2584ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 4 has occurred.

May also be shown as 8003010c2584ffff or 0x8003010c2584ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2585ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 5 has occurred.

May also be shown as 8003010c2585ffff or 0x8003010c2585ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2586ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 6 has occurred.

May also be shown as 8003010c2586ffff or 0x8003010c2586ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2587ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 7 has occurred.

May also be shown as 8003010c2587ffff or 0x8003010c2587ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010c-2588ffff Sensor [SensorElementName] has asserted.

Explanation: Lane failover on SMI lane Channel 8 has occurred.

May also be shown as 8003010c2588ffff or 0x8003010c2588ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8003010e-0701ffff Sensor [SensorElementName] has asserted.

Explanation: A memory resize has occurred.

May also be shown as 8003010e0701ffff or 0x8003010e0701ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0508

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80070201-0301ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a CPU 1 temperature Sensor has transitioned to critical.

May also be shown as 800702010301ffff or 0x800702010301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
 2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
 3. Make sure that the room temperature is within operating specifications.
-

80070201-0302ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a CPU 2 temperature Sensor has transitioned to critical.

May also be shown as 800702010302ffff or 0x800702010302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

80070201-0303ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a CPU 3 temperature Sensor has transitioned to critical.

May also be shown as 800702010303ffff or 0x800702010303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

80070201-0304ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a CPU 4 temperature Sensor has transitioned to critical.

May also be shown as 800702010304ffff or 0x800702010304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

80070201-0a01ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a PS 1 temperature Sensor has transitioned to critical.

May also be shown as 800702010a01ffff or 0x800702010a01ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

80070201-0a02ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a PS 2 temperature Sensor has transitioned to critical.

May also be shown as 800702010a02ffff or 0x800702010a02ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

80070201-1881ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: IMM has detected a MEU PS temperature Sensor has transitioned to critical.

May also be shown as 800702011881ffff or 0x800702011881ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

80070201-1e83ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: An internal system element has reached an over-temperature state.

May also be shown as 800702011e83ffff or 0x800702011e83ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check for and correct any system fan errors.
2. Make sure all server air passages are clear of debris or dust.
3. (Trained service technician only) Replace the I/O board.

80070202-0701ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: The Planar Fault sensor has detected a problem with the system board.

May also be shown as 800702020701ffff or 0x800702020701ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 1

Automatically notify Support: No

User response: Complete the following steps:

1. Remove any recently installed components.
2. Try to power on the node.
 - If the node successfully powers on, complete the following steps:

- a. Check the ServerProven website to make sure that recently installed components are compatible with the compute node.
 - b. Inspect the previously installed components for physical damage.
- If the node does not successfully power on or if this is not the first occurrence of this problem, (trained service technician only) replace the system board.

80070202-1881ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: Memory expansion module votage failure.

May also be shown as 800702021881ffff or 0x800702021881ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 1

Automatically notify Support: No

User response:

1. Check the memory expansion module LEDs.
2. Check the system-event log.
3. Replace the memory expansion module main board.

80070204-1881ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: Memory expansion module fan failure.

May also be shown as 800702041881ffff or 0x800702041881ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 11

Automatically notify Support: No

User response:

1. Check the memory expansion module LEDs.
2. Check the system-event log.
3. Replace the failed fan in memory expansion module.

80070208-1881ffff Sensor [SensorElementName] has transitioned to critical from a less severe state.

Explanation: Memory expansion module power failure.

May also be shown as 800702081881ffff or 0x800702081881ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0522

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Check the memory expansion module LEDs.
2. Check the system-event log.
3. Replace the failed power unit in memory expansion module.

80070301-0301ffff Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.

Explanation: IMM has detected that the temperature for CPU 1 has transitioned to a non recoverable state.

May also be shown as 800703010301ffff or 0x800703010301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0524

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 1 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 1 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 1.

80070301-0302ffff Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.

Explanation: IMM has detected that the temperature for CPU 2 has transitioned to a non recoverable state.

May also be shown as 800703010302ffff or 0x800703010302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0524

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 2 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 2 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 2.

80070301-0303ffff Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.

Explanation: IMM has detected that the temperature for CPU 3 has transitioned to a non recoverable state.

May also be shown as 800703010303ffff or 0x800703010303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0524

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 3 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 3 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 3.

80070301-0304ffff • 80070301-1e83ffff

80070301-0304ffff Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.

Explanation: IMM has detected that the temperature for CPU 4 has transitioned to a non recoverable state.

May also be shown as 800703010304ffff or 0x800703010304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0524

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 4 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 4 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 4.

80070301-1e83ffff Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.

Explanation: An internal system element has reached an over-temperature state.

May also be shown as 800703011e83ffff or 0x800703011e83ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0524

SNMP Trap ID: 0

Automatically notify Support: No

User response:

1. Check for and correct any system fan errors.
2. Make sure all server air passages are clear of debris or dust.
3. (Trained service technician only) Replace the I/O board.

80070603-0701ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A sensor (Pwr Rail A/B/C/D/E/F/G/H Fault) has transitioned to non-recoverable state.

May also be shown as 800706030701ffff or 0x800706030701ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and **ID:** 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:7
5. -(Trained service technician only) Replace the I/O board assembly
6. 4. If the Checkpoint display repeatedly blinks F:A then 6:8
7. - (Trained service technician only) Replace the CPU board
8. 5. If the Checkpoint display repeatedly blinks F:A then 6:9
9. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-0a01ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: Memory expansion module power supply 1 error detected.

May also be shown as 800706080a01ffff or 0x800706080a01ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Check memory expansion module LEDs.
2. Check memory expansion module power supply 1 LEDs.
3. Replace the memory expansion module power supply 1.

80070608-0a02ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: IMM has detected Power Supply related fault. (PS 12V OC Fault, PS 12V OV Fault, PS 12V UV Fault, or PS AUX UV Fault)

May also be shown as 800706080a02ffff or 0x800706080a02ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Check the power supply LEDs, see "Power-supply LEDs".
2. Replace the failing power supply.

80070608-1401ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081401ffff or 0x800706081401ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.
8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.

16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]
23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.
30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1402ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081402ffff or 0x800706081402ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.

8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.
16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]
23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.
30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1403ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081403ffff or 0x800706081403ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.
8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.
16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]
23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.

80070608-1404ffff

30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1404ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081404ffff or 0x800706081404ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.
8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.
16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]

23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.
30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1405ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081405ffff or 0x800706081405ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.
8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.

80070608-1406ffff

16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]
23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.
30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1406ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081406ffff or 0x800706081406ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.

8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.
16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]
23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.
30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1407ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081407ffff or 0x800706081407ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.
8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.
16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]
23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.

30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1408ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081408ffff or 0x800706081408ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle. Do so only when instructed to in the following steps.
2. 1. Using the IMM web interface, determine the version of FPGA installed and capture an IMM log for support reference.
3. Perform the following actions for the FPGA version installed.
4. [FPGA versions lower than 4.00]
5. 2. Remove AC power.
6. 3. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
7. a) Replace affected commodity if damage is found.
8. 4. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
9. 5. Restart the server and see if problem still identifies the same memory card slot.
10. a) If problem remains with original slot, replace the I/O board assembly.
11. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
12. [FPGA versions 4.00 and 4.01]
13. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
14. 3. Using the IMM web interface, capture a 'Service Data' file if available (note:) for support reference.
15. 4. Remove AC power.
16. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
17. a) Replace affected commodity if damage is found.
18. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
19. 7. Restart the server and see if problem still identifies the same memory card slot.
20. a) If problem remains with original slot, replace the I/O board assembly.
21. b) If problem occurs in slot where original memory card was moved to, replace the memory card.
22. [FPGA version 5.01]

80070608-1409ffff • 80070608-140affff

23. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
24. 3. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
25. 4. (Trained service technician only) Replace the CPU board, I/O board assembly and memory card identified.
26. [FPGA version 5.02]
27. 2. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
28. 3. Using the IMM web interface, capture a 'Service Data' file for support reference.
29. 4. Remove AC power.
30. 5. Remove memory card identified and check for connector pin damage on memory card and CPU memory card slot.
31. a) Replace affected commodity if damage is found.
32. 6. Swap the memory card in the slot identified, with a memory card from another slot with the same configuration of DIMMs (size, type, number)
33. 7. Restart the server and see if problem still identifies the same memory card slot.
34. a) If problem remains with original slot, replace the I/O board assembly.
35. b) If problem occurs in slot where original memory card was moved to, replace the memory card.

80070608-1409ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A fault has occurred on a memory card.

May also be shown as 800706081409ffff or 0x800706081409ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: Replace any memory card that is indicated by a lit error LED.

80070608-140affff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A CPU VRD failure has occurred.

May also be shown as 80070608140affff or 0x80070608140affff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:8.
5. - (Trained service technician only) Replace the CPU board

6. 4. If the Checkpoint display repeatedly blinks F:A then 6:9
7. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-140bffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A CPU VRD failure has occurred.

May also be shown as 80070608140bffff or 0x80070608140bffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:8.
5. - (Trained service technician only) Replace the CPU board
6. 4. If the Checkpoint display repeatedly blinks F:A then 6:9
7. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-140cffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A CPU VRD failure has occurred.

May also be shown as 80070608140cffff or 0x80070608140cffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:8.
5. - (Trained service technician only) Replace the CPU board
6. 4. If the Checkpoint display repeatedly blinks F:A then 6:9
7. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-140dffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A CPU VRD failure has occurred.

May also be shown as 80070608140dffff or 0x80070608140dffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:8.
5. - (Trained service technician only) Replace the CPU board
6. 4. If the Checkpoint display repeatedly blinks F:A then 6:9
7. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-140effff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A CPU 1 2 VIO fault has occurred.

May also be shown as 80070608140effff or 0x80070608140effff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:8
5. - (Trained service technician only) Replace the CPU board
6. 4. If the Checkpoint display repeatedly blinks F:A then 6:9
7. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-140fffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A CPU 3 4 VIO fault has occurred.

May also be shown as 80070608140fffff or 0x80070608140fffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Critical: Do Not attempt to power the system on, or AC cycle.
2. 1. If local, pull out the Operator Information Panel, observe and make note of what is being displayed on the Checkpoint display for support reference.
3. 2. Using the IMM web interface, capture a 'Service Data' file (note:) for support reference.
4. 3. If the Checkpoint display repeatedly blinks F:A then 6:8
5. - (Trained service technician only) Replace the CPU board
6. 4. If the Checkpoint display repeatedly blinks F:A then 6:9
7. - (Trained service technician only) Replace the CPU board and I/O board assembly

80070608-1410ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081410ffff or 0x800706081410ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: (Trained service technician only) Replace the I/O-board shuttle.

80070608-1411ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081411ffff or 0x800706081411ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: (Trained service technician only) Replace the CPU board.

80070608-1412ffff • 80070608-1414ffff

80070608-1412ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081412ffff or 0x800706081412ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: (Trained service technician only) Replace the I/O-board shuttle.

80070608-1413ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A fault has occurred on the I/O board.

May also be shown as 800706081413ffff or 0x800706081413ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: (Trained service technician only) Replace the I/O-board shuttle.

80070608-1414ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081414ffff or 0x800706081414ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: (Trained service technician only) Replace the CPU board.

80070608-1415ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: A system power fault has occurred.

May also be shown as 800706081415ffff or 0x800706081415ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response: (Trained service technician only) Replace the CPU board.

80070608-1881ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: IMM has detected MEU Power Supply related fault. (PS 12V OC Fault, PS 12V OV Fault, PS 12V UV Fault, or PS AUX UV Fault)

May also be shown as 800706081881ffff or 0x800706081881ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Check MEU power supply LEDs, see "Power-supply LEDs".
 2. Replace the failing power supply.
-

80070608-2201ffff Sensor [SensorElementName] has transitioned to non-recoverable.

Explanation: System power on is blocked due to an over-current issue.

May also be shown as 800706082201ffff or 0x800706082201ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0530

SNMP Trap ID: 4

Automatically notify Support: Yes

User response:

1. Check the checkpoint value (for example, F/A:6:9) displayed in light path.
2. (Trained service technician only) Replace the CPU board or I/O board according to the checkpoint value.

80080004-1d01ffff Device [LogicalDeviceElementName] has been removed from unit
[PhysicalPackageElementName].

Explanation: Device Fan 1 has been removed.

May also be shown as 800800041d01ffff or 0x800800041d01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d02ffff Device [LogicalDeviceElementName] has been removed from unit
[PhysicalPackageElementName].

Explanation: Device Fan 2 has been removed.

May also be shown as 800800041d02ffff or 0x800800041d02ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d03ffff Device [LogicalDeviceElementName] has been removed from unit
[PhysicalPackageElementName].

Explanation: Device Fan 3 has been removed.

May also be shown as 800800041d03ffff or 0x800800041d03ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d04ffff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device Fan 4 has been removed.

May also be shown as 800800041d04ffff or 0x800800041d04ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d05ffff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device Fan 5 has been removed.

May also be shown as 800800041d05ffff or 0x800800041d05ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d06ffff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device MEU Fan 1 has been removed.

May also be shown as 800800041d06ffff or 0x800800041d06ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d07ffff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device MEU Fan 2 has been removed.

May also be shown as 800800041d07ffff or 0x800800041d07ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d08ffff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device MEU Fan 3 has been removed.

May also be shown as 800800041d08ffff or 0x800800041d08ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d09ffff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device MEU Fan 4 has been removed.

May also be shown as 800800041d09ffff or 0x800800041d09ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

80080004-1d0affff Device [LogicalDeviceElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Device MEU Fan 5 has been removed.

May also be shown as 800800041d0affff or 0x800800041d0affff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0537

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

800b0008-1381ffff Redundancy [RedundancySetElementName] has been restored.

Explanation: Power supple redundancy was Restored

May also be shown as 800b00081381ffff or 0x800b00081381ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0561

SNMP Trap ID: 10

Automatically notify Support: No

User response: No action; information only.

800b0008-1382ffff Redundancy [RedundancySetElementName] has been restored.

Explanation: MEU power supple redundancy was Restored

May also be shown as 800b00081382ffff or 0x800b00081382ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0561

SNMP Trap ID: 10

Automatically notify Support: No

User response: No action; information only.

800b0108-1381ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: Power Supply Redundancy has been lost.

May also be shown as 800b01081381ffff or 0x800b01081381ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 9

Automatically notify Support: No

User response:

1. Power Unit :Check if Power Supply is missing, unplugged.
2. Check the power supply LEDs, see "Power-supply LEDs"
3. Replace the affected power supply.

800b0108-1382ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: MEU Power Supply Redundancy has been lost.

May also be shown as 800b01081382ffff or 0x800b01081382ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 9

Automatically notify Support: No

User response:

1. Power Unit :Check if Power Supply is missing, unplugged.
2. Check the power supply LEDs, see "Power-supply LEDs"
3. Replace the affected power supply.

800b010a-1e81ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: Fan Redundancy has been lost.

May also be shown as 800b010a1e81ffff or 0x800b010a1e81ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 1

800b010a-1e82ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: Fan Redundancy has been lost.

May also be shown as 800b010a1e82ffff or 0x800b010a1e82ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 2

800b010a-1e83ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: Fan Redundancy has been lost.

May also be shown as 800b010a1e83ffff or 0x800b010a1e83ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 3

800b010a-1e84ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: Fan Redundancy has been lost.

May also be shown as 800b010a1e84ffff or 0x800b010a1e84ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 4

800b010c-2581ffff Redundancy Lost for [RedundancySetElementName] has asserted.

Explanation: Backup Memory Redundancy has been lost.

May also be shown as 800b010c2581ffff or 0x800b010c2581ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0802

SNMP Trap ID: 41

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

800b0208-1381ffff Redundancy Degraded for [RedundancySetElementName] has asserted.

Explanation: Power unit is no longer in the redundant state.

May also be shown as 800b02081381ffff or 0x800b02081381ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0804

SNMP Trap ID: 10

Automatically notify Support: No

User response:

1. Check if Power Supply is missing, unplugged.
 2. Check the power supply LEDs, see "Power-supply LEDs"
 3. Replace the affected power supply.
-

800b0308-1382ffff Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has asserted.

Explanation: MEU Power unit is no longer in the redundant state.

May also be shown as 800b03081382ffff or 0x800b03081382ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0806

SNMP Trap ID: 10

Automatically notify Support: No

User response:

1. Check if Power Supply is missing, unplugged.
2. Check the power supply LEDs, see "Power-supply LEDs"
3. Replace the affected power supply.

800b030c-2581ffff Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has asserted.

Explanation: Backup Memory has transitioned from Redundancy Degraded or Fully Redundant to Non-redundant:Sufficient.

May also be shown as 800b030c2581ffff or 0x800b030c2581ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0806

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Check the system-event log for DIMM failure events (uncorrectable or PFA) and correct the failures.
2. Re-enable mirroring in the Setup utility.

800b050a-1e81ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted.

Explanation: Insufficient cooling provided by fan 1.

May also be shown as 800b050a1e81ffff or 0x800b050a1e81ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0810

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 1

800b050a-1e82ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted.

Explanation: Insufficient cooling provided by fan 2.

May also be shown as 800b050a1e82ffff or 0x800b050a1e82ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0810

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan2

800b050a-1e83ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted.

Explanation: Insufficient cooling provided by fan 3.

May also be shown as 800b050a1e83ffff or 0x800b050a1e83ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: **Prefix:** PLAT and **ID:** 0810

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 3

800b050a-1e84ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted.

Explanation: Insufficient cooling provided by fan 4.

May also be shown as 800b050a1e84ffff or 0x800b050a1e84ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: **Prefix:** PLAT and **ID:** 0810

SNMP Trap ID: 11

Automatically notify Support: No

User response: Replace Fan 4

800b050c-2581ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted.

Explanation: Backup Memory Sensor has transitioned to Non-redundant:Insufficient Resources.

May also be shown as 800b050c2581ffff or 0x800b050c2581ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: **Prefix:** PLAT and **ID:** 0810

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Check the system-event log for DIMM failure events (uncorrectable or PFA) and correct the failures.
2. Re-enable mirroring in the Setup utility.

806f0007-0301ffff [ProcessorElementName] has Failed with IERR.

Explanation: IMM has detected processor 1 failed - IERR condition.

May also be shown as 806f00070301ffff or 0x806f00070301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0042

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Make sure that the latest levels of firmware and device drivers are installed for all adapters and standard devices, such as Ethernet, SCSI, and SAS. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
2. Run the DSA program for the hard disk drives and other I/O devices.
3. (Trained service technician only) Replace microprocessor 1.

806f0007-0302ffff [ProcessorElementName] has Failed with IERR.

Explanation: IMM has detected processor 2 failed - IERR condition.

May also be shown as 806f00070302ffff or 0x806f00070302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0042

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Make sure that the latest levels of firmware and device drivers are installed for all adapters and standard devices, such as Ethernet, SCSI, and SAS. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
2. Run the DSA program for the hard disk drives and other I/O devices.
3. (Trained service technician only) Replace microprocessor 2.

806f0007-0303ffff [ProcessorElementName] has Failed with IERR.

Explanation: IMM has detected processor 3 failed - IERR condition.

May also be shown as 806f00070303ffff or 0x806f00070303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0042

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Make sure that the latest levels of firmware and device drivers are installed for all adapters and standard devices, such as Ethernet, SCSI, and SAS. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
2. Run the DSA program for the hard disk drives and other I/O devices.
3. (Trained service technician only) Replace microprocessor 3.

806f0007-0304ffff [ProcessorElementName] has Failed with IERR.

Explanation: IMM has detected processor 4 failed - IERR condition.

May also be shown as 806f00070304ffff or 0x806f00070304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0042

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Make sure that the latest levels of firmware and device drivers are installed for all adapters and standard devices, such as Ethernet, SCSI, and SAS. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
2. Run the DSA program for the hard disk drives and other I/O devices.
3. (Trained service technician only) Replace microprocessor 4.

806f0008-0a01ffff [PowerSupplyElementName] has been added to container [PhysicalPackageElementName].

Explanation: IMM has detected a Power Supply has been added.

May also be shown as 806f00080a01ffff or 0x806f00080a01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0084

SNMP Trap ID:

Automatically notify Support: No

User response: Power Supply 1 :Information only; no action is required.

806f0008-0a02ffff [PowerSupplyElementName] has been added to container [PhysicalPackageElementName].

Explanation: IMM has detected a Power Supply has been added.

May also be shown as 806f00080a02ffff or 0x806f00080a02ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0084

SNMP Trap ID:

Automatically notify Support: No

User response: Power Supply 2 :Information only; no action is required.

806f0008-1881ffff [PowerSupplyElementName] has been added to container [PhysicalPackageElementName].

Explanation: MEU Power supple has been added.

May also be shown as 806f00081881ffff or 0x806f00081881ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0084

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0009-1381ffff • 806f000d-0401ffff

806f0009-1381ffff [PowerSupplyElementName] has been turned off.

Explanation: IMM has detected that the system power has been turned off.

May also be shown as 806f00091381ffff or 0x806f00091381ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0106

SNMP Trap ID: 23

Automatically notify Support: No

User response: Host Power :Information only; no action is required.

806f000d-0400ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 0 has been installed.

May also be shown as 806f000d0400ffff or 0x806f000d0400ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0401ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 1 has been installed.

May also be shown as 806f000d0401ffff or 0x806f000d0401ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0402ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 2 has been installed.

May also be shown as 806f000d0402ffff or 0x806f000d0402ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0403ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 3 has been installed.

May also be shown as 806f000d0403ffff or 0x806f000d0403ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0404ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 4 has been installed.

May also be shown as 806f000d0404ffff or 0x806f000d0404ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0405ffff • 806f000d-0407ffff

806f000d-0405ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 5 has been installed.

May also be shown as 806f000d0405ffff or 0x806f000d0405ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0406ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 6 has been installed.

May also be shown as 806f000d0406ffff or 0x806f000d0406ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0407ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 7 has been installed.

May also be shown as 806f000d0407ffff or 0x806f000d0407ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0408ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 8 has been installed.

May also be shown as 806f000d0408ffff or 0x806f000d0408ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-0409ffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 9 has been installed.

May also be shown as 806f000d0409ffff or 0x806f000d0409ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-040affff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 10 has been installed.

May also be shown as 806f000d040affff or 0x806f000d040affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-040bffff • 806f000d-040dffff

806f000d-040bffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 11 has been installed.

May also be shown as 806f000d040bffff or 0x806f000d040bffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-040cffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 12 has been installed.

May also be shown as 806f000d040cffff or 0x806f000d040cffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-040dffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 13 has been installed.

May also be shown as 806f000d040dffff or 0x806f000d040dffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-040effff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 14 has been installed.

May also be shown as 806f000d040effff or 0x806f000d040effff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000d-040fffff The Drive [StorageVolumeElementName] has been added.

Explanation: Hard drive 15 has been installed.

May also be shown as 806f000d040fffff or 0x806f000d040fffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0162

SNMP Trap ID: 5

Automatically notify Support: No

User response: Information only; no action is required.

806f000f-220101ff The System [ComputerSystemElementName] has detected no memory in the system.

Explanation: IMM has detected that there is no memory in the system.

May also be shown as 806f000f220101ff or 0x806f000f220101ff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0794

SNMP Trap ID: 41

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-220102ff • 806f000f-220104ff

806f000f-220102ff Subsystem [MemoryElementName] has insufficient memory for operation.

Explanation: IMM has detected that the usable Memory is insufficient for operation. (ABR Status, Firmware Error)

May also be shown as 806f000f220102ff or 0x806f000f220102ff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0132

SNMP Trap ID: 41

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-220103ff The System [ComputerSystemElementName] encountered firmware error - unrecoverable boot device failure.

Explanation: IMM has detected that system firmware error unrecoverable boot device failure has occurred. (ABR Status or Firmware Error)

May also be shown as 806f000f220103ff or 0x806f000f220103ff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0770

SNMP Trap ID: 5

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-220104ff The System [ComputerSystemElementName]has encountered a motherboard failure.

Explanation: IMM has detected a fatal motherboard error in the system.

May also be shown as 806f000f220104ff or 0x806f000f220104ff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0795

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-220107ff The System [ComputerSystemElementName] encountered firmware error - unrecoverable keyboard failure.

Explanation: IMM has detected that System Firmware Error Unrecoverable Keyboard failure has occurred.

May also be shown as 806f000f220107ff or 0x806f000f220107ff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0764

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-22010aff The System [ComputerSystemElementName] encountered firmware error - no video device detected.

Explanation: IMM has detected that System Firmware Error No video device detected has occurred.

May also be shown as 806f000f22010aff or 0x806f000f22010aff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0766

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-22010bff Firmware BIOS (ROM) corruption was detected on system [ComputerSystemElementName] during POST.

Explanation: Firmware BIOS (ROM) corruption was detected on the system during POST.

May also be shown as 806f000f22010bff or 0x806f000f22010bff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0850

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-22010cff CPU voltage mismatch detected on [ProcessorElementName].

Explanation: IMM has detected a CPU voltage mismatch with the CPU socket voltage.

May also be shown as 806f000f22010cff or 0x806f000f22010cff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: **Prefix:** PLAT and **ID:** 0050

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f000f-2201ffff The System [ComputerSystemElementName] encountered a POST Error.

Explanation: IMM has detected a Post Error.

May also be shown as 806f000f2201ffff or 0x806f000f2201ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: **Prefix:** PLAT and **ID:** 0184

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Recover the UEFI firmware from the backup UEFI image.
 2. Update the UEFI firmware to the latest level.
 3. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
-

806f001b-1f07ffff The network port [ManagedElementName] has been connected.

Explanation: EXA Cable 1 is connected

May also be shown as 806f001b1f07ffff or 0x806f001b1f07ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0262

SNMP Trap ID: 60

Automatically notify Support: No

User response: Information only; no action is required.

806f001b-1f08ffff The network port [ManagedElementName] has been connected.

Explanation: EXA Cable 2 is connected

May also be shown as 806f001b1f08ffff or 0x806f001b1f08ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0262

SNMP Trap ID: 60

Automatically notify Support: No

User response: Information only; no action is required.

806f001b-1f09ffff The network port [ManagedElementName] has been connected.

Explanation: EXA Cable 3 is connected

May also be shown as 806f001b1f09ffff or 0x806f001b1f09ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0262

SNMP Trap ID: 60

Automatically notify Support: No

User response: Information only; no action is required.

806f001e-2201ffff No bootable media available for system [ComputerSystemElementName].

Explanation: No bootable media was found, retry limit has been reached.

May also be shown as 806f001e2201ffff or 0x806f001e2201ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0286

SNMP Trap ID:

Automatically notify Support: No

User response: Check all media in UEFI boot sequence, make sure at least one of them contains bootable program.

806f0021-0b04ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 1.

May also be shown as 806f00210b04ffff or 0x806f00210b04ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-0b05ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 2.

May also be shown as 806f00210b05ffff or 0x806f00210b05ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-0b06ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 3.

May also be shown as 806f00210b06ffff or 0x806f00210b06ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-0b07ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 4.

May also be shown as 806f00210b07ffff or 0x806f00210b07ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-0b08ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 5.

May also be shown as 806f00210b08ffff or 0x806f00210b08ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-0b09ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 6.

May also be shown as 806f00210b09ffff or 0x806f00210b09ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: No

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-0b0affff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault in PCIe slot 7.

May also be shown as 806f00210b0affff or 0x806f00210b0affff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: No

User response:

1. Check the I/O board LEDs.
2. Reseat the affected adapters.
3. Update the server and adapter firmware (UEFI and IMM).
4. Remove the adapter from the slot.
5. Replace the PCI Express adapter.

806f0021-2201ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected No Op ROM Space.

May also be shown as 806f00212201ffff or 0x806f00212201ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0021-2582ffff Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a fault in one of the PCI slots or the PCI bus without isolating the to a slot.

May also be shown as 806f00212582ffff or 0x806f00212582ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0330

SNMP Trap ID: 50

Automatically notify Support: Yes

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center

806f0023-2101ffff • 806f002b-2101ffff

for the appropriate user response.

806f0023-2101ffff Watchdog Timer expired for [WatchdogElementName].

Explanation: The IPMI Watchdog Timer has expired.

May also be shown as 806f00232101ffff or 0x806f00232101ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0368

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0028-2584ffff Sensor [SensorElementName] is unavailable or degraded on management system [ComputerSystemElementName].

Explanation: IMM was unable to communicate properly on an internet interface.

May also be shown as 806f00282584ffff or 0x806f00282584ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0398

SNMP Trap ID: 60

Automatically notify Support: No

User response:

1. Ensure the IMM is flashed to the latest level of firmware.
2. Collect DSA information and call service and support.

806f002b-2101ffff A hardware changeD occurred on system [ComputerSystemElementName].

Explanation: IMM detected a hardware change in a multi-node system.

May also be shown as 806f002b2101ffff or 0x806f002b2101ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0436

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0107-0301ffff An Over-Temperature Condition has been detected on [ProcessorElementName].

Explanation: The microprocessor 1 temperature has risen above the critical level, causing a hard shutdown of the node.

May also be shown as 806f01070301ffff or 0x806f01070301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0036

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 1 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 1 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 1.

806f0107-0302ffff An Over-Temperature Condition has been detected on [ProcessorElementName].

Explanation: The microprocessor 2 temperature has risen above the critical level, causing a hard shutdown of the node.

May also be shown as 806f01070302ffff or 0x806f01070302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0036

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 2 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 2 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 2.

806f0107-0303ffff An Over-Temperature Condition has been detected on [ProcessorElementName].

Explanation: The microprocessor 3 temperature has risen above the critical level, causing a hard shutdown of the node.

May also be shown as 806f01070303ffff or 0x806f01070303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0036

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 3 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 3 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 3.

806f0107-0304ffff An Over-Temperature Condition has been detected on [ProcessorElementName].

Explanation: The microprocessor 4 temperature has risen above the critical level, causing a hard shutdown of the node.

May also be shown as 806f01070304ffff or 0x806f01070304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0036

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. Make sure that the microprocessor 4 heat sink is securely installed.
5. (Trained service technician only) Make sure that the microprocessor 4 heat sink is installed correctly and the thermal material is correctly applied.
6. (Trained service technician only) Replace microprocessor 4.

806f0108-0a01ffff [PowerSupplyElementName] has Failed.

Explanation: IMM has detected a Fault on Power Supply 1.

May also be shown as 806f01080a01ffff or 0x806f01080a01ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0086

SNMP Trap ID: 4

Automatically notify Support: Yes

User response: Check the log for additional Power Supply Failure. Replace the Power Supply 1, if needed

806f0108-0a02ffff [PowerSupplyElementName] has Failed.

Explanation: IMM has detected a Fault on Power Supply 2.

May also be shown as 806f01080a02ffff or 0x806f01080a02ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0086

SNMP Trap ID: 4

Automatically notify Support: Yes

User response: Check the log for additional Power Supply Failure. Replace the Power Supply 2, if needed

806f0108-1881ffff [PowerSupplyElementName] has Failed.

Explanation: Memory expansion module power supply 2 error detected.

May also be shown as 806f01081881ffff or 0x806f01081881ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0086

SNMP Trap ID: 4

Automatically notify Support: No

User response:

1. Check memory expansion module LEDs.
2. Check memory expansion module power supply 2 LEDs.
3. Replace the memory expansion module power supply 2.

806f0109-1381ffff [PowerSupplyElementName] has been Power Cycled.

Explanation: System has been power cycled.

May also be shown as 806f01091381ffff or 0x806f01091381ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0108

SNMP Trap ID:

Automatically notify Support: No

User response: Host Power :Information only; no action is required.

806f010c-08810001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem
[MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 1.

May also be shown as 806f010c08810001 or 0x806f010c08810001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 1.

May also be shown as 806f010c08810002 or 0x806f010c08810002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 1.

May also be shown as 806f010c08810003 or 0x806f010c08810003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 1.

May also be shown as 806f010c08810004 or 0x806f010c08810004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 1.

May also be shown as 806f010c08810005 or 0x806f010c08810005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 1.

May also be shown as 806f010c08810006 or 0x806f010c08810006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 1.

May also be shown as 806f010c08810007 or 0x806f010c08810007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08810008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 1.

May also be shown as 806f010c08810008 or 0x806f010c08810008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 2.

May also be shown as 806f010c08820001 or 0x806f010c08820001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 2.

May also be shown as 806f010c08820002 or 0x806f010c08820002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 2.

May also be shown as 806f010c08820003 or 0x806f010c08820003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 2.

May also be shown as 806f010c08820004 or 0x806f010c08820004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 2.

May also be shown as 806f010c08820005 or 0x806f010c08820005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 2.

May also be shown as 806f010c08820006 or 0x806f010c08820006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 2.

May also be shown as 806f010c08820007 or 0x806f010c08820007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08820008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 2.

May also be shown as 806f010c08820008 or 0x806f010c08820008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 3.

May also be shown as 806f010c08830001 or 0x806f010c08830001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 3.

May also be shown as 806f010c08830002 or 0x806f010c08830002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 3.

May also be shown as 806f010c08830003 or 0x806f010c08830003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 3.

May also be shown as 806f010c08830004 or 0x806f010c08830004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 3.

May also be shown as 806f010c08830005 or 0x806f010c08830005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 3.

May also be shown as 806f010c08830006 or 0x806f010c08830006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 3.

May also be shown as 806f010c08830007 or 0x806f010c08830007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08830008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 3.

May also be shown as 806f010c08830008 or 0x806f010c08830008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 4.

May also be shown as 806f010c08840001 or 0x806f010c08840001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 4.

May also be shown as 806f010c08840002 or 0x806f010c08840002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 4.

May also be shown as 806f010c08840003 or 0x806f010c08840003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 4.

May also be shown as 806f010c08840004 or 0x806f010c08840004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 4.

May also be shown as 806f010c08840005 or 0x806f010c08840005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 4.

May also be shown as 806f010c08840006 or 0x806f010c08840006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 4.

May also be shown as 806f010c08840007 or 0x806f010c08840007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08840008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 4.

May also be shown as 806f010c08840008 or 0x806f010c08840008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 5.

May also be shown as 806f010c08850001 or 0x806f010c08850001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 5.

May also be shown as 806f010c08850002 or 0x806f010c08850002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 5.

May also be shown as 806f010c08850003 or 0x806f010c08850003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 5.

May also be shown as 806f010c08850004 or 0x806f010c08850004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 5.

May also be shown as 806f010c08850005 or 0x806f010c08850005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 5.

May also be shown as 806f010c08850006 or 0x806f010c08850006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 5.

May also be shown as 806f010c08850007 or 0x806f010c08850007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08850008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 5.

May also be shown as 806f010c08850008 or 0x806f010c08850008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 6.

May also be shown as 806f010c08860001 or 0x806f010c08860001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 6.

May also be shown as 806f010c08860002 or 0x806f010c08860002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 6.

May also be shown as 806f010c08860003 or 0x806f010c08860003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 6.

May also be shown as 806f010c08860004 or 0x806f010c08860004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 6.

May also be shown as 806f010c08860005 or 0x806f010c08860005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 6.

May also be shown as 806f010c08860006 or 0x806f010c08860006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 6.

May also be shown as 806f010c08860007 or 0x806f010c08860007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08860008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 6.

May also be shown as 806f010c08860008 or 0x806f010c08860008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 7.

May also be shown as 806f010c08870001 or 0x806f010c08870001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 7.

May also be shown as 806f010c08870002 or 0x806f010c08870002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 7.

May also be shown as 806f010c08870003 or 0x806f010c08870003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 7.

May also be shown as 806f010c08870004 or 0x806f010c08870004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 7.

May also be shown as 806f010c08870005 or 0x806f010c08870005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 7.

May also be shown as 806f010c08870006 or 0x806f010c08870006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 7.

May also be shown as 806f010c08870007 or 0x806f010c08870007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08870008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 7.

May also be shown as 806f010c08870008 or 0x806f010c08870008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of mem card 8.

May also be shown as 806f010c08880001 or 0x806f010c08880001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of mem card 8.

May also be shown as 806f010c08880002 or 0x806f010c08880002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of mem card 8.

May also be shown as 806f010c08880003 or 0x806f010c08880003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of mem card 8.

May also be shown as 806f010c08880004 or 0x806f010c08880004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of mem card 8.

May also be shown as 806f010c08880005 or 0x806f010c08880005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of mem card 8.

May also be shown as 806f010c08880006 or 0x806f010c08880006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of mem card 8.

May also be shown as 806f010c08880007 or 0x806f010c08880007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-08880008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of mem card 8.

May also be shown as 806f010c08880008 or 0x806f010c08880008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f010c-18810001 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 1 of memory expansion unit(MEU).

May also be shown as 806f010c18810001 or 0x806f010c18810001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810002 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 2 of memory expansion unit(MEU).

May also be shown as 806f010c18810002 or 0x806f010c18810002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810003 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 3 of memory expansion unit(MEU).

May also be shown as 806f010c18810003 or 0x806f010c18810003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810004 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 4 of memory expansion unit(MEU).

May also be shown as 806f010c18810004 or 0x806f010c18810004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810005 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 5 of memory expansion unit(MEU).

May also be shown as 806f010c18810005 or 0x806f010c18810005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810006 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 6 of memory expansion unit(MEU).

May also be shown as 806f010c18810006 or 0x806f010c18810006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810007 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 7 of memory expansion unit(MEU).

May also be shown as 806f010c18810007 or 0x806f010c18810007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810008 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 8 of memory expansion unit(MEU).

May also be shown as 806f010c18810008 or 0x806f010c18810008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810009 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 9 of memory expansion unit(MEU).

May also be shown as 806f010c18810009 or 0x806f010c18810009

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881000a Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 10 of memory expansion unit(MEU).

May also be shown as 806f010c1881000a or 0x806f010c1881000a

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881000b Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 11 of memory expansion unit(MEU).

May also be shown as 806f010c1881000b or 0x806f010c1881000b

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881000c Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 12 of memory expansion unit(MEU).

May also be shown as 806f010c1881000c or 0x806f010c1881000c

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881000d Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 13 of memory expansion unit(MEU).

May also be shown as 806f010c1881000d or 0x806f010c1881000d

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881000e Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 14 of memory expansion unit(MEU).

May also be shown as 806f010c1881000e or 0x806f010c1881000e

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881000f Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 15 of memory expansion unit(MEU).

May also be shown as 806f010c1881000f or 0x806f010c1881000f

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810010 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 16 of memory expansion unit(MEU).

May also be shown as 806f010c18810010 or 0x806f010c18810010

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810011 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 17 of memory expansion unit(MEU).

May also be shown as 806f010c18810011 or 0x806f010c18810011

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810012 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 18 of memory expansion unit(MEU).

May also be shown as 806f010c18810012 or 0x806f010c18810012

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810013 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 19 of memory expansion unit(MEU).

May also be shown as 806f010c18810013 or 0x806f010c18810013

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810014 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 20 of memory expansion unit(MEU).

May also be shown as 806f010c18810014 or 0x806f010c18810014

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810015 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 21 of memory expansion unit(MEU).

May also be shown as 806f010c18810015 or 0x806f010c18810015

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810016 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 22 of memory expansion unit(MEU).

May also be shown as 806f010c18810016 or 0x806f010c18810016

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810017 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 23 of memory expansion unit(MEU).

May also be shown as 806f010c18810017 or 0x806f010c18810017

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810018 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 24 of memory expansion unit(MEU).

May also be shown as 806f010c18810018 or 0x806f010c18810018

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810019 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 25 of memory expansion unit(MEU).

May also be shown as 806f010c18810019 or 0x806f010c18810019

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881001a Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 26 of memory expansion unit(MEU).

May also be shown as 806f010c1881001a or 0x806f010c1881001a

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881001b Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 27 of memory expansion unit(MEU).

May also be shown as 806f010c1881001b or 0x806f010c1881001b

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881001c Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 28 of memory expansion unit(MEU).

May also be shown as 806f010c1881001c or 0x806f010c1881001c

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881001d Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 29 of memory expansion unit(MEU).

May also be shown as 806f010c1881001d or 0x806f010c1881001d

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881001e Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 30 of memory expansion unit(MEU).

May also be shown as 806f010c1881001e or 0x806f010c1881001e

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-1881001f Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 31 of memory expansion unit(MEU).

May also be shown as 806f010c1881001f or 0x806f010c1881001f

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-18810020 Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error has occurred in DIMM 32 of memory expansion unit(MEU).

May also be shown as 806f010c18810020 or 0x806f010c18810020

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the MEU board.

806f010c-2581ffff Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected a Memory uncorrectable error in one of the DIMMs.

May also be shown as 806f010c2581ffff or 0x806f010c2581ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0138

SNMP Trap ID: 41

Automatically notify Support: Yes

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap one of the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slots, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace board on MEU.

806f010d-0400ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 0 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0400ffff or 0x806f010d0400ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0401ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 1 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0401ffff or 0x806f010d0401ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0402ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 2 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0402ffff or 0x806f010d0402ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0403ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 3 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0403ffff or 0x806f010d0403ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0404ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 4 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0404ffff or 0x806f010d0404ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0405ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 5 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0405ffff or 0x806f010d0405ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0406ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 6 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0406ffff or 0x806f010d0406ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0407ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 7 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0407ffff or 0x806f010d0407ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0408ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 8 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0408ffff or 0x806f010d0408ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-0409ffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 9 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d0409ffff or 0x806f010d0409ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-040affff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 10 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d040affff or 0x806f010d040affff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-040bffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 11 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d040bffff or 0x806f010d040bffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-040cffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 12 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d040cffff or 0x806f010d040cffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-040dffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 13 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d040dffff or 0x806f010d040dffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-040effff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 14 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d040effff or 0x806f010d040effff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010d-040fffff The Drive [StorageVolumeElementName] has been disabled due to a detected fault.

Explanation: The drive 15 has been disabled (defunct) due to a fault detected by the controller.

May also be shown as 806f010d040fffff or 0x806f010d040fffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0164

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

1. Check IBM Support site for Service Bulletins/RETAIN tips related to your particular drive.
2. Check IBM Support site for firmware updates related to your particular drive.
3. Check for any other RAID related errors.
4. Replace the drive.

806f010f-2201ffff The System [ComputerSystemElementName] encountered a firmware hang.

Explanation: IMM has detected a System Firmware Hang.

May also be shown as 806f010f2201ffff or 0x806f010f2201ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0186

SNMP Trap ID: 25

Automatically notify Support: No

User response:

1. Check the system- event log and correct the failures.
2. Remove the system ac power.
3. Wait 30 seconds, then restart the server.

806f0113-1701ffff A bus timeout has occurred on system [ComputerSystemElementName].

Explanation: A bus timeout has occurred.

May also be shown as 806f01131701ffff or 0x806f01131701ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0224

SNMP Trap ID: 50

Automatically notify Support: No

User response:

1. Remove the adapter from the PCI slot that is indicated by a lit LED.
2. Replace the adapter.
3. Remove all PCI adapters.
4. (Trained service technicians only) Replace the I/O board.

806f011b-0701ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: IMM has detected an internal connection error.

May also be shown as 806f011b0701ffff or 0x806f011b0701ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: Yes

User response:

1. If the sensor name is "Planar FPGA Err",
 2. a) try to flash FPGA firmware to the latest level.
 3. b) If the error still appears with the latest FPGA firmware, Replace the CPU board.

806f011b-1801ffff • 806f011b-1f05ffff

4. If the sensor name is "QPI Wrap Card x",
 5. a) the QPI wrap card, if installed.
 6. b) Reseat any installed QPI cables. Attention: Do not disconnect or connect any of the cables when the server or memory expansion module has power connected.
 7. c) Replace the CPU board.
8. If the sensor name is "USB Detect",
 9. a) Make sure that all the USB cables are connected and that there is no damage to the connectors.
10. b) Check the internal cable from the I/O board to the system front panel.

806f011b-1801ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: An internal memory expansion module FPGA error has occurred.

May also be shown as 806f011b1801ffff or 0x806f011b1801ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: No

User response:

1. Make sure that the QPI cables from the server to the memory expansion module are securely and properly attached.
2. Make sure that the latest level of firmware is installed on the memory expansion module and the server.

806f011b-1f05ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: A fan cable configuration error has occurred.

May also be shown as 806f011b1f05ffff or 0x806f011b1f05ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: No

User response: Make sure that the cable is connected securely and properly.

806f011b-1f06ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: A cable configuration error has occurred.

May also be shown as 806f011b1f06ffff or 0x806f011b1f06ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: No

User response: Make sure that the cable is connected securely and properly.

806f011b-1f07ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: A cable configuration error has occurred.

May also be shown as 806f011b1f07ffff or 0x806f011b1f07ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: No

User response: Make sure that the cable is connected securely and properly.

806f011b-1f08ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: A cable configuration error has occurred.

May also be shown as 806f011b1f08ffff or 0x806f011b1f08ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: No

User response: Make sure that the cable is connected securely and properly.

806f011b-1f09ffff • 806f0125-0c01ffff

806f011b-1f09ffff The connector [PhysicalConnectorElementName] has encountered a configuration error.

Explanation: A cable configuration error has occurred.

May also be shown as 806f011b1f09ffff or 0x806f011b1f09ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0266

SNMP Trap ID: 50

Automatically notify Support: No

User response: Make sure that the cable is connected securely and properly.

806f0123-2101ffff Reboot of system [ComputerSystemElementName] initiated by [WatchdogElementName].

Explanation: The IPMI Watchdog Timer has expired. A reboot of the system was initiated.

May also be shown as 806f01232101ffff or 0x806f01232101ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0370

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0125-0c01ffff [ManagedElementName] detected as absent.

Explanation: IMM has detected the Operator Information panel is absent.

May also be shown as 806f01250c01ffff or 0x806f01250c01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0392

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Reinsert or replace the operator information panel cable.
2. Replace the operator information panel.

806f0125-1801ffff [ManagedElementName] detected as absent.

Explanation: IMM has detected the memory drawer is absent.

May also be shown as 806f01251801ffff or 0x806f01251801ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0392

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Check if the memory drawer is connected or not.
2. If it's connected, replace the connection cable.
3. Replace the memory drawer.

806f0207-0301ffff [ProcessorElementName] has Failed with FRB1/BIST condition.

Explanation: IMM has detected a Microprocessor 1 Failed - FRB1/BIST condition.

May also be shown as 806f02070301ffff or 0x806f02070301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0044

SNMP Trap ID: 40

Automatically notify Support: Yes

User response:

1. Check for a server firmware update.
2. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
3. Make sure that the installed microprocessors are compatible with each other.
4. (Trained service technician only)
5. Reseat microprocessor 1.
6. (Trained service technician only)
7. Replace microprocessor 1.

806f0207-0302ffff [ProcessorElementName] has Failed with FRB1/BIST condition.

Explanation: IMM has detected a Microprocessor 2 Failed - FRB1/BIST condition.

May also be shown as 806f02070302ffff or 0x806f02070302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0044

SNMP Trap ID: 40

Automatically notify Support: Yes

User response:

1. Check for a server firmware update.
2. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
3. Make sure that the installed microprocessors are compatible with each other.
4. (Trained service technician only)
5. Reseat microprocessor 2.
6. (Trained service technician only)
7. Replace microprocessor 2.

806f0207-0303ffff [ProcessorElementName] has Failed with FRB1/BIST condition.

Explanation: IMM has detected a Microprocessor 3 Failed - FRB1/BIST condition.

May also be shown as 806f02070303ffff or 0x806f02070303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0044

SNMP Trap ID: 40

Automatically notify Support: Yes

User response:

1. Check for a server firmware update.
2. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
3. Make sure that the installed microprocessors are compatible with each other.
4. (Trained service technician only)
5. Reseat microprocessor 3.
6. (Trained service technician only)
7. Replace microprocessor 3.

806f0207-0304ffff [ProcessorElementName] has Failed with FRB1/BIST condition.

Explanation: IMM has detected a Microprocessor 4 Failed - FRB1/BIST condition.

May also be shown as 806f02070304ffff or 0x806f02070304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and **ID:** 0044

SNMP Trap ID: 40

Automatically notify Support: Yes

User response:

1. Check for a server firmware update.
2. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
3. Make sure that the installed microprocessors are compatible with each other.
4. (Trained service technician only)
5. Reseat microprocessor 4.
6. (Trained service technician only)
7. Replace microprocessor 4.

806f0208-0701ffff Failure predicted on [PowerSupplyElementName].

Explanation: AC power lost to a power supply.

May also be shown as 806f02080701ffff or 0x806f02080701ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0088

SNMP Trap ID: 164

Automatically notify Support: No

User response: Make sure there is enough power supplied to the server.

806f020d-0400ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 0.

May also be shown as 806f020d0400ffff or 0x806f020d0400ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and **ID:** 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0401ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 1.

May also be shown as 806f020d0401ffff or 0x806f020d0401ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0402ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 2.

May also be shown as 806f020d0402ffff or 0x806f020d0402ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0403ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 3.

May also be shown as 806f020d0403ffff or 0x806f020d0403ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0404ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 4.

May also be shown as 806f020d0404ffff or 0x806f020d0404ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0405ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 5.

May also be shown as 806f020d0405ffff or 0x806f020d0405ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0406ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 6.

May also be shown as 806f020d0406ffff or 0x806f020d0406ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0407ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 7.

May also be shown as 806f020d0407ffff or 0x806f020d0407ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0408ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 8.

May also be shown as 806f020d0408ffff or 0x806f020d0408ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-0409ffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 9.

May also be shown as 806f020d0409ffff or 0x806f020d0409ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-040affff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 10.

May also be shown as 806f020d040affff or 0x806f020d040affff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-040bffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 11.

May also be shown as 806f020d040bffff or 0x806f020d040bffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-040cffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 12.

May also be shown as 806f020d040cffff or 0x806f020d040cffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-040dffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 13.

May also be shown as 806f020d040dffff or 0x806f020d040dffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-040effff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 14.

May also be shown as 806f020d040effff or 0x806f020d040effff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f020d-040fffff Failure Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: Failure predicted (PFA) on the hard drive 15.

May also be shown as 806f020d040fffff or 0x806f020d040fffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0168

SNMP Trap ID: 27

Automatically notify Support: Yes

User response: Replace the hard disk drive at the next maintenance period.

806f0223-2101ffff Powering off system [ComputerSystemElementName] initiated by [WatchdogElementName].

Explanation: The IPMI Watchdog Timer has expired. The system was powered off.

May also be shown as 806f02232101ffff or 0x806f02232101ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0372

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0308-0a01ffff [PowerSupplyElementName] has lost input.

Explanation: Power Supply 1 AC input has been lost.

May also be shown as 806f03080a01ffff or 0x806f03080a01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0100

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0308-0a02ffff [PowerSupplyElementName] has lost input.

Explanation: Power Supply 2 AC input has been lost.

May also be shown as 806f03080a02ffff or 0x806f03080a02ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0100

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0308-1881ffff [PowerSupplyElementName] has lost input.

Explanation: MEU Power supply has lost.

May also be shown as 806f03081881ffff or 0x806f03081881ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0100

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f030c-08810001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 1.

May also be shown as 806f030c08810001 or 0x806f030c08810001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08810002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 1.

May also be shown as 806f030c08810002 or 0x806f030c08810002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08810003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 1.

May also be shown as 806f030c08810003 or 0x806f030c08810003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08810004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 1.

May also be shown as 806f030c08810004 or 0x806f030c08810004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08810005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 1.

May also be shown as 806f030c08810005 or 0x806f030c08810005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08810006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 1.

May also be shown as 806f030c08810006 or 0x806f030c08810006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08810007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 1.

May also be shown as 806f030c08810007 or 0x806f030c08810007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 2.

May also be shown as 806f030c08820001 or 0x806f030c08820001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 2.

May also be shown as 806f030c08820002 or 0x806f030c08820002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 2.

May also be shown as 806f030c08820003 or 0x806f030c08820003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 2.

May also be shown as 806f030c08820004 or 0x806f030c08820004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 2.

May also be shown as 806f030c08820005 or 0x806f030c08820005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 2.

May also be shown as 806f030c08820006 or 0x806f030c08820006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 2.

May also be shown as 806f030c08820007 or 0x806f030c08820007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08820008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 2.

May also be shown as 806f030c08820008 or 0x806f030c08820008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 3.

May also be shown as 806f030c08830001 or 0x806f030c08830001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 3.

May also be shown as 806f030c08830002 or 0x806f030c08830002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 3.

May also be shown as 806f030c08830003 or 0x806f030c08830003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 3.

May also be shown as 806f030c08830004 or 0x806f030c08830004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 3.

May also be shown as 806f030c08830005 or 0x806f030c08830005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 3.

May also be shown as 806f030c08830006 or 0x806f030c08830006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 3.

May also be shown as 806f030c08830007 or 0x806f030c08830007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08830008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 3.

May also be shown as 806f030c08830008 or 0x806f030c08830008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 4.

May also be shown as 806f030c08840001 or 0x806f030c08840001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 4.

May also be shown as 806f030c08840002 or 0x806f030c08840002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 4.

May also be shown as 806f030c08840003 or 0x806f030c08840003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 4.

May also be shown as 806f030c08840004 or 0x806f030c08840004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 4.

May also be shown as 806f030c08840005 or 0x806f030c08840005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 4.

May also be shown as 806f030c08840006 or 0x806f030c08840006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 4.

May also be shown as 806f030c08840007 or 0x806f030c08840007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08840008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 4.

May also be shown as 806f030c08840008 or 0x806f030c08840008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 5.

May also be shown as 806f030c08850001 or 0x806f030c08850001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 5.

May also be shown as 806f030c08850002 or 0x806f030c08850002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 5.

May also be shown as 806f030c08850003 or 0x806f030c08850003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 5.

May also be shown as 806f030c08850004 or 0x806f030c08850004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 5.

May also be shown as 806f030c08850005 or 0x806f030c08850005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 5.

May also be shown as 806f030c08850006 or 0x806f030c08850006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 5.

May also be shown as 806f030c08850007 or 0x806f030c08850007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08850008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 5.

May also be shown as 806f030c08850008 or 0x806f030c08850008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 6.

May also be shown as 806f030c08860001 or 0x806f030c08860001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 6.

May also be shown as 806f030c08860002 or 0x806f030c08860002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 6.

May also be shown as 806f030c08860003 or 0x806f030c08860003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 6.

May also be shown as 806f030c08860004 or 0x806f030c08860004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 6.

May also be shown as 806f030c08860005 or 0x806f030c08860005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 6.

May also be shown as 806f030c08860006 or 0x806f030c08860006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 6.

May also be shown as 806f030c08860007 or 0x806f030c08860007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08860008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 6.

May also be shown as 806f030c08860008 or 0x806f030c08860008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 7.

May also be shown as 806f030c08870001 or 0x806f030c08870001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 7.

May also be shown as 806f030c08870002 or 0x806f030c08870002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 7.

May also be shown as 806f030c08870003 or 0x806f030c08870003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 7.

May also be shown as 806f030c08870004 or 0x806f030c08870004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 7.

May also be shown as 806f030c08870005 or 0x806f030c08870005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 7.

May also be shown as 806f030c08870006 or 0x806f030c08870006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 7.

May also be shown as 806f030c08870007 or 0x806f030c08870007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08870008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 7.

May also be shown as 806f030c08870008 or 0x806f030c08870008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of mem card 8.

May also be shown as 806f030c08880001 or 0x806f030c08880001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of mem card 8.

May also be shown as 806f030c08880002 or 0x806f030c08880002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of mem card 8.

May also be shown as 806f030c08880003 or 0x806f030c08880003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of mem card 8.

May also be shown as 806f030c08880004 or 0x806f030c08880004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of mem card 8.

May also be shown as 806f030c08880005 or 0x806f030c08880005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of mem card 8.

May also be shown as 806f030c08880006 or 0x806f030c08880006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of mem card 8.

May also be shown as 806f030c08880007 or 0x806f030c08880007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-08880008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 8.

May also be shown as 806f030c08880008 or 0x806f030c08880008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-088810008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of mem card 1.

May also be shown as 806f030c088810008 or 0x806f030c088810008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the board.

806f030c-18810001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 1 of memory expansion module(MEU).

May also be shown as 806f030c18810001 or 0x806f030c18810001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 2 of memory expansion module(MEU).

May also be shown as 806f030c18810002 or 0x806f030c18810002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 3 of memory expansion module(MEU).

May also be shown as 806f030c18810003 or 0x806f030c18810003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 4 of memory expansion module(MEU).

May also be shown as 806f030c18810004 or 0x806f030c18810004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 5 of memory expansion module(MEU).

May also be shown as 806f030c18810005 or 0x806f030c18810005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 6 of memory expansion module(MEU).

May also be shown as 806f030c18810006 or 0x806f030c18810006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 7 of memory expansion module(MEU).

May also be shown as 806f030c18810007 or 0x806f030c18810007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 8 of memory expansion module(MEU).

May also be shown as 806f030c18810008 or 0x806f030c18810008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810009 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 9 of memory expansion module(MEU).

May also be shown as 806f030c18810009 or 0x806f030c18810009

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881000a Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 10 of memory expansion module(MEU).

May also be shown as 806f030c1881000a or 0x806f030c1881000a

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881000b Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 11 of memory expansion module(MEU).

May also be shown as 806f030c1881000b or 0x806f030c1881000b

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881000c Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 12 of memory expansion module(MEU).

May also be shown as 806f030c1881000c or 0x806f030c1881000c

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881000d Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 13 of memory expansion module(MEU).

May also be shown as 806f030c1881000d or 0x806f030c1881000d

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881000e Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 14 of memory expansion module(MEU).

May also be shown as 806f030c1881000e or 0x806f030c1881000e

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881000f Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 15 of memory expansion module(MEU).

May also be shown as 806f030c1881000f or 0x806f030c1881000f

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810010 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 16 of memory expansion module(MEU).

May also be shown as 806f030c18810010 or 0x806f030c18810010

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810011 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 17 of memory expansion module(MEU).

May also be shown as 806f030c18810011 or 0x806f030c18810011

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810012 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 18 of memory expansion module(MEU).

May also be shown as 806f030c18810012 or 0x806f030c18810012

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810013 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 19 of memory expansion module(MEU).

May also be shown as 806f030c18810013 or 0x806f030c18810013

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810014 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 20 of memory expansion module(MEU).

May also be shown as 806f030c18810014 or 0x806f030c18810014

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810015 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 21 of memory expansion module(MEU).

May also be shown as 806f030c18810015 or 0x806f030c18810015

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810016 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 22 of memory expansion module(MEU).

May also be shown as 806f030c18810016 or 0x806f030c18810016

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810017 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 23 of memory expansion module(MEU).

May also be shown as 806f030c18810017 or 0x806f030c18810017

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810018 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 24 of memory expansion module(MEU).

May also be shown as 806f030c18810018 or 0x806f030c18810018

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810019 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 25 of memory expansion module(MEU).

May also be shown as 806f030c18810019 or 0x806f030c18810019

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881001a Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 26 of memory expansion module(MEU).

May also be shown as 806f030c1881001a or 0x806f030c1881001a

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881001b Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 27 of memory expansion module(MEU).

May also be shown as 806f030c1881001b or 0x806f030c1881001b

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881001c Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 28 of memory expansion module(MEU).

May also be shown as 806f030c1881001c or 0x806f030c1881001c

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881001d Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 29 of memory expansion module(MEU).

May also be shown as 806f030c1881001d or 0x806f030c1881001d

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881001e Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 30 of memory expansion module(MEU).

May also be shown as 806f030c1881001e or 0x806f030c1881001e

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-1881001f Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 31 of memory expansion module(MEU).

May also be shown as 806f030c1881001f or 0x806f030c1881001f

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-18810020 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory test failed in DIMM 32 of memory expansion module(MEU).

May also be shown as 806f030c18810020 or 0x806f030c18810020

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slot, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace MEU board.

806f030c-2581ffff Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected a Memory Scrub failure.

May also be shown as 806f030c2581ffff or 0x806f030c2581ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and **ID:** 0136

SNMP Trap ID: 41

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for any applicable retain tip or firmware update that applies to this memory error.
3. Swap one of the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slots, replace the DIMM that was not moved. If the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occurs with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace board on MEU.

806f0313-1701ffff A software NMI has occurred on system [ComputerSystemElementName].

Explanation: A software NMI has occurred. Your system may have been rebooted, depending on the configuration setting.

May also be shown as 806f03131701ffff or 0x806f03131701ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0228

SNMP Trap ID: 50

Automatically notify Support: No

User response: Check Operating System logs and resolve any issues related to the NMI.

806f0323-2101ffff Power cycle of system [ComputerSystemElementName] initiated by [WatchdogElementName].

Explanation: The IPMI Watchdog Timer has expired. The system was powered off and powered on.

May also be shown as 806f03232101ffff or 0x806f03232101ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0374

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f032b-2101ffff A firmware or software incompatibility was detected on system [ComputerSystemElementName].

Explanation: IMM detected a firmware or software incompatibility in a multi-node system.

May also be shown as 806f032b2101ffff or 0x806f032b2101ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0442

SNMP Trap ID: 36

Automatically notify Support: No

User response: Information only; no action is required.

806f0409-1381ffff [PowerSupplyElementName] has lost power.

Explanation: IMM detected that a power unit had lost power

May also be shown as 806f04091381ffff or 0x806f04091381ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0112

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f040c-08810001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 1 has been Disabled.

May also be shown as 806f040c08810001 or 0x806f040c08810001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
 2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
 3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).
-

806f040c-08810002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 1 has been Disabled.

May also be shown as 806f040c08810002 or 0x806f040c08810002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08810003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 1 has been Disabled.

May also be shown as 806f040c08810003 or 0x806f040c08810003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08810004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 1 has been Disabled.

May also be shown as 806f040c08810004 or 0x806f040c08810004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08810005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 1 has been Disabled.

May also be shown as 806f040c08810005 or 0x806f040c08810005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08810006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 1 has been Disabled.

May also be shown as 806f040c08810006 or 0x806f040c08810006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08810007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 1 has been Disabled.

May also be shown as 806f040c08810007 or 0x806f040c08810007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08810008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 1 has been Disabled.

May also be shown as 806f040c08810008 or 0x806f040c08810008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 2 has been Disabled.

May also be shown as 806f040c08820001 or 0x806f040c08820001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 2 has been Disabled.

May also be shown as 806f040c08820002 or 0x806f040c08820002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 2 has been Disabled.

May also be shown as 806f040c08820003 or 0x806f040c08820003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 2 has been Disabled.

May also be shown as 806f040c08820004 or 0x806f040c08820004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 2 has been Disabled.

May also be shown as 806f040c08820005 or 0x806f040c08820005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 2 has been Disabled.

May also be shown as 806f040c08820006 or 0x806f040c08820006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 2 has been Disabled.

May also be shown as 806f040c08820007 or 0x806f040c08820007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08820008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 2 has been Disabled.

May also be shown as 806f040c08820008 or 0x806f040c08820008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 3 has been Disabled.

May also be shown as 806f040c08830001 or 0x806f040c08830001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 3 has been Disabled.

May also be shown as 806f040c08830002 or 0x806f040c08830002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 3 has been Disabled.

May also be shown as 806f040c08830003 or 0x806f040c08830003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 3 has been Disabled.

May also be shown as 806f040c08830004 or 0x806f040c08830004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 3 has been Disabled.

May also be shown as 806f040c08830005 or 0x806f040c08830005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 3 has been Disabled.

May also be shown as 806f040c08830006 or 0x806f040c08830006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 3 has been Disabled.

May also be shown as 806f040c08830007 or 0x806f040c08830007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08830008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 3 has been Disabled.

May also be shown as 806f040c08830008 or 0x806f040c08830008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 4 has been Disabled.

May also be shown as 806f040c08840001 or 0x806f040c08840001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 4 has been Disabled.

May also be shown as 806f040c08840002 or 0x806f040c08840002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 4 has been Disabled.

May also be shown as 806f040c08840003 or 0x806f040c08840003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 4 has been Disabled.

May also be shown as 806f040c08840004 or 0x806f040c08840004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 4 has been Disabled.

May also be shown as 806f040c08840005 or 0x806f040c08840005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 4 has been Disabled.

May also be shown as 806f040c08840006 or 0x806f040c08840006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 4 has been Disabled.

May also be shown as 806f040c08840007 or 0x806f040c08840007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08840008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 4 has been Disabled.

May also be shown as 806f040c08840008 or 0x806f040c08840008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 5 has been Disabled.

May also be shown as 806f040c08850001 or 0x806f040c08850001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 5 has been Disabled.

May also be shown as 806f040c08850002 or 0x806f040c08850002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 5 has been Disabled.

May also be shown as 806f040c08850003 or 0x806f040c08850003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 5 has been Disabled.

May also be shown as 806f040c08850004 or 0x806f040c08850004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 5 has been Disabled.

May also be shown as 806f040c08850005 or 0x806f040c08850005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 5 has been Disabled.

May also be shown as 806f040c08850006 or 0x806f040c08850006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 5 has been Disabled.

May also be shown as 806f040c08850007 or 0x806f040c08850007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08850008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 5 has been Disabled.

May also be shown as 806f040c08850008 or 0x806f040c08850008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 6 has been Disabled.

May also be shown as 806f040c08860001 or 0x806f040c08860001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 6 has been Disabled.

May also be shown as 806f040c08860002 or 0x806f040c08860002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 6 has been Disabled.

May also be shown as 806f040c08860003 or 0x806f040c08860003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 6 has been Disabled.

May also be shown as 806f040c08860004 or 0x806f040c08860004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 6 has been Disabled.

May also be shown as 806f040c08860005 or 0x806f040c08860005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 6 has been Disabled.

May also be shown as 806f040c08860006 or 0x806f040c08860006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 6 has been Disabled.

May also be shown as 806f040c08860007 or 0x806f040c08860007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08860008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 6 has been Disabled.

May also be shown as 806f040c08860008 or 0x806f040c08860008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 7 has been Disabled.

May also be shown as 806f040c08870001 or 0x806f040c08870001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 7 has been Disabled.

May also be shown as 806f040c08870002 or 0x806f040c08870002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 7 has been Disabled.

May also be shown as 806f040c08870003 or 0x806f040c08870003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 7 has been Disabled.

May also be shown as 806f040c08870004 or 0x806f040c08870004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 7 has been Disabled.

May also be shown as 806f040c08870005 or 0x806f040c08870005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 7 has been Disabled.

May also be shown as 806f040c08870006 or 0x806f040c08870006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 7 has been Disabled.

May also be shown as 806f040c08870007 or 0x806f040c08870007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08870008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 7 has been Disabled.

May also be shown as 806f040c08870008 or 0x806f040c08870008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 8 has been Disabled.

May also be shown as 806f040c08880001 or 0x806f040c08880001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 8 has been Disabled.

May also be shown as 806f040c08880002 or 0x806f040c08880002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 8 has been Disabled.

May also be shown as 806f040c08880003 or 0x806f040c08880003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 8 has been Disabled.

May also be shown as 806f040c08880004 or 0x806f040c08880004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 8 has been Disabled.

May also be shown as 806f040c08880005 or 0x806f040c08880005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 8 has been Disabled.

May also be shown as 806f040c08880006 or 0x806f040c08880006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 8 has been Disabled.

May also be shown as 806f040c08880007 or 0x806f040c08880007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-08880008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 8 has been Disabled.

May also be shown as 806f040c08880008 or 0x806f040c08880008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810001 or 0x806f040c18810001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810002 or 0x806f040c18810002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810003 or 0x806f040c18810003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810004 or 0x806f040c18810004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810005 or 0x806f040c18810005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810006 or 0x806f040c18810006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810007 or 0x806f040c18810007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810008 or 0x806f040c18810008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810009 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 9 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810009 or 0x806f040c18810009

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881000a [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 10 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881000a or 0x806f040c1881000a

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881000b [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 11 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881000b or 0x806f040c1881000b

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881000c [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 12 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881000c or 0x806f040c1881000c

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881000d • 806f040c-1881000e

806f040c-1881000d [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 13 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881000d or 0x806f040c1881000d

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881000e [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 14 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881000e or 0x806f040c1881000e

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881000f [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 15 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881000f or 0x806f040c1881000f

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810010 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 16 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810010 or 0x806f040c18810010

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810011 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 17 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810011 or 0x806f040c18810011

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810012 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 18 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810012 or 0x806f040c18810012

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810013 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 19 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810013 or 0x806f040c18810013

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810014 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 20 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810014 or 0x806f040c18810014

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810015 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 21 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810015 or 0x806f040c18810015

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810016 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 22 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810016 or 0x806f040c18810016

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810017 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 23 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810017 or 0x806f040c18810017

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810018 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 24 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810018 or 0x806f040c18810018

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810019 • 806f040c-1881001a

806f040c-18810019 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 25 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810019 or 0x806f040c18810019

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881001a [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 26 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881001a or 0x806f040c1881001a

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881001b [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 27 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881001b or 0x806f040c1881001b

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881001c [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 28 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881001c or 0x806f040c1881001c

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881001d • 806f040c-1881001e

806f040c-1881001d [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 29 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881001d or 0x806f040c1881001d

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881001e [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 30 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881001e or 0x806f040c1881001e

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-1881001f [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 31 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c1881001f or 0x806f040c1881001f

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-18810020 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 32 in memory expansion module(MEU) has been Disabled.

May also be shown as 806f040c18810020 or 0x806f040c18810020

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f040c-2581ffff [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: IMM has detected that Memory has been Disabled.

May also be shown as 806f040c2581ffff or 0x806f040c2581ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0131

SNMP Trap ID:

Automatically notify Support: No

User response:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

806f0507-0301ffff [ProcessorElementName] has a Configuration Mismatch.

Explanation: IMM has detected a Processor Configuration Mismatch on CPU 1.

May also be shown as 806f05070301ffff or 0x806f05070301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0062

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0507-0302ffff [ProcessorElementName] has a Configuration Mismatch.

Explanation: IMM has detected a Processor Configuration Mismatch on CPU 2.

May also be shown as 806f05070302ffff or 0x806f05070302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0062

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0507-0303ffff [ProcessorElementName] has a Configuration Mismatch.

Explanation: IMM has detected a Processor Configuration Mismatch on CPU 3.

May also be shown as 806f05070303ffff or 0x806f05070303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0062

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0507-0304ffff [ProcessorElementName] has a Configuration Mismatch.

Explanation: IMM has detected a Processor Configuration Mismatch on CPU 4.

May also be shown as 806f05070304ffff or 0x806f05070304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0062

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0507-2584ffff [ProcessorElementName] has a Configuration Mismatch.

Explanation: A configuration mismatch has occurred on 4S CPU.

May also be shown as 806f05072584ffff or 0x806f05072584ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0062

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Check to make sure that matched microprocessors are installed.
2. (Trained service technician only) Replace the microprocessor.

806f050c-08810001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810001 or 0x806f050c08810001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810002 or 0x806f050c08810002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810003 or 0x806f050c08810003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810004 or 0x806f050c08810004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810005 or 0x806f050c08810005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810006 or 0x806f050c08810006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810007 or 0x806f050c08810007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08810008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 1 memory logging limit has been reached.

May also be shown as 806f050c08810008 or 0x806f050c08810008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820001 or 0x806f050c08820001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820002 or 0x806f050c08820002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820003 or 0x806f050c08820003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820004 or 0x806f050c08820004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820005 or 0x806f050c08820005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820006 or 0x806f050c08820006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820007 or 0x806f050c08820007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08820008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 2 memory logging limit has been reached.

May also be shown as 806f050c08820008 or 0x806f050c08820008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830001 or 0x806f050c08830001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830002 or 0x806f050c08830002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830003 or 0x806f050c08830003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830004 or 0x806f050c08830004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830005 or 0x806f050c08830005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830006 or 0x806f050c08830006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830007 or 0x806f050c08830007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08830008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 3 memory logging limit has been reached.

May also be shown as 806f050c08830008 or 0x806f050c08830008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840001 or 0x806f050c08840001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840002 or 0x806f050c08840002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840003 or 0x806f050c08840003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840004 or 0x806f050c08840004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840005 or 0x806f050c08840005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840006 or 0x806f050c08840006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840007 or 0x806f050c08840007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08840008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 4 memory logging limit has been reached.

May also be shown as 806f050c08840008 or 0x806f050c08840008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850001 or 0x806f050c08850001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850002 or 0x806f050c08850002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850003 or 0x806f050c08850003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850004 or 0x806f050c08850004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850005 or 0x806f050c08850005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850006 or 0x806f050c08850006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850007 or 0x806f050c08850007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08850008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 5 memory logging limit has been reached.

May also be shown as 806f050c08850008 or 0x806f050c08850008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860001 or 0x806f050c08860001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860002 or 0x806f050c08860002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860003 or 0x806f050c08860003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860004 or 0x806f050c08860004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860005 or 0x806f050c08860005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860006 or 0x806f050c08860006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860007 or 0x806f050c08860007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08860008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 6 memory logging limit has been reached.

May also be shown as 806f050c08860008 or 0x806f050c08860008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870001 or 0x806f050c08870001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870002 or 0x806f050c08870002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870003 or 0x806f050c08870003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870004 or 0x806f050c08870004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870005 or 0x806f050c08870005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870006 or 0x806f050c08870006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870007 or 0x806f050c08870007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08870008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 7 memory logging limit has been reached.

May also be shown as 806f050c08870008 or 0x806f050c08870008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880001 or 0x806f050c08880001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880002 or 0x806f050c08880002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880003 or 0x806f050c08880003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880004 or 0x806f050c08880004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880005 or 0x806f050c08880005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880006 or 0x806f050c08880006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880007 or 0x806f050c08880007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-08880008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 8 memory logging limit has been reached.

May also be shown as 806f050c08880008 or 0x806f050c08880008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050c-18810001 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810001 or 0x806f050c18810001

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810002 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810002 or 0x806f050c18810002

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810003 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810003 or 0x806f050c18810003

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810004 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810004 or 0x806f050c18810004

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810005 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810005 or 0x806f050c18810005

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810006 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810006 or 0x806f050c18810006

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810007 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810007 or 0x806f050c18810007

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810008 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810008 or 0x806f050c18810008

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810009 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 9 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810009 or 0x806f050c18810009

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881000a Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 10 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881000a or 0x806f050c1881000a

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881000b Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 11 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881000b or 0x806f050c1881000b

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881000c Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 12 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881000c or 0x806f050c1881000c

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881000d Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 13 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881000d or 0x806f050c1881000d

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881000e Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 14 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881000e or 0x806f050c1881000e

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881000f Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 15 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881000f or 0x806f050c1881000f

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810010 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 16 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810010 or 0x806f050c18810010

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810011 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 17 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810011 or 0x806f050c18810011

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810012 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 18 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810012 or 0x806f050c18810012

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810013 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 19 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810013 or 0x806f050c18810013

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810014 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 20 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810014 or 0x806f050c18810014

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810015 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 21 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810015 or 0x806f050c18810015

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810016 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 22 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810016 or 0x806f050c18810016

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810017 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 23 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810017 or 0x806f050c18810017

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810018 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 24 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810018 or 0x806f050c18810018

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810019 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 25 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810019 or 0x806f050c18810019

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881001a Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 26 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881001a or 0x806f050c1881001a

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881001b Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 27 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881001b or 0x806f050c1881001b

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881001c Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 28 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881001c or 0x806f050c1881001c

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881001d Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 29 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881001d or 0x806f050c1881001d

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881001e Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 30 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881001e or 0x806f050c1881001e

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-1881001f Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 31 of MEU memory logging limit has been reached.

May also be shown as 806f050c1881001f or 0x806f050c1881001f

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-18810020 Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 32 of MEU memory logging limit has been reached.

May also be shown as 806f050c18810020 or 0x806f050c18810020

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: No

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace th MEU.
6. Replace the CPU board.

806f050c-2581ffff Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory logging limit has been reached.

May also be shown as 806f050c2581ffff or 0x806f050c2581ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0144

SNMP Trap ID: 43

Automatically notify Support: Yes

User response:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU (check this document and the Installation and User's Guide for population requirements for sparing/paring modes).
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics.
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. Replace the CPU board.

806f050d-0400ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0400ffff or 0x806f050d0400ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0401ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0401ffff or 0x806f050d0401ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0402ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0402ffff or 0x806f050d0402ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0403ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0403ffff or 0x806f050d0403ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0404ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0404ffff or 0x806f050d0404ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0405ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0405ffff or 0x806f050d0405ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0406ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0406ffff or 0x806f050d0406ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0407ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0407ffff or 0x806f050d0407ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0408ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0408ffff or 0x806f050d0408ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-0409ffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d0409ffff or 0x806f050d0409ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-040affff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d040affff or 0x806f050d040affff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-040bffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d040bffff or 0x806f050d040bffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-040cffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d040cffff or 0x806f050d040cffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-040dffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d040dffff or 0x806f050d040dffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-040effff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d040effff or 0x806f050d040effff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f050d-040fffff Array in system [ComputerSystemElementName] is in critical condition.

Explanation: The Drive is part of an RAID array that is in critical condition. Immediate action is required to avoid a system outage. To identify drives in the critical array all member drives will report this message.

May also be shown as 806f050d040fffff or 0x806f050d040fffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0174

SNMP Trap ID: 5

Automatically notify Support: No

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drive that is indicated by a lit status LED.

806f052b-2101ffff Invalid or Unsupported firmware or software was detected on system
[ComputerSystemElementName].

Explanation: The IMM primary firmware image has been corrupted. The IMM is running on the backup image.

May also be shown as 806f052b2101ffff or 0x806f052b2101ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0446

SNMP Trap ID: 50

Automatically notify Support: No

User response: Reflash or update the IMM firmware.

806f0607-0301ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has asserted.

Explanation: The UEFI has detected a configuration type issue with processor 1.

May also be shown as 806f06070301ffff or 0x806f06070301ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0816

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Check for a UEFI firmware update.
 2. Make sure that the installed microprocessors are compatible with each other.
 3. (Trained service technician only) Reseat microprocessor 1.
 4. (Trained service technician only) Replace microprocessor 1.
-

806f0607-0302ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has asserted.

Explanation: The UEFI has detected a configuration type issue with processor 2.

May also be shown as 806f06070302ffff or 0x806f06070302ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0816

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Check for a UEFI firmware update.
2. Make sure that the installed microprocessors are compatible with each other.
3. (Trained service technician only) Reseat microprocessor 2.
4. (Trained service technician only) Replace microprocessor 2.

806f0607-0303ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has asserted.

Explanation: The UEFI has detected a configuration type issue with processor 3.

May also be shown as 806f06070303ffff or 0x806f06070303ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0816

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Check for a UEFI firmware update.
2. Make sure that the installed microprocessors are compatible with each other.
3. (Trained service technician only) Reseat microprocessor 3.
4. (Trained service technician only) Replace microprocessor 3.

806f0607-0304ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has asserted.

Explanation: The UEFI has detected a configuration type issue with processor 4.

May also be shown as 806f06070304ffff or 0x806f06070304ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0816

SNMP Trap ID: 40

Automatically notify Support: No

User response:

1. Check for a UEFI firmware update.
2. Make sure that the installed microprocessors are compatible with each other.
3. (Trained service technician only) Reseat microprocessor 4.
4. (Trained service technician only) Replace microprocessor 4.

806f060d-0400ffff • 806f060d-0401ffff

806f060d-0400ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0400ffff or 0x806f060d0400ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0401ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0401ffff or 0x806f060d0401ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0402ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0402ffff or 0x806f060d0402ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0403ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0403ffff or 0x806f060d0403ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0404ffff • 806f060d-0405ffff

806f060d-0404ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0404ffff or 0x806f060d0404ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0405ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0405ffff or 0x806f060d0405ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0406ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0406ffff or 0x806f060d0406ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0407ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0407ffff or 0x806f060d0407ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0408ffff • 806f060d-0409ffff

806f060d-0408ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0408ffff or 0x806f060d0408ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-0409ffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d0409ffff or 0x806f060d0409ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-040affff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d040affff or 0x806f060d040affff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-040bffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d040bffff or 0x806f060d040bffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-040cffff • 806f060d-040dffff

806f060d-040cffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d040cffff or 0x806f060d040cffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-040dffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d040dffff or 0x806f060d040dffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-040effff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d040effff or 0x806f060d040effff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f060d-040fffff Array in system [ComputerSystemElementName] has failed.

Explanation: The Drive is part of an RAID array that is in the failed condition. To identify drives in the failed array all member drives will report this message.

May also be shown as 806f060d040fffff or 0x806f060d040fffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0176

SNMP Trap ID: 5

Automatically notify Support: Yes

User response:

- Check IMM log for Predictive Fault (PFA) or other hard drive messages to help identify failing drive(s).
- Replace the hard disk drives that are indicated by a lit status LED.
- Recreate the array.
- Restore data from backup.

806f070c-08810001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 1.

May also be shown as 806f070c08810001 or 0x806f070c08810001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 1.

May also be shown as 806f070c08810002 or 0x806f070c08810002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 1.

May also be shown as 806f070c08810003 or 0x806f070c08810003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 1.

May also be shown as 806f070c08810004 or 0x806f070c08810004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 1.

May also be shown as 806f070c08810005 or 0x806f070c08810005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 1.

May also be shown as 806f070c08810006 or 0x806f070c08810006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 1.

May also be shown as 806f070c08810007 or 0x806f070c08810007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08810008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 1.

May also be shown as 806f070c08810008 or 0x806f070c08810008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 2.

May also be shown as 806f070c08820001 or 0x806f070c08820001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 2.

May also be shown as 806f070c08820002 or 0x806f070c08820002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 2.

May also be shown as 806f070c08820003 or 0x806f070c08820003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 2.

May also be shown as 806f070c08820004 or 0x806f070c08820004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 2.

May also be shown as 806f070c08820005 or 0x806f070c08820005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 2.

May also be shown as 806f070c08820006 or 0x806f070c08820006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 2.

May also be shown as 806f070c08820007 or 0x806f070c08820007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08820008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 2.

May also be shown as 806f070c08820008 or 0x806f070c08820008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 3.

May also be shown as 806f070c08830001 or 0x806f070c08830001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 3.

May also be shown as 806f070c08830002 or 0x806f070c08830002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 3.

May also be shown as 806f070c08830003 or 0x806f070c08830003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 3.

May also be shown as 806f070c08830004 or 0x806f070c08830004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 3.

May also be shown as 806f070c08830005 or 0x806f070c08830005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 3.

May also be shown as 806f070c08830006 or 0x806f070c08830006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 3.

May also be shown as 806f070c08830007 or 0x806f070c08830007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08830008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 3.

May also be shown as 806f070c08830008 or 0x806f070c08830008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 4.

May also be shown as 806f070c08840001 or 0x806f070c08840001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 4.

May also be shown as 806f070c08840002 or 0x806f070c08840002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 4.

May also be shown as 806f070c08840003 or 0x806f070c08840003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 4.

May also be shown as 806f070c08840004 or 0x806f070c08840004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 4.

May also be shown as 806f070c08840005 or 0x806f070c08840005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 4.

May also be shown as 806f070c08840006 or 0x806f070c08840006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 4.

May also be shown as 806f070c08840007 or 0x806f070c08840007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08840008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 4.

May also be shown as 806f070c08840008 or 0x806f070c08840008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 5.

May also be shown as 806f070c08850001 or 0x806f070c08850001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 5.

May also be shown as 806f070c08850002 or 0x806f070c08850002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 5.

May also be shown as 806f070c08850003 or 0x806f070c08850003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 5.

May also be shown as 806f070c08850004 or 0x806f070c08850004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 5.

May also be shown as 806f070c08850005 or 0x806f070c08850005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 5.

May also be shown as 806f070c08850006 or 0x806f070c08850006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 5.

May also be shown as 806f070c08850007 or 0x806f070c08850007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08850008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 5.

May also be shown as 806f070c08850008 or 0x806f070c08850008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 6.

May also be shown as 806f070c08860001 or 0x806f070c08860001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 6.

May also be shown as 806f070c08860002 or 0x806f070c08860002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 6.

May also be shown as 806f070c08860003 or 0x806f070c08860003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 6.

May also be shown as 806f070c08860004 or 0x806f070c08860004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 6.

May also be shown as 806f070c08860005 or 0x806f070c08860005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 6.

May also be shown as 806f070c08860006 or 0x806f070c08860006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 6.

May also be shown as 806f070c08860007 or 0x806f070c08860007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08860008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 6.

May also be shown as 806f070c08860008 or 0x806f070c08860008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 7.

May also be shown as 806f070c08870001 or 0x806f070c08870001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 7.

May also be shown as 806f070c08870002 or 0x806f070c08870002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 7.

May also be shown as 806f070c08870003 or 0x806f070c08870003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 7.

May also be shown as 806f070c08870004 or 0x806f070c08870004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 7.

May also be shown as 806f070c08870005 or 0x806f070c08870005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 7.

May also be shown as 806f070c08870006 or 0x806f070c08870006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 7.

May also be shown as 806f070c08870007 or 0x806f070c08870007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08870008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 7.

May also be shown as 806f070c08870008 or 0x806f070c08870008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of mem card 8.

May also be shown as 806f070c08880001 or 0x806f070c08880001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of mem card 8.

May also be shown as 806f070c08880002 or 0x806f070c08880002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of mem card 8.

May also be shown as 806f070c08880003 or 0x806f070c08880003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of mem card 8.

May also be shown as 806f070c08880004 or 0x806f070c08880004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of mem card 8.

May also be shown as 806f070c08880005 or 0x806f070c08880005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of mem card 8.

May also be shown as 806f070c08880006 or 0x806f070c08880006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of mem card 8.

May also be shown as 806f070c08880007 or 0x806f070c08880007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-08880008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of mem card 8.

May also be shown as 806f070c08880008 or 0x806f070c08880008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-18810001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 1 of memory expansion unit(MEU).

May also be shown as 806f070c18810001 or 0x806f070c18810001

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 2 of memory expansion unit(MEU).

May also be shown as 806f070c18810002 or 0x806f070c18810002

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 3 of memory expansion unit(MEU).

May also be shown as 806f070c18810003 or 0x806f070c18810003

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 4 of memory expansion unit(MEU).

May also be shown as 806f070c18810004 or 0x806f070c18810004

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 5 of memory expansion unit(MEU).

May also be shown as 806f070c18810005 or 0x806f070c18810005

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 6 of memory expansion unit(MEU).

May also be shown as 806f070c18810006 or 0x806f070c18810006

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 7 of memory expansion unit(MEU).

May also be shown as 806f070c18810007 or 0x806f070c18810007

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 8 of memory expansion unit(MEU).

May also be shown as 806f070c18810008 or 0x806f070c18810008

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810009 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 9 of memory expansion unit(MEU).

May also be shown as 806f070c18810009 or 0x806f070c18810009

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881000a Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 10 of memory expansion unit(MEU).

May also be shown as 806f070c1881000a or 0x806f070c1881000a

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881000b Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 11 of memory expansion unit(MEU).

May also be shown as 806f070c1881000b or 0x806f070c1881000b

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881000c Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 12 of memory expansion unit(MEU).

May also be shown as 806f070c1881000c or 0x806f070c1881000c

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881000d Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 13 of memory expansion unit(MEU).

May also be shown as 806f070c1881000d or 0x806f070c1881000d

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881000e Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 14 of memory expansion unit(MEU).

May also be shown as 806f070c1881000e or 0x806f070c1881000e

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881000f Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 15 of memory expansion unit(MEU).

May also be shown as 806f070c1881000f or 0x806f070c1881000f

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810010 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 16 of memory expansion unit(MEU).

May also be shown as 806f070c18810010 or 0x806f070c18810010

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810011 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 17 of memory expansion unit(MEU).

May also be shown as 806f070c18810011 or 0x806f070c18810011

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810012 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 18 of memory expansion unit(MEU).

May also be shown as 806f070c18810012 or 0x806f070c18810012

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810013 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 19 of memory expansion unit(MEU).

May also be shown as 806f070c18810013 or 0x806f070c18810013

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810014 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 20 of memory expansion unit(MEU).

May also be shown as 806f070c18810014 or 0x806f070c18810014

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810015 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 21 of memory expansion unit(MEU).

May also be shown as 806f070c18810015 or 0x806f070c18810015

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810016 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 22 of memory expansion unit(MEU).

May also be shown as 806f070c18810016 or 0x806f070c18810016

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810017 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 23 of memory expansion unit(MEU).

May also be shown as 806f070c18810017 or 0x806f070c18810017

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810018 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 24 of memory expansion unit(MEU).

May also be shown as 806f070c18810018 or 0x806f070c18810018

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810019 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 25 of memory expansion unit(MEU).

May also be shown as 806f070c18810019 or 0x806f070c18810019

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881001a Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 26 of memory expansion unit(MEU).

May also be shown as 806f070c1881001a or 0x806f070c1881001a

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881001b Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 27 of memory expansion unit(MEU).

May also be shown as 806f070c1881001b or 0x806f070c1881001b

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881001c Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 28 of memory expansion unit(MEU).

May also be shown as 806f070c1881001c or 0x806f070c1881001c

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881001d Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 29 of memory expansion unit(MEU).

May also be shown as 806f070c1881001d or 0x806f070c1881001d

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881001e Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 30 of memory expansion unit(MEU).

May also be shown as 806f070c1881001e or 0x806f070c1881001e

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-1881001f Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 31 of memory expansion unit(MEU).

May also be shown as 806f070c1881001f or 0x806f070c1881001f

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-18810020 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration error has occurred on DIMM 32 of memory expansion unit(MEU).

May also be shown as 806f070c18810020 or 0x806f070c18810020

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards in MEU are installed in the correct sequence.

806f070c-2581ffff • 806f070c-2585ffff

806f070c-2581ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory card configuration error has occurred.

May also be shown as 806f070c2581ffff or 0x806f070c2581ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: **Prefix:** PLAT and **ID:** 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-2584ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A configuration error with the microprocessors has occurred.

May also be shown as 806f070c2584ffff or 0x806f070c2584ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure that the microprocessors are in a supported configuration.

806f070c-2585ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A configuration error has occurred because of missing memory for microprocessor 1.

May also be shown as 806f070c2585ffff or 0x806f070c2585ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure that the microprocessor 1 has the necessary memory installed.

806f070c-2586ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 1 bank) error has occurred.

May also be shown as 806f070c2586ffff or 0x806f070c2586ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-2587ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 2 bank) error has occurred.

May also be shown as 806f070c2587ffff or 0x806f070c2587ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-2588ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 3 bank) error has occurred.

May also be shown as 806f070c2588ffff or 0x806f070c2588ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-2589ffff • 806f070c-258bffff

806f070c-2589ffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 4 bank) error has occurred.

May also be shown as 806f070c2589ffff or 0x806f070c2589ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-258affff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 5 bank) error has occurred.

May also be shown as 806f070c258affff or 0x806f070c258affff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-258bffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 6 bank) error has occurred.

May also be shown as 806f070c258bffff or 0x806f070c258bffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-258cffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 7 bank) error has occurred.

May also be shown as 806f070c258cffff or 0x806f070c258cffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070c-258dffff Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory configuration (memory card 8 bank) error has occurred.

May also be shown as 806f070c258dffff or 0x806f070c258dffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0126

SNMP Trap ID: 41

Automatically notify Support: No

User response: Make sure the memory cards are installed in the correct sequence.

806f070d-0400ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild is in Progress.

May also be shown as 806f070d0400ffff or 0x806f070d0400ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0401ffff • 806f070d-0403ffff

806f070d-0401ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild is in Progress.

May also be shown as 806f070d0401ffff or 0x806f070d0401ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0402ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that An Array Rebuild is in Progress.

May also be shown as 806f070d0402ffff or 0x806f070d0402ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0403ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild is in Progress.

May also be shown as 806f070d0403ffff or 0x806f070d0403ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0404ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d0404ffff or 0x806f070d0404ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0405ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d0405ffff or 0x806f070d0405ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0406ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d0406ffff or 0x806f070d0406ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0407ffff • 806f070d-0409ffff

806f070d-0407ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d0407ffff or 0x806f070d0407ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0408ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d0408ffff or 0x806f070d0408ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-0409ffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d0409ffff or 0x806f070d0409ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-040affff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d040affff or 0x806f070d040affff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-040bffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d040bffff or 0x806f070d040bffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-040cffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d040cffff or 0x806f070d040cffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-040dffff • 806f070d-040fffff

806f070d-040dffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d040dffff or 0x806f070d040dffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-040effff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d040effff or 0x806f070d040effff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f070d-040fffff Rebuild in progress for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an array rebuild is in progress.

May also be shown as 806f070d040fffff or 0x806f070d040fffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0178

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0807-0301ffff [ProcessorElementName] has been Disabled.

Explanation: IMM has detected that Processor 1 has been disabled.

May also be shown as 806f08070301ffff or 0x806f08070301ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0061

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0807-0302ffff [ProcessorElementName] has been Disabled.

Explanation: IMM has detected that Processor 2 has been disabled.

May also be shown as 806f08070302ffff or 0x806f08070302ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0061

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0807-0303ffff [ProcessorElementName] has been Disabled.

Explanation: IMM has detected that Processor 3 has been disabled.

May also be shown as 806f08070303ffff or 0x806f08070303ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0061

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0807-0304ffff [ProcessorElementName] has been Disabled.

Explanation: IMM has detected that Processor 4 has been disabled.

May also be shown as 806f08070304ffff or 0x806f08070304ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0061

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0807-2584ffff [ProcessorElementName] has been Disabled.

Explanation: One of CPUs has been disabled.

May also be shown as 806f08072584ffff or 0x806f08072584ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0061

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0813-1801ffff A Uncorrectable Bus Error has occurred on system [ComputerSystemElementName].

Explanation: IMM has detected a bus uncorrectable error.

May also be shown as 806f08131801ffff or 0x806f08131801ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0240

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0813-2581ffff A Uncorrectable Bus Error has occurred on system [ComputerSystemElementName].

Explanation: IMM has detected a bus uncorrectable error.

May also be shown as 806f08132581ffff or 0x806f08132581ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0240

SNMP Trap ID: 50

Automatically notify Support: Yes

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0813-2582ffff A Uncorrectable Bus Error has occurred on system [ComputerSystemElementName].

Explanation: IMM has detected a Bus Uncorrectable Error.

May also be shown as 806f08132582ffff or 0x806f08132582ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0240

SNMP Trap ID: 50

Automatically notify Support: Yes

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0813-2584ffff A Uncorrectable Bus Error has occurred on system [ComputerSystemElementName].

Explanation: IMM has detected a bus uncorrectable error.

May also be shown as 806f08132584ffff or 0x806f08132584ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0240

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f090c-2586ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 1 has throttled.

May also be shown as 806f090c2586ffff or 0x806f090c2586ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-2587ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 2 has throttled.

May also be shown as 806f090c2587ffff or 0x806f090c2587ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-2588ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 3 has throttled.

May also be shown as 806f090c2588ffff or 0x806f090c2588ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-2589ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 4 has throttled.

May also be shown as 806f090c2589ffff or 0x806f090c2589ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-258affff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 5 has throttled.

May also be shown as 806f090c258affff or 0x806f090c258affff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-258bffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 6 has throttled.

May also be shown as 806f090c258bffff or 0x806f090c258bffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-258cffff • 806f090c-258effff

806f090c-258cffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 7 has throttled.

May also be shown as 806f090c258cffff or 0x806f090c258cffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-258dffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A DIMM in mem card 8 has throttled.

May also be shown as 806f090c258dffff or 0x806f090c258dffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-258effff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A memory in MEU bank 1 has throttled.

May also be shown as 806f090c258effff or 0x806f090c258effff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-258ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A memory in MEU bank 2 has throttled.

May also be shown as 806f090c258ffff or 0x806f090c258ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-2590ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A memory in MEU bank 3 has throttled.

May also be shown as 806f090c2590ffff or 0x806f090c2590ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f090c-2591ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.

Explanation: A memory in MEU bank 4 has throttled.

May also be shown as 806f090c2591ffff or 0x806f090c2591ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0142

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

806f0a07-0301ffff [ProcessorElementName] is operating in a Degraded State.

Explanation: The processor 1 is being throttled due to thermal or power conditions.

May also be shown as 806f0a070301ffff or 0x806f0a070301ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0038

SNMP Trap ID: 42

Automatically notify Support: No

User response: Check the IMM event log for any fan, cooling, or power related issues.

For a thermal condition:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
2. Make sure that the room temperature is within operating specifications.

For a power condition:

1. If Power Supply Unit is rated 1400 Watt, Make sure it is connected to 220V AC input
2. If using a 900 Watt rated power supply (connected at either 110V or 220 V), may need to upgrade to a 1400 Watt rated power supply (connected at 220V).

806f0a07-0302ffff [ProcessorElementName] is operating in a Degraded State.

Explanation: The processor 2 is being throttled due to thermal or power conditions.

May also be shown as 806f0a070302ffff or 0x806f0a070302ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0038

SNMP Trap ID: 42

Automatically notify Support: No

User response: Check the IMM event log for any fan, cooling, or power related issues.

For a thermal condition:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
2. Make sure that the room temperature is within operating specifications.

For a power condition:

1. If Power Supply Unit is rated 1400 Watt, Make sure it is connected to 220V AC input
2. If using a 900 Watt rated power supply (connected at either 110V or 220 V), may need to upgrade to a 1400 Watt rated power supply (connected at 220V).

806f0a07-0303ffff [ProcessorElementName] is operating in a Degraded State.

Explanation: The processor 3 is being throttled due to thermal or power conditions.

May also be shown as 806f0a070303ffff or 0x806f0a070303ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and **ID:** 0038

SNMP Trap ID: 42

Automatically notify Support: No

User response: Check the IMM event log for any fan, cooling, or power related issues.

For a thermal condition:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
2. Make sure that the room temperature is within operating specifications.

For a power condition:

1. If Power Supply Unit is rated 1400 Watt, Make sure it is connected to 220V AC input
2. If using a 900 Watt rated power supply (connected at either 110V or 220 V), may need to upgrade to a 1400 Watt rated power supply (connected at 220V).

806f0a07-0304ffff [ProcessorElementName] is operating in a Degraded State.

Explanation: The processor 4 is being throttled due to thermal or power conditions.

May also be shown as 806f0a070304ffff or 0x806f0a070304ffff

Severity: Warning

Alert Category: Warning

Serviceable: Yes

CIM Information: Prefix: PLAT and **ID:** 0038

SNMP Trap ID: 42

Automatically notify Support: No

User response: Check the IMM event log for any fan, cooling, or power related issues.

For a thermal condition:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
2. Make sure that the room temperature is within operating specifications.

For a power condition:

1. If Power Supply Unit is rated 1400 Watt, Make sure it is connected to 220V AC input
2. If using a 900 Watt rated power supply (connected at either 110V or 220 V), may need to upgrade to a 1400 Watt rated power supply (connected at 220V).

806f0a0c-2586ffff • 806f0a0c-2587ffff

806f0a0c-2586ffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 1.

May also be shown as 806f0a0c2586ffff or 0x806f0a0c2586ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-2587ffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 2.

May also be shown as 806f0a0c2587ffff or 0x806f0a0c2587ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-2588ffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 3.

May also be shown as 806f0a0c2588ffff or 0x806f0a0c2588ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-2589ffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 4.

May also be shown as 806f0a0c2589ffff or 0x806f0a0c2589ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-258affff • 806f0a0c-258bffff

806f0a0c-258affff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 5.

May also be shown as 806f0a0c258affff or 0x806f0a0c258affff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-258bffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 6.

May also be shown as 806f0a0c258bffff or 0x806f0a0c258bffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-258cffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 7.

May also be shown as 806f0a0c258cffff or 0x806f0a0c258cffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-258dffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the memory card 8.

May also be shown as 806f0a0c258dffff or 0x806f0a0c258dffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-258effff • 806f0a0c-258fffff

806f0a0c-258effff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the MEU bank 1.

May also be shown as 806f0a0c258effff or 0x806f0a0c258effff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-258fffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the MEU bank 2.

May also be shown as 806f0a0c258fffff or 0x806f0a0c258fffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-2590ffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the MEU bank 3.

May also be shown as 806f0a0c2590ffff or 0x806f0a0c2590ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a0c-2591ffff An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: IMM has detected an over temperature condition on the MEU bank 4.

May also be shown as 806f0a0c2591ffff or 0x806f0a0c2591ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0146

SNMP Trap ID: 0

Automatically notify Support: No

User response: Complete the following steps:

1. Check the IMM event log for any fan, cooling, or power related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place and correctly installed.
3. Make sure that the room temperature is within operating specifications.

806f0a13-2401ffff • 81010002-2801ffff

806f0a13-2401ffff A Fatal Bus Error has occurred on system [ComputerSystemElementName].

Explanation: IMM has detected a bus fatal error.

May also be shown as 806f0a132401ffff or 0x806f0a132401ffff

Severity: Error

Alert Category: Critical

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0244

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

806f0a13-2402ffff A Fatal Bus Error has occurred on system [ComputerSystemElementName].

Explanation: IMM has detected a bus fatal error.

May also be shown as 806f0a132402ffff or 0x806f0a132402ffff

Severity: Error

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0244

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

81010002-2801ffff Numeric sensor [NumericSensorElementName] going low (lower non-critical) has deasserted.

Explanation: A previously low CMOS battery voltage has returned to above its specified threshold

May also be shown as 810100022801ffff or 0x810100022801ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0477

SNMP Trap ID: 13

Automatically notify Support: No

User response: Information only; no action is required.

81010202-0701ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: A previously low voltage has returned to above its specified threshold (sensor Planar 12V, Planar 3.3V, or Planar 5V).

May also be shown as 810102020701ffff or 0x810102020701ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 1

Automatically notify Support: No

User response: Information only; no action is required.

81010202-2801ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: The previously low CMOS battery voltage has returned to above its specified threshold.

May also be shown as 810102022801ffff or 0x810102022801ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 1

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d01ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (Fan 1A Tach, Fan 1B Tach) going low has deasserted.

May also be shown as 810102041d01ffff or 0x810102041d01ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d02ffff • 81010204-1d04ffff

81010204-1d02ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (Fan 2A Tach, Fan 2B Tach) going low has deasserted.

May also be shown as 810102041d02ffff or 0x810102041d02ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d03ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (Fan 3A Tach, Fan 3B Tach) going low has deasserted.

May also be shown as 810102041d03ffff or 0x810102041d03ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d04ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (Fan 4A Tach, Fan 4B Tach) going low has deasserted.

May also be shown as 810102041d04ffff or 0x810102041d04ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d05ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (Fan 5A Tach, Fan 5B Tach) going low has deasserted.

May also be shown as 810102041d05ffff or 0x810102041d05ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d06ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (MEU Fan 1A Tach, MEU Fan 1B Tach) going low has deasserted.

May also be shown as 810102041d06ffff or 0x810102041d06ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d07ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (MEU Fan 2 Tach) going low has deasserted.

May also be shown as 810102041d07ffff or 0x810102041d07ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d08ffff • 81010204-1d0affff

81010204-1d08ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (MEU Fan 3 Tach) going low has deasserted.

May also be shown as 810102041d08ffff or 0x810102041d08ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d09ffff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (MEU Fan 4 Tach) going low has deasserted.

May also be shown as 810102041d09ffff or 0x810102041d09ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010204-1d0affff Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.

Explanation: IMM has detected a Fan (MEU Fan 5 Tach) going low has deasserted.

May also be shown as 810102041d0affff or 0x810102041d0affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0481

SNMP Trap ID: 11

Automatically notify Support: No

User response: Information only; no action is required.

81010701-0c01ffff Numeric sensor [NumericSensorElementName] going high (upper non-critical) has deasserted.

Explanation: An upper non-critical sensor going high has deasserted.

May also be shown as 810107010c01ffff or 0x810107010c01ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0491

SNMP Trap ID: 12

Automatically notify Support: No

User response: No action; information only.

81010701-1801ffff Numeric sensor [NumericSensorElementName] going high (upper non-critical) has deasserted.

Explanation: An upper non-critical sensor going high has deasserted.

May also be shown as 810107011801ffff or 0x810107011801ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0491

SNMP Trap ID: 12

Automatically notify Support: No

User response: No action, warning of increased temperature.

81010703-1500ffff Numeric sensor [NumericSensorElementName] going high (upper non-critical) has deasserted.

Explanation: An upper non-critical current sensor going high has deasserted.

May also be shown as 810107031500ffff or 0x810107031500ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0491

SNMP Trap ID: 164

Automatically notify Support: No

User response: No action, warning of increased temperature.

81010901-0c01ffff • 81010902-0701ffff

81010901-0c01ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has deasserted.

Explanation: An upper critical sensor going high has deasserted.

May also be shown as 810109010c01ffff or 0x810109010c01ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0495

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81010901-1801ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has deasserted.

Explanation: An upper critical sensor going high has deasserted.

May also be shown as 810109011801ffff or 0x810109011801ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0495

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81010902-0701ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has deasserted.

Explanation: A previously high voltage has returned to below its specified threshold (sensor Planar 12V, Planar 3.3V, or Planar 5V).

May also be shown as 810109020701ffff or 0x810109020701ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0495

SNMP Trap ID: 1

Automatically notify Support: No

User response: No action; information only.

81010903-1500ffff Numeric sensor [NumericSensorElementName] going high (upper critical) has deasserted.

Explanation: An upper critical current sensor going high has deasserted

May also be shown as 810109031500ffff or 0x810109031500ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0495

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81010b01-0c01ffff Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has deasserted.

Explanation: An upper non-recoverable sensor going high has deasserted.

May also be shown as 81010b010c01ffff or 0x81010b010c01ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0499

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81010b01-1801ffff Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has deasserted.

Explanation: An upper non-recoverable sensor going high has deasserted.

May also be shown as 81010b011801ffff or 0x81010b011801ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0499

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81010b03-1500ffff • 8103010c-2581ffff

81010b03-1500ffff Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has deasserted.

Explanation: An upper non-recoverable current sensor going high has deasserted.

May also be shown as 81010b031500ffff or 0x81010b031500ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0499

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

8103010c-1881ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel on the memory expansion module has deasserted.

May also be shown as 8103010c1881ffff or 0x8103010c1881ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2581ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 1 has deasserted.

May also be shown as 8103010c2581ffff or 0x8103010c2581ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2582ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 2 has deasserted.

May also be shown as 8103010c2582ffff or 0x8103010c2582ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2583ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 3 has deasserted.

May also be shown as 8103010c2583ffff or 0x8103010c2583ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2584ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 4 has deasserted.

May also be shown as 8103010c2584ffff or 0x8103010c2584ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2585ffff • 8103010c-2587ffff

8103010c-2585ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 5 has deasserted.

May also be shown as 8103010c2585ffff or 0x8103010c2585ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2586ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 6 has deasserted.

May also be shown as 8103010c2586ffff or 0x8103010c2586ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2587ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 7 has deasserted.

May also be shown as 8103010c2587ffff or 0x8103010c2587ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010c-2588ffff Sensor [SensorElementName] has deasserted.

Explanation: Lane failover on SMI lane Channel 8 has deasserted.

May also be shown as 8103010c2588ffff or 0x8103010c2588ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

8103010e-0701ffff Sensor [SensorElementName] has deasserted.

Explanation: A memory resize has deasserted.

May also be shown as 8103010e0701ffff or 0x8103010e0701ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0509

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81070201-0301ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: IMM has detected a CPU 1 Overtemp Sensor transition to less severe from critical.

May also be shown as 810702010301ffff or 0x810702010301ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-0302ffff • 81070201-0304ffff

81070201-0302ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: IMM has detected a CPU 2 Overtemp Sensor transition to less severe from critical.

May also be shown as 810702010302ffff or 0x810702010302ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-0303ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: IMM has detected a CPU 3 Overtemp Sensor transition to less severe from critical.

May also be shown as 810702010303ffff or 0x810702010303ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-0304ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: IMM has detected a CPU 4 Overtemp Sensor transition to less severe from critical.

May also be shown as 810702010304ffff or 0x810702010304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-0a01ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: Power supply 1 thermal fault transition to less severe from critical

May also be shown as 810702010a01ffff or 0x810702010a01ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-0a02ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: Power supply 2 thermal fault transition to less severe from critical

May also be shown as 810702010a02ffff or 0x810702010a02ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-1881ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: MEU thermal fault transition to less severe from critical

May also be shown as 810702011881ffff or 0x810702011881ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070201-1e83ffff • 81070202-1881ffff

81070201-1e83ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: IOH thermal status transition to less severe from critical

May also be shown as 810702011e83ffff or 0x810702011e83ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070202-0701ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: The Planar Fault sensor no longer detects a problem with the system board.

May also be shown as 810702020701ffff or 0x810702020701ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 1

Automatically notify Support: No

User response: No action; information only.

81070202-1881ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: Memory expansion module votage failure transitioned to a less severe state from critical.

May also be shown as 810702021881ffff or 0x810702021881ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 1

Automatically notify Support: No

User response: No action; information only.

81070204-1881ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: MEU power supply fan transition to less severe from critical

May also be shown as 810702041881ffff or 0x810702041881ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

81070208-1881ffff Sensor [SensorElementName] has transitioned to a less severe state from critical.

Explanation: Memory expansion module power failure transitioned to a less severe state from critical.

May also be shown as 810702081881ffff or 0x810702081881ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0523

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070301-0301ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.

Explanation: The microprocessor 1 temperature has returned to below its specified threshold.

May also be shown as 810703010301ffff or 0x810703010301ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0525

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070301-0302ffff • 81070301-0304ffff

81070301-0302ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.

Explanation: The microprocessor 2 temperature has returned to below its specified threshold.

May also be shown as 810703010302ffff or 0x810703010302ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0525

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070301-0303ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.

Explanation: The microprocessor 3 temperature has returned to below its specified threshold.

May also be shown as 810703010303ffff or 0x810703010303ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0525

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070301-0304ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.

Explanation: The microprocessor 4 temperature has returned to below its specified threshold.

May also be shown as 810703010304ffff or 0x810703010304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0525

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070301-1e83ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.

Explanation: IOH temp status transition to non-recoverable from less severe has deasserted

May also be shown as 810703011e83ffff or 0x810703011e83ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0525

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

81070603-0701ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: Voltage regulator transition to non-recoverable has deasserted

May also be shown as 810706030701ffff or 0x810706030701ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-0a01ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: Memory expansion module power supply 1 error (transition to non-recoverable) has deasserted

May also be shown as 810706080a01ffff or 0x810706080a01ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-0a02ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: Memory expansion module power supply 2 error (transition to non-recoverable) has deasserted
May also be shown as 810706080a02ffff or 0x810706080a02ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1401ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.
May also be shown as 810706081401ffff or 0x810706081401ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1402ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.
May also be shown as 810706081402ffff or 0x810706081402ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1403ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081403ffff or 0x810706081403ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1404ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081404ffff or 0x810706081404ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1405ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081405ffff or 0x810706081405ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1406ffff • 81070608-1408ffff

81070608-1406ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081406ffff or 0x810706081406ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1407ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081407ffff or 0x810706081407ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1408ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081408ffff or 0x810706081408ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1409ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator transition to non-recoverable has deasserted.

May also be shown as 810706081409ffff or 0x810706081409ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-140affff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: CPU 1 voltage regulator transition to non-recoverable has deasserted.

May also be shown as 81070608140affff or 0x81070608140affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-140bffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: CPU 2 voltage regulator transition to non-recoverable has deasserted.

May also be shown as 81070608140bffff or 0x81070608140bffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-140cffff • 81070608-140effff

81070608-140cffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: CPU 3 voltage regulator transition to non-recoverable has deasserted.

May also be shown as 81070608140cffff or 0x81070608140cffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-140dffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: CPU 4 voltage regulator transition to non-recoverable has deasserted.

May also be shown as 81070608140dffff or 0x81070608140dffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-140effff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in CPU 1 or 2 transition to non-recoverable has deasserted.

May also be shown as 81070608140effff or 0x81070608140effff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-140fffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in CPU 3 or 4 transition to non-recoverable has deasserted.

May also be shown as 81070608140fffff or 0x81070608140fffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1410ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in I/O board transition to non-recoverable has deasserted.

May also be shown as 810706081410ffff or 0x810706081410ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1411ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in SAS transition to non-recoverable has deasserted.

May also be shown as 810706081411ffff or 0x810706081411ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1412ffff • 81070608-1414ffff

81070608-1412ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator transition to non-recoverable has deasserted.

May also be shown as 810706081412ffff or 0x810706081412ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1413ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator transition to non-recoverable has deasserted.

May also be shown as 810706081413ffff or 0x810706081413ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1414ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator transition to non-recoverable has deasserted.

May also be shown as 810706081414ffff or 0x810706081414ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1415ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator transition to non-recoverable has deasserted.

May also be shown as 810706081415ffff or 0x810706081415ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-1881ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: A voltage regulator in memory expansion module transition to non-recoverable has deasserted.

May also be shown as 810706081881ffff or 0x810706081881ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81070608-2201ffff Sensor [SensorElementName] has deasserted the transition to non-recoverable.

Explanation: System power on blocking has deasserted.

May also be shown as 810706082201ffff or 0x810706082201ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0531

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

81080004-1d01ffff • 81080004-1d03ffff

81080004-1d01ffff Device [LogicalDeviceElementName] has been added.

Explanation: Device Fan 1 has been inserted.

May also be shown as 810800041d01ffff or 0x810800041d01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d02ffff Device [LogicalDeviceElementName] has been added.

Explanation: Device Fan 2 has been inserted.

May also be shown as 810800041d02ffff or 0x810800041d02ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d03ffff Device [LogicalDeviceElementName] has been added.

Explanation: Device Fan 3 has been inserted.

May also be shown as 810800041d03ffff or 0x810800041d03ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d04ffff Device [LogicalDeviceElementName] has been added.

Explanation: Device Fan 4 has been inserted.

May also be shown as 810800041d04ffff or 0x810800041d04ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d05ffff Device [LogicalDeviceElementName] has been added.

Explanation: Device Fan 5 has been inserted.

May also be shown as 810800041d05ffff or 0x810800041d05ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d06ffff Device [LogicalDeviceElementName] has been added.

Explanation: Fan 1 in memory expansion module has been inserted.

May also be shown as 810800041d06ffff or 0x810800041d06ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d07ffff • 81080004-1d09ffff

81080004-1d07ffff Device [LogicalDeviceElementName] has been added.

Explanation: Fan 2 in memory expansion module has been inserted.

May also be shown as 810800041d07ffff or 0x810800041d07ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d08ffff Device [LogicalDeviceElementName] has been added.

Explanation: Fan 3 in memory expansion module has been inserted.

May also be shown as 810800041d08ffff or 0x810800041d08ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d09ffff Device [LogicalDeviceElementName] has been added.

Explanation: Fan 4 in memory expansion module has been inserted.

May also be shown as 810800041d09ffff or 0x810800041d09ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

81080004-1d0affff Device [LogicalDeviceElementName] has been added.

Explanation: Fan 5 in memory expansion module has been inserted.

May also be shown as 810800041d0affff or 0x810800041d0affff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0536

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

810b010a-1e81ffff Redundancy Lost for [RedundancySetElementName] has deasserted.

Explanation: Fan 1 redundancy has been regained.

May also be shown as 810b010a1e81ffff or 0x810b010a1e81ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0803

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b010a-1e82ffff Redundancy Lost for [RedundancySetElementName] has deasserted.

Explanation: Fan 2 redundancy has been regained.

May also be shown as 810b010a1e82ffff or 0x810b010a1e82ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0803

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b010a-1e83ffff • 810b010c-2581ffff

810b010a-1e83ffff Redundancy Lost for [RedundancySetElementName] has deasserted.

Explanation: Fan 3 redundancy has been regained.

May also be shown as 810b010a1e83ffff or 0x810b010a1e83ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0803

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b010a-1e84ffff Redundancy Lost for [RedundancySetElementName] has deasserted.

Explanation: Fan 4 redundancy has been regained.

May also be shown as 810b010a1e84ffff or 0x810b010a1e84ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0803

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b010c-2581ffff Redundancy Lost for [RedundancySetElementName] has deasserted.

Explanation: Memory component group has regained its redundancy

May also be shown as 810b010c2581ffff or 0x810b010c2581ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0803

SNMP Trap ID: 41

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

810b030c-2581ffff Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has deasserted.

Explanation: Memory component group has regained its redundancy.

May also be shown as 810b030c2581ffff or 0x810b030c2581ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0807

SNMP Trap ID: 43

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

810b050a-1e81ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted.

Explanation: Fan 1 has regained its redundancy.

May also be shown as 810b050a1e81ffff or 0x810b050a1e81ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0811

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b050a-1e82ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted.

Explanation: Fan 2 has regained its redundancy.

May also be shown as 810b050a1e82ffff or 0x810b050a1e82ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0811

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b050a-1e83ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted.

Explanation: Fan 3 has regained its redundancy.

May also be shown as 810b050a1e83ffff or 0x810b050a1e83ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0811

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b050a-1e84ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted.

Explanation: Fan 4 has regained its redundancy.

May also be shown as 810b050a1e84ffff or 0x810b050a1e84ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0811

SNMP Trap ID: 11

Automatically notify Support: No

User response: No action; information only.

810b050c-2581ffff Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted.

Explanation: Memory component group has regained its redundancy.

May also be shown as 810b050c2581ffff or 0x810b050c2581ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0811

SNMP Trap ID: 41

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0007-0301ffff [ProcessorElementName] has Recovered from IERR.

Explanation: IMM has detected that processor 1 recovered from an IERR condition.

May also be shown as 816f00070301ffff or 0x816f00070301ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0043

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0007-0302ffff [ProcessorElementName] has Recovered from IERR.

Explanation: IMM has detected that processor 2 recovered from an IERR condition.

May also be shown as 816f00070302ffff or 0x816f00070302ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0043

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0007-0303ffff [ProcessorElementName] has Recovered from IERR.

Explanation: IMM has detected that processor 3 recovered from an IERR condition.

May also be shown as 816f00070303ffff or 0x816f00070303ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0043

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0007-0304ffff • 816f0008-0a02ffff

816f0007-0304ffff [ProcessorElementName] has Recovered from IERR.

Explanation: IMM has detected that processor 4 recovered from an IERR condition.

May also be shown as 816f00070304ffff or 0x816f00070304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0043

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0008-0a01ffff [PowerSupplyElementName] has been removed from container [PhysicalPackageElementName].

Explanation: IMM has detected that Power Supply 1 has been removed.

May also be shown as 816f00080a01ffff or 0x816f00080a01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0085

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0008-0a02ffff [PowerSupplyElementName] has been removed from container [PhysicalPackageElementName].

Explanation: IMM has detected that Power Supply 2 has been removed.

May also be shown as 816f00080a02ffff or 0x816f00080a02ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0085

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0008-1881ffff [PowerSupplyElementName] has been removed from container [PhysicalPackageElementName].

Explanation: MEU Power supply has been removed.

May also be shown as 816f00081881ffff or 0x816f00081881ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0085

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

816f0009-1381ffff [PowerSupplyElementName] has been turned on.

Explanation: IMM has detected that the system power has been turned on.

May also be shown as 816f00091381ffff or 0x816f00091381ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0107

SNMP Trap ID: 24

Automatically notify Support: No

User response: No action; information only.

816f000d-0400ffff The Drive [StorageVolumeElementName] has been removed from unit
[PhysicalPackageElementName].

Explanation: Presence of drive 0 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0400ffff or 0x816f000d0400ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0401ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 1 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0401ffff or 0x816f000d0401ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0402ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 2 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0402ffff or 0x816f000d0402ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0403ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 3 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0403ffff or 0x816f000d0403ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0404ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 4 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0404ffff or 0x816f000d0404ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0405ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 5 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0405ffff or 0x816f000d0405ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0406ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 6 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0406ffff or 0x816f000d0406ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0407ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 7 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0407ffff or 0x816f000d0407ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0408ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 8 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0408ffff or 0x816f000d0408ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-0409ffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 9 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d0409ffff or 0x816f000d0409ffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-040affff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 10 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d040affff or 0x816f000d040affff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-040bffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 11 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d040bffff or 0x816f000d040bffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-040cffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 12 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d040cffff or 0x816f000d040cffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-040dffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 13 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d040dffff or 0x816f000d040dffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-040effff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 14 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d040effff or 0x816f000d040effff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000d-040fffff The Drive [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].

Explanation: Presence of drive 15 is no longer detected. If hard drive is absent from drive bay a filler is required.

May also be shown as 816f000d040fffff or 0x816f000d040fffff

Severity: Info

Alert Category: System

Serviceable: Yes

CIM Information: Prefix: PLAT and ID: 0163

SNMP Trap ID: 22

Automatically notify Support: No

User response:

- If drive was intentionally removed, no action required.
- Make sure that the drive properly seated.
- If drive is properly seated, replace the drive.

816f000f-2201ffff The System [ComputerSystemElementName] has detected a POST Error deassertion.

Explanation: IMM has detected that Post Error has deasserted. (ABR Status or Firmware Error).

May also be shown as 816f000f2201ffff or 0x816f000f2201ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0185

SNMP Trap ID:

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f001b-1f05ffff The network port [ManagedElementName] has been disconnected.

Explanation: Memory expansion module fan cable was disconnected.

May also be shown as 816f001b1f05ffff or 0x816f001b1f05ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0263

SNMP Trap ID: 60

Automatically notify Support: No

User response: no action; information only

816f001b-1f06ffff • 816f001b-1f08ffff

816f001b-1f06ffff The network port [ManagedElementName] has been disconnected.

Explanation: Memory expansion module LED cable was disconnected.

May also be shown as 816f001b1f06ffff or 0x816f001b1f06ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0263

SNMP Trap ID: 60

Automatically notify Support: No

User response: no action; information only

816f001b-1f07ffff The network port [ManagedElementName] has been disconnected.

Explanation: The EXA Cable 1 is disconnected.

May also be shown as 816f001b1f07ffff or 0x816f001b1f07ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0263

SNMP Trap ID: 60

Automatically notify Support: No

User response: no action; information only

816f001b-1f08ffff The network port [ManagedElementName] has been disconnected.

Explanation: The EXA Cable 2 is disconnected.

May also be shown as 816f001b1f08ffff or 0x816f001b1f08ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0263

SNMP Trap ID: 60

Automatically notify Support: No

User response: no action; information only

816f001b-1f09ffff The network port [ManagedElementName] has been disconnected.

Explanation: The EXA Cable 3 is disconnected.

May also be shown as 816f001b1f09ffff or 0x816f001b1f09ffff

Severity: Warning

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0263

SNMP Trap ID: 60

Automatically notify Support: No

User response: no action; information only

816f0021-0b04ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a fault condition in PCIe slot 4 has been removed.

May also be shown as 816f00210b04ffff or 0x816f00210b04ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-0b05ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a fault condition in PCIe slot 5 has been removed.

May also be shown as 816f00210b05ffff or 0x816f00210b05ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-0b06ffff • 816f0021-0b08ffff

816f0021-0b06ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a fault condition in PCIe slot 6 has been removed.

May also be shown as 816f00210b06ffff or 0x816f00210b06ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-0b07ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a fault condition in PCIe slot 7 has been removed.

May also be shown as 816f00210b07ffff or 0x816f00210b07ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-0b08ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a fault condition in PCIe slot 8 has been removed.

May also be shown as 816f00210b08ffff or 0x816f00210b08ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-0b09ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: Fault condition in PCIe slot 6 has been removed

May also be shown as 816f00210b09ffff or 0x816f00210b09ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-0b0affff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: Fault condition in PCIe slot 7 has been removed

May also be shown as 816f00210b0affff or 0x816f00210b0affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0021-2201ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected a Fault condition in a slot has been removed.

May also be shown as 816f00212201ffff or 0x816f00212201ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0021-2582ffff Fault condition removed on slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].

Explanation: IMM has detected that a fault condition in a PCIe slot has been removed.

May also be shown as 816f00212582ffff or 0x816f00212582ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0331

SNMP Trap ID: 50

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0028-2584ffff Sensor [SensorElementName] has returned to normal on management system [ComputerSystemElementName].

Explanation: IMM was unable to communicate properly on an internet interface has deasserted

May also be shown as 816f00282584ffff or 0x816f00282584ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0399

SNMP Trap ID: 60

Automatically notify Support: No

User response: no action; information only.

816f0107-0301ffff An Over-Temperature Condition has been removed on [ProcessorElementName].

Explanation: The microprocessor 1 temperature has returned to below the critical level.

May also be shown as 816f01070301ffff or 0x816f01070301ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0037

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0107-0302ffff An Over-Temperature Condition has been removed on [ProcessorElementName].

Explanation: The microprocessor 2 temperature has returned to below the critical level.

May also be shown as 816f01070302ffff or 0x816f01070302ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0037

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0107-0303ffff An Over-Temperature Condition has been removed on [ProcessorElementName].

Explanation: The microprocessor 3 temperature has returned to below the critical level.

May also be shown as 816f01070303ffff or 0x816f01070303ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0037

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0107-0304ffff An Over-Temperature Condition has been removed on [ProcessorElementName].

Explanation: The microprocessor 4 temperature has returned to below the critical level.

May also be shown as 816f01070304ffff or 0x816f01070304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0037

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0108-0a01ffff • 816f0108-1881ffff

816f0108-0a01ffff [PowerSupplyElementName] has returned to OK status.

Explanation: IMM has detected that Power Supply 1 has returned to a normal operational status.

May also be shown as 816f01080a01ffff or 0x816f01080a01ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0087

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

816f0108-0a02ffff [PowerSupplyElementName] has returned to OK status.

Explanation: IMM has detected that Power Supply 2 has returned to a normal operational status.

May also be shown as 816f01080a02ffff or 0x816f01080a02ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0087

SNMP Trap ID: 4

Automatically notify Support: No

User response: No action; information only.

816f0108-1881ffff [PowerSupplyElementName] has returned to OK status.

Explanation: Memory expansion module power supply return to normal operational status.

May also be shown as 816f01081881ffff or 0x816f01081881ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0087

SNMP Trap ID: 4

Automatically notify Support: No

User response: Information only; on action is required.

816f010c-08810001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 1.

May also be shown as 816f010c08810001 or 0x816f010c08810001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 1.

May also be shown as 816f010c08810002 or 0x816f010c08810002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 1.

May also be shown as 816f010c08810003 or 0x816f010c08810003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 1.

May also be shown as 816f010c08810004 or 0x816f010c08810004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 1.

May also be shown as 816f010c08810005 or 0x816f010c08810005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 1.

May also be shown as 816f010c08810006 or 0x816f010c08810006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 1.

May also be shown as 816f010c08810007 or 0x816f010c08810007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08810008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 1.

May also be shown as 816f010c08810008 or 0x816f010c08810008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 2.

May also be shown as 816f010c08820001 or 0x816f010c08820001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 2.

May also be shown as 816f010c08820002 or 0x816f010c08820002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 2.

May also be shown as 816f010c08820003 or 0x816f010c08820003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 2.

May also be shown as 816f010c08820004 or 0x816f010c08820004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 2.

May also be shown as 816f010c08820005 or 0x816f010c08820005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 2.

May also be shown as 816f010c08820006 or 0x816f010c08820006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 2.

May also be shown as 816f010c08820007 or 0x816f010c08820007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08820008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 2.

May also be shown as 816f010c08820008 or 0x816f010c08820008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 3.

May also be shown as 816f010c08830001 or 0x816f010c08830001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 3.

May also be shown as 816f010c08830002 or 0x816f010c08830002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 3.

May also be shown as 816f010c08830003 or 0x816f010c08830003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 3.

May also be shown as 816f010c08830004 or 0x816f010c08830004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 3.

May also be shown as 816f010c08830005 or 0x816f010c08830005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 3.

May also be shown as 816f010c08830006 or 0x816f010c08830006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 3.

May also be shown as 816f010c08830007 or 0x816f010c08830007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08830008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 3.

May also be shown as 816f010c08830008 or 0x816f010c08830008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 4.

May also be shown as 816f010c08840001 or 0x816f010c08840001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 4.

May also be shown as 816f010c08840002 or 0x816f010c08840002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 4.

May also be shown as 816f010c08840003 or 0x816f010c08840003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 4.

May also be shown as 816f010c08840004 or 0x816f010c08840004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 4.

May also be shown as 816f010c08840005 or 0x816f010c08840005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 4.

May also be shown as 816f010c08840006 or 0x816f010c08840006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 4.

May also be shown as 816f010c08840007 or 0x816f010c08840007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08840008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 4.

May also be shown as 816f010c08840008 or 0x816f010c08840008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 5.

May also be shown as 816f010c08850001 or 0x816f010c08850001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 5.

May also be shown as 816f010c08850002 or 0x816f010c08850002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 5.

May also be shown as 816f010c08850003 or 0x816f010c08850003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 5.

May also be shown as 816f010c08850004 or 0x816f010c08850004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 5.

May also be shown as 816f010c08850005 or 0x816f010c08850005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 5.

May also be shown as 816f010c08850006 or 0x816f010c08850006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 5.

May also be shown as 816f010c08850007 or 0x816f010c08850007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08850008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 5.

May also be shown as 816f010c08850008 or 0x816f010c08850008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 6.

May also be shown as 816f010c08860001 or 0x816f010c08860001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 6.

May also be shown as 816f010c08860002 or 0x816f010c08860002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 6.

May also be shown as 816f010c08860003 or 0x816f010c08860003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 6.

May also be shown as 816f010c08860004 or 0x816f010c08860004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 6.

May also be shown as 816f010c08860005 or 0x816f010c08860005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 6.

May also be shown as 816f010c08860006 or 0x816f010c08860006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 6.

May also be shown as 816f010c08860007 or 0x816f010c08860007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08860008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 6.

May also be shown as 816f010c08860008 or 0x816f010c08860008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 7.

May also be shown as 816f010c08870001 or 0x816f010c08870001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 7.

May also be shown as 816f010c08870002 or 0x816f010c08870002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 7.

May also be shown as 816f010c08870003 or 0x816f010c08870003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 7.

May also be shown as 816f010c08870004 or 0x816f010c08870004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 7.

May also be shown as 816f010c08870005 or 0x816f010c08870005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 7.

May also be shown as 816f010c08870006 or 0x816f010c08870006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 7.

May also be shown as 816f010c08870007 or 0x816f010c08870007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08870008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 7.

May also be shown as 816f010c08870008 or 0x816f010c08870008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of mem card 8.

May also be shown as 816f010c08880001 or 0x816f010c08880001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of mem card 8.

May also be shown as 816f010c08880002 or 0x816f010c08880002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of mem card 8.

May also be shown as 816f010c08880003 or 0x816f010c08880003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of mem card 8.

May also be shown as 816f010c08880004 or 0x816f010c08880004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of mem card 8.

May also be shown as 816f010c08880005 or 0x816f010c08880005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of mem card 8.

May also be shown as 816f010c08880006 or 0x816f010c08880006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of mem card 8.

May also be shown as 816f010c08880007 or 0x816f010c08880007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-08880008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of mem card 8.

May also be shown as 816f010c08880008 or 0x816f010c08880008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810001 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 1 of memory expansion unit(MEU).

May also be shown as 816f010c18810001 or 0x816f010c18810001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810002 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 2 of memory expansion unit(MEU).

May also be shown as 816f010c18810002 or 0x816f010c18810002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810003 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 3 of memory expansion unit(MEU).

May also be shown as 816f010c18810003 or 0x816f010c18810003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810004 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 4 of memory expansion unit(MEU).

May also be shown as 816f010c18810004 or 0x816f010c18810004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810005 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 5 of memory expansion unit(MEU).

May also be shown as 816f010c18810005 or 0x816f010c18810005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810006 • 816f010c-18810008

816f010c-18810006 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 6 of memory expansion unit(MEU).

May also be shown as 816f010c18810006 or 0x816f010c18810006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810007 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 7 of memory expansion unit(MEU).

May also be shown as 816f010c18810007 or 0x816f010c18810007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810008 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 8 of memory expansion unit(MEU).

May also be shown as 816f010c18810008 or 0x816f010c18810008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810009 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 9 of memory expansion unit(MEU).

May also be shown as 816f010c18810009 or 0x816f010c18810009

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881000a Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 10 of memory expansion unit(MEU).

May also be shown as 816f010c1881000a or 0x816f010c1881000a

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881000b Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 11 of memory expansion unit(MEU).

May also be shown as 816f010c1881000b or 0x816f010c1881000b

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881000c Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 12 of memory expansion unit(MEU).

May also be shown as 816f010c1881000c or 0x816f010c1881000c

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881000d Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 13 of memory expansion unit(MEU).

May also be shown as 816f010c1881000d or 0x816f010c1881000d

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881000e Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 14 of memory expansion unit(MEU).

May also be shown as 816f010c1881000e or 0x816f010c1881000e

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881000f Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 15 of memory expansion unit(MEU).
May also be shown as 816f010c1881000f or 0x816f010c1881000f

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810010 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 16 of memory expansion unit(MEU).
May also be shown as 816f010c18810010 or 0x816f010c18810010

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810011 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 17 of memory expansion unit(MEU).
May also be shown as 816f010c18810011 or 0x816f010c18810011

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810012 • 816f010c-18810014

816f010c-18810012 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 18 of memory expansion unit(MEU).

May also be shown as 816f010c18810012 or 0x816f010c18810012

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810013 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 19 of memory expansion unit(MEU).

May also be shown as 816f010c18810013 or 0x816f010c18810013

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810014 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 20 of memory expansion unit(MEU).

May also be shown as 816f010c18810014 or 0x816f010c18810014

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810015 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 21 of memory expansion unit(MEU).
May also be shown as 816f010c18810015 or 0x816f010c18810015

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810016 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 22 of memory expansion unit(MEU).
May also be shown as 816f010c18810016 or 0x816f010c18810016

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810017 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 23 of memory expansion unit(MEU).
May also be shown as 816f010c18810017 or 0x816f010c18810017

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810018 • 816f010c-1881001a

816f010c-18810018 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 24 of memory expansion unit(MEU).

May also be shown as 816f010c18810018 or 0x816f010c18810018

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810019 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 25 of memory expansion unit(MEU).

May also be shown as 816f010c18810019 or 0x816f010c18810019

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881001a Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 26 of memory expansion unit(MEU).

May also be shown as 816f010c1881001a or 0x816f010c1881001a

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881001b Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 27 of memory expansion unit(MEU).

May also be shown as 816f010c1881001b or 0x816f010c1881001b

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881001c Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 28 of memory expansion unit(MEU).

May also be shown as 816f010c1881001c or 0x816f010c1881001c

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881001d Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 29 of memory expansion unit(MEU).

May also be shown as 816f010c1881001d or 0x816f010c1881001d

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881001e Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 30 of memory expansion unit(MEU).
May also be shown as 816f010c1881001e or 0x816f010c1881001e

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-1881001f Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 31 of memory expansion unit(MEU).
May also be shown as 816f010c1881001f or 0x816f010c1881001f

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-18810020 Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has occurred in DIMM 32 of memory expansion unit(MEU).
May also be shown as 816f010c18810020 or 0x816f010c18810020

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010c-2581ffff Uncorrectable error recovery detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: A memory uncorrectable error recovery has been detected.

May also be shown as 816f010c2581ffff or 0x816f010c2581ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0139

SNMP Trap ID: 41

Automatically notify Support: No

User response: Information only; no action required.

816f010d-0400ffff The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 0 has been enabled.

May also be shown as 816f010d0400ffff or 0x816f010d0400ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0401FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 1 has been enabled.

May also be shown as 816f010d0401FFFF or 0x816f010d0401FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0402FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 2 has been enabled.

May also be shown as 816f010d0402FFFF or 0x816f010d0402FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0403FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 3 has been enabled.

May also be shown as 816f010d0403FFFF or 0x816f010d0403FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0404FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 4 has been enabled.

May also be shown as 816f010d0404FFFF or 0x816f010d0404FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0405FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 5 has been enabled.

May also be shown as 816f010d0405FFFF or 0x816f010d0405FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0406FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 6 has been enabled.

May also be shown as 816f010d0406FFFF or 0x816f010d0406FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0407FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 7 has been enabled.

May also be shown as 816f010d0407FFFF or 0x816f010d0407FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0408FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 8 has been enabled.

May also be shown as 816f010d0408FFFF or 0x816f010d0408FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-0409FFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 9 has been enabled.

May also be shown as 816f010d0409FFFF or 0x816f010d0409FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-040aFFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 10 has been enabled.

May also be shown as 816f010d040aFFFF or 0x816f010d040aFFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-040bFFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 11 has been enabled.

May also be shown as 816f010d040bFFFF or 0x816f010d040bFFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-040cFFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 12 has been enabled.

May also be shown as 816f010d040cFFFF or 0x816f010d040cFFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-040dFFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 13 has been enabled.

May also be shown as 816f010d040dFFFF or 0x816f010d040dFFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-040eFFFF • 816f010f-2201FFFF

816f010d-040eFFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 14 has been enabled.

May also be shown as 816f010d040eFFFF or 0x816f010d040eFFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010d-040fFFFF The Drive [StorageVolumeElementName] has been enabled.

Explanation: The previously disabled drive 15 has been enabled.

May also be shown as 816f010d040fFFFF or 0x816f010d040fFFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0167

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f010f-2201FFFF The System [ComputerSystemElementName] has recovered from a firmware hang.

Explanation: IMM has recovered from a System Firmware Hang.

May also be shown as 816f010f2201FFFF or 0x816f010f2201FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0187

SNMP Trap ID: 25

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0113-1701FFFF System [ComputerSystemElementName] has recovered from a bus timeout.

Explanation: System has recovered from a bus timeout

May also be shown as 816f01131701FFFF or 0x816f01131701FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0225

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-0701FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: IMM has detected an Interconnect Configuration error has been repaired.

May also be shown as 816f011b0701FFFF or 0x816f011b0701FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-1801FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: System has recovered from an internal memory expansion module FPGA error.

May also be shown as 816f011b1801FFFF or 0x816f011b1801FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-1f05FFFF • 816f011b-1f07FFFF

816f011b-1f05FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: An fan cable configuration error was repaired

May also be shown as 816f011b1f05FFFF or 0x816f011b1f05FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-1f06FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: An LED cable configuration error was repaired

May also be shown as 816f011b1f06FFFF or 0x816f011b1f06FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-1f07FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: EXA cable 1 configuration error was repaired

May also be shown as 816f011b1f07FFFF or 0x816f011b1f07FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-1f08FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: EXA cable 2 configuration error was repaired

May also be shown as 816f011b1f08FFFF or 0x816f011b1f08FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f011b-1f09FFFF The connector [PhysicalConnectorElementName] configuration error has been repaired.

Explanation: EXA cable 3 configuration error was repaired

May also be shown as 816f011b1f09FFFF or 0x816f011b1f09FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0267

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0125-0c01FFFF [ManagedElementName] detected as present.

Explanation: IMM has detected the operator information panel is present.

May also be shown as 816f01250c01FFFF or 0x816f01250c01FFFF

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0390

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0207-0301FFFF [ProcessorElementName] has Recovered from FRB1/BIST condition.

Explanation: IMM has detected that Processor 1 has recovered from a FRB1/BIST condition.

May also be shown as 816f02070301FFFF or 0x816f02070301FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0045

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0207-0302FFFF [ProcessorElementName] has Recovered from FRB1/BIST condition.

Explanation: IMM has detected that Processor 2 has recovered from a FRB1/BIST condition.

May also be shown as 816f02070302FFFF or 0x816f02070302FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0045

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0207-0303FFFF [ProcessorElementName] has Recovered from FRB1/BIST condition.

Explanation: IMM has detected that Processor 3 has recovered from a FRB1/BIST condition.

May also be shown as 816f02070303FFFF or 0x816f02070303FFFF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0045

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0207-0304ffff [ProcessorElementName] has Recovered from FRB1/BIST condition.

Explanation: IMM has detected that Processor 4 has recovered from a FRB1/BIST condition.

May also be shown as 816f02070304ffff or 0x816f02070304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0045

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0208-0701ffff Failure no longer predicted on [PowerSupplyElementName].

Explanation: EPOW fault recovered

May also be shown as 816f02080701ffff or 0x816f02080701ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0089

SNMP Trap ID: 164

Automatically notify Support: No

User response: No action; information only.

816f020d-0400ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 0 no longer exists.

May also be shown as 816f020d0400ffff or 0x816f020d0400ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0401ffff • 816f020d-0403ffff

816f020d-0401ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 1 no longer exists.

May also be shown as 816f020d0401ffff or 0x816f020d0401ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0402ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 2 no longer exists.

May also be shown as 816f020d0402ffff or 0x816f020d0402ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0403ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 3 no longer exists.

May also be shown as 816f020d0403ffff or 0x816f020d0403ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0404ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 4 no longer exists.

May also be shown as 816f020d0404ffff or 0x816f020d0404ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0405ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 5 no longer exists.

May also be shown as 816f020d0405ffff or 0x816f020d0405ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0406ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 6 no longer exists.

May also be shown as 816f020d0406ffff or 0x816f020d0406ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0407ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 7 no longer exists.

May also be shown as 816f020d0407ffff or 0x816f020d0407ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0408ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 8 no longer exists.

May also be shown as 816f020d0408ffff or 0x816f020d0408ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-0409ffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 9 no longer exists.

May also be shown as 816f020d0409ffff or 0x816f020d0409ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-040affff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 10 no longer exists.

May also be shown as 816f020d040affff or 0x816f020d040affff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-040bffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 11 no longer exists.

May also be shown as 816f020d040bffff or 0x816f020d040bffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-040cffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 12 no longer exists.

May also be shown as 816f020d040cffff or 0x816f020d040cffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-040dffff • 816f020d-040ffffF

816f020d-040dffff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 13 no longer exists.

May also be shown as 816f020d040dffff or 0x816f020d040dffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-040effff Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 14 no longer exists.

May also be shown as 816f020d040effff or 0x816f020d040effff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f020d-040ffffF Failure no longer Predicted on drive [StorageVolumeElementName] for array [ComputerSystemElementName].

Explanation: The predicted failure for Drive 15 no longer exists.

May also be shown as 816f020d040ffffF or 0x816f020d040ffffF

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0169

SNMP Trap ID: 27

Automatically notify Support: No

User response: No action; information only.

816f0308-0a01ffff [PowerSupplyElementName] has returned to a Normal Input State.

Explanation: IMM has detected that the input power for Power Supply 1 has returned to normal.

May also be shown as 816f03080a01ffff or 0x816f03080a01ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0099

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0308-0a02ffff [PowerSupplyElementName] has returned to a Normal Input State.

Explanation: IMM has detected that the input power for Power Supply 2 has returned to normal.

May also be shown as 816f03080a02ffff or 0x816f03080a02ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0099

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0308-1881ffff [PowerSupplyElementName] has returned to a Normal Input State.

Explanation: Power supply has returned to normal

May also be shown as 816f03081881ffff or 0x816f03081881ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0099

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f030c-08810001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 1.

May also be shown as 816f030c08810001 or 0x816f030c08810001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08810002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 1.

May also be shown as 816f030c08810002 or 0x816f030c08810002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08810003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 1.

May also be shown as 816f030c08810003 or 0x816f030c08810003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08810004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 1.

May also be shown as 816f030c08810004 or 0x816f030c08810004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08810005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 1.

May also be shown as 816f030c08810005 or 0x816f030c08810005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08810006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 1.

May also be shown as 816f030c08810006 or 0x816f030c08810006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08810007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 1.

May also be shown as 816f030c08810007 or 0x816f030c08810007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 2.

May also be shown as 816f030c08820001 or 0x816f030c08820001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 2.

May also be shown as 816f030c08820002 or 0x816f030c08820002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 2.

May also be shown as 816f030c08820003 or 0x816f030c08820003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 2.

May also be shown as 816f030c08820004 or 0x816f030c08820004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 2.

May also be shown as 816f030c08820005 or 0x816f030c08820005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 2.

May also be shown as 816f030c08820006 or 0x816f030c08820006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 2.

May also be shown as 816f030c08820007 or 0x816f030c08820007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08820008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 2.

May also be shown as 816f030c08820008 or 0x816f030c08820008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 3.

May also be shown as 816f030c08830001 or 0x816f030c08830001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 3.

May also be shown as 816f030c08830002 or 0x816f030c08830002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 3.

May also be shown as 816f030c08830003 or 0x816f030c08830003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 3.

May also be shown as 816f030c08830004 or 0x816f030c08830004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 3.

May also be shown as 816f030c08830005 or 0x816f030c08830005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 3.

May also be shown as 816f030c08830006 or 0x816f030c08830006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 3.

May also be shown as 816f030c08830007 or 0x816f030c08830007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08830008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 3.

May also be shown as 816f030c08830008 or 0x816f030c08830008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 4.

May also be shown as 816f030c08840001 or 0x816f030c08840001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840002 • 816f030c-08840004

816f030c-08840002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 4.

May also be shown as 816f030c08840002 or 0x816f030c08840002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 4.

May also be shown as 816f030c08840003 or 0x816f030c08840003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 4.

May also be shown as 816f030c08840004 or 0x816f030c08840004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 4.

May also be shown as 816f030c08840005 or 0x816f030c08840005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 4.

May also be shown as 816f030c08840006 or 0x816f030c08840006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 4.

May also be shown as 816f030c08840007 or 0x816f030c08840007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08840008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 4.

May also be shown as 816f030c08840008 or 0x816f030c08840008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 5.

May also be shown as 816f030c08850001 or 0x816f030c08850001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 5.

May also be shown as 816f030c08850002 or 0x816f030c08850002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 5.

May also be shown as 816f030c08850003 or 0x816f030c08850003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 5.

May also be shown as 816f030c08850004 or 0x816f030c08850004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 5.

May also be shown as 816f030c08850005 or 0x816f030c08850005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 5.

May also be shown as 816f030c08850006 or 0x816f030c08850006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 5.

May also be shown as 816f030c08850007 or 0x816f030c08850007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08850008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 5.

May also be shown as 816f030c08850008 or 0x816f030c08850008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 6.

May also be shown as 816f030c08860001 or 0x816f030c08860001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 6.

May also be shown as 816f030c08860002 or 0x816f030c08860002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 6.

May also be shown as 816f030c08860003 or 0x816f030c08860003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 6.

May also be shown as 816f030c08860004 or 0x816f030c08860004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 6.

May also be shown as 816f030c08860005 or 0x816f030c08860005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 6.

May also be shown as 816f030c08860006 or 0x816f030c08860006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 6.

May also be shown as 816f030c08860007 or 0x816f030c08860007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08860008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 6.

May also be shown as 816f030c08860008 or 0x816f030c08860008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 7.

May also be shown as 816f030c08870001 or 0x816f030c08870001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 7.

May also be shown as 816f030c08870002 or 0x816f030c08870002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 7.

May also be shown as 816f030c08870003 or 0x816f030c08870003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 7.

May also be shown as 816f030c08870004 or 0x816f030c08870004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 7.

May also be shown as 816f030c08870005 or 0x816f030c08870005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 7.

May also be shown as 816f030c08870006 or 0x816f030c08870006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 7.

May also be shown as 816f030c08870007 or 0x816f030c08870007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08870008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 7.

May also be shown as 816f030c08870008 or 0x816f030c08870008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of mem card 8.

May also be shown as 816f030c08880001 or 0x816f030c08880001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of mem card 8.

May also be shown as 816f030c08880002 or 0x816f030c08880002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of mem card 8.

May also be shown as 816f030c08880003 or 0x816f030c08880003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of mem card 8.

May also be shown as 816f030c08880004 or 0x816f030c08880004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of mem card 8.

May also be shown as 816f030c08880005 or 0x816f030c08880005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of mem card 8.

May also be shown as 816f030c08880006 or 0x816f030c08880006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of mem card 8.

May also be shown as 816f030c08880007 or 0x816f030c08880007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-08880008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 8.

May also be shown as 816f030c08880008 or 0x816f030c08880008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-088810008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of mem card 1.

May also be shown as 816f030c088810008 or 0x816f030c088810008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810001 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 1 of memory expansion module(MEU).

May also be shown as 816f030c18810001 or 0x816f030c18810001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810002 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 2 of memory expansion module(MEU).

May also be shown as 816f030c18810002 or 0x816f030c18810002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810003 • 816f030c-18810005

816f030c-18810003 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 3 of memory expansion module(MEU).

May also be shown as 816f030c18810003 or 0x816f030c18810003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810004 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 4 of memory expansion module(MEU).

May also be shown as 816f030c18810004 or 0x816f030c18810004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810005 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 5 of memory expansion module(MEU).

May also be shown as 816f030c18810005 or 0x816f030c18810005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810006 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 6 of memory expansion module(MEU).

May also be shown as 816f030c18810006 or 0x816f030c18810006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810007 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 7 of memory expansion module(MEU).

May also be shown as 816f030c18810007 or 0x816f030c18810007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810008 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 8 of memory expansion module(MEU).

May also be shown as 816f030c18810008 or 0x816f030c18810008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810009 • 816f030c-1881000b

816f030c-18810009 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 9 of memory expansion module(MEU).

May also be shown as 816f030c18810009 or 0x816f030c18810009

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881000a Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 10 of memory expansion module(MEU).

May also be shown as 816f030c1881000a or 0x816f030c1881000a

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881000b Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 11 of memory expansion module(MEU).

May also be shown as 816f030c1881000b or 0x816f030c1881000b

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881000c Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 12 of memory expansion module(MEU).

May also be shown as 816f030c1881000c or 0x816f030c1881000c

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881000d Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 13 of memory expansion module(MEU).

May also be shown as 816f030c1881000d or 0x816f030c1881000d

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881000e Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 14 of memory expansion module(MEU).

May also be shown as 816f030c1881000e or 0x816f030c1881000e

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881000f • 816f030c-18810011

816f030c-1881000f Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 15 of memory expansion module(MEU).

May also be shown as 816f030c1881000f or 0x816f030c1881000f

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810010 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 16 of memory expansion module(MEU).

May also be shown as 816f030c18810010 or 0x816f030c18810010

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810011 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 17 of memory expansion module(MEU).

May also be shown as 816f030c18810011 or 0x816f030c18810011

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810012 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 18 of memory expansion module(MEU).

May also be shown as 816f030c18810012 or 0x816f030c18810012

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810013 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 19 of memory expansion module(MEU).

May also be shown as 816f030c18810013 or 0x816f030c18810013

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810014 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 20 of memory expansion module(MEU).

May also be shown as 816f030c18810014 or 0x816f030c18810014

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810015 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 21 of memory expansion module(MEU).

May also be shown as 816f030c18810015 or 0x816f030c18810015

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810016 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 22 of memory expansion module(MEU).

May also be shown as 816f030c18810016 or 0x816f030c18810016

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810017 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 23 of memory expansion module(MEU).

May also be shown as 816f030c18810017 or 0x816f030c18810017

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810018 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 24 of memory expansion module(MEU).

May also be shown as 816f030c18810018 or 0x816f030c18810018

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810019 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 25 of memory expansion module(MEU).

May also be shown as 816f030c18810019 or 0x816f030c18810019

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881001a Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 26 of memory expansion module(MEU).

May also be shown as 816f030c1881001a or 0x816f030c1881001a

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881001b • 816f030c-1881001d

816f030c-1881001b Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 27 of memory expansion module(MEU).

May also be shown as 816f030c1881001b or 0x816f030c1881001b

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881001c Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 28 of memory expansion module(MEU).

May also be shown as 816f030c1881001c or 0x816f030c1881001c

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881001d Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 29 of memory expansion module(MEU).

May also be shown as 816f030c1881001d or 0x816f030c1881001d

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881001e Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 30 of memory expansion module(MEU).

May also be shown as 816f030c1881001e or 0x816f030c1881001e

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-1881001f Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 31 of memory expansion module(MEU).

May also be shown as 816f030c1881001f or 0x816f030c1881001f

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-18810020 Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.

Explanation: Memory test failure has been recovered in DIMM 32 of memory expansion module(MEU).

May also be shown as 816f030c18810020 or 0x816f030c18810020

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f030c-2581ffff Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has recovered.

Explanation: A DIMM has recovered from a memory test failure.

May also be shown as 816f030c2581ffff or 0x816f030c2581ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0137

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f032b-2101ffff The firmware or software on system [ComputerSystemElementName]are compatible.

Explanation: A firmware or software incompatibility in a multi-node system has deasserted.

May also be shown as 816f032b2101ffff or 0x816f032b2101ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0443

SNMP Trap ID: 36

Automatically notify Support: No

User response: No action; information only.

816f0409-1381ffff [PowerSupplyElementName] power was restored.

Explanation: A power supply unit has been restored

May also be shown as 816f04091381ffff or 0x816f04091381ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0113

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 1 has been enabled.

May also be shown as 816f040c08810001 or 0x816f040c08810001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 1 has been enabled.

May also be shown as 816f040c08810002 or 0x816f040c08810002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 1 has been enabled.

May also be shown as 816f040c08810003 or 0x816f040c08810003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810004 • 816f040c-08810006

816f040c-08810004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 1 has been enabled.

May also be shown as 816f040c08810004 or 0x816f040c08810004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 1 has been enabled.

May also be shown as 816f040c08810005 or 0x816f040c08810005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 1 has been enabled.

May also be shown as 816f040c08810006 or 0x816f040c08810006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 1 has been enabled.

May also be shown as 816f040c08810007 or 0x816f040c08810007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08810008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 1 has been enabled.

May also be shown as 816f040c08810008 or 0x816f040c08810008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 2 has been enabled.

May also be shown as 816f040c08820001 or 0x816f040c08820001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820002 • 816f040c-08820004

816f040c-08820002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 2 has been enabled.

May also be shown as 816f040c08820002 or 0x816f040c08820002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 2 has been enabled.

May also be shown as 816f040c08820003 or 0x816f040c08820003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 2 has been enabled.

May also be shown as 816f040c08820004 or 0x816f040c08820004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 2 has been enabled.

May also be shown as 816f040c08820005 or 0x816f040c08820005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 2 has been enabled.

May also be shown as 816f040c08820006 or 0x816f040c08820006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 2 has been enabled.

May also be shown as 816f040c08820007 or 0x816f040c08820007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08820008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 2 has been enabled.

May also be shown as 816f040c08820008 or 0x816f040c08820008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 3 has been enabled.

May also be shown as 816f040c08830001 or 0x816f040c08830001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 3 has been enabled.

May also be shown as 816f040c08830002 or 0x816f040c08830002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 3 has been enabled.

May also be shown as 816f040c08830003 or 0x816f040c08830003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 3 has been enabled.

May also be shown as 816f040c08830004 or 0x816f040c08830004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 3 has been enabled.

May also be shown as 816f040c08830005 or 0x816f040c08830005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 3 has been enabled.

May also be shown as 816f040c08830006 or 0x816f040c08830006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 3 has been enabled.

May also be shown as 816f040c08830007 or 0x816f040c08830007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08830008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 3 has been enabled.

May also be shown as 816f040c08830008 or 0x816f040c08830008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 4 has been enabled.

May also be shown as 816f040c08840001 or 0x816f040c08840001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 4 has been enabled.

May also be shown as 816f040c08840002 or 0x816f040c08840002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 4 has been enabled.

May also be shown as 816f040c08840003 or 0x816f040c08840003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840004 • 816f040c-08840006

816f040c-08840004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 4 has been enabled.

May also be shown as 816f040c08840004 or 0x816f040c08840004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 4 has been enabled.

May also be shown as 816f040c08840005 or 0x816f040c08840005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 4 has been enabled.

May also be shown as 816f040c08840006 or 0x816f040c08840006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 4 has been enabled.

May also be shown as 816f040c08840007 or 0x816f040c08840007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08840008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 4 has been enabled.

May also be shown as 816f040c08840008 or 0x816f040c08840008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 5 has been enabled.

May also be shown as 816f040c08850001 or 0x816f040c08850001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850002 • 816f040c-08850004

816f040c-08850002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 5 has been enabled.

May also be shown as 816f040c08850002 or 0x816f040c08850002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 5 has been enabled.

May also be shown as 816f040c08850003 or 0x816f040c08850003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 5 has been enabled.

May also be shown as 816f040c08850004 or 0x816f040c08850004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 5 has been enabled.

May also be shown as 816f040c08850005 or 0x816f040c08850005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 5 has been enabled.

May also be shown as 816f040c08850006 or 0x816f040c08850006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 5 has been enabled.

May also be shown as 816f040c08850007 or 0x816f040c08850007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08850008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 5 has been enabled.

May also be shown as 816f040c08850008 or 0x816f040c08850008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 6 has been enabled.

May also be shown as 816f040c08860001 or 0x816f040c08860001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 6 has been enabled.

May also be shown as 816f040c08860002 or 0x816f040c08860002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 6 has been enabled.

May also be shown as 816f040c08860003 or 0x816f040c08860003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 6 has been enabled.

May also be shown as 816f040c08860004 or 0x816f040c08860004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 6 has been enabled.

May also be shown as 816f040c08860005 or 0x816f040c08860005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 6 has been enabled.

May also be shown as 816f040c08860006 or 0x816f040c08860006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 6 has been enabled.

May also be shown as 816f040c08860007 or 0x816f040c08860007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08860008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 6 has been enabled.

May also be shown as 816f040c08860008 or 0x816f040c08860008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 7 has been enabled.

May also be shown as 816f040c08870001 or 0x816f040c08870001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 7 has been enabled.

May also be shown as 816f040c08870002 or 0x816f040c08870002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 7 has been enabled.

May also be shown as 816f040c08870003 or 0x816f040c08870003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 7 has been enabled.

May also be shown as 816f040c08870004 or 0x816f040c08870004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 7 has been enabled.

May also be shown as 816f040c08870005 or 0x816f040c08870005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 7 has been enabled.

May also be shown as 816f040c08870006 or 0x816f040c08870006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 7 has been enabled.

May also be shown as 816f040c08870007 or 0x816f040c08870007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08870008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 7 has been enabled.

May also be shown as 816f040c08870008 or 0x816f040c08870008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in mem card 8 has been enabled.

May also be shown as 816f040c08880001 or 0x816f040c08880001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880002 • 816f040c-08880004

816f040c-08880002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in mem card 8 has been enabled.

May also be shown as 816f040c08880002 or 0x816f040c08880002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in mem card 8 has been enabled.

May also be shown as 816f040c08880003 or 0x816f040c08880003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in mem card 8 has been enabled.

May also be shown as 816f040c08880004 or 0x816f040c08880004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in mem card 8 has been enabled.

May also be shown as 816f040c08880005 or 0x816f040c08880005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in mem card 8 has been enabled.

May also be shown as 816f040c08880006 or 0x816f040c08880006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in mem card 8 has been enabled.

May also be shown as 816f040c08880007 or 0x816f040c08880007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-08880008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in mem card 8 has been enabled.

May also be shown as 816f040c08880008 or 0x816f040c08880008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810001 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 1 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810001 or 0x816f040c18810001

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810002 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 2 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810002 or 0x816f040c18810002

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810003 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 3 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810003 or 0x816f040c18810003

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810004 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 4 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810004 or 0x816f040c18810004

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810005 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 5 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810005 or 0x816f040c18810005

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810006 • 816f040c-18810008

816f040c-18810006 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 6 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810006 or 0x816f040c18810006

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810007 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 7 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810007 or 0x816f040c18810007

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810008 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 8 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810008 or 0x816f040c18810008

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810009 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 9 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810009 or 0x816f040c18810009

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881000a [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 10 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881000a or 0x816f040c1881000a

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881000b [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 11 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881000b or 0x816f040c1881000b

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881000c • 816f040c-1881000e

816f040c-1881000c [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 12 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881000c or 0x816f040c1881000c

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881000d [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 13 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881000d or 0x816f040c1881000d

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881000e [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 14 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881000e or 0x816f040c1881000e

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881000f [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 15 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881000f or 0x816f040c1881000f

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810010 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 16 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810010 or 0x816f040c18810010

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810011 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 17 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810011 or 0x816f040c18810011

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810012 • 816f040c-18810014

816f040c-18810012 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 18 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810012 or 0x816f040c18810012

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810013 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 19 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810013 or 0x816f040c18810013

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810014 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 20 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810014 or 0x816f040c18810014

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810015 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 21 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810015 or 0x816f040c18810015

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810016 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 22 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810016 or 0x816f040c18810016

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810017 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 23 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810017 or 0x816f040c18810017

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810018 • 816f040c-1881001a

816f040c-18810018 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 24 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810018 or 0x816f040c18810018

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810019 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 25 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810019 or 0x816f040c18810019

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881001a [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 26 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881001a or 0x816f040c1881001a

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881001b [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 27 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881001b or 0x816f040c1881001b

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881001c [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 28 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881001c or 0x816f040c1881001c

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881001d [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 29 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881001d or 0x816f040c1881001d

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881001e • 816f040c-18810020

816f040c-1881001e [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 30 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881001e or 0x816f040c1881001e

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-1881001f [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 31 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c1881001f or 0x816f040c1881001f

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-18810020 [PhysicalMemoryElementName] Disabled on Subsystem [MemoryElementName].

Explanation: DIMM 32 in memory expansion module(MEU) has been enabled.

May also be shown as 816f040c18810020 or 0x816f040c18810020

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f040c-2581ffff [PhysicalMemoryElementName] Enabled on Subsystem [MemoryElementName].

Explanation: A DIMM has been enabled.

May also be shown as 816f040c2581ffff or 0x816f040c2581ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0130

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0507-0301ffff [ProcessorElementName] has Recovered from a Configuration Mismatch.

Explanation: Processor 1 has Recovered from a Processor Configuration Mismatch.

May also be shown as 816f05070301ffff or 0x816f05070301ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0063

SNMP Trap ID: 40

Automatically notify Support: No

User response: No action; information only.

816f0507-0302ffff [ProcessorElementName] has Recovered from a Configuration Mismatch.

Explanation: Processor 2 has Recovered from a Processor Configuration Mismatch.

May also be shown as 816f05070302ffff or 0x816f05070302ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0063

SNMP Trap ID: 40

Automatically notify Support: No

User response: No action; information only.

816f0507-0303ffff [ProcessorElementName] has Recovered from a Configuration Mismatch.

Explanation: Processor 3 has Recovered from a Processor Configuration Mismatch.

May also be shown as 816f05070303ffff or 0x816f05070303ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0063

SNMP Trap ID: 40

Automatically notify Support: No

User response: No action; information only.

816f0507-0304ffff [ProcessorElementName] has Recovered from a Configuration Mismatch.

Explanation: Processor 4 has Recovered from a Processor Configuration Mismatch.

May also be shown as 816f05070304ffff or 0x816f05070304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0063

SNMP Trap ID: 40

Automatically notify Support: No

User response: No action; information only.

816f0507-2584ffff [ProcessorElementName] has Recovered from a Configuration Mismatch.

Explanation: System has recovered from a processor configuration mismatch.

May also be shown as 816f05072584ffff or 0x816f05072584ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and **ID:** 0063

SNMP Trap ID: 40

Automatically notify Support: No

User response: No action; information only.

816f050c-08810001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810001 or 0x816f050c08810001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810002 or 0x816f050c08810002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810003 or 0x816f050c08810003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810004 or 0x816f050c08810004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810005 or 0x816f050c08810005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810006 or 0x816f050c08810006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810007 or 0x816f050c08810007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08810008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 1 memory logging limit has been removed.

May also be shown as 816f050c08810008 or 0x816f050c08810008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820001 or 0x816f050c08820001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820002 or 0x816f050c08820002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820003 or 0x816f050c08820003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820004 or 0x816f050c08820004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820005 or 0x816f050c08820005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820006 or 0x816f050c08820006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820007 or 0x816f050c08820007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08820008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 2 memory logging limit has been removed.

May also be shown as 816f050c08820008 or 0x816f050c08820008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830001 or 0x816f050c08830001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830002 or 0x816f050c08830002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830003 or 0x816f050c08830003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830004 or 0x816f050c08830004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830005 or 0x816f050c08830005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830006 or 0x816f050c08830006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830007 or 0x816f050c08830007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08830008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 3 memory logging limit has been removed.

May also be shown as 816f050c08830008 or 0x816f050c08830008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840001 or 0x816f050c08840001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840002 or 0x816f050c08840002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840003 or 0x816f050c08840003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840004 or 0x816f050c08840004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840005 or 0x816f050c08840005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840006 or 0x816f050c08840006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840007 or 0x816f050c08840007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08840008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 4 memory logging limit has been removed.

May also be shown as 816f050c08840008 or 0x816f050c08840008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850001 or 0x816f050c08850001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850002 or 0x816f050c08850002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850003 or 0x816f050c08850003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850004 or 0x816f050c08850004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850005 or 0x816f050c08850005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850006 or 0x816f050c08850006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850007 or 0x816f050c08850007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08850008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 5 memory logging limit has been removed.

May also be shown as 816f050c08850008 or 0x816f050c08850008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860001 or 0x816f050c08860001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860002 or 0x816f050c08860002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860003 or 0x816f050c08860003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860004 or 0x816f050c08860004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860005 or 0x816f050c08860005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860006 or 0x816f050c08860006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860007 or 0x816f050c08860007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08860008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 6 memory logging limit has been removed.

May also be shown as 816f050c08860008 or 0x816f050c08860008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870001 or 0x816f050c08870001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870002 or 0x816f050c08870002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870003 or 0x816f050c08870003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870004 or 0x816f050c08870004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870005 or 0x816f050c08870005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870006 or 0x816f050c08870006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870007 or 0x816f050c08870007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08870008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 7 memory logging limit has been removed.

May also be shown as 816f050c08870008 or 0x816f050c08870008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880001 or 0x816f050c08880001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880002 or 0x816f050c08880002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880003 or 0x816f050c08880003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880004 or 0x816f050c08880004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880005 or 0x816f050c08880005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880006 or 0x816f050c08880006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880007 or 0x816f050c08880007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-08880008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of Mem card 8 memory logging limit has been removed.

May also be shown as 816f050c08880008 or 0x816f050c08880008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810001 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 1 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810001 or 0x816f050c18810001

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810002 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 2 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810002 or 0x816f050c18810002

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810003 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 3 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810003 or 0x816f050c18810003

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810004 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 4 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810004 or 0x816f050c18810004

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810005 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 5 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810005 or 0x816f050c18810005

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810006 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 6 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810006 or 0x816f050c18810006

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810007 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 7 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810007 or 0x816f050c18810007

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810008 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 8 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810008 or 0x816f050c18810008

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810009 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 9 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810009 or 0x816f050c18810009

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881000a Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 10 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881000a or 0x816f050c1881000a

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881000b Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 11 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881000b or 0x816f050c1881000b

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881000c Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 12 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881000c or 0x816f050c1881000c

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881000d Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 13 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881000d or 0x816f050c1881000d

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881000e Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 14 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881000e or 0x816f050c1881000e

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881000f Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 15 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881000f or 0x816f050c1881000f

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810010 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 16 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810010 or 0x816f050c18810010

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810011 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 17 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810011 or 0x816f050c18810011

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810012 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 18 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810012 or 0x816f050c18810012

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810013 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 19 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810013 or 0x816f050c18810013

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810014 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 20 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810014 or 0x816f050c18810014

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810015 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 21 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810015 or 0x816f050c18810015

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810016 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 22 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810016 or 0x816f050c18810016

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810017 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 23 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810017 or 0x816f050c18810017

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810018 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 24 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810018 or 0x816f050c18810018

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810019 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 25 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810019 or 0x816f050c18810019

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881001a Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 26 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881001a or 0x816f050c1881001a

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881001b Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 27 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881001b or 0x816f050c1881001b

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881001c Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 28 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881001c or 0x816f050c1881001c

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881001d Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 29 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881001d or 0x816f050c1881001d

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881001e Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 30 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881001e or 0x816f050c1881001e

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-1881001f Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 31 of MEU memory logging limit has been removed.

May also be shown as 816f050c1881001f or 0x816f050c1881001f

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-18810020 Memory Logging Limit removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: DIMM 32 of MEU memory logging limit has been removed.

May also be shown as 816f050c18810020 or 0x816f050c18810020

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050c-2581ffff Memory Logging Limit Removed for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Memory logging limit has been removed.

May also be shown as 816f050c2581ffff or 0x816f050c2581ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0145

SNMP Trap ID: 43

Automatically notify Support: No

User response: No action; information only.

816f050d-0400ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0400ffff or 0x816f050d0400ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0401ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0401ffff or 0x816f050d0401ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0402ffff • 816f050d-0404ffff

816f050d-0402ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0402ffff or 0x816f050d0402ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0403ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0403ffff or 0x816f050d0403ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0404ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0404ffff or 0x816f050d0404ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0405ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0405ffff or 0x816f050d0405ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0406ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0406ffff or 0x816f050d0406ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0407ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0407ffff or 0x816f050d0407ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0408ffff • 816f050d-040affff

816f050d-0408ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0408ffff or 0x816f050d0408ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-0409ffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d0409ffff or 0x816f050d0409ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-040affff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d040affff or 0x816f050d040affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-040bffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d040bffff or 0x816f050d040bffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-040cffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d040cffff or 0x816f050d040cffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-040dffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d040dffff or 0x816f050d040dffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-040effff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d040effff or 0x816f050d040effff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f050d-040fffff Critical Array [ComputerSystemElementName] has deasserted.

Explanation: The RAID array is no longer in a critical condition.

May also be shown as 816f050d040fffff or 0x816f050d040fffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0175

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f0607-0301ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has deasserted.

Explanation: An SM BIOS uncorrectable CPU complex error has been deasserted for microprocessor 1.

May also be shown as 816f06070301ffff or 0x816f06070301ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0817

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0607-0302ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has deasserted.

Explanation: An SM BIOS uncorrectable CPU complex error has been deasserted for microprocessor 2.

May also be shown as 816f06070302ffff or 0x816f06070302ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0817

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0607-0303ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has deasserted.

Explanation: An SM BIOS uncorrectable CPU complex error has been deasserted for microprocessor 3.

May also be shown as 816f06070303ffff or 0x816f06070303ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0817

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0607-0304ffff An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has deasserted.

Explanation: An SM BIOS uncorrectable CPU complex error has been deasserted for microprocessor 4.

May also be shown as 816f06070304ffff or 0x816f06070304ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0817

SNMP Trap ID: 40

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f060d-0400ffff • 816f060d-0402ffff

816f060d-0400ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0400ffff or 0x816f060d0400ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0401ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0401ffff or 0x816f060d0401ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0402ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0402ffff or 0x816f060d0402ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0403ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0403ffff or 0x816f060d0403ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0404ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0404ffff or 0x816f060d0404ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0405ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0405ffff or 0x816f060d0405ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0406ffff • 816f060d-0408ffff

816f060d-0406ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0406ffff or 0x816f060d0406ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0407ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0407ffff or 0x816f060d0407ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0408ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0408ffff or 0x816f060d0408ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-0409ffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d0409ffff or 0x816f060d0409ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-040affff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d040affff or 0x816f060d040affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-040bffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d040bffff or 0x816f060d040bffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-040cffff • 816f060d-040effff

816f060d-040cffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d040cffff or 0x816f060d040cffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-040dffff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d040dffff or 0x816f060d040dffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-040effff Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d040effff or 0x816f060d040effff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f060d-040ffffF Array in system [ComputerSystemElementName] has been restored.

Explanation: IMM has detected that a Failed Array has been Restored.

May also be shown as 816f060d040ffffF or 0x816f060d040ffffF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0177

SNMP Trap ID: 5

Automatically notify Support: No

User response: No action; information only.

816f070c-08810001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 1.

May also be shown as 816f070c08810001 or 0x816f070c08810001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 1.

May also be shown as 816f070c08810002 or 0x816f070c08810002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 1.

May also be shown as 816f070c08810003 or 0x816f070c08810003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 1.

May also be shown as 816f070c08810004 or 0x816f070c08810004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 1.

May also be shown as 816f070c08810005 or 0x816f070c08810005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 1.

May also be shown as 816f070c08810006 or 0x816f070c08810006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 1.

May also be shown as 816f070c08810007 or 0x816f070c08810007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08810008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 1.

May also be shown as 816f070c08810008 or 0x816f070c08810008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 2.

May also be shown as 816f070c08820001 or 0x816f070c08820001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 2.

May also be shown as 816f070c08820002 or 0x816f070c08820002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 2.

May also be shown as 816f070c08820003 or 0x816f070c08820003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 2.

May also be shown as 816f070c08820004 or 0x816f070c08820004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 2.

May also be shown as 816f070c08820005 or 0x816f070c08820005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 2.

May also be shown as 816f070c08820006 or 0x816f070c08820006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820007 • 816f070c-08830001

816f070c-08820007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 2.

May also be shown as 816f070c08820007 or 0x816f070c08820007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08820008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 2.

May also be shown as 816f070c08820008 or 0x816f070c08820008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 3.

May also be shown as 816f070c08830001 or 0x816f070c08830001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 3.

May also be shown as 816f070c08830002 or 0x816f070c08830002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 3.

May also be shown as 816f070c08830003 or 0x816f070c08830003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 3.

May also be shown as 816f070c08830004 or 0x816f070c08830004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 3.

May also be shown as 816f070c08830005 or 0x816f070c08830005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 3.

May also be shown as 816f070c08830006 or 0x816f070c08830006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 3.

May also be shown as 816f070c08830007 or 0x816f070c08830007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08830008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 3.

May also be shown as 816f070c08830008 or 0x816f070c08830008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 4.

May also be shown as 816f070c08840001 or 0x816f070c08840001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 4.

May also be shown as 816f070c08840002 or 0x816f070c08840002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 4.

May also be shown as 816f070c08840003 or 0x816f070c08840003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 4.

May also be shown as 816f070c08840004 or 0x816f070c08840004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 4.

May also be shown as 816f070c08840005 or 0x816f070c08840005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 4.

May also be shown as 816f070c08840006 or 0x816f070c08840006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 4.

May also be shown as 816f070c08840007 or 0x816f070c08840007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08840008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 4.

May also be shown as 816f070c08840008 or 0x816f070c08840008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 5.

May also be shown as 816f070c08850001 or 0x816f070c08850001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 5.

May also be shown as 816f070c08850002 or 0x816f070c08850002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 5.

May also be shown as 816f070c08850003 or 0x816f070c08850003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 5.

May also be shown as 816f070c08850004 or 0x816f070c08850004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 5.

May also be shown as 816f070c08850005 or 0x816f070c08850005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 5.

May also be shown as 816f070c08850006 or 0x816f070c08850006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850007 • 816f070c-08860001

816f070c-08850007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 5.

May also be shown as 816f070c08850007 or 0x816f070c08850007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08850008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 5.

May also be shown as 816f070c08850008 or 0x816f070c08850008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 6.

May also be shown as 816f070c08860001 or 0x816f070c08860001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 6.

May also be shown as 816f070c08860002 or 0x816f070c08860002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 6.

May also be shown as 816f070c08860003 or 0x816f070c08860003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 6.

May also be shown as 816f070c08860004 or 0x816f070c08860004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 6.

May also be shown as 816f070c08860005 or 0x816f070c08860005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 6.

May also be shown as 816f070c08860006 or 0x816f070c08860006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 6.

May also be shown as 816f070c08860007 or 0x816f070c08860007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08860008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 6.

May also be shown as 816f070c08860008 or 0x816f070c08860008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 7.

May also be shown as 816f070c08870001 or 0x816f070c08870001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 7.

May also be shown as 816f070c08870002 or 0x816f070c08870002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870003 • 816f070c-08870005

816f070c-08870003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 7.

May also be shown as 816f070c08870003 or 0x816f070c08870003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 7.

May also be shown as 816f070c08870004 or 0x816f070c08870004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 7.

May also be shown as 816f070c08870005 or 0x816f070c08870005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 7.

May also be shown as 816f070c08870006 or 0x816f070c08870006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 7.

May also be shown as 816f070c08870007 or 0x816f070c08870007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08870008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 7.

May also be shown as 816f070c08870008 or 0x816f070c08870008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of mem card 8.

May also be shown as 816f070c08880001 or 0x816f070c08880001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of mem card 8.

May also be shown as 816f070c08880002 or 0x816f070c08880002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of mem card 8.

May also be shown as 816f070c08880003 or 0x816f070c08880003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of mem card 8.

May also be shown as 816f070c08880004 or 0x816f070c08880004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of mem card 8.

May also be shown as 816f070c08880005 or 0x816f070c08880005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of mem card 8.

May also be shown as 816f070c08880006 or 0x816f070c08880006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of mem card 8.

May also be shown as 816f070c08880007 or 0x816f070c08880007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-08880008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of mem card 8.

May also be shown as 816f070c08880008 or 0x816f070c08880008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810001 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 1 of memory expansion unit(MEU).

May also be shown as 816f070c18810001 or 0x816f070c18810001

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810002 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 2 of memory expansion unit(MEU).

May also be shown as 816f070c18810002 or 0x816f070c18810002

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810003 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 3 of memory expansion unit(MEU).

May also be shown as 816f070c18810003 or 0x816f070c18810003

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810004 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 4 of memory expansion unit(MEU).

May also be shown as 816f070c18810004 or 0x816f070c18810004

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810005 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 5 of memory expansion unit(MEU).

May also be shown as 816f070c18810005 or 0x816f070c18810005

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810006 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 6 of memory expansion unit(MEU).

May also be shown as 816f070c18810006 or 0x816f070c18810006

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810007 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 7 of memory expansion unit(MEU).

May also be shown as 816f070c18810007 or 0x816f070c18810007

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810008 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 8 of memory expansion unit(MEU).

May also be shown as 816f070c18810008 or 0x816f070c18810008

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810009 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 9 of memory expansion unit(MEU).

May also be shown as 816f070c18810009 or 0x816f070c18810009

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881000a Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 10 of memory expansion unit(MEU).

May also be shown as 816f070c1881000a or 0x816f070c1881000a

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881000b • 816f070c-1881000d

816f070c-1881000b Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 11 of memory expansion unit(MEU).

May also be shown as 816f070c1881000b or 0x816f070c1881000b

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881000c Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 12 of memory expansion unit(MEU).

May also be shown as 816f070c1881000c or 0x816f070c1881000c

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881000d Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 13 of memory expansion unit(MEU).

May also be shown as 816f070c1881000d or 0x816f070c1881000d

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881000e Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 14 of memory expansion unit(MEU).

May also be shown as 816f070c1881000e or 0x816f070c1881000e

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881000f Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 15 of memory expansion unit(MEU).

May also be shown as 816f070c1881000f or 0x816f070c1881000f

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810010 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 16 of memory expansion unit(MEU).

May also be shown as 816f070c18810010 or 0x816f070c18810010

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810011 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 17 of memory expansion unit(MEU).

May also be shown as 816f070c18810011 or 0x816f070c18810011

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810012 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 18 of memory expansion unit(MEU).

May also be shown as 816f070c18810012 or 0x816f070c18810012

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810013 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 19 of memory expansion unit(MEU).

May also be shown as 816f070c18810013 or 0x816f070c18810013

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810014 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 20 of memory expansion unit(MEU).

May also be shown as 816f070c18810014 or 0x816f070c18810014

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810015 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 21 of memory expansion unit(MEU).

May also be shown as 816f070c18810015 or 0x816f070c18810015

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810016 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 22 of memory expansion unit(MEU).

May also be shown as 816f070c18810016 or 0x816f070c18810016

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810017 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 23 of memory expansion unit(MEU).

May also be shown as 816f070c18810017 or 0x816f070c18810017

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810018 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 24 of memory expansion unit(MEU).

May also be shown as 816f070c18810018 or 0x816f070c18810018

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810019 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 25 of memory expansion unit(MEU).

May also be shown as 816f070c18810019 or 0x816f070c18810019

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881001a Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 26 of memory expansion unit(MEU).

May also be shown as 816f070c1881001a or 0x816f070c1881001a

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881001b Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 27 of memory expansion unit(MEU).

May also be shown as 816f070c1881001b or 0x816f070c1881001b

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881001c Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 28 of memory expansion unit(MEU).

May also be shown as 816f070c1881001c or 0x816f070c1881001c

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881001d • 816f070c-1881001f

816f070c-1881001d Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 29 of memory expansion unit(MEU).

May also be shown as 816f070c1881001d or 0x816f070c1881001d

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881001e Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 30 of memory expansion unit(MEU).

May also be shown as 816f070c1881001e or 0x816f070c1881001e

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-1881001f Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 31 of memory expansion unit(MEU).

May also be shown as 816f070c1881001f or 0x816f070c1881001f

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-18810020 Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has been deasserted.

Explanation: A memory configuration error has been deasserted on DIMM 32 of memory expansion unit(MEU).

May also be shown as 816f070c18810020 or 0x816f070c18810020

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2581ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error has deasserted.

May also be shown as 816f070c2581ffff or 0x816f070c2581ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2584ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A configuration error of missing micoprocessor has been deasserted.

May also be shown as 816f070c2584ffff or 0x816f070c2584ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2585ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A configuration error of missing boot memory has been deasserted.

May also be shown as 816f070c2585ffff or 0x816f070c2585ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2586ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 1 bank has deasserted.

May also be shown as 816f070c2586ffff or 0x816f070c2586ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2587ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 2 bank has deasserted.

May also be shown as 816f070c2587ffff or 0x816f070c2587ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2588ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 3 bank has deasserted.

May also be shown as 816f070c2588ffff or 0x816f070c2588ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-2589ffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 4 bank has deasserted.

May also be shown as 816f070c2589ffff or 0x816f070c2589ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-258affff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 5 bank has deasserted.

May also be shown as 816f070c258affff or 0x816f070c258affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-258bffff • 816f070c-258dffff

816f070c-258bffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 6 bank has deasserted.

May also be shown as 816f070c258bffff or 0x816f070c258bffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-258cffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 7 bank has deasserted.

May also be shown as 816f070c258cffff or 0x816f070c258cffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070c-258dffff Configuration error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]has deasserted.

Explanation: A memory DIMM configuration error in mem card 8 bank has deasserted.

May also be shown as 816f070c258dffff or 0x816f070c258dffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0127

SNMP Trap ID: 41

Automatically notify Support: No

User response: No action; information only.

816f070d-0400ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0400ffff or 0x816f070d0400ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0401ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0401ffff or 0x816f070d0401ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0402ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0402ffff or 0x816f070d0402ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0403ffff • 816f070d-0405ffff

816f070d-0403ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0403ffff or 0x816f070d0403ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0404ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0404ffff or 0x816f070d0404ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0405ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0405ffff or 0x816f070d0405ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0406ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0406ffff or 0x816f070d0406ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0407ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0407ffff or 0x816f070d0407ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0408ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0408ffff or 0x816f070d0408ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-0409ffff • 816f070d-040bffff

816f070d-0409ffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d0409ffff or 0x816f070d0409ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-040affff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d040affff or 0x816f070d040affff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-040bffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d040bffff or 0x816f070d040bffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-040cffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d040cffff or 0x816f070d040cffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-040dffff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d040dffff or 0x816f070d040dffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-040effff Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d040effff or 0x816f070d040effff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f070d-040ffffF • 816f0807-0302ffff

816f070d-040ffffF Rebuild completed for Array in system [ComputerSystemElementName].

Explanation: IMM has detected that an Array Rebuild has Completed.

May also be shown as 816f070d040ffffF or 0x816f070d040ffffF

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0179

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0807-0301ffff [ProcessorElementName] has been Enabled.

Explanation: IMM has detected Processor 1 has been Enabled.

May also be shown as 816f08070301ffff or 0x816f08070301ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0060

SNMP Trap ID:

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0807-0302ffff [ProcessorElementName] has been Enabled.

Explanation: IMM has detected Processor 2 has been Enabled.

May also be shown as 816f08070302ffff or 0x816f08070302ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0060

SNMP Trap ID:

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0807-0303ffff [ProcessorElementName] has been Enabled.

Explanation: IMM has detected Processor 3 has been Enabled.

May also be shown as 816f08070303ffff or 0x816f08070303ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0060

SNMP Trap ID:

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0807-0304ffff [ProcessorElementName] has been Enabled.

Explanation: IMM has detected Processor 4 has been Enabled.

May also be shown as 816f08070304ffff or 0x816f08070304ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0060

SNMP Trap ID:

Automatically notify Support: No

User response: This is a UEFI detected event. The UEFI diagnostic code for this event can be found in the logged IMM message text. Please refer to the UEFI diagnostic code in the "UEFI diagnostic code" section of the Info Center for the appropriate user response.

816f0807-2584ffff [ProcessorElementName] has been Enabled.

Explanation: One CPU has been enabled.

May also be shown as 816f08072584ffff or 0x816f08072584ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0060

SNMP Trap ID:

Automatically notify Support: No

User response: Information only; no action is required.

816f0813-2581ffff • 816f0813-2584ffff

816f0813-2581ffff System [ComputerSystemElementName]has recovered from an Uncorrectable Bus Error.

Explanation: IMM has detected that the system has recovered from a bus uncorrectable error.

May also be shown as 816f08132581ffff or 0x816f08132581ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0241

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0813-2582ffff System [ComputerSystemElementName]has recovered from an Uncorrectable Bus Error.

Explanation: IMM has detected that the system has recovered from a bus uncorrectable error.

May also be shown as 816f08132582ffff or 0x816f08132582ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0241

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0813-2584ffff System [ComputerSystemElementName]has recovered from an Uncorrectable Bus Error.

Explanation: System has recovered from a bus uncorrectable error

May also be shown as 816f08132584ffff or 0x816f08132584ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: **Prefix:** PLAT and **ID:** 0241

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f090c-2586ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 1 bank has deasserted.

May also be shown as 816f090c2586ffff or 0x816f090c2586ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-2587ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 2 bank has deasserted.

May also be shown as 816f090c2587ffff or 0x816f090c2587ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-2588ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 3 bank has deasserted.

May also be shown as 816f090c2588ffff or 0x816f090c2588ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-2589ffff • 816f090c-258bffff

816f090c-2589ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 4 bank has deasserted.

May also be shown as 816f090c2589ffff or 0x816f090c2589ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-258affff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 5 bank has deasserted.

May also be shown as 816f090c258affff or 0x816f090c258affff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-258bffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 6 bank has deasserted.

May also be shown as 816f090c258bffff or 0x816f090c258bffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-258cffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 7 bank has deasserted.

May also be shown as 816f090c258cffff or 0x816f090c258cffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-258dffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in mem card 8 bank has deasserted.

May also be shown as 816f090c258dffff or 0x816f090c258dffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-258effff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in MEU mem bank 1 has deasserted.

May also be shown as 816f090c258effff or 0x816f090c258effff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-258ffffF • 816f090c-2591ffff

816f090c-258ffffF [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in MEU mem bank 2 has deasserted.

May also be shown as 816f090c258ffffF or 0x816f090c258ffffF

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-2590ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in MEU mem bank 3 has deasserted.

May also be shown as 816f090c2590ffff or 0x816f090c2590ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f090c-2591ffff [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.

Explanation: Memory throttle in MEU mem bank 4 has deasserted.

May also be shown as 816f090c2591ffff or 0x816f090c2591ffff

Severity: Info

Alert Category: System

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0143

SNMP Trap ID:

Automatically notify Support: No

User response: No action; information only.

816f0a07-0301ffff [ProcessorElementName] is no longer operating in a Degraded State.

Explanation: IMM has detected Processor 1 is no longer running in the Degraded state.

May also be shown as 816f0a070301ffff or 0x816f0a070301ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0039

SNMP Trap ID: 42

Automatically notify Support: No

User response: No action; information only.

816f0a07-0302ffff [ProcessorElementName] is no longer operating in a Degraded State.

Explanation: IMM has detected Processor 2 is no longer running in the Degraded state.

May also be shown as 816f0a070302ffff or 0x816f0a070302ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0039

SNMP Trap ID: 42

Automatically notify Support: No

User response: No action; information only.

816f0a07-0303ffff [ProcessorElementName] is no longer operating in a Degraded State.

Explanation: IMM has detected Processor 3 is no longer running in the Degraded state.

May also be shown as 816f0a070303ffff or 0x816f0a070303ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0039

SNMP Trap ID: 42

Automatically notify Support: No

User response: No action; information only.

816f0a07-0304ffff [ProcessorElementName] is no longer operating in a Degraded State.

Explanation: IMM has detected Processor 4 is no longer running in the Degraded state.

May also be shown as 816f0a070304ffff or 0x816f0a070304ffff

Severity: Info

Alert Category: Warning

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0039

SNMP Trap ID: 42

Automatically notify Support: No

User response: No action; information only.

816f0a0c-2586ffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 1 bank has deasserted.

May also be shown as 816f0a0c2586ffff or 0x816f0a0c2586ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-2587ffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 2 bank has deasserted.

May also be shown as 816f0a0c2587ffff or 0x816f0a0c2587ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-2588ffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 3 bank has deasserted.

May also be shown as 816f0a0c2588ffff or 0x816f0a0c2588ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-2589ffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 4 bank has deasserted.

May also be shown as 816f0a0c2589ffff or 0x816f0a0c2589ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-258affff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 5 bank has deasserted.

May also be shown as 816f0a0c258affff or 0x816f0a0c258affff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-258bffff • 816f0a0c-258dffff

816f0a0c-258bffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 6 bank has deasserted.

May also be shown as 816f0a0c258bffff or 0x816f0a0c258bffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-258cffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 7 bank has deasserted.

May also be shown as 816f0a0c258cffff or 0x816f0a0c258cffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-258dffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in mem card 8 bank has deasserted.

May also be shown as 816f0a0c258dffff or 0x816f0a0c258dffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-258effff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in MEU bank 1 has deasserted.

May also be shown as 816f0a0c258effff or 0x816f0a0c258effff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-258ffffF An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in MEU bank 2 has deasserted.

May also be shown as 816f0a0c258ffffF or 0x816f0a0c258ffffF

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-2590ffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in MEU bank 3 has deasserted.

May also be shown as 816f0a0c2590ffff or 0x816f0a0c2590ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a0c-2591ffff An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].

Explanation: Over-temp in MEU bank 4 has deasserted.

May also be shown as 816f0a0c2591ffff or 0x816f0a0c2591ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0147

SNMP Trap ID: 0

Automatically notify Support: No

User response: No action; information only.

816f0a13-2401ffff System [ComputerSystemElementName] has recovered from a Fatal Bus Error.

Explanation: System has recovered from a bus fatal error

May also be shown as 816f0a132401ffff or 0x816f0a132401ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0245

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

816f0a13-2402ffff System [ComputerSystemElementName] has recovered from a Fatal Bus Error.

Explanation: MEU has recovered from a bus fatal error

May also be shown as 816f0a132402ffff or 0x816f0a132402ffff

Severity: Info

Alert Category: Critical

Serviceable: No

CIM Information: Prefix: PLAT and ID: 0245

SNMP Trap ID: 50

Automatically notify Support: No

User response: No action; information only.

Appendix C. UEFI/POST error codes

This topic provides details about error codes that display after the server performs a series of tests called the power-on self test, or POST, to check the operation of the server components and some optional devices.

About this task

When you turn on the server, it performs a series of tests to check the operation of the server components and some optional devices in the server. This series of tests is called the power-on self-test, or POST.

If a power-on password is set, you must type the password and press Enter, when you are prompted, for POST to run.

If POST is completed without detecting any problems, the server startup is completed.

If POST detects a problem, an error message is sent to the POST event log.

The following table describes the POST error codes and suggested actions to correct the detected problems. These errors can appear as severe, warning, or informational.

I.11002 **[I.11002] A processor mismatch has been detected between one or more processors in the system.**

Explanation: One or More Mismatched Processors Detected

Severity: Error

User response: Complete the following steps:

1. This message could occur with messages about other Processor configuration problems. Resolve those messages first.
2. If the problem persists, ensure that matching processors are installed (i.e., matching option part numbers, etc)
3. Verify that the Processor's are installed in the sockets correctly according to the service information for this product. If not, correct that problem.
4. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this Processor error.
5. (Trained Service technician only) Replace mismatching processor. Inspect Processor socket and replace the system board first if socket is damaged.

I.2018002 [I.2018002] The device found at Bus % Device % Function % could not be configured due to resource constraints. The Vendor ID for the device is % and the Device ID is %.

Explanation: OUT_OF_RESOURCES (PCI Option ROM)

Severity: Info

User response: Complete the following steps:

1. If this PCIe device and/or any attached cables were recently installed, moved, serviced or upgraded, reseal adapter and any attached cables.
2. Check IBM support site for any applicable RETAIN tip or UEFI or adapter firmware update that applies to this error. NOTE: It may be necessary to disable unused option ROMs from UEFI F1 setup or ASU or using adapter manufacturer utilities so that adapter firmware can be updated.
3. Move the card to a different slot on the I/O card. If issue persist, move card to a different prowl I/O card. If Error re-occurs, replace the adapter.
4. (Trained Service technician only) If adapter was moved to a different slot and error did not re-occur, verify that this is not a system limitation and then replace the system board. Also, if this is not the initial installation and the error persists after adapter replacement, replace system board.

I.2018003 [I.2018003] A bad option ROM checksum was detected for the device found at Bus % Device % Function %. The Vendor ID for the device is % and the Device ID is %.

Explanation: ROM CHECKSUM ERROR

Severity: Error

User response: Complete the following steps:

1. If this PCIe device and/or any attached cables were recently installed, moved, serviced or upgraded, reseal adapter and any attached cables.
2. Move the card to a different slot on the I/O card. If issue persist, move card to a different I/O card. If Error re-occurs, replace the adapter.
3. Check IBM support site for any applicable RETAIN tip or UEFI or adapter firmware update that applies to this error. NOTE: It may be necessary to configure slot to Gen1 or to use special utility software so that adapter firmware can be upgraded. Gen1/Gen2 settings can be configured via F1 Setup -> System Settings -> Devices and I/O Ports -> PCIe Gen1/Gen2/Gen3 Speed Selection, or the ASU Utility.
4. Replace adapter.

I.3048005 [I.3048005] UEFI has booted from the backup flash bank.

Explanation: Booting Backup UEFI Image

Severity: Info

User response: Complete the following steps:

1. Refer to service information for this product section on UEFI Recovery to return system to primary bank.

I.3108002

Explanation: GPT Corruption Recoverd

Severity: Info

User response: Complete the following steps:

1. No action needed.

I.3808004 [I.3808004] The IMM System Event log (SEL) is full.

Explanation: IPMI System Event Log is Full

Severity: Info

User response: Complete the following steps:

1. Use IMM Web Interface to clear event log.
2. If IMM communication is unavailable, use F1 Setup to access System Event Logs Menu and Choose Clear IMM System Event Log and Restart Server.

I.3818001 [I.3818001] The firmware image capsule signature for the currently booted flash bank is invalid.

Explanation: Current Bank CRTM Capsule Update Signature Invalid

Severity: Info

User response: Complete the following steps:

1. Reboot system. Will come up on backup UEFI image. Reflash the primary UEFI image.
2. If error does not persist no additional recovery action is required.
3. If error persists, or boot is unsuccessful, (Trained service technician only) Replace the system board.

I.3818002 [I.3818002] The firmware image capsule signature for the non-booted flash bank is invalid.

Explanation: Opposite Bank CRTM Capsule Update Signature Invalid

Severity: Info

User response: Complete the following steps:

1. Reflash backup UEFI image.
2. If error does not persist no additional recovery action is required.
3. If error persists, or boot is unsuccessful, (Trained service technician only) Replace the system board.

I.3818003 [I.3818003] The CRTM flash driver could not lock the secure flash region.

Explanation: CRTM Could not lock secure flash region

Severity: Info

User response: Complete the following steps:

1. If system failed to boot successfully, power cycle system.
2. If system boots to F1 setup, flash UEFI image and reset bank to primary (if required). If system boots without error, recovery is complete and no additional action is required.
3. If system fails to boot, or if flash attempt fails, (Trained service technician only) Replace the system board.

I.580A4 [I.580A4] **Memory population change detected.**

Explanation: DIMM Population Change Detected

Severity: Info

User response: Complete the following steps:

1. Check system event log for uncorrected DIMM failures and replace those DIMMs.
-

I.580A5 [I.580A5] **Mirror Fail-over complete. DIMM number % has failed over to to the mirrored copy.**

Explanation: DIMM Mirror Fail-over Detected

Severity: Info

User response: Complete the following steps:

1. : Check system event log for related DIMM failures and perform associated user actions.
-

I.580A6 [I.580A6] **Memory spare copy has completed successfully.**

Explanation: Spare Copy Complete

Severity: Info

User response: Complete the following steps:

1. Check system event log for related DIMM failures and perform associated user actions.
-

S.2011001 [S.2011001] **An Uncorrected PCIe Error has Occurred at Bus % Device % Function %. The Vendor ID for the device is % and the Device ID is %.**

Explanation: PCI SERR Detected

Severity: Error

User response: Complete the following steps:

1. If this node and/or any attached cables were recently installed, moved, serviced or upgraded, a. Reseat Adapter and any attached cables. b. Reload Device Driver c. If device is not recognized, reconfiguring slot to Gen1 or Gen2 may be required. Gen1/Gen2 settings can be configured via F1 Setup -> System Settings -> Devices and I/O Ports -> PCIe Gen1/Gen2/Gen3 Speed Selection, or the ASU Utility.
2. Check IBM support site for an applicable device driver, firmware update, revision of service information for this product or other information that applies to this error. Load new device driver and any required firmware updates.
3. If problem persists, then remove Adapter Card. If system reboots successfully without the adapter, replace that card.
4. (Trained Service technician only) Replace the system board.

S.2018001 [S.2018001] An Uncorrected PCIe Error has Occurred at Bus % Device % Function %. The Vendor ID for the device is % and the Device ID is %.

Explanation: PCIe Uncorrected Error Detected

Severity: Error

User response: Complete the following steps:

1. If this node and/or any attached cables were recently installed, moved, serviced or upgraded, a. Reseat Adapter and any attached cables. b. Reload Device Driver c. If device is not recognized, reconfiguring slot to Gen1 or Gen2 may be required. Gen1/Gen2 settings can be configured via F1 Setup -> System Settings -> Devices and I/O Ports -> PCIe Gen1/Gen2/Gen3 Speed Selection, or the ASU Utility.
2. Check IBM support site for an applicable device driver, firmware update, version of service information for this product or other information that applies to this error. Load new device driver and any required firmware updates.
3. If problem persists, then remove Adapter Card. If system reboots successfully without the adapter, replace that card.
4. (Trained Service technician only) Replace I/O card.

S.3058004 [S.3058004] A Three Strike boot failure has occurred. The system has booted with default UEFI settings.

Explanation: POST failure has occurred! System booted with default settings.

Severity: Error

User response: Complete the following steps:

1. This event resets UEFI to the default settings for the next boot. If successful, user is forced into F1 setup. Original UEFI settings are still present.
2. If User did not intentionally trigger the reboots, check logs for probable cause.
3. Undo recent system changes (settings or devices added). If not recent system changes, remove all options then remove CMOS battery for 30 seconds to clear CMOS contents. Verify that the system boots. Then, re-install options one at a time to locate the problem.
4. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
5. Reflash UEFI firmware.
6. Remove and re-install CMOS battery for 30 seconds to clear CMOS contents
7. (Trained service technician only) Replace the system board.

S.3818004 [S.3818004] The CRTM flash driver could not successfully flash the staging area. A failure occurred.

Explanation: CRTM Update Failed

Severity: Error

User response: Complete the following steps:

1. Continue booting system. If system does not reset, manually reset the system.
2. If the error is not reported on the subsequent boot, no additional recovery action is required.
3. If the error persists, continue booting system and reflash UEFI image.
4. (Trained service technician only) Replace system board.

S.3818007 • S.51003

S.3818007 [S.3818007] The firmware image capsules for both flash banks could not be verified.

Explanation: CRTM image capsule could not be verified

Severity: Error

User response: Complete the following steps:

1. If system failed to boot successfully, DC cycle system.
2. If system boots to F1 steup, flash UEFI image and reset bank to primary (if required). If system boots without error, recovery is complete and no additional action is required.
3. If system fails to boot, or if flash attempt fails, (Trained service technician only) Replace the system board.

S.3828001

Explanation: Boot Permission denied by Management Module: System Halted

Severity: Error

User response: Complete the following steps:

1. No action required

S.3828002

Explanation: Timed Out waiting on boot permission from Management Module: System Halted

Severity: Error

User response: Complete the following steps:

1. Step 1: Attempt to login to the IMM Webpage. If the web page does not load, power cycle the system. Step2: If the issue persists try to the access the backup image. From there, reflash the primary image Step 3: (Trained Service Technician only) Replace IO board

S.51003 [S.51003] An uncorrectable memory error was detected in DIMM slot % on rank %.

Explanation: [S.51003] An uncorrectable memory error was detected on processor % channel %. The failing DIMM within the channel could not be determined.Fatal Memory Error Occurred

Severity: Error

User response: Complete the following steps:

1. Refer to TIP H212293 for minimum code level.
2. Check IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. Swap one of the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If failure remains on original slots, replace the DIMM that was not moved. if the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If problem re-occures with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace Memory card.

S.51006 [S.51006] A memory mismatch has been detected. Please verify that the memory configuration is valid.

Explanation: One or More Mismatched DIMMs Detected

Severity: Error

User response: Complete the following steps:

1. Could follow an uncorrectable memory error or failed memory test. Check log and service that event first. DIMMs disabled by other errors or actions could cause this event.
2. Verify that the DIMMs are installed in the correct population sequence, according to the service information for this product.
3. Disable memory mirroring and sparing. If this action eliminates the mismatch, check IBM Support site for information related to this problem.
4. Reflash UEFI firmware.
5. Replace DIMM,if problem persists,(Trained Service technician only)replace memory card identified by event log entry.

S.58008 [S.58008] A DIMM has failed the POST memory test.

Explanation: DIMM Failed Memory Test

Severity: Error

User response: Complete the following steps:

1. Refer to TIP H212293 for minimum code level.
2. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. Swap one of the affected DIMM with a similar DIMM (size/type) on a different channel.
4. Re-enable all DIMM slots.
5. If the failure remains on the original slots, replace the DIMM that was not moved. if the failure follows the DIMM that was moved, replace the DIMM that was swapped.
6. If the problem re-occures with the same DIMM connector, inspect the DIMM connector for foreign material. If damaged, replace the Memory card.

S.68005 [S.68005] An error has been detected by the the IIO core logic on Bus %. The Global Fatal Error Status register contains %. The Global Non-Fatal Error Status register contains %. Please check error logs for the presence of additional downstream device error data.

Explanation: Critical IOH-PCI Error

Severity: Error

User response: Complete the following steps:

1. Check log for a separate error for an associated PCIe device and service that error.
2. Check IBM support site for an applicable RETAIN tip or firmware update for the system or adapter that applies to this error.
3. (Trained Service technician only) Replace IO board.

W.11004 • W.305000A

W.11004 [W.11004] A processor within the system has failed the BIST.

Explanation: Processor Self Test Failure Detected

Severity: Error

User response: Complete the following steps:

1. If the Processor or firmware was just updated, check IBM support site for an applicable RETAIN tip or firmware update that applies to this Processor error.
 2. (Trained service technician only) If there are multiple Processor's, swap Processor's to move affected Processor to another Processor socket and retry. If problem follows the affected Processor, or this is a single Processor system, replace the Processor. Inspect Processor socket on each Processor removal and replace system board first if damaged or mis-aligned pins are found.
 3. (Trained Service technician only) Replace cpu board.
-

W.201000A

Explanation: PCI Resource resizable

Severity: Warning

User response: Complete the following steps:

1. User can try to enable PCI 64-BIT resource setting in F1 Setup to allocate memory mapped resource above 4G for PCIE device.
-

W.3048006 [W.3048006] UEFI has booted from the backup flash bank due to an Automatic Boot Recovery (ABR) event.

Explanation: Automated Boot Recovery, Booting Backup UEFI Image

Severity: Warning

User response: Complete the following steps:

1. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
 2. Reflash Primary UEFI image. Refer to UEFI Recovery section of service information for this product.
 3. (Trained service technician only) Replace the system board.
-

W.305000A [W.305000A] An invalid date and time have been detected.

Explanation: RTC Date and Time Incorrect

Severity: Warning

User response: Complete the following steps:

1. Check IMM/chassis event log. This event should immediately precede 0068002 error. Service that event or any other battery related errors.
2. Use F1 Setup to reset date and time. If problem persists after a system reset, replace CMOS battery.
3. If problem persists then check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
4. Trained Service technician only) Replace IO board.

W.3108002

Explanation: GPT Corruption happened

Severity: Warning

User response: Complete the following steps:

1. Check hard disk data integrity, Check PCIE storage cards option rom firmware version and function if hard disks connected to the PCIE storage cards.

W.3808000 [W.3808000] An IMM communication failure has occurred.

Explanation: IMM Communication Failure

Severity: Warning

User response: Complete the following steps:

1. Reset IMM.
2. Remove power from the node. This will reboot the entire node.
3. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
4. Reflash UEFI Firmware.
5. (Trained service technician only) Replace IO board.

W.3808002 [W.3808002] An error occurred while saving UEFI settings to the IMM.

Explanation: Error Updating System Configuration to IMM

Severity: Warning

User response: Complete the following steps:

1. Use F1 Setup, Verify Settings and Save Settings to recover settings.
2. Reset IMM.
3. Remove power from the node. This will reboot the entire node.
4. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
5. Reflash IMM Firmware.
6. Remove and re-install CMOS battery for 30 seconds to clear CMOS contents.
7. (Trained Service technician only) Replace IO board.

W.3808003 [W.3808003] Unable to retrieve the system configuration from the IMM.

Explanation: Error Retrieving System Configuration from IMM

Severity: Warning

User response: Complete the following steps:

1. Use F1 Setup, Verify Settings and Save Settings to recover settings.
2. Reset the IMM.
3. Remove power from the node. This will reboot the entire node.
4. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
5. Reflash IMM Firmware.
6. Remove and re-install CMOS battery for 30 seconds to clear CMOS contents.
7. (Trained Service technician only) Replace IO board.

W.3818005 [W.3818005] The CRTM flash driver could not successfully flash the staging area. The update was aborted

Explanation: CRTM Update Aborted

Severity: Warning

User response: Complete the following steps:

1. Continue booting system. If system does not reset, manually reset the system.
2. If the error is not reported on the subsequent boot, no additional recovery action is required.
3. If the event persists, continue booting system and reflash UEFI image.
4. (Trained service technician only) Replace cpu board.

W.50001 [W.50001] A DIMM has been disabled due to an error detected during POST.

Explanation: DIMM Disabled

Severity: Info

User response: Complete the following steps:

1. Make sure the DIMM is installed correctly.
2. If the DIMM was disabled because of a memory fault, follow the suggested actions for that error event and restart the server.
3. Check the IBM support website for an applicable retain tip or firmware update that applies to this memory event. If no memory fault is recorded in the logs and no DIMM connector error LED is lit, you can re-enable the DIMM through the Setup utility or the Advanced Settings Utility (ASU).

W.58001 [W.58001] The PFA Threshold limit (correctable error logging limit) has been exceeded on DIMM number % at address %. MC5 Status contains % and MC5 Misc contains %.

Explanation: DIMM PFA Threshold Exceeded

Severity: Error

User response: Complete the following steps:

1. Refer to TIP H212293 for minimum code level.
2. Check IBM support site for an applicable retain tip or firmware update that applies to this memory error.
3. At the next maintenance opportunity, swap affected DIMM (as indicated by the Light path diagnostics) to a different memory channel or CPU
4. If PFA re-occurs (on the same DIMM) replace the affected DIMM as indicated by the Light path diagnostics or failure log entry
5. If problem stays with the same DIMM connector, inspect DIMM connector for foreign material. If damaged, replace the Memory card.
6. If problem still exists, replace CPU board

W.58007 [W.58007] Invalid memory configuration (Unsupported DIMM Population) detected. Please verify memory configuration is valid.

Explanation: Unsupported DIMM Population

Severity: Error

User response: Complete the following steps:

1. Could follow an uncorrectable memory error or failed memory test. Check log and service that event first. DIMMs disabled by other errors or actions could cause this event.
2. Ensure that the DIMM connectors are populated according to the guidelines in the service information for this product.

W.58017

Explanation: DIMM Re-Enabled

Severity: Warning

User response: Complete the following steps:

1. No action; information only.

W.580A1 [W.580A1] Invalid memory configuration for Mirror Mode. Please correct memory configuration.

Explanation: Unsupported DIMM Population for Mirror Mode

Severity: Error

User response: Complete the following steps:

1. If a DIMM connector error LED is lit, resolve the failure.
2. Make sure that the DIMM connectors are correctly populated for mirroring mode, according to the service information for this product.

W.580A2 [W.580A2] Invalid memory configuration for Sparing Mode. Please correct memory configuration.

Explanation: Unsupported DIMM Population for Spare Mode

Severity: Error

User response: Complete the following steps:

1. Make sure that the DIMM connectors are correctly populated for sparing mode, according to the service information for this product.

W.580A3 [W.580A3] Invalid memory configuration for Lock-Step Mode. Please correct memory configuration.

Explanation: Unsupported DIMM Population for Lockstep Mode

Severity: Warning

User response: Complete the following steps:

1. Make sure that the DIMM connectors are correctly populated for lock-step mode, according to the service information for this product.

W.580A7

Explanation: DIMM Service Action Detected, Slot Re-Enabled

Severity: Warning

User response: Complete the following steps:

1. No action; information only.
-

W.580B0

Explanation: Memory SMI Link Failure

Severity: Warning

User response: Complete the following steps:

1. Check the IBM support site for an applicable retain tip or firmware update that applies to this memory error.
 2. Check the Memory card and associated Planar connector/ Pins for damage.
 3. Check Memory card associated CPU socket and CPU (Use the CPU installation/removal tool.).
 4. Replace the memory card (or board if error occurred on MEU).
-

W.580B1

Explanation: Memory SMI Lane failover

Severity: Warning

User response: Complete the following steps:

1. No action; information only.
-

W.68008

Explanation: EXA Cable Removed

Severity: Warning

User response: Complete the following steps:

1. Check EXA cable is connected correctly.
 2. If EXA cable is damaged,replace a new EXA cable.
-

W.680B2 [W.680B2] Currently, there is no additional information for this event.

Explanation: Internal QPI Link Width Reduction Detected

Severity: Error

User response: Complete the following steps:

1. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
2. Check the cpu identified in the event log entry. (Trained service technician) Replace the cpu.

W.680B3 [W.680B3] **Currently, there is no additional information for this event.**

Explanation: External QPI Link Width Reduction Detected

Severity: Error

User response: Complete the following steps:

1. make sure that your QPI wrap cards or QPI scalability cables are installed and in the proper sequence
2. Check the QPI port link LEDs to find the failing port or cable.
3. Reseat the QPI wrap cards or the QPI scalability cables
4. Replace the QPI wrap cards or the QPI scalability cables

W.680B4 [W.680B4] **Internal QPI Link Half Width Reduction Detected**

Explanation: Internal QPI Link Half Width Reduction Detected

Severity: Error

User response: Complete the following steps:

1. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
2. Inspect processor socket for foreign debris or damage. If debris is found remove debris.
3. If error recurs, or socket damage is found, replace the system board (Trained Service technician only) .

W.680B5 [W.680B5] **Internal QPI Link Quarter Width Reduction Detected**

Explanation: Internal QPI Link Quarter Width Reduction Detected

Severity: Error

User response: Complete the following steps:

1. Check IBM support site for an applicable RETAIN tip or firmware update that applies to this error.
2. Inspect processor socket for foreign debris or damage. If debris is found remove debris.
3. Trained Service technician only, If error recurs, or socket damage is found, replace the cpu board .

W.680B6 [W.680B6] **External QPI Link Half Width Reduction Detected**

Explanation: External QPI Link Half Width Reduction Detected

Severity: Error

User response: Complete the following steps:

1. make sure that your QPI wrap cards or QPI scalability cables are installed and in the proper sequence
2. Check the QPI port link LEDs to find the failing port or cable.
3. Reseat the QPI wrap cards or the QPI scalability cables
4. Replace the QPI wrap cards or the QPI scalability cables

W.680B7

W.680B7 [W.680B7] External QPI Link Quarter Width Reduction Detected

Explanation: External QPI Link Quarter Width Reduction Detected

Severity: Error

User response: Complete the following steps:

1. make sure that your QPI wrap cards or QPI scalability cables are installed and in the proper sequence
2. Check the QPI port link LEDs to find the failing port or cable.
3. Reseat the QPI wrap cards or the QPI scalability cables
4. Replace the QPI wrap cards or the QPI scalability cables

Appendix D. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you.

Use this information to obtain additional information about IBM and IBM products, determine what to do if you experience a problem with your IBM system or optional device, and determine whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself.

If you believe that you require IBM to perform warranty service on your IBM product, the IBM service technicians will be able to assist you more efficiently if you prepare before you call.

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated software, firmware, and operating-system device drivers for your IBM product. The IBM Warranty terms and conditions state that you, the owner of the IBM product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your IBM service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
- If you have installed new hardware or software in your environment, check to make sure that the hardware and software is supported by your IBM product.
- Go to [to check for information to help you solve the problem.](#)
- Gather the following information to provide to IBM Support. This data will help IBM Support quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.
 - Hardware and Software Maintenance agreement contract numbers, if applicable
 - Machine type number (IBM 4-digit machine identifier)
 - Model number
 - Serial number
 - Current system UEFI and firmware levels
 - Other pertinent information such as error messages and logs
- Go to [to submit an Electronic Service Request.](#) Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to IBM Support quickly and efficiently. IBM service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the

documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Using the documentation

Information about your IBM system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files.

See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to .

Getting help and information from the World Wide Web

On the World Wide Web, up-to-date information about IBM systems, optional devices, services, and support is available at <http://www.ibm.com/supportportal/> .

You can find the most up-to-date product information for System x products at <http://www.ibm.com/systems/x/> .

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with your IBM products.

For more information about Support Line and other IBM services, see or see for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services.

To locate a reseller authorized by IBM to provide warranty service, go to and click **Find Business Partners** on the right side of the page. For IBM support telephone numbers, see . In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

IBM Taiwan product service

Use this information to contact IBM Taiwan product service.

台灣 IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

IBM Taiwan product service contact information:

IBM Taiwan Corporation
3F, No 7, Song Ren Rd.
Taipei, Taiwan
Telephone: 0800-016-888

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product, and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies.

A current list of IBM trademarks is available on the web at [.ibm.com](#).

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1,048,576 bytes, and GB stands for 1,073,741,824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1,000,000 bytes, and GB stands for 1,000,000,000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives that are available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

Each solid-state memory cell has an intrinsic, finite number of write cycles that the cell can incur. Therefore, a solid-state device has a maximum number of write cycles that it can be subjected to, expressed as “total bytes written” (TBW). A device that has exceeded this limit might fail to respond to system-generated

commands or might be incapable of being written to. IBM is not responsible for replacement of a device that has exceeded its maximum guaranteed number of program/erase cycles, as documented in the Official Published Specifications for the device.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven[®], including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Particulate contamination

Attention: Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the server that is described in this document. Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the server to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If IBM determines that the levels of particulates or gases in your environment have caused damage to the server, IBM may condition provision of repair or replacement of servers or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 26. Limits for particulates and gases

Contaminant	Limits
Particulate	<ul style="list-style-type: none"> • The room air must be continuously filtered with 40% atmospheric dust spot efficiency (MERV 9) according to ASHRAE Standard 52.2¹. • Air that enters a data center must be filtered to 99.97% efficiency or greater, using high-efficiency particulate air (HEPA) filters that meet MIL-STD-282. • The deliquescent relative humidity of the particulate contamination must be more than 60%². • The room must be free of conductive contamination such as zinc whiskers.
Gaseous	<ul style="list-style-type: none"> • Copper: Class G1 as per ANSI/ISA 71.04-1985³ • Silver: Corrosion rate of less than 300 Å in 30 days

Table 26. Limits for particulates and gases (continued)

Contaminant	Limits
	<p>¹ ASHRAE 52.2-2008 - <i>Method of Testing General Ventilation Air-Cleaning Devices for Removal Efficiency by Particle Size</i>. Atlanta: American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.</p> <p>² The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.</p> <p>³ ANSI/ISA-71.04-1985. <i>Environmental conditions for process measurement and control systems: Airborne contaminants</i>. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.</p>

Documentation format

The publications for this product are in Adobe Portable Document Format (PDF) and should be compliant with accessibility standards. If you experience difficulties when you use the PDF files and want to request a web-based format or accessible PDF document for a publication, direct your mail to the following address:

*Information Development
IBM Corporation
205/A015
3039 E. Cornwallis Road
P.O. Box 12195
Research Triangle Park, North Carolina 27709-2195
U.S.A.*

In the request, be sure to include the publication part number and title.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

Telecommunication regulatory statement

This product may not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

Electronic emission notices

When you attach a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices that are supplied with the monitor.

Federal Communications Commission (FCC) statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

Industry Canada Class A emission compliance statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Australia and New Zealand Class A statement

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

European Union EMC Directive conformance statement

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the fitting of non-IBM option cards.

Attention: This is an EN 55022 Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Responsible manufacturer:

International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
914-499-1900

European Community contact:

IBM Deutschland GmbH
Technical Regulations, Department M372
IBM-Allee 1, 71139 Ehningen, Germany
Telephone: +49 7032 15 2941
Email: lugi@de.ibm.com

Germany Class A statement

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der IBM gesteckt/eingebaut werden.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden: "Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC EG Richtlinie 2004/108/EG) für Geräte der Klasse A

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:

International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH
Technical Regulations, Abteilung M372
IBM-Allee 1, 71139 Ehningen, Germany
Telephone: +49 7032 15 2941
Email: lugi@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

Japan VCCI Class A statement

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

Japan Electronics and Information Technology Industries Association (JEITA) statement

高調波ガイドライン適合品

Japan Electronics and Information Technology Industries Association (JEITA)
Confirmed Harmonics Guidelines (products less than or equal to 20 A per phase)

Japan Electronics and Information Technology Industries Association (JEITA) statement

高調波ガイドライン準用品

Japan Electronics and Information Technology Industries Association (JEITA)
Confirmed Harmonics Guidelines with Modifications (products greater than 20 A per phase)

Korea Communications Commission (KCC) statement

이 기기는 업무용(A급)으로 전자파적합기기로
서 판매자 또는 사용자는 이 점을 주의하시기
바라며, 가정외의 지역에서 사용하는 것을 목
적으로 합니다.

This is electromagnetic wave compatibility equipment for business (Type A). Sellers and users need to pay attention to it. This is for any areas other than home.

Russia Electromagnetic Interference (EMI) Class A statement

ВНИМАНИЕ! Настоящее изделие относится к классу А.
В жилых помещениях оно может создавать радиопомехи, для
снижения которых необходимы дополнительные меры

People's Republic of China Class A electronic emission statement

中华人民共和国“A类”警告声明

声明

此为A级产品，在生活环境中，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对其干扰采取切实可行的措施。

Taiwan Class A compliance statement

警告使用者：
這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

Index

A

- ac
 - good LED 70
 - power LED 17
 - power LEDs 70
- ac power supply specifications 30
- accessible documentation 1034
- adapter
 - removing 110
 - replacing 111
- administrator password 206, 208
- Advanced Settings Utility (ASU)
 - program, overview 217
- air baffle, memory expansion module
 - removing 179
 - replacing 180
- assertion event, system-event log 38
- assistance, getting 1027
- attention notices 7
- Australia Class A statement 1035

B

- battery
 - removing 112
 - replacing 113
- bays 8
 - power supply 123, 124, 125
 - QPI wrap card 127
- bezel 109
 - memory expansion module,
 - removing 177
 - replacing 109
- bezel, memory expansion module
 - replacing 178
- bezel, removing 106
- blue-screen capture feature,
 - overview 215
- boot 75
 - failure recovery 211
 - manager 205
 - Nx boot failure 75
 - recovery jumper (J22) 74
 - recovery jumper location 27
 - selection menu 202
 - selection menu program, using 208
 - sequence manipulation 212
- button
 - DVD drive eject 13
 - locator 14
 - NMI 15
 - power-control 14
 - remind 15
 - reset 16

C

- cable
 - routing external 104
 - routing internal 101

- cable assembly 153
- cabling
 - external 104
 - the server 104
- Canada Class A electronic emission statement 1035
- caution statements 7
- CD drive
 - problems 43
- checkout procedure 40
- checkout procedure, performing 41
- checkout procedures 40
- China Class A electronic emission statement 1039
- Class A electronic emission notice 1035
- CMOS, resetting data 77
- CNFG, light path diagnostic LED 66
 - collecting data 1
- components
 - on the server 90
- components, removing and replacing 97
- configuration 75, 201
 - minimum 69, 77
 - updating server 202
 - with ServerGuide 210
- configuring 218
 - QPI multi-node 226
- configuring, RAID arrays 216
- connectors
 - cable 104
 - DIMM 131
 - external 104
 - front 13, 104
 - I/O board 26
 - internal 22
 - memory card DIMM 22
 - microprocessor board 24
 - rear 104
 - rear of server 16
 - SAS-backplane 29
- consumable part 105
- contamination, particulate and gaseous 8, 1033
- controller, configuring Ethernet 216
- controls and LEDs
 - light path diagnostics panel 15
 - operator information panel 14
- corrupted server firmware 73
- cover, removing 106
- CPU
 - light path diagnostic LED 67
- creating 220
 - scalable partition 220
- creating partition 223
- CRUs, removing
 - DIMM 137
- CRUs, replacing
 - adapters 110
 - DVD drive 115
 - fans, front 120
 - front USB assembly 141

- CRUs, replacing (*continued*)
 - hot-swap hard disk drive 117
 - internal flash memory 140
 - middle fan 122
 - operator information panel assembly 119
 - power supply 123, 124, 125
 - rear I/O shuttle 143
 - SAS hard disk drive backplane assembly 153
 - SSD backplane assembly 156
- customer replaceable unit 105
- customer replaceable units (CRUs) 83
- customer replaceable units (CRUs),
 - memory expansion module 90

D

- danger statements 7
- data collection 1
- dc
 - good LED 70
 - power LED 17
 - power LEDs 70
- deassertion event, system-event log 38
- delete partition, using IMM Telnet 224
- diagnosing hardware problems 40
- diagnostic
 - event log 38
 - programs 71
 - tools, overview 37
- diagnostics 37
- dimensions 8
- dimensions of memory enclosure 31
- DIMM 137, 138
- DIMM population sequence
 - memory expansion module
 - mirroring mode 190
 - non-mirroring mode 188
- DIMM, memory expansion module
 - removing 185
 - replacing 186
- DIMMs
 - connectors 131
 - connectors, memory card 22
 - error LED 129
 - installing 136, 138
 - replacing 136
 - supported 129
- DIMMs, memory expansion module
 - removing 185
 - replacing 186
- display problems 50
- documentation
 - format 1034
 - using 1028
- documents, related 6
- drives 8
 - removing hard disk 117
- DSA
 - description 71

- DSA (*continued*)
 - editions 72
 - portable 72
 - preboot 72
- DSA preboot 73
- DVD cable 146
- DVD cable, replacing 146
- DVD drive
 - activity LED 13
 - eject button 13
 - install 116
 - internal cabling 102
 - problems 43
 - replacing 115
- Dynamic System Analysis (DSA) 71

E

- electrical equipment, servicing viii
- electrical input 9
- electrical input specifications 31
- electronic emission Class A notice 1035
- Electronic Service Agent 37
- embedded hypervisor
 - problems 44
 - using 214
- environment 8
- environmental specifications 31
- error codes
 - POST 38
- error codes and messages, POST 1013
- error LED
 - memory 129
 - memory card 23, 129
 - microprocessor 24
 - microprocessor board 24
 - power supply 69, 70
- error messages
 - IMM 367
- error symptoms
 - CD-ROM or DVD-ROM drive 43
 - general 44
 - hard disk drive 45
 - intermittent 45
 - keyboard, USB 46
 - memory 48
 - microprocessor 49
 - monitor 50
 - mouse, USB 46
 - optional devices 52
 - pointing device, USB 46
 - power 53
 - power supply LEDs 70
 - serial port 55
 - ServerGuide 55
 - software 56
 - USB port 57
- Ethernet
 - activity LED 15
 - connectors 17
 - controller
 - configuration 203
 - configuring 216
 - troubleshooting 76
 - enabling utility program 216
 - icon LED 14
 - link status LED 15

- Ethernet (*continued*)
 - transmit/receive activity LED 17
- European Union EMC Directive
 - conformance statement 1036
- event logs 38
 - viewing without restarting server 39
- expansion bays 8
- expansion module, MAX5 memory
 - rear view 33
- expansion module, memory
 - front view 32
- expansion slots 8
- external cabling 104

F

- fan
 - cable routing 101
 - front
 - installing 122
 - removing 120
 - light path diagnostic LED 65
 - middle
 - installing 123
 - removing 122
- FCC Class A notice 1035
- features 7
 - IMM 211
 - partition creating, IMM Telnet 223
 - partition delete, IMM Telnet 224
 - remote presence 215
 - scalable partition 218, 220, 221
 - scalable partition, IMM Telnet 223
 - ServerGuide 210
 - toggle partition, IMM Telnet 225
- features and specifications 29
- features RAS 10
- field replaceable unit (FRU) 105
- field replaceable units (FRUs) 83
- field replaceable units (FRUs), memory
 - expansion module 90
- firmware recovery
 - automatic in-band method 74
 - manual in-band method 74
 - out-of-band 75
- firmware updates 209
- firmware, recovering 73
- firmware, updating 201
- five-drop fan cable assembly, memory
 - expansion module
 - removing 194
 - replacing 196
- front
 - fan
 - installing 122
 - removing 120
 - USB assembly
 - removing 141
 - replacing 142
 - view 13, 104
- front bezel 109
- front view, memory expansion
 - module 32
- FRUs
 - installing
 - memory-card cage 176
 - listing 83

- FRUs (*continued*)
 - removing
 - memory-card cage 175
 - microprocessor 162
 - microprocessor-board
 - assembly 171
 - removing and replacing 160
 - replacing
 - microprocessor 165
 - microprocessor-board
 - assembly 173

G

- gaseous contamination 8, 1033
- Germany Class A statement 1036
- getting help 1028
- gigabit Ethernet controller,
 - configuring 216
- grease, thermal 170
- guidelines
 - servicing electrical equipment viii
 - trained service technicians vii

H

- handling, static-sensitive devices 100
- hard disk drive
 - problems 45
 - status LED 14
- hard disk drive backplane 153
 - removing 151
- hard disk drive backplane cable,
 - removing 151
- hardware problems 40
- hardware service and support telephone
 - numbers 1028
- heat output 8
- heat output specifications 31
- heat sink
 - applying thermal grease 166
 - installing 165, 166
 - removing 162
- help
 - from the World Wide Web 1028
 - sources of 1027
- help, World Wide Web 1028
- hot swap
 - front fans
 - installing 122
 - removing 120
 - hard disk drive
 - installing 118
 - removing 117
 - middle fan
 - installing 123
 - removing 122
 - power supply
 - installing 127
 - removing 123, 124, 125
- hot-swap
 - fan, memory expansion module
 - removing 183
 - replacing 184

- hot-swap (*continued*)
 - power supply, memory expansion module
 - removing 192
 - replacing 193
- humidity 8
- humidity specifications 31
- hypervisor key
 - installing 141
 - removing 140
- hypervisor, embedded problems 44

I

- I/O board
 - connector illustrations 26
 - jumpers 27
 - LEDs 26, 27
- I/O shuttle
 - removing 143
 - replacing 144
- IBM Advanced Settings Utility program, overview 217
- IBM Systems Director
 - updating 217
- IBM Taiwan product service 1029
- illustration
 - I/O board connectors 26
 - I/O board LEDs 26
 - I/O-board jumpers 27
 - memory card connectors 22
 - microprocessor-board connectors 24
 - microprocessor-board LEDs 24
- IMM
 - server error messages 367
 - using 211
- IMM failure 75
- IMM Telnet 223, 224, 225
 - creating partition 223
 - delete partition 224
 - resetting partition 225
 - scalable partition 223
 - starting partition 225
 - stopping partition 225
 - toggle partition 225
- IMM Telnet, creating partition 223
- IMM Telnet, delete partition 224
- IMM Telnet, toggle partitions 225
- important notices 7, 1032
- in-band server firmware recovery 74
- indicators, LEDs, and power
 - MAX5 rear view 33
 - memory expansion module front view 32
- information center 1028
- information LED 14
- information panel, memory expansion module
 - removing 180
 - replacing 182
- inspecting for unsafe conditions vii
- install
 - adapter 111
 - battery 113
 - DIMM 138
 - DVD drive 116

- install (*continued*)
 - eXFlash drive cage and backplane 159
 - front USB assembly 142
 - hot-swap front fans 122
 - hot-swap hard disk drive 118
 - hot-swap power supply 127
 - hypervisor key 141
 - I/O shuttle 144
 - internal flash memory 141
 - memory card 137
 - microprocessor-board assembly 173
 - middle hot-swap fan 123
 - operator information panel assembly 120
 - SAS hard disk drive backplane assembly 155
 - solid state drive 117
 - solid state drive backplane assembly 159
 - top cover and bezel 107
- installation guidelines 97
- installing
 - heat sink 165
 - memory expansion module system-board tray 198
 - memory-card cage 176
 - microprocessor 165
- integrated functions 9
- integrated management module error messages 367
- intermittent problems 45
- internal
 - connectors 22
 - flash memory, replacing 140
 - LEDs 22
- internal cabling
 - DVD and USB 102
 - DVD power 101
 - fans 101
 - operator information cables 101
- internal connectors 34
- introduction, IBM System x3850 X5 and x3950 X5 Types 7145, 7146, 7143, and 7191 5
- IP address, obtaining for Web interface 213
- IPMItool, viewing event logs 39

J

- Japan Class A electronic emission statement 1037
- Japan Electronics and Information Technology Industries Association statement 1038
- JEITA statement 1038
- jumpers
 - I/O board
 - boot recovery 27
 - password override 27
 - Wake on LAN bypass 27

K

- Korea Class A electronic emission statement 1038

L

- LED
 - ac power 17
 - dc power 17
 - error
 - memory 129
 - memory card 129
 - microprocessor 24
 - microprocessor board 24
 - power-error 17
- LEDs 13, 32
 - Ethernet activity 15
 - Ethernet icon 14
 - Ethernet-link status 15
 - front 13
 - hard disk drive 14
 - I/O board 26
 - information 14
 - internal 22
 - light path 15
 - light path diagnostics 63
 - light path, viewing without power 57
 - locator 14, 19
 - memory card 23, 61
 - microprocessor board 25, 59
 - operator information panel 14
 - power supply 70
 - power-on
 - front 14
 - rear 19
 - power-supply 17
 - power-supply detected problems 19
 - QPI link 18
 - rear view 17
 - system error 14
 - system-error
 - rear 19
 - light path diagnostics
 - description 57
 - panel 59
 - panel, controls and LEDs 15
 - remind button 62
 - using 57
 - light path diagnostics LEDs 63
 - limitations, single power supply 99
 - locator LED 14, 19
 - logs
 - event 38
 - POST event 38
 - system-event 38
 - system-event messages 76
 - view through Setup utility 39
 - logs, event
 - viewing without restarting server 39

M

- MAX5
 - indicators, LEDs, and power rear view 33

- MEM, light path diagnostic LED 66
- memory 129
 - installation 136
 - problems 48
 - specifications 8
 - supported 129
- memory card
 - connector illustrations 22
 - DIMM connectors 131
 - LEDs 23, 61
 - removing 136
- memory card, replacing 137
- memory expansion module 29, 34
 - bezel
 - replacing 178
 - components
 - removing and replacing 176
 - DIMM population sequence
 - non-mirroring mode 188
 - front view 32
 - hot-swap power supply
 - replacing 193
 - indicators, LEDs, and power
 - front view 32
 - information panel
 - replacing 182
 - information panel, removing 180
 - population sequence, mirroring
 - mode 190
 - removing bezel 177
 - replaceable units 90
 - system-board tray
 - removing 197
 - replacing 198
 - Tier 1 CRUs 176
 - Tier 2 CRUs 197
 - turning on and off 34
- memory expansion module air baffle
 - removing 179
 - replacing 180
- memory expansion module DIMM
 - removing 185
 - replacing 186
- memory expansion module hot-swap fan
 - replacing 184
 - removing 183
- memory expansion module hot-swap power supply
 - removing 192
- memory expansion module
 - indicators 32
- memory expansion module, turning on and off 34
- memory expansion module, MAX5
 - rear view 33
- memory mirroring
 - description, memory expansion module 188
- memory-card cage
 - installing 176
 - removing 175
- memory-mirroring population sequence
 - memory expansion module 190
- menu choices in Setup utility 203
- messages
 - POST error 38, 1013

- microprocessor
 - applying thermal grease 166
 - heat sink 169
 - problems 49
 - removing 162
 - replacing 160, 165
 - specifications 8
 - supported types 160
 - tray, replacing 160
- microprocessor-board
 - assembly, replacing 171
 - illustration 24
 - LEDs 59
- middle hot-swap fan, installing 123
- minimum configuration 69, 77
- mirroring mode, memory expansion module 188
- monitor problems 50
- mouse problems 46
- multi-node system 218, 220, 221, 223
- multi-node system, configuring 218
- multi-node system, creating 220
- multi-node system, IMM Telnet 223
- multi-node system, partitioning 221
- multi-node systems, servicing 100

N

- New Zealand Class A statement 1035
- NMI
 - button 15
 - light path diagnostic LED 66
- noise emissions 8, 31
- non-mirroring DIMM population sequence
 - memory expansion module 188
- notes 7
- notes, important 1032
- notices 1031
 - electronic emission 1035
 - FCC, Class A 1035
- notices and statements 7

O

- obtaining IP address for Web interface 213
- online
 - publications 6, 81
- operating specifications 29
- operating system installation
 - with ServerGuide 211
 - without ServerGuide 211
- operator
 - information panel 14
 - information panel, replacing 119
- operator information panel cable routing 101
- optical drive
 - power cable routing 101
- optional device problems 52
- out-of-band server firmware recovery 75

P

- part numbers, replacement parts 83
- particulate contamination 8, 1033
- partition creating, using IMM Telnet 223
- partition, delete 224
- partitioning 221
 - scalable partition 221
- parts listing 81, 83
- parts listing, memory expansion module 90
- password
 - administrator 208
 - power-on 207
 - power-on setting 206
- PCI
 - adapter, installing 111
 - adapter, removing 110
 - light path diagnostic LED 65
- People's Republic of China Class A
 - electronic emission statement 1039
- pointing device problems 46
- POST
 - error codes 38, 1013
 - event log 38
 - event viewer 206
 - view event log 39
- power 13, 32
 - cords 92
 - features 20
 - problems 53
 - requirement 9
- power requirement specifications 31
- power supply
 - error LED 70
 - specification 8
 - specifications 30
- power supply, hot-swap memory expansion module
 - removing 192
 - replacing 193
- power-control button 14
- power-cord connector 16
- power-error LED 17
- power-on
 - LED
 - front 14
 - password 207
 - password setting 206
- power-on LED
 - rear 19
- power-supply
 - LED errors 69, 70
 - LED locations 69
 - LEDs 17
 - LEDs and detected problems 19
 - removing 123, 124, 125
 - replacing 123, 124, 125
- problem
 - determination tips 78
 - embedded hypervisor 44
 - isolation tables 42
 - power 53
 - software 56
 - undetermined 77
- problems
 - CD-ROM, DVD-ROM drive 43
 - Ethernet controller 76

- problems (*continued*)
 - general 44
 - hard disk drive 45
 - intermittent 45
 - keyboard 46
 - memory 48
 - microprocessor 49
 - monitor 50
 - optional devices 52
 - POST 1013
 - serial port 55
 - ServerGuide 55
 - USB port 57
 - video 50, 57
- product service, IBM Taiwan 1029
- publications 6

Q

- QPI
 - link LEDs 18
- QPI multi-node 226
- QPI ports 16

R

- RAID adapter
 - removing 146
 - replacing 149
- RAID arrays, configuring 216
- RAS features 10
- rear
 - connectors 104
 - I/O shuttle, removing 143
 - view 16
- rear view, MAX5 33
- recovering server firmware 73
- recovery CDs, product 94
- recovery CDs, VMware ESXi 95
- remind button 15, 62
- remote presence feature, using 215
- remove
 - hypervisor key 140
 - I/O shuttle 143
 - internal flash memory 140
 - memory card 136
 - operator information panel assembly 119
 - SAS hard disk drive backplane assembly 153
 - solid state drive 116
 - solid state drive backplane assembly 156
 - top cover and bezel 106
- removing 116, 137
 - adapters 110
 - battery 112
 - bezel 109
 - bezel, memory expansion module 177
 - DIMM 137
 - DVD drive 115
 - fan, middle 122
 - fans, front 120
 - front USB assembly 141
 - hard disk drive 117

- removing (*continued*)
 - hard disk drive backplane 151
 - hard disk drive backplane cable 151
 - heat sink 162
 - hot-swap power supply 123, 124, 125
 - memory expansion module air baffle 179
 - memory expansion module DIMMs 185
 - memory expansion module five-drop fan cable assembly 194
 - memory expansion module hot-swap fan 183
 - memory expansion module hot-swap power supply 192
 - memory expansion module information panel 180
 - memory expansion module system-board tray 197
 - memory-card cage 175
 - microprocessor 162
 - microprocessor-board assembly 171
 - RAID adapter and carrier 146
 - ServeRAID SAS controller battery 128
 - top-cover bracket 107
- removing and replacing
 - memory expansion module components 176
- replace
 - FRUs 160
 - thermal grease 170
- replaceable component types 83
- replaceable components 105
- replaceable parts illustration 81
- replacement parts for the memory expansion module 90
- replacement parts, part numbers 83
- replacing 138, 146
 - adapters 110
 - battery 113
 - bezel 106
 - cable assembly 153
 - cover 106
 - DVD drive 115
 - fan, middle 122
 - fans, front 120
 - front USB assembly 141
 - hard disk drive backplane 153
 - hot-swap hard disk drive 117
 - internal flash memory 140
 - memory expansion module air baffle 180
 - memory expansion module bezel 178
 - memory expansion module DIMM 186
 - memory expansion module five-drop fan cable assembly 196
 - memory expansion module hot-swap fans 184
 - memory expansion module hot-swap power supply 193
 - memory expansion module information panel 182
 - memory expansion module system-board tray 198
 - microprocessor 160, 165

- replacing (*continued*)
 - operator information panel assembly 119
 - power supply 123, 124, 125
 - QPI wrap card 128
 - RAID adapter 149
 - rear I/O shuttle 143
 - SAS hard disk drive backplane assembly 153
 - ServeRAID SAS controller battery 129
 - SSD backplane assembly 156
 - Tier 1 CRUs 105
 - Tier 2 CRUs 139
 - top-cover bracket 108
- replacing and removing
 - memory expansion module components 176
- reset button 16
- reset partition, using IMM Telnet 225
- returning devices 104
- Russia Class A electronic emission statement 1038

S

- safety v
- safety statements v, ix
- SAS
 - backplane connectors 29
 - hard disk drive backplane assembly, replacing 153
- scalability 9
- scalable partition, creating 220
- scalable partition, partitioning 221
- scalable partition, using 218
- scalable partition, using IMM Telnet 223
- serial
 - port problems 55
- server
 - configuration, updating 202
 - firmware 73
 - firmware, starting backup 209
 - power features 20
 - replaceable units 83
- server components 90
- server controls 13
- ServeRAID SAS controller battery, removing 128
- ServerGuide
 - features 210
 - problems 55
 - using 209
 - using to install operating system 211
- service
 - calling for 79
- service and support
 - before you call 1027
 - hardware 1028
 - software 1028
- servicing electrical equipment viii
- servicing multi-node systems 100
- setup and configuration with
 - ServerGuide 210
- Setup utility 39
- Setup utility menu choices 203
- size 8

- size of memory enclosure 31
- slots 8
- software
 - problems 56
- software service and support telephone numbers 1028
- solid state drive 116
- solid state drive backplane, removing 156
- sparing 129
- specifications 7
- specifications, memory expansion module 29
- SSD
 - backplane assembly, replacing 156
- start here 40
- start partition, using IMM Telnet 225
- starting 39
- starting backup server firmware 209
- statements and notices 7
- static electricity 99
- static-sensitive devices 100
- stop partition, using IMM Telnet 225
- system
 - event log 38
 - locator LED, front 14
 - reliability guidelines 99
- system-board tray, memory expansion module
 - removing 197
 - replacing 198
- system-error LED
 - front 14
 - rear 19
- system-event log 76
- Systems Director, updating 217
- systems-management connector 16

T

- table
 - I/O board jumpers 28
 - I/O board LEDs 27
 - memory
 - cost-sensitive configuration 132
 - memory-mirroring configuration 133
 - performance configuration 131
 - microprocessor board LEDs 25
 - parts listing 83
- Taiwan Class A electronic emission statement 1039
- telecommunication regulatory statement 1034
- telephone numbers 1028
- TEMP light path diagnostic LED 65
- temperature 8
- temperature specifications 31
- thermal
 - grease 170
 - material, heat sink 169
- Tier 1 CRUs, memory expansion module 176
- Tier 1 customer replaceable unit 105
- Tier 2 customer replaceable unit 105
- toggle partition, using IMM Telnet 225
- toggle partitions 225

- tools, diagnostic 37
- top-cover bracket 107, 108
- trademarks 1032
- trained service technicians, guidelines vii
- troubleshooting 1
 - tables 42
- turning memory expansion module on and off 34
- turning off the server 21
- turning on the server 20

U

- UEFI firmware, recovering 73
- undetermined problems 77
- undocumented problems 3
- United States FCC Class A notice 1035
- Universal Serial Bus (USB) problems 57
- unsafe conditions, inspecting for vii
- updating
 - IBM Systems Director 217
 - server configuration 202
- updating firmware 201
- USB
 - assembly, installing 142
 - assembly, removing 141
 - connectors 16
 - front connectors 13
 - internal cabling 102
 - keyboard, mouse, or pointing device problems 46
 - port problems 57
 - serial
 - connector 16
 - video
 - connector 16
- using
 - boot selection menu program 208
 - embedded hypervisor 214
 - remote presence feature 215
 - scalable partition 218
 - ServerGuide 209

V

- video
 - problems 50
- viewing event logs 39

W

- Web interface
 - logging on to 213
 - obtaining IP address 213
- web interface, scalable partition 218, 220, 221, 223
- web site
 - ServerGuide 209
- weight 8
- weight of memory enclosure 31



Part Number: 00FH790

Printed in USA

(1P) P/N: 00FH790

