

Sentaurus™ Topography User Guide

Version N-2017.09, September 2017

SYNOPSYS®

Copyright and Proprietary Information Notice

©2017 Synopsys, Inc. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <https://www.synopsys.com/company/legal/trademarks-brands.html>. All other product or company names may be trademarks of their respective owners.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc.
690 E. Middlefield Road
Mountain View, CA 94043
www.synopsys.com

Contents

About This Guide	xi
Related Publications	xi
Conventions	xi
Customer Support	xi
Accessing SolvNet	xii
Contacting Synopsys Support	xii
Contacting Your Local TCAD Support Team Directly	xii
Acknowledgments	xiii

Chapter 1 Getting Started	1
Introduction	1
Starting Sentaurus Topography	2
From Sentaurus Workbench	2
From the Command Line	2
Starting Different Versions of Sentaurus Topography	2
Input	2
Command File	3
Boundary File	3
Coordinate File	3
Particle Angular Distribution File	3
Machine and Mask Library Files	4
Output	4
Standard Output	4
Log File	4
Boundary File	4
Particle Angular Distribution File	5
Extract Files	5
File for Raphael Simulations	5
Introductory Example	6
References	7

Chapter 2 Simulation Methodology	9
Modeling Hierarchy	9
Plasma Reactor Simulation	10
Feature-Scale Simulation	10
References	11

Chapter 3 Model Descriptions	13
Introduction	13
Deposition Modeling	14
Low-Pressure Effects	14
Deposition Modeling With Reemission Mechanisms	15
Deposition Modeling With Redeposition Mechanisms	17
Isotropic Deposition Model	19
Physical Vapor Deposition Model	19
Unidirectional Source Vapor Deposition Model	20
Hemispherical Source Vapor Deposition Model	20
Low-Pressure Chemical Vapor Deposition Model	21
Plasma-Enhanced Chemical Vapor Deposition Model	21
High-Density Plasma Deposition Model	22
Chemical Deposition Model	24
Other Deposition Models	24
Reflow Deposition Model	24
Spin-on-Glass Deposition Model	24
Etch Modeling	25
Simple Etch Model	26
Hemispherical Etch Model	27
Ion-Enhanced Etch Model	27
Ion-Mill Etch Model	29
Reactive Ion Etch Model	29
High-Density Plasma Etch Model	30
Chemical-Mechanical Polishing Model	30
Dry Etch Model	30
Chemical Etch Model	31
Surface Reaction Model	32
General Reaction Formula	32
Simplifications	33
Generation Rates	34
Separating Reaction Rate Parameters	35
Calculating Surface Species Density	35
Surface–Surface Reaction	36
Surface–Neutral Reaction	36
Surface–Ion Reaction	37
Growth Rate	38
Surface Species Modeling	38
Very Unstable Surface Species	42
Very Stable Surface Species	42

Plasma Modeling	42
Momentum Transfer or Charge Exchange	44
Collisionless Child–Langmuir: (fieldmodel=1)	45
Collision-Dominated Discharge: (fieldmodel=2)	45
Linear Variation: (fieldmodel=3)	45
Constant: (fieldmodel=4)	45
References	46

Chapter 4 Simulation Details **49**

Simulated Structures and Coordinate System	49
File Identifiers	50
Command File Identifier: <basename>.cmd	50
Log File: <basename>.log	50
Boundary Output Files: <basename>.tdr	50
Extract Output Files: <basename>.ext	51
Environment Variables	51
Discretization Size and Accuracy	51
Integration Order	53
Direct Interface Between Sentauros Topography and Sentauros Process	53
Syntax	54
Standard Output and Log File	54
Coordinate System	54
Direct Interface Between Sentauros Topography and Sentauros Lithography	55
Warning and Error Messages	55
Syntax Errors	55
Timer Output	55
Execution Errors	56
Known Issues	56
References	57

Chapter 5 Input Commands **59**

Introduction	59
Description of Input Commands	59
Parameter Types	60
Logical	60
Numeric	60
Character	60
Format of Command Descriptions	60
Syntax of Parameter Lists	61
Command Summary	62

Contents

deposit	63
Command Use	65
Planar Deposition	65
Coordinate Deposition (Using an External Profile)	66
Machine Deposition (Using a Specified Machine)	66
etch	68
Command Use	71
Geometric Etch a Structure (Remove All Exposed Layers)	71
Geometric Etch a Structure by Depth	71
Geometric Etch a Material	71
Coordinate Etch a Structure (Using an External Profile)	73
Machine Etch (Using a Specified Machine)	74
Machine Etch Using Automatic Grid Refinement	75
extract	76
Command Use	77
initialize	80
Command Use	81
Initializing With an External Structure	81
Defining a New Structure	81
Simulating Half of a Symmetric Structure	81
Simulating Half of a Cylindrically Symmetric Structure	82
litho	83
machdepo	84
Command Use	89
machetch	91
Command Use	96
machlitho	98
mask	99
Command Use	99
merge	100
Command Use	100
plasma	101
Command Use	102
save	103
Command Use	103
set	104
stop	105
truncate	105
Command Use	105
References	106

Chapter 6 Chemical Reaction Models	107
Model Library	107
The species.dat File	108
Syntax	108
Example	108
The chem Directory	108
The flux Directory	109
Syntax	109
Example	109
Reaction File Structure	110
Definition Block	110
Syntax	110
Example	110
Surface Species Block	111
Syntax	111
Example	111
Bulk Material Block	111
Syntax	111
Example	112
Density Block	112
Syntax	112
Example	112
Reaction Block	112
Syntax	113
Example	113
Reaction Path	113
Reaction Path Name	113
Reaction Formula	114
Parameter List	115
Syntax	115
Examples	118
Deposition of Polysilicon	118
Deposition of Doped Polysilicon	118
Isotropic Etching of Silicon	119
References	120
Chapter 7 Physical Model Interface for Deposition and Etching	121
Overview	121
Command File Interface for Deposition Models	121
Generic Command File Parameters for Deposition Models	122

Contents

Defining a PMI-Based Deposition Machine	122
C++ Interface for Deposition Models	122
Implementing a New Deposition Model	123
Level Set–Related Data	124
Additional Input Data	124
Error Handling	124
Compiling the Source Code	125
Using Additional Source Files or Libraries	125
Using the Standard Template Library	126
Loading the Shared Library	126
Debugging PMI Code	126
Input and Output Parameters for Deposition Models	128
Example Model for Deposition	128
Pmi_depo_rate_simple.hh	129
Pmi_depo_rate_simple.cc	131
Command File Interface for Etching Models	132
Material-Independent Form of machetch	132
Material-Dependent Form of machetch	133
Defining a PMI-Based Etching Machine	133
C++ Interface for Etching Models	133
Structure and Surface Material Information	134
Material Interfaces	134
Input and Output Parameters for Etching Models	135
Example Model for Etching	136
Pmi_etch_rate_simple.hh	136
Pmi_etch_rate_simple.cc	138
Command File Interface for Simultaneous Etching and Deposition Models	141
C++ Interface for Simultaneous Etching and Deposition Models	141
Input and Output Parameters for Simultaneous Etching and Deposition Models	141

Chapter 8 Deposition Examples	143
Coordinate Deposition	143
Planar Deposition (With a Specified Thickness at a Given X-Location)	145
Isotropic (Conformal) Deposition	146
Curvature-Dependent Deposition	147
Physical Vapor Deposition	148
Low-Pressure Chemical Vapor Deposition	149
Plasma-Enhanced Chemical Vapor Deposition	151
High-Density Plasma Deposition	153
Competing Deposition and Etching Effects	153
Comparative Simulation Results at Selected Intervals	154

Reflow Simulation	156
Full Spin-on-Glass	158
Simple Spin-on-Glass	159

Chapter 9 Plasma and Etch Examples **161**

Plasma Example: Angular Distribution	161
Geometric Etch	163
Coordinate Etch	165
Simple Etch Model: From Directional Etch to Isotropic Etch	166
Curvature-Dependent Etch	168
Hemispherical Etch Model: Emulating Broad Ion-Angular Distributions	169
Ion-Enhanced Etch Model: Sidewall Bowing and RIE Lag Effects	171
Ion-Mill Simulation	173
Reactive Ion Etch Simulation	174
High-Density Plasma Etch Simulation	175
Chemical-Mechanical Polishing	177
Dry Etch: Deep Trench Effects	179

Glossary **181**

Contents

About This Guide

The Synopsys Sentaurus™ Topography tool simulates the critical topography-modifying processes required to fabricate integrated circuits and discrete devices in two-dimensional cross sections of the wafer. This includes several different etch and deposition processes, spin-on-glass, chemical-mechanical polishing, and reflow.

Related Publications

For additional information, see:

- The TCAD Sentaurus release notes, available on the Synopsys SolvNet® support site (see [Accessing SolvNet on page xii](#)).
- Documentation available on SolvNet at <https://solvnet.synopsys.com/DocsOnWeb>.

Conventions

The following conventions are used in Synopsys documentation.

Convention	Description
Blue text	Identifies a cross-reference (only on the screen).
Bold text	Identifies a selectable icon, button, menu, or tab. It also indicates the name of a field or an option.
Courier font	Identifies text that is displayed on the screen or that the user must type. It identifies the names of files, directories, paths, parameters, keywords, and variables.
<i>Italicized text</i>	Used for emphasis, the titles of books and journals, and non-English words. It also identifies components of an equation or a formula, a placeholder, or an identifier.
Menu > Command	Indicates a menu command, for example, File > New (from the File menu, select New).

Customer Support

Customer support is available through the Synopsys SolvNet customer support website and by contacting the Synopsys support center.

Accessing SolvNet

The SolvNet support site includes an electronic knowledge base of technical articles and answers to frequently asked questions about Synopsys tools. The site also gives you access to a wide range of Synopsys online services, which include downloading software, viewing documentation, and entering a call to the Support Center.

To access the SolvNet site:

1. Go to the web page at <https://solvnet.synopsys.com>.
2. If prompted, enter your user name and password. (If you do not have a Synopsys user name and password, follow the instructions to register.)

If you need help using the site, click **Help** on the menu bar.

Contacting Synopsys Support

If you have problems, questions, or suggestions, you can contact Synopsys support in the following ways:

- Go to the Synopsys [Global Support Centers](#) site on synopsys.com. There you can find e-mail addresses and telephone numbers for Synopsys support centers throughout the world.
 - Go to either the Synopsys SolvNet site or the Synopsys Global Support Centers site and [open a case online](#) (Synopsys user name and password required).
-

Contacting Your Local TCAD Support Team Directly

Send an e-mail message to:

- support-tcad-us@synopsys.com from within North America and South America.
- support-tcad-eu@synopsys.com from within Europe.
- support-tcad-ap@synopsys.com from within Asia Pacific (China, Taiwan, Singapore, Malaysia, India, Australia).
- support-tcad-kr@synopsys.com from Korea.
- support-tcad-jp@synopsys.com from Japan.

Acknowledgments

Portions of this software are owned by Spatial Corp. © 1986–2017. All rights reserved.

About This Guide
Acknowledgments

This chapter provides an overview of the functionality of Sentaurus Topography, the required input files, and the output files generated. A simple example is provided.

Introduction

Sentaurus Topography is a two-dimensional simulator for evaluating and optimizing critical topography processing steps such as deposition, etch, spin-on-glass, reflow, and chemical-mechanical polishing.

The main objectives of Sentaurus Topography are:

- For process integration and device engineers, Sentaurus Topography serves as a rapid prototyping design tool, for example, to explore the effects of the deposition or etch process variation on the structure.
- For process development engineers, Sentaurus Topography can be used (with state-of-the-art physical models) to analyze an existing process or to develop a new process.

The main functionality of Sentaurus Topography is its capability to simulate various physical deposition and etching processes (the machine-based mode of deposition and etching) using the level set method [1] to perform the topographic evolution of a structure. This simulation capability is complemented by the so-called geometric deposition and etching modes, which can be used to generate structures that serve as initial structures for machine-based deposition and etching.

Two-dimensional structures are created using Sentaurus Topography. Boundary files (in TDR or SAT format) of the structures generated by Sentaurus Process or Sentaurus Structure Editor can also be a starting point for performing topography simulations in Sentaurus Topography. The resulting boundary files can then be used for further processing in Sentaurus Process or Sentaurus Structure Editor.

NOTE Sentaurus Topography deals only with the boundary of a structure. Therefore, the input structure to Sentaurus Topography must be strictly a boundary file (in TDR or SAT format), and the output from Sentaurus Topography will also be a boundary file (in TDR or SAT format). For a structure, mesh information and doping information defined on this mesh are not valid input for Sentaurus Topography.

1: Getting Started

Starting Sentaurus Topography

Starting Sentaurus Topography

Sentaurus Topography simulation can be invoked and used in one of two modes.

From Sentaurus Workbench

Sentaurus Topography is fully integrated in Sentaurus Workbench. On the command line, type the following command to start Sentaurus Workbench:

```
swb
```

From the Command Line

Sentaurus Topography can be started directly using the command file (which can be prepared using any text editor) for a simulation run, for example:

```
sptopo <basename>
```

Sentaurus Topography displays a header, which identifies the program version and then begins to execute the commands included in the file `<basename>.cmd`.

Starting Different Versions of Sentaurus Topography

A specific release and version number of Sentaurus Topography can be selected using the `-rel` and `-ver` command-line options. For example, the following command starts the simulation using the 1.0 version of the release M-2016.12 as long as it is installed:

```
sptopo -rel M-2016.12 -ver 1.0 <basename>
```

Input

Depending on the initial information available to start a simulation, Sentaurus Topography requires the following input files.

Command File

The command file is *mandatory* for all Sentaurus Topography simulations and contains the sequence of commands (describing the process steps) that direct the simulation. It is a text file that can be created and modified using any text editor or through Sentaurus Workbench. A detailed description of the input commands and their formats is provided in [Chapter 5 on page 59](#).

Boundary File

Sentaurus Topography can read the boundary file of a structure generated previously by other Sentaurus tools (such as Sentaurus Process and Sentaurus Structure Editor) or by a previous run of Sentaurus Topography. This can be in either the TDR format or SAT format (a format used by Sentaurus Structure Editor).

Coordinate File

Sentaurus Topography can read a file containing coordinates of an arbitrary cross section, which is used to deposit a specified material or to etch a given structure as described in [Coordinate Deposition \(Using an External Profile\) on page 66](#) and [Coordinate Etch a Structure \(Using an External Profile\) on page 73](#), respectively. This is useful to create an initial structure in Sentaurus Topography using data from experiments (for example, a scanning electron microscope (SEM) micrograph) or from other simulators.

Particle Angular Distribution File

For certain types of plasma deposition (for example, high-density plasma deposition) or etch simulation (for example, ion-enhanced etching), Sentaurus Topography can read a file containing the angular distribution of energetic particles arriving at a wafer surface during these plasma processes. More details can be found under `machdepo` (see [machdepo on page 84](#)) and `machetch` (see [machetch on page 91](#)).

Such distributions can be generated by plasma simulation in Sentaurus Topography using the `plasma` command (see [plasma on page 101](#)).

Machine and Mask Library Files

Sentaurus Topography can read the library files `machdepo.lib` and `machetch.lib`, which contain predefined deposition machines and etch machines for performing machine-based (using the level set method [1]) deposition and etching, respectively. Such files contain only `machdepo` and `machetch` commands, respectively (see [machdepo on page 84](#) and [machetch on page 91](#)).

A library file `mask.lib` containing predefined masks can also be read by Sentaurus Topography. Such a mask library file can be generated using the `mask` command (see [mask on page 99](#)).

These library files can be shared between different topography simulation projects and between different users of Sentaurus Topography.

Output

Standard Output

All commands specified by the input file as well as messages and output indicating the progress of Sentaurus Topography are displayed on-screen. Any error or warning condition encountered is also displayed. The `set` command can be used to change the amount of output created by Sentaurus Topography (see [set on page 104](#)).

Log File

The log file contains the same information as the standard output. The file should be examined after completion of a Sentaurus Topography simulation.

Boundary File

Boundary files contain information about the structure generated or modified by a Sentaurus Topography simulation. At the end of each simulation, Sentaurus Topography automatically writes the structure boundary information in TDR format.

At any stage of the simulation, the `save` command can be used to write the structure boundary information explicitly in TDR format or SAT format (see [save on page 103](#)).

Graphical output is created by Sentaurus Topography during a time profile evolution for either etching or deposition processes when the parameter `dtplot` has been set to a value greater than zero. Simulation results are saved in TDR format in the current working directory. See [Boundary Output Files: <basename>.tdr on page 50](#) for additional information.

Particle Angular Distribution File

Sentaurus Topography can simulate the angular distribution of energetic particles arriving at a wafer surface during processes that involve capacitively coupled plasmas. This is performed using the `plasma` command (see [plasma on page 101](#)) and the resulting distributions are saved to a file.

For certain types of plasma deposition (for example, high-density plasma deposition) or etch simulation (for example, ion-enhanced etching), Sentaurus Topography can read the angular distribution of the energetic particles, which are output by the `plasma` command.

Extract Files

Sentaurus Topography can extract the thickness, slope, and minimum or maximum slope of the specified layer in a file using the `extract` command (see [extract on page 76](#)). This extracted information can be used to analyze or to compare the results of the Sentaurus Topography simulation with available experimental or simulation data.

File for Raphael Simulations

When activated in the `save` command, Sentaurus Topography can write a file in RC2 format for the capacitance extraction tool Raphael™. Raphael uses this file to extract electrical characteristics (see [save on page 103](#)).

Introductory Example

This example shows an input file that simulates a two-dimensional cross section with deposition and etching processes, and that plots the resulting structure:

```
# Simple Sentaurus Topography example
# Example: spt_generalex.cmd

# Initialize the structure
initialize width=3 height=0.5

# Deposit layers
deposit thickness=0.519 material=Oxide
deposit thickness=0.91 material=Resist

# Define a simple mask
mask name=MASK1 s0=1 e0=2

# Do a geometric etch
etch mask=MASK1 material=Resist

# Define an etch machine
machetch material=Oxide name=Etcher rate=0.5 anisotropy=0.75
machetch material=Resist name=Etcher rate=0 anisotropy=0
machetch material=Silicon name=Etcher rate=0 anisotropy=0

# Etch with the defined machine
etch machname=Etcher time=1.2 dtplot=0.1
```

The initialization of the simulation *structure* is specified through the parameters in the `initialize` command by creating a new structure using the parameters `width` and `height` with the default substrate material (`Silicon`).

Two planar deposition commands and a masked etch process are used to create a simple initial structure. A new etch machine is defined with the default model (`simple`), which is a level set-based etching model. This is then used to etch the oxide layer.

The definition of the `dtplot` parameter in the `etch` command prompts Sentaurus Topography to create a series of TDR files at the time intervals specified by `dtplot`. The final structure created with this example file is shown in [Figure 1 on page 7](#).




Figure 1 Final structure created with file spt_generalex.cmd

References

- [1] J. A. Sethian and D. Adalsteinsson, “An Overview of Level Set Methods for Etching, Deposition, and Lithography Development,” *IEEE Transactions on Semiconductor Manufacturing*, vol. 10, no. 1, pp. 167–184, 1997.

1: Getting Started
References

CHAPTER 2 Simulation Methodology

Topography simulation is a vast topic spanning multiple disciplines. This chapter presents the simulation methodology used in Sentaurus Topography.

Modeling Hierarchy

In general, topography simulation consists of two conceptually different but closely related activities: modeling reactor-scale dynamics and simulating surface feature-scale processes as shown in Figure 2. The reaction chemistry of surfaces provides boundary conditions for reactor scale processes and simulation at the feature scale requires fluxes from reactor-scale phenomena.




Figure 2 Schematic showing the different components of topography simulation

Plasma Reactor Simulation

Most plasma deposition or etch processes are based on either DC discharges or radio frequency (RF)–excited plasmas of the capacitively coupled (CCP) or inductively coupled (ICP) type, typically driven at an RF of 13.56 MHz. In such discharges, electrons, ions, and reactive species are generated mainly in plasma bulk. The fidelity of pattern transfer during etching depends on ion impact at a process surface. Several important characteristics of ion impact phenomena can be summarized by defining ion-energy distribution functions (IEDFs) and ion-angular distribution functions (IADFs).

The actual forms of the ion-energy and ion-angular distribution functions at the process surface are controlled by the ion dynamics in negatively biased sheaths that separate the bulk from the surface. The theoretical study of sheath phenomena is therefore critical to developing analytic models that will increase understanding of the influence of reactor conditions on plasma etching behavior. Sentaurus Topography provides a basic model of plasma simulation in a CCP reactor and is described in detail in [Plasma Modeling on page 42](#).

Feature-Scale Simulation

The feature-scale simulation component in Sentaurus Topography evaluates the normal velocity of movement of the surface at different points using fluxes of different species in the reactor: ions, chemical radicals, and deposition precursors. [Figure 3 on page 11](#) depicts a more detailed view of the feature-scale simulator for a general deposition or etching step. The particle angular distribution (IADF) incident on the wafer surface is used. Fluxes of incoming particles are strongly influenced by shadowing effects.

For each kind of deposition process (for example, plasma-enhanced chemical vapor deposition) or etch process (for example, reactive ion etch), the flux calculation module computes these fluxes at discrete time intervals to account for this effect. This is described in [Chapter 3 on page 13](#). These fluxes are then converted into deposition or etch rates that are finally used to advance the surface. A numeric technique such as the level set algorithm (introduced by Osher and Sethian [1]) is then used to advance the surface to a new position.




Figure 3 Schematic showing the feature-scale simulation in Sentaurus Topography for a deposition or an etch step

References

- [1] S. Osher and J. A. Sethian, "Fronts Propagating with Curvature-Dependent Speed: Algorithms Based on Hamilton–Jacobi Formulations," *Journal of Computational Physics*, vol. 79, no. 1, pp. 12–49, 1988.

2: Simulation Methodology

References

This chapter describes the simulation capabilities provided by Sentaurus Topography for the analysis of integrated circuit fabrication, including etch, deposition, chemical-mechanical polishing (CMP), spin-on-glass (SOG), and reflow processes.

Introduction

As described in [Feature-Scale Simulation on page 10](#), the feature-scale simulation consists of the evaluation of the normal velocity of movement of the surface at different points using fluxes of three different species:

- Ions: The ions are characterized by an angular distribution obtained either through experimental measurements or by using the `plasma` command.
- Chemical radicals: Sentaurus Topography characterizes the chemical radical flux as a uniform flux over the surface.
- Deposition precursors: The deposition flux is the result of three different contributions:
 - Direct or unshadowed deposition from the gas phase.
 - Reemission flux characterized by a single sticking coefficient.
 - Redeposition flux of material sputtered by ions from the surface.

Each of these fluxes has its own peculiarities. When these fluxes are calculated, surface models must be applied to obtain the etch or deposition rates at each point on the surface. A numeric technique (level set) must then be used to advance the surface to a new position.

The following sections outline the capabilities of Sentaurus Topography to simulate the topographic evolution of a structure during deposition and etching processing steps. In addition, the plasma model available in Sentaurus Topography to simulate the angular distribution of particles arriving at the wafer surface is described. For each of these processes, a description is provided of the models used and their relation to the input parameters (as documented in [Chapter 5 on page 59](#)).

Deposition Modeling

Sentaurus Topography can simulate the deposition of a specified material on the surface of the current structure or can deposit a layer of the specified material with a specific topographic shape.

There are three different modes of deposition in Sentaurus Topography: planar, coordinate, and machine (see [deposit on page 63](#)). The first two modes are provided to construct structures that can be used as initial structures for machine-based deposition. This section describes the various deposition processes (or machines) that can be simulated in Sentaurus Topography using the machine mode.

First, using the `machdepo` command (see [machdepo on page 84](#) for details about each model and its parameters), a new deposition machine is defined. Alternatively, a predefined deposition machine (from the library file `machdepo.lib`) can be used as it is or you can alter its coefficients using the `machdepo` command.

Any one of several different deposition processes can be simulated: isotropic (conformal), unidirectional (beam deposition), hemispherical (physical vapor deposition), low-pressure chemical vapor deposition (LPCVD), plasma-enhanced chemical vapor deposition (PECVD), high-density plasma (HDP) deposition, spin coating, or reflow.

Next, the `deposit` command is used (see [Machine Deposition \(Using a Specified Machine\) on page 66](#)) along with the machine name as defined in the `machdepo` command. As a result, the machine coefficients associated with this defined machine are used for the deposition simulation. The `time` parameter in the `deposit` command specifies the total time for the simulation of the deposition step.

Low-Pressure Effects

As most deposition processes occur at very low pressures, the mean free path of the deposition precursors is very large when compared to the feature scale. As a result, the deposited film topography is often strongly affected by the geometric self-shadowing of the structure from the vapor flux, as well as by the source geometry of the deposition system.

The mechanisms that are applicable to deposition simulations in Sentaurus Topography are:

- Isotropic coverage
- Unidirectional source vapor deposition
- Hemispherical source vapor deposition
- Reemission models with a sticking coefficient

- Combination of direct and isotropic deposition models
- Redeposition of sputtered material
- Sputtering of material from the layer being deposited

For these cases, the following assumptions are made:

- The mean free path of scattering for atoms in transit to the substrate is greater than the distance from the source to the substrate.
- The source-to-substrate distance is great compared to variations of the simulation structure.
- There is no intermixing or alteration of the underlying materials.
- There is no relaxation of molecules on the surface to more energetically favorable positions.
- The magnitude and direction of the film growth follows the cosine law [1][2][3], meaning that the growth direction is along the vapor stream.

The reemission and redeposition mechanisms used by certain models are now described.

Deposition Modeling With Reemission Mechanisms

This mechanism is used by machines of type LPCVD or HDP that are defined by the command machdepo. For this deposition mechanism, the active species are classified as deposition precursors. They are transported to a given position on the surface by either direct deposition or reemission mechanisms, as depicted in Figure 4.

There is strong experimental and modeling evidence that these two transport mechanisms play a major role in defining the topological characteristics of most LPCVD systems [4][5].




Figure 4 Direct deposition (F_d) or reemission (F_r) of active species

3: Model Descriptions

Deposition Modeling

Figure 4 on page 15 shows the domain of the integration for the direct unshadowed flux and reemitted flux in a trench. For trenches, the three-dimensional shadowing of the direct flux is reduced considerably. Since there is less shadowing, trenches exhibit better step coverage than vias with the same aspect ratio. The implementation in Sentaurus Topography follows the literature [6].

To calculate the total flux at any point on the surface, the direct flux from the gas phase is calculated. All the contributions of reemitting surfaces that have direct visibility to the point are added, as shown in Eq. 1:

$$\begin{aligned}\Gamma_i &= \Gamma_{d,i} + \sum_{j \neq i} g_{ij} \Gamma_{re,j} \\ &= \Gamma_{d,i} + \sum_{j \neq i} (1-s) g_{ij} \Gamma_j\end{aligned}\tag{1}$$

where:

- Γ_i is the total incoming flux at position i .
- $\Gamma_{d,i}$ is the direct incoming flux at position i .
- $\Gamma_{re,j}$ is the flux reemitted from position j .
- g_{ij} is the view factor for particles reemitted from position j to position i .
- s is the sticking coefficient (parameter `sc`).

The two fluxes considered correspond to the direct unshadowed flux coming from the gas phase and the reemitted flux from every point on the surface that has a direct line of sight to the point under consideration. The reemission flux is the result of particles that arrive at a certain position, are adsorbed, and are thermally reemitted into the ambient. This reemission process is characterized by a single sticking coefficient defined with the `sc` parameter in the `machdepo` command.

In Sentaurus Topography, the deposition rate is assumed to be proportional to the total deposition flux. The total deposition rate for deposition on a flat unshadowed wafer surface is defined with the `rate` parameter in the `machdepo` command. The total flux that reacts and contributes to the growing rate is normalized to unity on the wafer surface. In this way, the growth rate at any point on the surface is proportional to the reacting rate, and the proportionality constant is the value specified with the parameter `rate`.

The intensity of emission is a function of the sticking coefficient and the probability of a particle being reemitted in a given direction. Sentaurus Topography assumes a cosine distribution for this probability.

The terms in Eq. 1 can be rearranged into Eq. 2. In this matrix form, the vector $\vec{\Gamma}$ is the unknown total flux at every point on the surface, and the vector Γ_d is the direct flux to the

surface and is obtained by direct integration. The coefficient matrix contains the information associated with the view factors and intensity of emission:

$$\mathbf{A} \cdot \vec{\Gamma} = \vec{\Gamma}_d \quad (2)$$

$$A_{ij} = \begin{cases} 1 & i = j \\ (s-1)g_{ij} & i \neq j \end{cases}$$

where A_{ij} is the view factor for particles reemitted from position j to position i .

In general, in this matrix expression, the matrix A is neither symmetric nor sparse. The number of null elements is a function of the visibility of every segment to every other segment. In this way, concave structures tend to give full matrices, while convex structures correspond to sparse matrices. Furthermore, applications characterized by large sticking coefficients (near unity) tend to be diagonal dominant and are solved more efficiently by iterative methods. However, for low sticking coefficients, where matrices are not diagonal dominant, direct methods are required.

Deposition Modeling With Redeposition Mechanisms

This mechanism is used by machines of type HDP and is defined using the `machdepo` command. In this mechanism, the ion flux is calculated at every point on the surface of the structure by three-dimensional integrations of ion-angular distributions.

These distributions are characterized by one of the following:

- A $\cos^m \theta$ distribution (where m is the parameter exponent).
- A distribution calculated by Sentaurus Topography using the `plasma` command.




Figure 5 Ion flux (F_i) material sputtered from surface with redeposition flux (F_{rd}) reemitted with angular cosine distribution

3: Model Descriptions

Deposition Modeling

Every point with an ion flux becomes a source of the redeposition flux with an intensity proportional to the ion flux. The yield depends on the angle between the surface normal and the mean angle of incidence of ions:

$$\gamma(\theta_i) = s_1 \cos \theta_i + s_2 \cos^2 \theta_i + s_4 \cos^4 \theta_i \quad (3)$$

where:

- $\gamma(\theta_i)$ is the sputter yield.
- θ_i is the angle between incoming ions and the surface normal.
- s_1 is the parameter `sputc1`.
- s_2 is the parameter `sputc2`.
- s_4 is the parameter `sputc4`.

The sum of `sputc1`, `sputc2`, and `sputc4` must be one.

The redeposition flux is given by:

$$F_{rd}(x, y) = \gamma(\theta_i) F_i(x, y) \quad (4)$$

where:

- $F_i(x, y)$ is the ion flux at position (x, y) .
- $F_{rd}(x, y)$ is the redeposition flux emitted from position (x, y) .

The total redeposited flux at a given position (x, y) on the surface is the result of the integration of all redeposition source fluxes that have direct visibility with that position:

$$R_{rd}(x, y) = \iint F_{rd}(\xi, \eta) \cos \phi_1 \cos \phi_2 d\xi d\eta \quad (5)$$

where:

- ϕ_1 is the angle between the surface normal at (ξ, η) and the direction between (ξ, η) and (x, y) .
- ϕ_2 is the angle between the surface normal at (x, y) and the direction between (ξ, η) and (x, y) .
- $F_{rd}(\xi, \eta)$ is the redeposition flux emitted from position (ξ, η) .
- $R_{rd}(x, y)$ is the redeposited flux at position (x, y) .

Isotropic Deposition Model

A machine is defined as an isotropic deposition machine when `isotropic` is specified during machine definition with the `machdepo` command. With this model, the material is deposited conformally over the surface [7][8]. Physically, this model corresponds to the topography that results during a chemical vapor deposition (CVD) process when reactants, or reactive intermediates, have a very low sticking coefficient. Regardless of the initial surface topography, a uniform concentration of reactants is formed along the surface. As a result, along normal paths from the surface to the interface with the underlying material, the thickness of the material is constant. For the isotropic deposition model, the growth rate is:

$$\vec{R}(x, y) = R_y \vec{n}(x, y) \quad (6)$$

where:

- $\vec{n}(x, y)$ is the unit vector perpendicular to the surface at position (x, y) .
- R_y is the vertical deposition rate on the unshadowed horizontal surface (parameter `rate`).
- $\vec{R}(x, y)$ is the deposition rate at position (x, y) .

CVD of silicon dioxide by decomposition of tetraethyloxysilane (TEOS), polysilicon, and silicon nitride are examples of deposition processes that often result in isotropic deposition profiles.

A curvature-dependent deposition process can be simulated by the following relation:

$$R(x, y) = R_y(1 - k\kappa(x, y)) \quad (7)$$

where $\kappa(x, y)$ is the curvature at position (x, y) and k is the parameter `kcurv`. With this parameter, the deposition rate is lower at a convex surface and higher at a concave surface. The net effect of the curvature-driven deposition is to smooth the surface as it evolves.

Physical Vapor Deposition Model

A deposition machine is defined as a physical vapor deposition (PVD) machine when `pvd` is specified during machine definition with the `machdepo` command. In this model, the fluxes arriving at the wafer surface are characterized by their angular distribution. A sticking coefficient of unity is assumed for the deposition process, which usually applies to metallization processes. Therefore, the deposition profile is controlled by the incoming angular distribution and the geometric shadowing effect.

Unidirectional Source Vapor Deposition Model

A machine is defined as a unidirectional source vapor deposition machine when `unidirectional` is specified during machine definition with the `machdepo` command. Physically, this model simulates the physical vapor deposition (PVD) process of unidirectional-angle evaporation. Atoms in the vapor stream impinge on the structure surface at one angle only, and material deposition does not occur in the shadowed regions. For unshadowed regions, the cosine law growth rate is expressed by:

$$R_{\text{cosine}}(x, y) = R_y \cos \theta(x, y) \quad (8)$$

where $\theta(x, y)$ is the angle between the incoming flow and the surface normal at position (x, y) .

Hemispherical Source Vapor Deposition Model

A deposition machine is defined as a hemispherical source vapor deposition machine when `hemispherical` is specified during machine definition with the `machdepo` command. In this model, the vapor flux is distributed continuously throughout a range of incidence angles in three-dimensional space. Physically, this model corresponds to the topography that results during a CVD process when incoming reactants, or reactive intermediates, have a long mean free path for scattering and adsorb, react, and convert without any surface migration occurring.

This type of coverage is typical of the PVD process of aluminum when targets are sputtered at low temperatures. This model also corresponds to the type of coverage typical of many evaporated metals. The resultant deposition rate is:

$$R(x, y) \propto R_d (\cos \vartheta(x, y) (\sin \phi_2 - \sin \phi_1) + \sin \vartheta(x, y) (\cos \phi_1 - \cos \phi_2)) \quad (9)$$

where:

- ϕ_1 is the lower bound angle of the ion distribution measured from the positive x-axis and corresponds to the parameter `angle1`.
- ϕ_2 is the upper bound angle of the ion distribution measured from the positive x-axis and corresponds to the parameter `angle2`.
- $\vartheta(x, y)$ is the angle between the surface normal at position (x, y) and the positive x-axis.
- R_d is the directional deposition rate.
- $R(x, y)$ is the deposition rate at position (x, y) .

Low-Pressure Chemical Vapor Deposition Model

A deposition machine is defined as a low-pressure chemical vapor deposition (LPCVD) machine when `lpcvd` is specified during machine definition with the `machdepo` command. In this model, the vapor flux of chemical precursors is distributed continuously throughout a range of incidence angles in three-dimensional space. In addition, a chemical precursor that sticks and reacts at the place of arrival on the surface is characterized by a single parameter called the reactive sticking coefficient (parameter `sc`). This parameter assumes values between 0.0 and 1.0. Precursors that do not react at the surface are reemitted with a cosine probability distribution for the angular distribution with respect to the directional deposition of the surface normal. The total deposition rate at a flat unshadowed surface is specified by the parameter `rate`.

Plasma-Enhanced Chemical Vapor Deposition Model

A deposition machine is defined as a plasma-enhanced chemical vapor deposition (PECVD) machine when `pecvd` is specified during machine definition with the `machdepo` command. In this model, the fluxes arriving at the wafer surface are characterized by two components: thermally driven low-pressure chemical vapor deposition precursors and ion-induced deposition precursors. The thermal CVD component is relatively more conformal, whereas the ion-induced deposition component is relatively more directional.

The thermal CVD component is simulated as a normal LPCVD process by calculating the reemission process and is characterized by a sticking coefficient parameter. The ion-induced deposition component is simulated by the calculation of the shadowing effects and is characterized by the ion-angular distribution.

The total deposition rate on a flat unshadowed surface is specified by the parameter `rate`, and the ratio of the directional rate to total deposition rate is specified by the parameter `anisotropy`:

$$R = R_i + R_d \quad (10)$$

where:

- R is the total deposition rate on the unshadowed horizontal surface.
- R_d is the directional deposition rate.
- R_i is the isotropic deposition rate.

3: Model Descriptions

Deposition Modeling

The anisotropy A is defined as:

$$A = \frac{R_d}{R_i + R_d} \quad (11)$$

High-Density Plasma Deposition Model

A deposition machine is defined as a high-density plasma (HDP) deposition machine when `hdp` is specified during machine definition with the `machdepo` command. In this model, two competing mechanisms occur: deposition and simultaneous etching by physical sputtering. The following factors are taken into account:

- Deposition by direct deposition from the gas phase.
- Deposition by reemission mechanisms.
- Ion-enhanced deposition mechanisms.
- Deposition by redeposition of material sputtered from the surface.
- Etching that assumes physical sputtering mechanisms.

The implementation of this model follows the work of Li [9]. The net deposition rate on a flat unshadowed surface is the result of the difference of the total deposition rate (specified by the parameter `rate`) minus the total etch rate (specified by the parameter `millrate`):

$$R(x, y) = R_y - R_m \quad (12)$$

where R_m is the mill rate.

The total deposition rate is characterized by three components: an ion-enhanced deposition term R_{ion} , a component that is not affected by the ion flux (called the thermal component) R_{th} , and the contribution of redeposited material R_{redep} :

$$R = R_{ion} + R_{th} + R_{redep} \quad (13)$$

where:

- R_{ion} is the ion-enhanced deposition rate.
- R_{th} is the ion flux-independent rate (thermal component).
- R_{redep} is the redeposition rate.

The ratio of the ion-enhanced deposition component to the total deposition rate on a flat surface is specified by the parameter `anisotropy A`:

$$A = \frac{R_{\text{ion}}}{R_{\text{th}} + R_{\text{ion}}} \quad (14)$$

The component R_{th} is calculated with a reemission mechanism characterized by the sticking coefficient defined by the parameter `sc`. If the parameter `sc` is not specified, a perfectly isotropic deposition is assumed.

In turn, the parameter `redepratio` defines the fraction of the material sputtered from the surface that is to be redeposited with a unity probability.

To characterize the angular distribution of the ion flux, there are two possibilities:

- An angular distribution given by $\cos^m \theta$ where m is the parameter `exponent` and θ is the angle between incoming ions and the y-axis.
- An angular distribution obtained with the `plasma` command (by specifying the parameter `plasmafile`).

The etch mechanism is assumed to be purely physical sputtering with a yield model defined by the parameters `sputc1`, `sputc2`, and `sputc4`:

$$\gamma(\theta_i) = s_1 \cos \theta_i + s_2 \cos^2 \theta_i + s_4 \cos^4 \theta_i \quad (15)$$

where:

- $\gamma(\theta_i)$ is the sputter yield.
- θ_i is the angle between incoming ions and the surface normal.
- s_1 is the parameter `sputc1`.
- s_2 is the parameter `sputc2`.
- s_4 is the parameter `sputc4`.

The sum of `sputc1`, `sputc2`, and `sputc4` must be one.

The total etch rate is calculated as the product of the yield, milling rate coefficient, and the ion flux:

$$R(x, y) = R_m \gamma(\theta_i) F_i(x, y) \quad (16)$$

where $F_i(x, y)$ is the ion flux at position (x, y) , and R_m is the mill rate (parameter `millrate`).

Chemical Deposition Model

The chemical deposition model is based on surface chemistry models [10] and is used to simulate different deposition processes such as low-pressure chemical vapor deposition (LPCVD), physical vapor deposition (PVD), and high-density plasma (HDP) chemical vapor deposition.

You must provide ion and neutral flux distributions and surface reaction models as input. For each time step of the simulation, the incoming ion and neutral fluxes are calculated at each point of the exposed surface. Together with the surface reaction models, these fluxes are used to calculate the deposition rate for each surface point.

A deposition machine is defined as a chemical deposition machine when `chem` is specified during machine definition with the `machdepo` command.

Other Deposition Models

Reflow Deposition Model

A deposition machine is defined as a reflow machine when `reflow` is specified during machine definition with the `machdepo` command. In this model, the top layer of specified material redistributes between surface regions of different free energies at certain process conditions (either at high temperature or by certain chemical reaction mechanisms), with materials flowing from an area of higher free energy to an area of lower free energy.

In addition, the final flow-shape surface profile is governed by the surface tension, which is assumed to be a function of surface curvature. The dependency of the profile on the local curvature is characterized by the parameter `kcurv`. The rate at which the lowest point on a concave surface is filled is used to indicate the planarization speed and is specified with the parameter `rate`.

Spin-on-Glass Deposition Model

A deposition machine is defined as a spin-on-glass (SOG) machine when `sog` is specified during machine definition with the `machdepo` command. This model is a combination of three processes: curvature-dependent deposition, reflow, and shrinking.

The specified material is first deposited on the surface, is subsequently reflowed for planarization purposes, and then undergoes a shrinking process. The shrinking is mainly governed by the local stress, which is assumed to be a function of surface curvature. If the

simple mode is specified in the machine definition, a combination of simple planarization and shrinking is used instead to emulate the whole process.

The thickness of the initial deposition is specified by the parameter `initspin`. The planarization speed of the reflow process is specified by the parameter `sogreflow`. The percentage of the material that undergoes the shrinking process is specified by the parameter `shrinkage`. The dependency of the profile on the local curvature in processes of either reflow or shrinking is characterized by the parameter `kcurv`. The model development is based on published work [11][12][13][14][15].

Etch Modeling

Sentaurus Topography can simulate the etching of a specified material on the surface of the current structure or can etch the current structure with a specific topographic shape.

There are basically three different modes of etching in Sentaurus Topography: geometric, coordinate, and machine (see [etch on page 68](#)). The first two modes are provided to construct a structure that can serve as an initial structure for machine-based etching or to clean up or remove mask layers. This section describes the various etching processes (or machines) that can be simulated in Sentaurus Topography using the machine mode.

First, using the `machetch` command, a new etching machine is defined (see [machetch on page 91](#) for details about each machine and its parameters). Alternatively, a predefined etch machine (from the library file `machetch.lib`) can be used as it is or you can alter its coefficients using the `machetch` command. Any one of several different etch processes can be simulated: isotropic/anisotropic, hemispherical, ion-enhanced etch, ion-milling, reactive ion etch, high-density plasma etch, and chemical-mechanical polishing.

Next, the `etch` command is used (see [Machine Etch \(Using a Specified Machine\) on page 74](#)) along with the machine name as defined in the `machetch` command. As a result, the machine coefficients associated with this defined machine are used in the etching simulation. The `etch` command requires the `time` parameter, which specifies the total time for the simulation of the etch step.

Modern integrated circuit technology relies on a diverse set of etching processes for the fabrication of these devices. These include wet chemical etch, plasma etch, and reactive ion etch. However, there are no widely applicable, physically based models for these processes.

In comparison with other critical processes, such as ion implantation and impurity diffusion for which physically based models exist (in tools such as Sentaurus Process), the etch processes are not yet well enough understood to formulate models of equivalent accuracy. Development of these models is a dynamic area of research. However, to circumvent this fundamental

3: Model Descriptions

Etch Modeling

modeling problem and still provide a useful tool, it is possible to model these processes empirically.

It has been found that many etching processes are treated as a combination of isotropic and directional parts:

$$R = R_i + R_d \quad (17)$$

where:

- R is the total etching rate on the unshadowed horizontal surface.
- R_d is the directional etching rate.
- R_i is the isotropic etching rate.

Simple Etch Model

In this type of etching (defined by the etch machine `simple`), every point on the surface of the structure exposed to the etchant moves at the same rate normal to the surface. A machine is defined to have an isotropic etching component when the etch anisotropy parameter, `anisotropy`, is less than one. The etch is also completely isotropic when the `anisotropy` parameter is zero and no other etch rate components are defined. The anisotropy coefficient as defined by Mogab [16] is:

$$A = \frac{R_d}{R_i + R_d} \quad (18)$$

where:

- A is the anisotropy.
- R_d is the directional etching rate.
- R_i is the isotropic etching rate.

Physically, isotropic etching usually corresponds to the purely chemical component of the etch. For example, wet chemical etch and fluorine-based plasma etch processes, in the absence of ion flux, often result in isotropic etch profiles.

Directional etching corresponds to the opposite extreme compared to isotropic etching. In this case, only those points on the structure that are illuminated by a perfectly collimated beam of incoming energetic ions or reactants are eroded. The surface of the structure erodes in the same direction as the incoming ion flux.

A machine is defined as having a directional etching component when the `anisotropy` parameter is greater than zero. The etch is completely directional when the `anisotropy` parameter is one and no other etch rate components are defined.

Physically, plasma-assisted processes from reactive ions or neutrals impinging upon the structure surface usually result in directional etching.

For unshadowed regions, the directional etch rate component is:

$$R(x, y) = R_d \cos \vartheta(x, y) \quad (19)$$

where:

- $\vartheta(x, y)$ is the angle between the surface normal at position (x, y) and the positive x-axis.
- R_d is the directional etching rate.
- $R(x, y)$ is the directional etching rate at position (x, y) .

A curvature-dependent etching process can be simulated by the following relation:

$$R(x, y) = R_y(1 - k\kappa(x, y)) \quad (20)$$

where $\kappa(x, y)$ is the curvature at position (x, y) and k is the parameter `kcurv`. With this parameter, the etch rate is lower at a concave surface and higher at a convex surface. The net effect of the curvature-driven etch is to smooth the surface as it evolves.

Hemispherical Etch Model

For this case, the etching machine requires the setting of the logical parameter `hemispherical`. For this etching model, the anisotropic component is calculated by performing a flux integration at every point of the surface, assuming an angular distribution of cosine type (isotropic) from the gas phase. The isotropic component of the etching rate is calculated as in the `simple` model (see [Simple Etch Model on page 26](#)).

Ion-Enhanced Etch Model

This etching machine requires the setting of the logical parameter `spetch`. For this etching model, the active species are classified as chemical radicals and ions, which are key contributors to the etch rate when performing plasma-assisted etching.

As described in the literature [17][18], in this implementation, chemical radicals, which are electrically neutral, are considered unaffected by the electric field in the plasma, and they contribute isotropically to the etching rate. In contrast, ions are affected by the conditions of the plasma discharge, and the direct unshadowed flux is calculated for each point on the surface.

3: Model Descriptions

Etch Modeling

Figure 6 shows the shadowing for the direct ion flux at a point on the surface for the case of a very long trench. The ion flux is normalized to unity on the flat unshadowed surface of the wafer. The ion-angular distribution used to calculate the flux is obtained with a simulation of the plasma discharge using the `plasma` command.




Figure 6 Shadowing for direct flux at a point on the surface

The flux of chemical radicals and the ion flux are used to obtain the etch rate using a linear superposition of both fluxes, as represented in Eq. 21:

$$R = R_{\text{chem}} + R_{\text{ion}} \quad (21)$$

where:

- R is the total etching rate (the parameter `rate`).
- R_{chem} is the chemical (isotropic) etching rate.
- R_{ion} is the ion flux–dependent etching rate.

The total etch rate on an unshadowed surface is defined by the `rate` parameter. The relative contributions of the chemical and ion components are specified by the `anisotropy` parameter, as shown in Eq. 22:

$$A = \frac{R_{\text{ion}}}{R_{\text{chem}} + R_{\text{ion}}} \quad (22)$$




Figure 7 Ion-enhanced etch model with planar interfaces and underlying materials (etching over sidewall spacers)

Ion-Mill Etch Model

An etching machine is defined as an ion-mill etching machine when `ionmill` is specified during machine definition with the `machetch` command.

The etch rate in the ion-mill etch model at every surface node is defined by:

$$\gamma(\theta_i) = s_1 \cos \theta_i + s_2 \cos^2 \theta_i + s_4 \cos^4 \theta_i \quad (23)$$

where:

- $\gamma(\theta_i)$ is the sputter yield.
- θ_i is the angle between incoming ions and the surface normal.
- s_1 is the parameter `sputc1`.
- s_2 is the parameter `sputc2`.
- s_4 is the parameter `sputc4`.

The sum of `sputc1`, `sputc2`, and `sputc4` must be one.

More details on the theory can be found in the literature [19].

Reactive Ion Etch Model

An etching machine is defined as a reactive ion etch (RIE) machine when `rie` is specified during machine definition with the `machetch` command. This model assumes that the etching is composed of two processes of isotropic (conformal) etch and anisotropic (nonconformal) etch. The total etch rate (`rate`) is the sum of the isotropic and anisotropic etch rates, while the parameter `anisotropy` defines the ratio of the anisotropic etch rate to the total rate.

The isotropic etch emulates the wet (chemical) etch process. The anisotropic etch emulates the plasma etch process in which the etch rate at any surface node is linear with the arriving ion flux. Therefore, the anisotropic etch process is controlled by the shadowing effect and the directionality of the incoming ions, which is characterized by the parameter `exponent` when analytic cosine distribution functions are used. The higher `exponent` is specified, the more directional the distribution is. A perfectly isotropic distribution corresponds to `exponent=1`, while an ion beam can be emulated by an `exponent` of more than 30.

High-Density Plasma Etch Model

An etching machine is defined as a high-density plasma (HDP) etch machine when `hdpetch` is specified during machine definition with the `machetch` command. The mechanism of this model is very similar to that of the `rie` model, except that in this case much higher ion density and ion energy are assumed. The plasma etch process is mainly ion-milling.

This model again assumes that the etching is composed of two processes of isotropic (conformal) etch and anisotropic (nonconformal) etch. The total etch rate (`rate`) is the sum of the isotropic and anisotropic etch rates, while the parameter `anisotropy` defines the ratio of the anisotropic etch rate to the total rate.

The isotropic etch emulates the wet (chemical) etch process. The anisotropic etch emulates the plasma etch process in which the etch rate at any surface node is linear with the arriving ion flux and the local sputter yield.

The local ion flux is calculated from the shadowing effect and the directionality of the incoming ions, which is characterized by the parameter `exponent` when using analytic cosine distribution functions. The higher `exponent` is specified, the more directional the distribution is. A perfectly isotropic distribution corresponds to `exponent=1`, while an ion beam can be emulated by an `exponent` of more than 30. The sputter yield calculation is the same as that of the ion-mill model (see [Eq. 23](#)).

Chemical-Mechanical Polishing Model

An etching machine is defined as a chemical-mechanical polishing (CMP) etch machine when `cmp` is specified during machine definition with the `machetch` command. This model is an approximation of the Warnock CMP model [20]. The parameter `kcmp` is used in this empirical model to characterize the planarization speed. The higher `kcmp` is, the faster planarization is achieved. The maximum polishing rate on a surface is specified by the parameter `rate`.

Dry Etch Model

With the dry etch model, a combination of sputter etching and polymer deposition can be simulated. It is especially suitable for the simulation of the dry etching process of silicon dioxide, where a thin layer of polymer is deposited on the sidewalls. The polymer can be the by-product of the gas phase reaction.

The sputter yield has a strong dependency on the angle between the incoming ions and the surface normal. Usually, for angles between 0° and approximately 60° , the resulting etching rate is much higher than for greater angles:

$$\gamma(\theta_i) = s_1 \cos \theta_i + s_2 \cos^2 \theta_i + s_4 \cos^4 \theta_i \quad (24)$$

where:

- $\gamma(\theta_i)$ is the sputter yield.
- θ_i is the angle between incoming ions and the surface normal.
- s_1 is the parameter `sputc1`.
- s_2 is the parameter `sputc2`.
- s_4 is the parameter `sputc4`.

At the bottom of a trench, the deposited polymer is usually removed together with the etched material, while that deposited on the sidewalls forms a thin layer. This layer may inhibit subsequent etching processes.

The etching rate on an unshadowed surface is given by:

$$R = R_{\text{flat}} \gamma(\theta_i) \quad (25)$$

R_{flat} is the etching rate for a flat unshadowed surface, given by the parameter `rate`.

The deposition of the polymer is modeled by a reemission process. It is characterized by the reemission rate R_{reem} and the sticking coefficient s .

R_{reem} is the parameter `reemrate`.

s is the parameter `sc`.

Chemical Etch Model

The chemical etch model [10] is similar to the chemical deposition model and is used to simulate different etching processes, such as reactive ion etch (RIE) and chemical dry etch (CDE). The main difference is that, instead of deposition rates, etching rates are calculated.

An etching machine is defined as a chemical etching machine when `chem` is specified during machine definition with the `machetch` command.

3: Model Descriptions

Etch Modeling

The chemical etch model has two different modes:

- In the first mode, only etching occurs.
- In the second mode, the so-called etchdepo mode, simultaneous etching and deposition occur. It is similar to the dry etch model (see [Dry Etch Model on page 30](#)). The etchdepo mode is activated when the parameter `depomaterial` of the `machetch` command is set.

Surface Reaction Model

This section describes the modeling capabilities of the chemical reaction module, which is used by the `chem` models of the `machdepo` and `machetch` commands. The different input files for specifying chemical reactions and their syntax are described in [Chapter 6 on page 107](#).

General Reaction Formula

Typically during an etching or a deposition process, several chemical reactions occur simultaneously. For simulation with the chemical reaction module, each of these so-called reaction paths must be specified separately. The chemical reaction module then calculates the reaction rate for each reaction path.

The following formula shows the i -th surface reaction path in its general form:

$$\begin{aligned} v'_{ji}I_j^{n+} + v'_{ji}ne^- + y_i(E, \theta) \left(v'_{ki}G_k + \sum_{l=1}^L v'_{li}S_l + v'_{mi}B_m \right) \\ \Rightarrow v''_{ji}I_j^0 + y_i(E, \theta) \left(\sum_{k=1}^K v''_{ki}G_k + \sum_{l=1}^L v''_{li}S_l + v''_{mi}B_m \right), i = 1, \dots, I \end{aligned} \quad (26)$$

where:

- I_j^{n+} is the j -th incoming ion, which is n times positively charged.
- e^- is an electron.
- G_k is the k -th gas-phase neutral species.
- S_l is the l -th surface species.
- B_m is the m -th bulk material.
- The factors v'_{xi} and v''_{xi} are the stoichiometric coefficients for the reactants and products, respectively.
- y_i is the reaction yield, which typically depends on the energy E and the angle θ of the incident ions.

Each reaction path must conserve the number of surface sites:

$$\sum_{l=1}^L v'_{li} = \sum_{l=1}^L v''_{li} \quad (27)$$

Simplifications

The chemical reaction module uses several simplifications, and it takes into account only irreversible reactions. If the reverse reaction should be taken into account, an additional reaction formula must be specified.

In general, the stoichiometric coefficients are positive integers. However, the chemical reaction module only takes zero or one incoming particle per reaction formula into account. Therefore, the stoichiometric coefficients v'_{ji} for the j -th ion species and v'_{ki} for the k -th neutral species have the values 0 or 1. If v'_{ji} and v'_{ki} have the value 1 in the same reaction formula, only the ion-induced reaction is taken into account, and the neutral particle is neglected.

The chemical reaction module does not enforce mass conservation. For example, by-products of the reaction that are not important for the simulation can be omitted from the reaction formula. This makes it easier to specify a reaction. However, it can also make it more difficult to understand a reaction model.

The angular distribution of a neutral gas-phase species is assumed to be isotropic. The angle of incidence and the translational energy are not taken into account.

Gas-phase ion species are assumed to have an anisotropic angular distribution. However, the charge of incident ions is not taken into account. The incoming ion is modeled as being neutralized before reaching the surface and scattered as a neutral particle with high translational energy.

The chemical reaction module does not conserve charge. Therefore, the electron term in [Eq. 26, p. 32](#) is not taken into account and can be omitted when specifying a reaction path.

In general, the flux of incident ions $F_{\text{ion},j}(E, \theta)$ shows a distribution regarding the energy and the angle of incidence. It is assumed that the reaction yield can be split into the product of an energy-dependent and an energy-independent factor:

$$y_i(E, \theta) = y_i(E)y_i(\theta) \quad (28)$$

3: Model Descriptions

Etch Modeling

Using this separation, you can calculate an energy-integrated ion-flux distribution, which only depends on the angle of incidence:

$$F_{\text{ion},j}(\theta) = \frac{1}{E_{\text{max}} - E_{\text{min}}} \int_{E_{\text{min}}}^{E_{\text{max}}} y_i(E) F_{\text{ion},j}(E, \theta) dE \quad (29)$$

Using an energy-integrated ion-flux distribution reduces the computation time considerably.

Generation Rates

To calculate etching or deposition rates, you must determine the generation rates for the products of all I reaction formulas describing an etching or a deposition process. \dot{I}_j , \dot{G}_k , \dot{S}_l , and \dot{B}_m are the generation rates for the j -th gas-phase ion species I_j , the k -th gas-phase neutral species G_k , the l -th surface species S_l , and the m -th bulk material B_m , respectively, and have the unit $\text{mol m}^{-2} \text{s}^{-1}$:

$$\dot{I}_j = \sum_{i=1}^I (v''_{ji} - v'_{ji}) \int q_i(\theta) d\theta \quad j = 1, \dots, J \quad (30)$$

$$\dot{G}_k = \sum_{i=1}^I (v''_{ki} - v'_{ki}) \int y_i(\theta) q_i(\theta) d\theta \quad k = 1, \dots, K \quad (31)$$

$$\dot{S}_l = \sum_{i=1}^I (v''_{li} - v'_{li}) \int y_i(\theta) q_i(\theta) d\theta \quad l = 1, \dots, L \quad (32)$$

$$\dot{B}_m = \sum_{i=1}^I (v''_{mi} - v'_{mi}) \int y_i(\theta) q_i(\theta) d\theta \quad m = 1, \dots, M \quad (33)$$

The reaction rate of the i -th surface reaction formula $q_i(\theta)$ is defined in the following way:

$$q_i(\theta) = \frac{2}{\pi} k_i(\theta) F_{\text{ion},j}(\theta)^{v'_{ji}} F_{\text{neut},k}^{v'_{ki}} \prod_{l=1}^L \left(\frac{\bar{S}_l}{B_m} \right)^{v'_{li}} \quad (34)$$

where:

- $k_i(\theta)$ is the reaction rate constant of the i -th reaction formula.
- $F_{\text{ion},j}(\theta)$ is the incident flux of the j -th ion species I_j .
- $F_{\text{neut},k}$ is the incident flux of the k -th neutral species G_k . As previously mentioned, the neutral species is assumed to have an isotropic angular distribution.

- \bar{S}_l is the density of the l -th surface species S_l .
- \bar{B}_m is the surface density of the m -th bulk material B_m .
- The ratio of S_l and B_m is the surface coverage for the l -th surface species.

Separating Reaction Rate Parameters

In general, it is difficult to extract yield $y_i(\theta)$ and the reaction constant $k_i(\theta)$ separately from experimental data. Therefore, usually a so-called overall reaction yield, which is the product of $y_i(\theta)$ and $k_i(\theta)$, is used.

$k_i(\theta)$ and $y_i(\theta)$ each can be separated into the product of an angle-independent and an angle-dependent factor:

$$\begin{aligned} k_i(\theta) &= k_{0,i} k_{\theta,i}(\theta) \\ y_i(\theta) &= y_{0,i} y_{\theta,i}(\theta) \end{aligned} \quad (35)$$

For the specification of the reaction rate parameters, the overall yield is separated into four different parts:

$$\begin{aligned} \alpha_i &= y_{0,i} k_{0,i} \\ \beta_i &= y_{\theta,i} k_{\theta,i} \\ \gamma_i &= \left\{ I_j^{n+}, G_k^{v_{ki}} \right\} \\ \delta_i &= \left\{ S_l^{v_{li}} | l = 1, \dots, L \right\} \end{aligned} \quad (36)$$

where:

- α_i and β_i are the angle-independent and angle-dependent parts of the overall reaction yield, respectively.
- γ_i specifies the gas-phase ion and neutral species.
- δ_i specifies the surface species involved in the reaction.

Calculating Surface Species Density

From [Eq. 27, p. 33](#), it follows that the system of reactions conserves the total number of surface sites. In addition, the overall surface coverage must be one:

$$\sum_{l=1}^L \frac{\bar{S}_l}{\bar{B}_m} = 1 \quad (37)$$

3: Model Descriptions

Etch Modeling

In general, the surface reactions are much faster than the evolution of the surface. Therefore, it can be assumed that the surface coverage has reached its steady state when the growth rate is calculated for each time step. By setting the generation rates for the surface species S_l to zero, the density of the corresponding surface species can be calculated:

$$\dot{S}_l = \sum_{i=1}^L (v''_{li} - v'_{li}) \int y_i(\theta) q_i(\theta) d\theta = 0 \quad l = 1, \dots, L \quad (38)$$

Surface–Surface Reaction

For a surface–surface reaction, where adsorbed species react with the bulk material without any incident flux being involved, the general reaction formula (Eq. 26, p. 32) can be simplified:

$$\sum_{l=1}^L v'_{li} S_l + v'_{mi} B_m \Rightarrow \sum_{k=1}^K v''_{ki} G_k + \sum_{l=1}^L v''_{li} S_l + v''_{mi} B_m \quad (39)$$

Then, the reaction rate reduces to:

$$q_i(\theta) = k_{0,i} \prod_{l=1}^L \left(\frac{\bar{S}_l}{\bar{B}_m} \right)^{v'_{li}} \quad (40)$$

and the reaction rate parameters can also be simplified:

$$\alpha_i = k_{0,i} \quad (41)$$

$$\delta_i = \left\{ S_l^{v'_{li}} | l = 1, \dots, L \right\}$$

Surface–Neutral Reaction

For the reaction between a gas-phase neutral and the surface, the general reaction formula (Eq. 26, p. 32) reduces to:

$$G_k + \sum_{l=1}^L v'_{li} S_l + v'_{mi} B_m \Rightarrow \sum_{k=1}^K v''_{ki} G_k + \sum_{l=1}^L v''_{li} S_l + v''_{mi} B_m \quad (42)$$

and the reaction rate is given by:


$$q_i = \frac{2}{\pi} k_{0,i} F_{\text{neut},k} \prod_{l=1}^L \left(\frac{\bar{S}_l}{\bar{B}_m} \right)^{v'_{li}} \quad (43)$$

The reaction rate parameters are:

$$\begin{aligned}\alpha_i &= k_{0,i} \\ \gamma_i &= G_k \\ \delta_i &= \left\{ S_l^{v_{li}} \mid l = 1, \dots, L \right\}\end{aligned}\tag{44}$$

Surface–Ion Reaction

For the reaction between a gas-phase ion and the surface, the general reaction formula (Eq. 26, p. 32) can be written as:



As previously mentioned, the charge is not conserved, and the electron term is neglected by the chemical reaction module.

The reaction rate is defined as:

$$q_i(\theta) = \frac{2}{\pi} k_{0,i} k_{\theta,i} F_{\text{ion},j}(\theta)^{v_{ji}} \prod_{l=1}^L \left(\frac{\bar{S}_l}{B_m} \right)^{v_{li}}\tag{46}$$

and the reaction rate parameters are:

$$\begin{aligned}\alpha_i &= y_{0,i} k_{0,i} \\ \beta_i &= y_{0,i} k_{\theta,i} \\ \gamma_i &= I_j^{n+} \\ \delta_i &= \left\{ S_l^{v_{li}} \mid l = 1, \dots, L \right\}\end{aligned}\tag{47}$$

Growth Rate

The growth rate for the m -th bulk material is calculated by dividing Eq. 33, p. 34 by the density of the bulk material ρ_m , which has the unit mol m^{-3} :

$$r_m = \frac{\dot{B}_m}{\rho_m} = 1/\rho_m \sum_{i=1}^I (v''_{mi} - v'_{mi}) \int y_i(\theta) q_i(\theta) d\theta \quad (48)$$

The unit of r_m is m s^{-1} . Positive values of r_m indicate deposition; negative values indicate etching.

Surface Species Modeling

The surface reaction model determines the etching and deposition rates by calculating the steady-state solution of Langmuir-type surface reactions [21]. For the successful use of the surface reaction model, it is necessary to create a system of surface reactions for which a steady-state solution can be found for all possible ion and neutral fluxes. This task is complicated by the fact that, on certain parts of the surface, the ion flux may be blocked by other parts of the surface. In addition, the affected parts of the surface may change from time step to time step.

A system of surface reactions must comply with the following four general rules to ensure that a steady-state solution can be found:

- Rule 1: Nonzero reaction rates
Only reaction paths with nonzero reaction rates are taken into account.
- Rule 2: Generating and consuming reaction paths for surface species
Each surface species must have at least one generating and one consuming reaction path.
- Rule 3: Generating and consuming reaction paths for surface species groups
Each surface species group must have at least one generating and one consuming reaction path. As a consequence, the directed graph must not be separated into disconnected subgraphs.
- Rule 4: Reactant coverage-dependent reaction paths
The rate of any reaction path that changes the coverage of the surface site must depend on the reactant coverage of the surface site.

NOTE A *surface species group* is a group of surface species, in which all surface species are connected by reaction paths. In the directed graph, all nodes corresponding to the surface species of a surface species group are connected by directed edges.

A system of surface reactions can be visualized by a directed graph, which makes checking the rules much easier. The surface species and the reaction paths are represented as nodes and directed edges, respectively.

A directed edge leading to a node represents a generating reaction path for the surface species corresponding to the node. A directed edge leading from a node represents a consuming reaction path for the surface species corresponding to the node. Figure 8 shows a directed graph in which all surface species have at least one generating and at least one consuming reaction path.




Figure 8 Directed graph of a system of reaction paths that comply with all four rules

For surface-ion reactions, the reaction rate depends on the ion flux. Therefore, when checking if a system of reaction paths complies with Rule 1 to Rule 4, it is necessary to distinguish two cases depending on the ion fluxes:

- In the first case, the system of reaction paths should be visualized and checked without the surface-ion reactions.
- In the second case, the full system of reaction paths should be visualized and checked.

The surface species SiCL<S> in Figure 9 on page 40 has only a generating reaction path, but no consuming reaction path. Therefore, as the rate for this reaction is nonzero according to Rule 1, in the steady state, all surface sites will be occupied by SiCL<S>. In this case, the reactions are meaningless and must be removed.

3: Model Descriptions

Surface Species Modeling




Figure 9 Directed graph of a system of reaction paths in which Rule 2 is violated for $\text{SICL}\langle\text{S}\rangle$

In [Figure 10](#), all surface species inside the dashed loop are connected and, therefore, they form a surface species group.




Figure 10 Surface species inside dashed loop are all connected and form a surface species group

In [Figure 11](#), the surface species inside the dashed loop are not all connected. There is no edge between $\text{SiCl}\langle\text{S}\rangle$ and any of the other surface species inside the dashed loop. Therefore, the surface species inside the dashed loop do not form a surface species group.




Figure 11 Surface species inside dashed loop are not all connected and do not form a surface species group

The surface species group indicated by the dashed loop in [Figure 12](#) does not have a generating reaction path. If, according to Rule 1, the reaction rate for the consuming reaction path is nonzero, in the steady-state solution, the surface concentration of the surface species of this surface species group will be zero. Therefore, the surface species and the reaction paths of this surface species group should be removed from the system of surface reaction paths.




Figure 12 Surface species group without generating reaction path

Very Unstable Surface Species

For a surface species or surface species group for which all generating reaction paths have a very low reaction rate, the coverage of the surface site tends to be zero and has no influence on the other surface site coverages. Therefore, it is recommended to remove these surface species or surface species groups and their reaction paths from the system of reaction paths.

Very Stable Surface Species

For a surface species or surface species group for which all consuming reaction paths have a very low reaction rate, the coverage of the surface site of all other species tends to be zero. Therefore, it is recommended to remove all other surface species and reaction paths from the system of reaction paths.

Plasma Modeling

In plasma deposition or etch systems, ions play a major role in the resulting topography either through direct physical sputtering mechanisms or by enhancing chemical reactions. The angular and energy distributions of ions are a key parameter in understanding topographic modifications. To analyze these distributions, either experimental techniques [22] or analytic techniques [17][23] are used.

For ion-enhanced etching and high-density plasma deposition, Sentaurus Topography can simulate the ion-angular distribution using the `plasma` command (see [plasma on page 101](#)). In this way, important etching features, such as the bowing of sidewalls and RIE lag effects, can be modeled. The `plasmafile` parameter of the `machdepo` (see [machdepo on page 84](#)) and `machetch` (see [machetch on page 91](#)) commands can be used to specify the name of the output file of the `plasma` command for use with the plasma deposition or etching models.

This section describes the model used in the `plasma` command. In weakly ionized etching discharges, two types of region are identified: the plasma region and the bulk region. The bulk region is identified by its glow, and the *dark sheath regions* that surround the electrodes and the walls. The plasma region acts as a source of ions that are considered, in most cases, as thermalized with a characteristic ion temperature. The plasma region is electrically neutral and isolated from the electrodes by the sheath regions. When ions enter the sheath, they accelerate towards the electrodes because of the voltage drop in the sheath. According to the relation between the mean free path and the sheath thickness, the ions may collide with other gaseous species in their trajectory.

Sentaurus Topography uses a Monte Carlo technique to follow the paths of many ions through the sheath. It is assumed that the degree of ionization is very low ($<10^{-3}$), so that ion-to-ion collisions are unlikely. In addition, although the spatial field variation across the sheath is dependent on the collision mechanisms, this variation is not calculated self-consistently. Each ion trajectory is calculated independently. Figure 13 shows a schematic representation of the ion transport calculation.




Figure 13 Two different ion collision mechanisms: (left) momentum transfer and (right) charge exchange

Several parameters that describe the nature of the discharge and the chemicals used are defined in this command. The total pressure of the chamber is defined with the parameter `pressure`. The gas temperature is defined with the parameter `gastemp`. As ions are affected by the oscillating fields, their ‘temperature’ may be different from the gas temperature. Most discharges are correctly described with the same ion temperature as the majority neutral gas temperature by making `iontemp` the same as `gastemp`.

The time-dependent potential difference between the sheath–plasma interface and the wafer surface (V_i) is described by the parameters `dcpot`, `acpot`, and `frequency` as in the following equation:

$$V_{sh} = V_{DC} + V_{AC} \sin 2\pi ft \quad (49)$$

where:

- f is the parameter `frequency`.
- V_{AC} is the parameter `acpot`.
- V_{DC} is the parameter `dcpot`.
- V_{sh} is the potential difference between the sheath–plasma interface and the wafer surface.

Note here that the DC part of the sheath voltage `dcpot` differs from the self bias (V_{bias}), the measured potential between the electrode and the power supply, in that it includes the DC part of the plasma potential, that is, $V_{bias} = V_{plasma} + |V_{bias}|$, where V_{plasma} is the DC part of the plasma potential. For the RIE mode, V_{plasma} is often small compared to V_{bias} , so $V_{DC} \cong |V_{bias}|$.

Similarly, the actual position of the interface varies with time and oscillates according to:

$$x_{\text{sh}} = x_{\text{DC}} + x_{\text{AC}} \sin 2\pi ft \quad (50)$$

where:

- f is the parameter frequency.
- x_{AC} is the sheath thickness due to V_{AC} (parameter `acthickness`).
- x_{DC} is the sheath thickness due to V_{DC} (parameter `dcthickness`).
- x_{sh} is the position of the sheath–plasma interface.

The atomic mass of the majority neutral species is defined by `gasmass`, and the mass of the majority ion species is defined by `ionmass`. Since the electric field is not calculated self-consistently, the models are selected with the `fieldmodel` parameter. In this type of simulation, the cross sections of two different types of interaction are defined with the parameter `momentumxsect` for the momentum transfer–type of collision and `chargexsect` for the charge exchange–type of collision.

These values are difficult to obtain for typical conditions of electronics processing. Typical values are of the order of 5 to 20 Å². Usually, the momentum-transfer cross section dominates the collision process, with the exception of discharges in which both majority neutrals and ions have the same mass, such as in argon discharges. The `energydiv` and `anglediv` parameters are used to specify the number of energy and angle subdivisions in the output array for the distributions. The `neutrals` parameter specifies whether the distribution of the energetic neutrals must be generated.

Momentum Transfer or Charge Exchange

Ions depart from the interface between the bulk and the sheath. In their trajectory to the electrode surface, they may interact with neutral particles with charge exchange or momentum transfer collisions. In a charge exchange, the ion is ‘neutralized,’ gaining an electron from a nearby neutral with no momentum transfer. New ion particles with a Maxwellian distribution are formed.

In a momentum transfer collision, no charge is exchanged, but momentum is transferred according to hard ball collision mechanisms. In this model, it is assumed that the collision cross sections are energy independent.

In [Figure 13 on page 43](#), the momentum transfer collision involves the collision of an ion with a neutral. Both particles undergo a change in momentum. In the charge exchange mechanism, an ion acquires an electron, becomes a neutral, and continues in a straight path. The neutral that lost an electron becomes an ion and is accelerated by the electric field.

Collisions in the sheath generate fast neutrals. These energetic neutral particles affect the etch mechanism; their angular distribution is calculated with the `plasma` command by setting the parameter `neutrals` to `true`.

A selection of different models for the spatial dependence of the electric field must be specified in the input file.

Collisionless Child–Langmuir: (`fieldmodel=1`)

$$E = \frac{4V_{\text{sh}}}{3L_{\text{sh}}}\left(\frac{x}{L_{\text{sh}}}\right)^{1/3} \quad (51)$$

where:

- E is the electric field.
- x is the particle position in the sheath.
- L_{sh} is the sheath thickness.
- V_{sh} is the sheath potential.

Collision-Dominated Discharge: (`fieldmodel=2`)

$$E = \frac{3V_{\text{sh}}}{2L_{\text{sh}}}\left(\frac{x}{L_{\text{sh}}}\right)^{1/2} \quad (52)$$

Linear Variation: (`fieldmodel=3`)

$$E = \frac{2V_{\text{sh}}x}{L_{\text{sh}}^2} \quad (53)$$

Constant: (`fieldmodel=4`)

$$E = \frac{V_{\text{sh}}}{L_{\text{sh}}} \quad (54)$$

Note that most experimental measurements of sheath fields have found a linear variation for the electric field.

In the `plasma` command (see [plasma on page 101](#)), the input parameters for this ion trajectory simulation are described. These parameters are necessary for the simulation. However, the Knudsen number is the most physically significant parameter, and it is calculated as follows:

$$\sigma = \sigma_{\text{m}} + \sigma_{\text{ch}} \quad (55)$$

3: Model Descriptions

References

where σ is the total cross section, σ_m is the momentum-transfer cross section, and σ_{ch} is the charge-transfer cross section.

$$\lambda_m = \frac{1}{\sigma N_n} \quad (56)$$

where λ_m is the length of the mean free path, σ is the total cross section, and N_n is the neutral concentration.

$$Kn = \frac{\lambda_m}{L_{sh}} \quad (57)$$

where λ_m is the length of the mean free path, Kn is the Knudsen number, and L_{sh} is the thickness of the plasma sheath.

A typical Knudsen number for a reactive ion etch (RIE) process at 50 mTorr is approximately 1.0. The Knudsen number tends to increase as pressure is reduced. The ion flux tends to be very directional if the Knudsen number is greater than 3, and the ion flux tends to be more isotropic if the Knudsen number is less than 0.3. The sheath thickness is approximated as about one-half of the observed thickness of the dark space as viewed from outside of the discharge. Typically, the sheath thickness is approximately 1 cm at 50 mTorr and decreases with increasing pressure.

References

- [1] I. A. Blech, "Evaporated Film Profiles Over Steps in Substrates," *Thin Solid Films*, vol. 6, no. 2, pp. 113–118, 1970.
- [2] I. A. Blech, D. B. Fraser, and S. E. Haszko, "Optimization of Al step coverage through computer simulation and scanning electron microscopy," *Journal of Vacuum Science & Technology*, vol. 15, no. 1, pp. 13–19, 1978.
- [3] I. A. Blech, D. B. Fraser, and S. E. Haszko, "Erratum: Optimization of Al step coverage through computer simulation and scanning electron microscopy," *Journal of Vacuum Science & Technology*, vol. 15, no. 6, p. 1856, 1978.
- [4] J. C. Rey *et al.*, "Monte Carlo low pressure deposition profile simulations," *Journal of Vacuum Science & Technology A*, vol. 9, no. 3, pp. 1083–1087, 1991.
- [5] J. P. McVittie *et al.*, "LPCVD Profile Simulation Using a Re-Emission Model," in *IEDM Technical Digest*, San Francisco, CA, USA, pp. 917–920, December 1990.
- [6] V. K. Singh, E. S. G. Shaqfeh, and J. P. McVittie, "Simulation of profile evolution in silicon reactive ion etching with re-emission and surface diffusion," *Journal of Vacuum Science & Technology B*, vol. 10, no. 3, pp. 1091–1104, 1992.
- [7] A. C. Adams, "Dielectric and Polysilicon Film Deposition," *VLSI Technology*, S. M. Sze (ed.), New York: McGraw-Hill Book Company, pp. 93–129, 1983.

- [8] M. J. Cooke, "Monte-Carlo Simulation of Thin Film Deposition in a Square Groove," in *Simulation of Semiconductor Devices and Processes (SISDEP)*, vol. 2, Swansea, UK, pp. 398–404, July 1986.
- [9] J. Li, *Topography Simulation of Intermetal Dielectric Deposition and Interconnection Metal Deposition Processes*, Ph.D. thesis, Stanford University, Stanford, CA, USA, March 1996.
- [10] T. Ichikawa, T. Takase, and N. Tamaoki, "Modeling of Deposition During $C_5F_8/CO/O_2/Ar$ Plasma Etching Using Topography and Composition Simulation," in *International Conference on Simulation of Semiconductor Processes and Devices (SISPAD)*, Vienna, Austria, pp. 425–428, September 2007.
- [11] W. H. Press *et al.*, *Numerical Recipes in C: The Art of Scientific Computing*, Cambridge: Cambridge University Press, 2nd ed., 1992.
- [12] L. M. Peurrung, and D. B. Graves, "Film Thickness Profiles over Topography in Spin Coating," *Journal of the Electrochemical Society*, vol. 138, no. 7, pp. 2115–2124, 1991.
- [13] P. Haaland, J. McKibben, and M. Parodi, "The art and science of thin-film coating: A progress report," *Solid State Technology*, vol. 38, no. 4, pp. 83–89, 1995.
- [14] P. Pai, W. G. Oldham, and C. H. Ting, "Process Considerations for Using Spin-on Glass as a Planarizing Dielectric Film," in *Fourth International IEEE VLSI Multilevel Interconnection Conference (VMIC)*, San Clara, CA, USA, pp. 364–370, June 1987.
- [15] H. W. M. Chung, S. K. Gupta, and T. A. Baldwin, "Fabrication of CMOS Circuits Using Non-Etchback SOG Processing for Dielectric Planarization," in *Sixth International IEEE VLSI Multilevel Interconnection Conference (VMIC)*, Santa Clara, CA, USA, pp. 373–381, June 1989.
- [16] C. J. Mogab, "Dry Etching," *VLSI Technology*, S. M. Sze (ed.), New York: McGraw-Hill Book Company, pp. 303–345, 1983.
- [17] J. I. Ulacia-Fresnedo, *Theoretical and experimental considerations necessary to build a dry-etching process simulator*, Ph.D. thesis, Stanford University, Stanford, CA, USA, 1988.
- [18] J. P. McVittie *et al.*, "SPEEDIE: A Profile Simulator for Etching and Deposition," in *Proceedings of SPIE, Advanced Techniques for Integrated Circuit Processing*, vol. 1392, Santa Clara, CA, USA, pp. 126–138, October 1990.
- [19] D. Adalsteinsson and J. A. Sethian, "A Level Set Approach to a Unified Model for Etching, Deposition, and Lithography I: Algorithms and Two-Dimensional Simulations," *Journal of Computational Physics*, vol. 120, no. 1, pp. 128–144, 1995.
- [20] G. Nanz and L. E. Camilletti, "Modeling of Chemical–Mechanical Polishing: A Review," *IEEE Transactions on Semiconductor Manufacturing*, vol. 8, no. 4, pp. 382–389, 1995.
- [21] J. M. Thomas and W. J. Thomas, *Principles and Practice of Heterogeneous Catalysis*, Weinheim, Germany: VCH Verlagsgesellschaft, 1997.

3: Model Descriptions

References

- [22] H. H. Sawin, J. Liu, and G. L. Huppert, “Ion Bombardment in RF Plasmas,” in *Proceedings of the Eighth Symposium on Plasma Processing*, vol. 90-14, Montréal, Québec, Canada, pp. 11–24, May 1990.
- [23] M. J. Kushner, “Distribution of ion energies incident on electrodes in capacitively coupled rf discharges,” *Journal of Applied Physics*, vol. 58, no. 11, pp. 4024–4031, 1985.

CHAPTER 4 Simulation Details

This chapter describes Sentaurus Topography simulations, including the structures simulated and the coordinate system used, the input and output file identifiers, the environment variables used, and warning and error messages. The final section mentions the known problems of this release of Sentaurus Topography.

Simulated Structures and Coordinate System

Sentaurus Topography simulates structures that are composed of one or more distinct layers (as shown in [Figure 1 on page 7](#)). Each layer consists of a given material. The structure represents a cross section of an infinite, arbitrarily shaped, prismatic structure.

The structure can be formed by several methods:

- Depositing new layers.
- Etching existing layers.
- Reading structure files created or modified by other Sentaurus process tools (Sentaurus Process, Sentaurus Structure Editor) in TDR or SAT format.

Sentaurus Topography uses a right-handed coordinate system with the positive x-axis pointing to the right and the positive y-axis pointing upwards.

NOTE Other TCAD Sentaurus tools such as Sentaurus Process use different coordinate systems. Therefore, it is necessary to transform coordinates when reading TDR files created by these tools and when writing TDR files for use with these tools.

The `initialize` and `save` commands have the parameter `invert` with which you can activate or deactivate the inversion of the y-coordinates. By default, y-coordinates are inverted for reading and writing TDR files.

When Sentaurus Topography reads or writes a SAT file, the internal coordinate system is used without any inversion of the y-coordinates.

Coordinate specifications for the `extract` command (see [extract on page 76](#)) and the extraction results use the internal coordinate system of Sentaurus Topography.

4: Simulation Details

File Identifiers

NOTE Coordinates for the coordinate deposition and etching are given in the Sentaurus Topography coordinate system.

NOTE When an input structure uses the unified coordinate system, it is transformed to the internal coordinate system of Sentaurus Topography. Independent of the coordinate system used by the input structure, commands are given in the Sentaurus Topography coordinate system.

File Identifiers

Command File Identifier: <basename>.cmd

The identifier for the command file is represented in terms of the following components:

- <basename> is the portion of the file name before the last period.
- <ext> is the portion of the file name after the last period.

The file identifier is represented as <basename>.<ext>. If the file name does not include a period (.), <basename> is defined as the entire file name.

Log File: <basename>.log

The standard output is placed in the file <basename>.log and consists of a list of the simulation input commands, error and warning messages, and printed output produced during a Sentaurus Topography session. Each input command is preceded in the list by a number. The file <basename>.log should be examined after completion of a Sentaurus Topography simulation.

Boundary Output Files: <basename>.tdr

Boundary files contain information about the structure generated or modified by a Sentaurus Topography simulation. At the end of each simulation, Sentaurus Topography automatically writes the structure boundary information in TDR format as <basename>.tdr.

At any stage of the simulation, the `save` command can be used to write the output in TDR or SAT format explicitly using the base name specified by the user.

During machine deposition or etching, Sentaurus Topography can create boundary files (in TDR format) at time intervals specified with the `dtplot` parameter.

The naming convention for files created using `dtplot` is:

```
<basename>_<command_number>_[etch|depo]_<plot_number>.tdr
```

where `<command_number>` identifies the command number in the input file and `[etch|depo]` indicates that either word will be included in the output file name depending on the kind of process being executed. `<plot_number>` corresponds to the number of the time plot that has been created.

During a time plot evolution, you can observe how the surface changes during the processing time.

NOTE For the full spin-on-glass (SOG) deposition model, the keyword `depo` will be replaced with `depo_sogdepo`, `depo_sogreflow`, and `depo_sogshrink`. Similarly for the simple SOG deposition model, `depo` will be replaced with `depo_sogreflow` and `depo_sogshrink`.

Extract Output Files: `<basename>.ext`

If no file is specified for the `extract` command, Sentaurus Topography writes the extracted information in the file `<basename>.ext`.

Environment Variables

A unique environment variable `SPTOPO_LIBRARY_PATH` is associated with Sentaurus Topography. It defines the path to the directories in which Sentaurus Topography looks for the library files `machdepo.lib`, `machetch.lib`, and `mask.lib`. If a file contains a mask or machine with the same name as specified in a file that has already been read, this mask or machine is modified. If `SPTOPO_LIBRARY_PATH` is not defined or is empty, the present working directory is searched.

Discretization Size and Accuracy

Numeric simulation methods, in general, only produce approximations to the exact results. Usually, the quality of the approximation can be improved by increasing the computational effort. For the level set method, the required memory and CPU time is determined mainly by the spatial and time discretization.

Decreasing the size of the spatial discretization increases the required memory and the CPU time because there are more grid points to store and process. Due to the

4: Simulation Details

Discretization Size and Accuracy

Courant–Friedrichs–Lewy (CFL) condition [1], the maximum time-step size must be reduced. This causes a further increase of the CPU time.

Usually when setting up an etching or a deposition simulation, it is necessary to find a compromise between the required accuracy and the limited available computational resources. A good understanding of the relationship between the discretization sizes and the resulting accuracy is important not only when setting up a simulation, but also when interpreting the results of a simulation.

In general, the spatial accuracy that can be achieved when using the level set method is of the order of the spatial discretization. Therefore, you need to decide which features of the input structure and the expected output structure are important and to choose the spatial discretization accordingly.

Subresolution accuracy may be achieved in those parts of the simulation domain where the surface shows little variation. For example, when using a deposition model for which the rate does not depend on any property of the surface, the thickness of a deposited layer can be determined with higher accuracy than the spatial discretization size in those areas of the surface that are at a distance from the corners of the surface.

For etching, the situation is more complicated, and some additional considerations must be taken into account. Generally, several materials are etched simultaneously with different etching rates. By default, Sentaurus Topography determines the material-dependent etching rate at each level-set grid point. Thin parts of the input structure, which fall between the grid points, will not be resolved properly, leading to unexpected results. For several etching models, the material-dependent etching rate can be calculated at the vertices of the exposed surface. This increases the spatial resolution and allows the use of coarser discretizations for structures with thin layers.

To underetch masking materials properly and to avoid certain artifacts, special treatment is necessary at the interface of two different materials. At the grid points directly at an interface or next to an interface, the higher etching rate of the two materials is used. This can lead to problems with very thin layers for which the etching rate is lower than for the neighboring materials. In this case when using the default method, the spatial discretization must be chosen to be one-third of the layer thickness or less to resolve the thin layer. Otherwise, in the discretized representation, the thin layer may not be contained at all. When using the etching rate calculation at the vertices of the exposed surface, it is sufficient to choose the spatial discretization to be slightly less than the thickness of the thin layer.

The CFL condition defines an upper limit on the time-step size of the level set method. However, this only guarantees the numeric stability of the time integration. To achieve good accuracy, it may be necessary to reduce the time-step size below the CFL time-step size. For etching or deposition models where the rate depends on certain properties of the surface, different time-step sizes may lead to differences in the result. This is obvious for models in which the visibility is taken into account for determining the incoming flux. In addition,

models where the rate depends on the angle between the surface normal and the vertical are affected.

For etching, an automatic grid refinement mode is available. After an initial simulation with the specified value or the default value of dx , the simulation is repeated with reduced values of dx until the difference between consecutive surfaces is smaller than a threshold (see [etch on page 68](#)).

Integration Order

By default, a convex first-order scheme is used to integrate the level-set function. The parameter `secondorder` of the `deposit` and `etch` commands can be used to activate a convex second-order space scheme [2]. The second-order scheme improves the accuracy and, therefore, allows the use of coarser spatial and time discretizations than the first-order scheme to achieve the same accuracy.

When using the same discretization, the computational effort for the second-order scheme is slightly higher than for the first-order scheme. However, when using a coarser discretization that results in the same accuracy, the overall computational effort for the second-order scheme is considerably lower.

Direct Interface Between Sentaurus Topography and Sentaurus Process

A direct interface from Sentaurus Process to Sentaurus Topography is available. This interface allows you to perform etching and deposition with Sentaurus Topography by issuing the appropriate commands from within the Sentaurus Process command file.

The transfer of all required data between Sentaurus Process and Sentaurus Topography is handled automatically, without the need for any additional user intervention. This makes it much more convenient to use the etching and deposition capabilities of Sentaurus Topography in a process flow that is otherwise simulated by Sentaurus Process. The setup of such a simulation is greatly simplified, and the robustness is improved considerably when compared to a simulation flow that does not use the interface.

4: Simulation Details

Direct Interface Between Sentaurus Topography and Sentaurus Process

Syntax

Sentaurus Topography can be used from within a Sentaurus Process command file either by using the keyword `sptopo` followed by a Sentaurus Topography command:

```
sptopo <sptopo command>
```

or by the keyword `sptopo` followed by a group of Sentaurus Topography commands enclosed in braces:

```
sptopo {  
    <sptopo command>  
    <sptopo command>  
    ...  
}
```

The first form of the `sptopo` command allows the use of all of the usual Sentaurus Process Tcl constructions in the parameter specification of `<sptopo command>`. For more information, refer to the Sentaurus Topography interface in the *Sentaurus™ Process User Guide*.

Standard Output and Log File

The output generated by Sentaurus Topography is written to the standard output and to the Sentaurus Process log file.

The Sentaurus Process parameter `InfoDefault` can be used to control the amount of output written by Sentaurus Topography instead of the Sentaurus Topography command:

```
set infolevel=<n>
```

See [set on page 104](#).

Coordinate System

Independent of the coordinate system used in Sentaurus Process, the structure is transformed to the Sentaurus Topography coordinate system for simulation in Sentaurus Topography and is transformed back when the result is read by Sentaurus Process. All commands for Sentaurus Topography must be given in the Sentaurus Topography coordinate system.

Direct Interface Between Sentaurus Topography and Sentaurus Lithography

A direct interface between Sentaurus Topography and Sentaurus Lithography is available. This interface allows you to perform lithography simulations with Sentaurus Lithography to create resist regions by issuing the appropriate commands from within the Sentaurus Topography command file.

The transfer of the command, geometry, and mask data between Sentaurus Topography and Sentaurus Lithography is handled without the need for any additional user intervention. This makes it more convenient to use the lithography capabilities of Sentaurus Lithography in a process flow that is otherwise simulated by Sentaurus Topography.

Two commands, `litho` and `machlitho`, are available in Sentaurus Topography to modify the parameters of a lithography simulation and to perform such a simulation, respectively (see [litho on page 83](#) and [machlitho on page 98](#)). The 2D cross sections of resist regions created by the lithography simulation are incorporated into the geometric structure in Sentaurus Topography.

NOTE To use the interface, you must set the environment variable `PATH` so that the `slitho` executable can be accessed. An additional license for Sentaurus Lithography is required.

Warning and Error Messages

Syntax Errors

The input commands in the command file are assigned sequential numbers. They are printed with these numbers to the standard output. Each command is checked for syntax errors. Syntax error messages are displayed on-screen and are written to the output file.

Timer Output

Timers have been added to all commands. If `infolevel` is set to at least 2, a summary of the timings is printed at the end of the simulation. See [set on page 104](#).

Execution Errors

If no syntax errors are found, the input commands are checked for the validity of parameter values and combinations of parameters. Warning messages are indicated by messages displayed on-screen and written to the output file.

Execution errors terminate program execution after it is determined that no further reliable error checking can be performed. Warning messages are not fatal and serve only to indicate possible problems that you can choose to correct. Warning messages also indicate the automatic corrective action taken by Sentaurus Topography.

Known Issues

The following issues are known to exist for this release of Sentaurus Topography:

- There is no warning for most invalid parameter combinations, for example, `material` and `machname` for the `deposit` command.
- The values specified with the `initialize`, `machdepo`, and `deposit` parameters `diel` and `volt` are not stored in SAT and TDR files.
- At the interface of two different materials, the greater of the two etching rates is used, which may lead to artifacts in the resulting geometry.
- Inconsistent geometry due to too coarse discretization: It is important to use an appropriate spatial discretization for the machine-based etching and deposition simulations to resolve the starting structure properly.

This is especially important for etching because it is necessary to resolve different regions to use the correct etching rates. If regions for which the etching rate is set explicitly or implicitly to zero are not resolved properly, an error may occur.

- Sentaurus Lithography requires material properties for all materials in the input geometry. However, the materials in Sentaurus Topography and Sentaurus Lithography are different. This makes it necessary to add specifications for the materials used in a Sentaurus Topography structure. This can be done in several ways:
 - Sentaurus Lithography database
 - SLO file
 - `machlitho` command
- Problems with overhanging structures in Sentaurus Lithography: Etching and deposition processes can create overhanging structures. Such structures can cause problems in Sentaurus Lithography and can lead to an error message "Topography too complex for exposure".

References

- [1] R. Courant, K. Friedrichs, and H. Lewy, “On the Partial Difference Equations of Mathematical Physics,” *IBM Journal*, vol. 11, no. 2, pp. 215–234, 1967.
- [2] J. A. Sethian, *Level Set Methods and Fast Marching Methods: Evolving interfaces in computational geometry, fluid mechanics, computer vision, and materials science*, Cambridge: Cambridge University Press, 1999.

4: Simulation Details

References

CHAPTER 5 Input Commands

This chapter describes the commands that Sentaurus Topography recognizes.

Introduction

You can direct Sentaurus Topography with input commands specified in the input file. This chapter contains the following sections:

- General format of the input and defines the syntax used in the other sections.
 - Initialization, geometry property extraction, merge, and save commands.
 - Process steps (deposit, etch, and plasma simulation).
 - Machine and mask specifications.
-

Description of Input Commands

The input commands of Sentaurus Topography are specified in the following format:

- Each command consists of a command name followed by a list of parameter names and values.
- A command can occupy more than one line by using continuation lines.
- An input line is a continuation line if the first character is a plus sign (+).
- Commands can only be broken for continuation between parameter specifications.
- Empty lines are ignored.
- Nonprinting characters such as backspace, horizontal tabulation, line feed, form feed, and return are converted to empty characters.
- Parameter names consist of one or more consecutive characters.
- If parameters are assigned values, the value is separated from the parameter name by an equal sign (=).
- Parameter name–value pairs are separated from the command name and from each other by empty characters. Empty characters are permitted anywhere, except within a name or a value.
- Comment lines can be defined beginning with # at the start of the line.
- The order of the parameters in a command is not important.

Parameter Types

In Sentaurus Topography, the parameters can be one of three types:

- Logical
- Numeric
- Character

The syntax for specifying the value of a parameter depends on its type.

Logical

A logical parameter has a value of `true` or `false`. The value is `true` if the parameter name appears by itself. The value is `false` if the parameter name is preceded by an exclamation mark (!).

Numeric

A numeric parameter is assigned a numeric value by following the parameter name with an equal sign (=) and the numeric value. Blanks on either side of the equal sign are ignored.

Character

A character parameter assumes the character value it is assigned by following the parameter name with an equal sign (=) and the character value. Blanks on either side of the equal sign are ignored. The character value is specified with any valid character expression.

NOTE The length of a character value must not exceed 80 characters.

Format of Command Descriptions

The remainder of this chapter describes the input commands that Sentaurus Topography recognizes. The description of each command consists of a formatted list of valid parameter combinations, followed by a list of parameter descriptions. The parameter list indicates the parameter type and identifies optional parameters.

Each item in the list of parameter descriptions gives the full name of the parameter, its type, and a description of its function, its default value, its unit and, if applicable, its valid range. The parameter type is specified as one of the following:

- Logical – logical parameter
- Number – numeric parameter
- Character – character parameter

Syntax of Parameter Lists

The special characters used in the formatted parameter list that appear at the beginning of each command description are angle brackets < >, brackets [], vertical bar |, braces { }, and parentheses ().

A lowercase letter in angle brackets represents a value of a given type, such as:

- <n> – numeric value
- <c> – character value

For example, `param1=<n>` indicates that the `param1` parameter is assigned a numeric value.

Braces, parentheses, and brackets are used to define groups of parameters or groups of groups. For example:

```
{(param1 [param2 [param3]] param4) param5}
```

is a valid group, composed of the subgroups `(param1 [param2 [param3]] param4)` and `param5`. The first subgroup can be further subdivided into the subgroups `param1`, `[param2 [param3]]`, and `param4`.

Brackets enclose groups that are optional. For example:

```
stmt1 [param1] [param2 param3] [param4 [param5]]
```

indicates that, in the `stmt1` command, the parameter `param1` is optional. The group `[param2 param3]` is optional, but if `param2` is specified, `param3` must also be specified. The group `[param4 [param5]]` is optional, but `param5` can be specified only if `param4` is specified.

When one of a list of groups must be selected, the groups are enclosed in braces and separated by vertical bars. For example:

```
stmt2 {param1 | param2 | (param3 param4)}
```

indicates that the `stmt2` command requires that one of the three groups `param1`, `param2`, or `(param3 param4)` must be specified.

5: Input Commands

Command Summary

Parentheses enclose groups that are to be considered to be single items in higher level groupings. For example, in the above `stmt2` command, the group `(param3 param4)` is one of three choices and is enclosed in parentheses.

NOTE The special characters (`<`, `>`, `[`, `]`, `|`, `{`, `}`, and `(`, `)`) in the above examples serve to indicate parameter types, optional groups, alternate choices, and group hierarchy. They must not form part of the actual input to Sentaurus Topography.

Command Summary

The following commands specify the initialization step that Sentaurus Topography uses and the utilities to use the program efficiently:

<code>initialize</code>	Initializes the structure (see initialize on page 80).
<code>extract</code>	Extracts geometric properties from structures formed by topography evolution process steps (see extract on page 76).
<code>merge</code>	Merges neighboring regions of the same material type (see merge on page 100).
<code>save</code>	Saves the structure in a file (see save on page 103).
<code>set</code>	Sets the verbosity of information written to standard output and the log file (see set on page 104).
<code>stop</code>	Ends the execution of Sentaurus Topography (see stop on page 105).

The following commands specify the process steps (including plasma simulation) simulated by Sentaurus Topography:

<code>deposit</code>	Deposits a material layer on the structure (see deposit on page 63).
<code>etch</code>	Etches any number of material layers of the structure (see etch on page 68).
<code>litho</code>	Performs a lithography simulation and adds a resist region (see litho on page 83).
<code>plasma</code>	Simulates angular distribution of particles in plasma discharges (see plasma on page 101).

The following commands specify the machine and mask coefficients used in Sentaurus Topography:

<code>machdepo</code>	Defines deposition machines (see machdepo on page 84).
<code>machetch</code>	Defines etch machines (see machetch on page 91).
<code>machlitho</code>	Defines lithography machines (see machlitho on page 98).
<code>mask</code>	Defines masks (see mask on page 99).

The environment variable `SPTOPO_LIBRARY_PATH` defines the path to the directories in which Sentaurus Topography looks for the files `machdepo.lib`, `machetch.lib`, and `mask.lib` (see [Environment Variables on page 51](#)).

The abovementioned commands are described in alphabetic order in the following sections.

deposit

The `deposit` command is used to simulate the deposition of a specified material on the surface of the current structure or to deposit a layer of the specified material with a specific topographic shape. When using the `dtplot` parameter, a two-dimensional plot sequence is generated.

The three different deposition modes are:

- Planar deposition:

```
deposit material=<c> [diel=<n>] [name=<c>] [thickness=<n>] [volt=<n>]
[xloc=<n>]
```

- Coordinate deposition (using an external profile):

```
deposit file=<c> material=<c> [diel=<n>] [name=<c>] [volt=<n>]
```

- Machine deposition (using a specified machine):

```
deposit machname=<c> time=<n>
{(adaptive=<n> [cfl=<n>]) | cfl=<n> | [dtmax=<n>]}
[dtplot=<n>] [dx=<n>] [dy=<n>] [finalx=<n> finaly=<n>] [fs]
[minvoidratio=<n>] [name=<n>] [nband=<n>] [nonconvex] [secondorder]
```

5: Input Commands

deposit

Table 1 Parameters of deposit command

Parameter	Type	Description	Default [range]	Unit
adaptive	number	Activates adaptive time-stepping. The specified value is the target value for the maximum relative local discretization error for time integration.	none	none
cfl	number	Time-step size as a fraction of the maximum time step according to the CFL criterion.	0.5 [0.1, 1]	none
diel	number	Relative dielectric constant of the deposited insulator region.	1	none
dtmax	number	Maximum time step for the level set algorithm.	none	minute
dtplot	number	Time interval used for writing intermediate structures to a TDR file.	none	minute
dx	number	Discretization size in the horizontal direction.	0.1	micrometer
dy	number	Discretization size in the vertical direction.	0.1	micrometer
file	character	The name of the file that contains the coordinates used to define a boundary for a new material to be deposited on the structure.	none	none
finalx	number	Specifies the x-coordinate of the final point.	none	micrometer
finaly	number	Specifies the y-coordinate of the final point.	none	micrometer
fs	logical	Specifies that the fast sweeping method is used for reinitialization of the narrow band.	true	none
machname	character	The name of the machine used for the deposition process. This needs to be given by the user in the machdepo command.	none	none
material	character	The name of the material to be deposited.	none	none
minvoidratio	number	Specifies the minimum void area ratio.	1 [0.0001, 10000]	none
name	character	Specifies the name of the deposited region.	region_n	none
nband	number	The width of the band around the exposed surface within which the simulation is performed to update the surface position, measured in the number of discretization steps.	12	none
nonconvex	logical	Specifies that a nonconvex integration scheme is used.	false (except for HDP model)	none

Table 1 Parameters of deposit command

Parameter	Type	Description	Default [range]	Unit
secondorder	logical	Indicates that a second-order space convex scheme is used.	false	none
thickness	number	The minimum thickness of a deposited planarization layer.	0	micrometer
time	number	The total time for the deposition step being simulated.	none	minute
volt	number	Potential of the deposited conductor or semiconductor region.	0	volt
xloc	number	Position at which the thickness of a deposited planarized layer is defined.	0	micrometer

Command Use

The `deposit` command is used to deposit a specified material on top of an existing simulation structure. The material deposited can be any one of the materials defined in the standard file `datexcodes.txt`. If the material you wish to deposit is not defined in the standard `datexcodes.txt`, you can create a local version of this file and define your material in this file.

NOTE If a specified region name is not unique, it is made unique by appending `_<n>` to it. If no region name is specified, then the default value `region_<n>` is used. In either case, `<n>` is an integer that makes the name unique.

NOTE For planar and coordinate deposition modes only, the parameters `diel` and `volt` can be used to specify the relative dielectric constant and the potential for an insulator and a conductor or semiconductor regions, respectively, for export to an RC2 file.

Planar Deposition

```
deposit material=<c> [diel=<n>] [name=<c>] [thickness=<n>] [volt=<n>]
[xloc=<n>]
```

If neither `file` nor `machname` is specified, the deposition is for a planarized layer of the specified material, and the thickness is applied to the top of the highest y-coordinate in the structure. The region name can be specified by the parameter name.

5: Input Commands

deposit

The `xloc` parameter overrides the default behavior described above, and the thickness of the layer is applied to the specific location along the x-axis defined by this parameter.

Coordinate Deposition (Using an External Profile)

```
deposit file=<c> material<=c> [diel=<n>] [name=<c>] [volt=<n>]
```

When the `file` parameter is specified, a coordinate deposition is performed. This allows an arbitrarily shaped profile to be input from a text file to deposit the specified material. This allows you to:

- Construct an arbitrary structure.
- Input a structure that is obtained from a SEM micrograph.
- Input a structure from another simulator.

The format is assumed to be a standard text file containing two columns:

- The first column contains the x-coordinate value.
- The second column contains the y-coordinate value.

The specified surface passes from left to right on the structure, so that the deposited material is below the profile defined by each segment of the coordinate array.

The first coordinate value must start exactly at the left boundary and the last node must be exactly at the right boundary. Segments of the specified surface that lie below the surface of the current structure are clipped. The profile must not be self-intersecting or self-touching.

NOTE The planar and coordinate deposition modes described above are for the sole purpose of creating the initial structures for input to the machine-based topography simulation in Sentaurus Topography. Their use is limited and they must not be considered as the main modes of deposition.

Machine Deposition (Using a Specified Machine)

```
deposit machname=<c> time=<n>  
  {(adaptive=<n> [cfl=<n>]) | cfl=<n> | [dtmax=<n>]} [dtplot=<n>  
  [dx=<n>] [dy=<n>] [finalx=<n>] [finaly=<n>] [fs] [minvoidratio=<n>]  
  [name=<n>] [nband=<n>] [nonconvex] [secondorder]
```

When the `machname` parameter is specified with the name of a valid deposition machine (which must be predefined by the `machdepo` command), any one of the different types of deposition as described under the `machdepo` command (see [machdepo on page 84](#)) can be simulated.

[Chapter 8 on page 143](#) presents various examples of machine deposition simulations in more detail.

Sentaurus Topography uses the level set algorithm to move the surfaces for the machine deposition mode. The time and space discretization is controlled by Sentaurus Topography with three parameters used by the `deposit` command.

To control the spatial discretization along the x-direction, the parameter `dx` is used and, correspondingly, the parameter `dy` is used for the y-direction. There are three different methods for the time discretization as described below. For all three methods, the time-step size is limited for stability by the Courant–Friedrichs–Levy (CFL) condition [1]. Additional details about the level set method can be found in the literature [2][3][4][5][6][7][8].

By default, a constant time step is used, for which the value can be set using the parameter `dtmax`. Alternatively, a variable time step according to the CFL criterion can be used by setting the parameter `cfl`. The third method performs adaptive time-stepping based on the estimated maximum relative local discretization error. It is activated when the parameter `adaptive` is specified. The size of the time steps is chosen in such a way that the estimated value of the maximum relative local discretization error is less than the specified value. The specified value must be positive and should be in the range from 0.01 to 0.1.

Small voids can be artifacts of the level set method and can cause problems during mesh generation. The parameter `minvoidratio` can be used to prevent the creation of small voids. Voids for which the area is smaller than `minvoidratio*dx*dy` are ignored.

During machine deposition, Sentaurus Topography can create boundary files (in TDR format) at time intervals specified by the `dtplot` parameter. See [Boundary Output Files: <basename>.tdr on page 50](#) for details. In the structures created with the `dtplot` parameter, the voids are filled with gas regions, and a gas region is added at the top of the structure.

The plot time step is computed to be as close as possible to a level-set time step. Level-set time-stepping is not affected by the plot step. For values of `dtplot` that are not multiples of the time step used for time integration, the plots are created at the closest time step for time integration.

When `infolevel` is set to a value greater than or equal to two, the time at which a plot file is created is written to the standard output and the log file. The target value for plotting is output in parentheses.

NOTE To obtain plots at specific times, you specify a constant time step using the parameter `dtmax` such that `dtplot` is a multiple of `dtmax`. The value used for `dtmax` must be smaller than the value required by the CFL criterion.

Time-stepping can be stopped when the surface reaches or crosses a specified final point. The final point is specified with the parameters `finalx` and `finaly`. For deposition, the final point

5: Input Commands

etch

must lie above the initial surface and between the leftmost vertex and rightmost vertex of the initial structure.

By default, the fast sweeping method [9] is used to calculate the signed distance when reinitializing the narrow band. The parameter `fs` can be used to switch to the old and less efficient method for calculating the signed distance.

etch

The `etch` command is used to simulate the etching of the current structure, to etch the existing structure to a specified shape, or to remove the exposed regions of a specified material. When using the `dtplot` parameter, the `etch` command generates a two-dimensional plot sequence.

The material etched can be any one of the materials defined in the standard file `datexcodes.txt`. If the material you want to etch is not defined in the standard `datexcodes.txt`, you can create a local version of this file and define your material in this file.

The different etching modes are:

- Geometric etch a structure (remove all exposed layers):

```
etch
```

- Geometric etch a structure by depth:

```
etch depth=<n> [mask=<c> [xshift=<n>]]
```

- Geometric etch a material:

```
etch material=<c> [complete] [depth=<n>] [mask=<c> [xshift=<n>]]
```

- Coordinate etch a structure (using an external profile):

```
etch file=<c>
```

- Machine etch (using a specified machine):

```
etch machname=<c> time=<n>  
{(adaptive=<n> [cfl=<n>]) | cfl=<n> | [dtmax=<n>]}  
[dtplot=<n>] [dx=<n>] [dy=<n>] [finalx=<n> finaly=<n>]  
[fs] [nband=<n>] [nonconvex] [secondorder]
```

- Machine etch using automatic grid refinement:

```
etch machname=<c> time=<n>
  {(maxdiff=<n> [meandiff=<n>] [meansqdiff=<n>]) |
   (meandiff=<n> [maxdiff=<n>] [meansqdiff=<n>]) |
   (meansqdiff=<n> [maxdiff=<n>] [meandiff=<n>])}
  {(adaptive=<n> [cfl=<n>]) | cfl=<n> | [dtmax=<n>]} [dtplot=<n>] [dx=<n>]
  [maxreflevel=<n>] [nband=<n>] [nonconvex] [refinefactor=<n>]
  [refineplot] [testfraction=<n>]
```

Table 2 Parameters of etch command

Parameter	Type	Description	Default [range]	Unit
adaptive	number	Activates adaptive time-stepping. The specified value is the target value for the maximum relative local discretization error for time integration.	none	none
cfl	number	Time-step size as a fraction of the maximum time step according to the CFL criterion.	0.5 [0.1, 1]	none
complete	logical	Specifies that an etched layer is to be removed completely.	false	none
depth	number	The etching depth defined as the distance from the highest y-coordinate of the structure.	none	micrometer
dtmax	number	Maximum time step for the level set algorithm.	none	minute
dtplot	number	Time interval used for writing intermediate structures to a TDR file.	none	minute
dx	number	Discretization size in the horizontal direction.	0.1	micrometer
dy	number	Discretization size in the vertical direction.	0.1	micrometer
file	character	The identifier of the file containing data describing the etch profile. All regions of the structure existing above this profile are removed.	none	none
finalx	number	Specifies the x-coordinate of the final point.	none	micrometer
finaly	number	Specifies the y-coordinate of the final point.	none	micrometer
fs	logical	Specifies that the fast sweeping method is used for reinitialization of the narrow band.	true	none
machname	character	The name of the etch machine or process to be used. This must be predefined in the machetch command.	none	none
mask	character	Specifies the name of the mask to be used.	none	none

5: Input Commands

etch

Table 2 Parameters of etch command

Parameter	Type	Description	Default [range]	Unit
material	character	Specifies the name of the material to be etched.	none	none
maxdiff	number	The threshold for the maximum difference between the surfaces of two refinement levels.	none	micrometer
maxreflevel	number	The maximum number of refinement levels.	16 positive	none
meandiff	number	The threshold for the mean absolute difference between the surfaces of two refinement levels.	none	micrometer
meansqdiff	number	The threshold for the mean square difference between the surfaces of two refinement levels.	none	micrometer
nband	number	Width of the band around the exposed surface within which the simulation is performed to update the surface position, measured in the number of discretization steps.	12	none
nonconvex	logical	Specifies that a nonconvex integration scheme is used.	false	none
refinefactor	number	The factor by which dx is decreased.	0.61803]0.0, 1.0[none
refineplot	logical	Specifies that a TDR file is created for each refinement level.	false	none
secondorder	logical	Indicates that a second-order space convex scheme is used.	false	none
testfraction	number	Specifies the fraction of the process time after which the surfaces of two refinement levels are compared.	1.0]0.0, 1.0]	none
time	number	Total time for the etch step being simulated.	none	minute
xshift	number	Specifies the misalignment for the specified mask layer in the x-direction.	0	micrometer

Command Use

The `etch` command is used to simulate a specified etch machine or process on the current structure, to remove material within a specified etch profile, or to remove a layer entirely. The material to be etched must be any material defined in the standard file `datexcodes.txt`. If the material you want to etch is not in the file `datexcodes.txt`, you can create a local version of this file and define your material in this file.

Geometric Etch a Structure (Remove All Exposed Layers)

```
etch
```

When no parameters are specified, the `etch` command *completely* removes all the material layers that are exposed to the gas except the substrate.

Geometric Etch a Structure by Depth

```
etch depth=<n> [mask=<c> [xshift=<n>]]
```

When the `depth` parameter is specified and the `material` parameter is not specified, the `etch` command completely removes all the exposed material layers except the substrate (which can be etched until a minimum thickness of 0.1 μm is reached) by the specified `depth` defined as the distance from the highest y-coordinate of the structure.

In addition, if the mask information is also specified by `mask`, all the exposed layers of the given structure are etched by the specified `depth` using the specified mask.

Geometric Etch a Material

```
etch material=<c> [complete] [depth=<n>] [mask=<c> [xshift=<n>]]
```

In this mode, the `etch` command etches the exposed layers of the specified material vertically. A layer is considered to be exposed if it is visible from above.

In addition, if the mask information is also specified, all the exposed layers of the specified material are etched vertically using this specified mask.

If the specified material is partially covered by other materials, then only the part of the specified material exposed to the gas is etched vertically until the next underlying material layer which is then exposed. If this newly exposed layer is of the same material as the specified material, the vertical etching will continue until it reaches a layer of different material underneath.

5: Input Commands

etch

NOTE If the specified material is a substrate, the etching is performed until a minimum thickness (0.1 μm) of the substrate is reached to ensure that the substrate is not completely removed or etched through.

In addition, if the `depth` parameter is also specified, the surface of the exposed layers of the specified material will be etched vertically by the amount `depth` (defined as the distance from the highest y-coordinate of the structure). In addition to `depth`, if the mask information is also specified, all the exposed layers of the specified material are etched vertically using this specified mask by the amount `depth`.

If the specified material is partially covered by other materials, only the part of the specified material layers exposed to the gas is etched vertically by the `depth`.

If the `complete` parameter is specified, then all the exposed layers of the specified material are removed completely.

NOTE At any stage of the simulation, any material layers that become separated (or floating) from the underlying substrate structure are removed.

NOTE The geometric etch mode with the parameter `complete` is sometimes used to remove simultaneously several materials that are in contact with the gas. Often, this does not give the expected results because of a misunderstanding of how the geometric etch mode works.

The geometric etch mode *only* modifies layers that are visible from above. Without the parameter `complete`, only the parts that are visible from above are removed. With the parameter `complete`, a layer that is at least partially visible from above is removed completely. In addition, any layer that would be floating after this removal is also removed. However, a layer that is in contact with the gas, but is not visible from above, is *not* modified.

For the geometric etch mode with the parameter `complete`, three different configurations must be distinguished as shown in [Figure 14 on page 73](#). When the command `etch material=Oxide complete` is used for this structure, the left stack of oxide and nitride is removed because the oxide is visible from above and the nitride layer would be floating. The middle stack is not modified because the oxide is not visible from above. The right stack may or may not be removed. The result depends on the exact coordinates of the boundary. If at least one point of the oxide is visible from above, even by a very small amount, the situation is the same as for the left stack. Otherwise, it is treated in the same way as the middle stack.

It can be difficult to determine whether a layer is visible from above. Especially when a structure similar to [Figure 14](#) is created by a machine-based etching step, it is difficult to predict whether the oxide layer is visible from above.

A small change in the etching parameters or the use of a different version of the simulator may give slightly different results.

Therefore, it is advisable to first remove the upper layer and then the lower layer with two separate `etch` commands:

```
etch material=Nitride complete
etch material=Oxide complete
```




Figure 14 Oxide visible from above (*left*), not visible from above (*middle*), and possibly visible from above (*right*)

Coordinate Etch a Structure (Using an External Profile)

```
etch file=<c>
```

The `file` parameter enables you to input an arbitrary etch profile from a text file to construct a structure of your choice. All parts of the current structure that are above the specified profile are removed.

The file format is assumed to be a standard text file containing two columns:

- The first column is the *x*-coordinate value.
- The second column is the *y*-coordinate value.

The specified profile must cover the entire structure from left to right with the start and end coordinates of the profile corresponding exactly with the leftmost and rightmost coordinate values in the structure, respectively. The specified profile must not be self-intersecting or self-touching.

5: Input Commands

etch

NOTE The geometric and coordinate etching modes described above are for the sole purpose of creating the initial structures for input to the machine-based topography simulation or for the removal of resist, and other cleanup steps on the final structures after the machine etching. Their use is limited and they must not be considered as the main modes of etching.

Machine Etch (Using a Specified Machine)

```
etch machname=<c> time=<n> {(adaptive=<n> [cfl=<n>]) | cfl=<n> | [dtmax=<n>]}
    [dtplot=<n>] [dx=<n>] [dy=<n>] [finalx=<n> finaly=<n>] [fs] [nband=<n>]
    [nonconvex] [secondorder]
```

When the `machname` parameter is specified with the name of a valid etch machine (which must be predefined by the `machetch` command), the coefficients associated with that machine are used, and the etch simulation proceeds. See the `machetch` command for a description of the etch machine coefficients (see [machetch on page 91](#)).

[Chapter 9 on page 161](#) presents various examples of machine etch simulations in more detail.

As with the deposition using the machine mode, Sentaurus Topography uses the level set algorithm to move the surfaces for the machine etch mode. The time and space discretization is controlled by Sentaurus Topography with three parameters used by the `etch` command.

To control the spatial discretization along the x-direction, the parameter `dx` is used and, correspondingly, the parameter `dy` is used for the y-direction. There are three different methods for the time discretization as described below. For all three methods, the time-step size is limited for stability by the CFL condition [1]. Additional details about the level set method can be found in the literature [2][3][4][5][6][7][8].

By default, a constant time step is used, for which the value can be set using the parameter `dtmax`. Alternatively, a variable time step according to the CFL criterion can be used by setting the parameter `cfl`. The third method performs adaptive time-stepping based on the estimated maximum relative local discretization error. It is activated when the parameter `adaptive` is specified. The size of the time steps is chosen in such a way that the estimated value of the maximum relative local discretization error is less than the specified value. The specified value must be positive and should be in the range from 0.01 to 0.1.

During machine etching, Sentaurus Topography can create boundary files (in TDR format) at time intervals specified by the `dtplot` parameter. In the structures created with the `dtplot` parameter, the voids are filled with gas regions, and a gas region is added at the top of the structure.

The plot time step is computed to be as close as possible to a level-set time step. Level-set time-stepping is not affected by the plot step. For values of `dtplot` that are not multiples of the time step used for time integration, the plots are created at the closest time step for time integration.

When `infolevel` is set to a value greater than or equal to two, the time at which a plot file is created is written to the standard output and the log file. The target value for plotting is output in parentheses.

NOTE To obtain plots at specific times, you specify a constant time step using the parameter `dtmax` such that `dtplot` is a multiple of `dtmax`. The value used for `dtmax` must be smaller than the value required by the CFL criterion.

Time-stepping can be stopped before the specified simulation time is reached when the surface reaches or crosses a specified final point. The final point is specified with the parameters `finalx` and `finaly`. For etching, the final point must lie inside the initial structure.

In addition, time-stepping is stopped before the specified simulation time is reached when the etching rate is zero. When the parameter `rateonsurface` of an etching model is set to `true`, time-stepping is stopped when the etching rate is zero for all surface vertices. When `rateonsurface` is set to `false`, time-stepping is stopped when the etching rate for all grid points in the narrow band is zero.

By default, the fast sweeping method [9] is used to calculate the signed distance when reinitializing the narrow band. The parameter `fs` can be used to switch to the old and less efficient method for calculating the signed distance.

NOTE The use of the nonconvex scheme for models other than HDP deposition has not been tested. However, due to the similarity of the equations describing the `hdpetch` and `ionmill` etching models, it may be necessary to use the nonconvex integration scheme for these models to achieve good numeric results.

Machine Etch Using Automatic Grid Refinement

```
etch machname=<c> time=<n>
  {(maxdiff=<n> [meandiff=<n>] [meansqdiff=<n>]) |
   (meandiff=<n> [maxdiff=<n>] [meansqdiff=<n>]) |
   (meansqdiff=<n> [maxdiff=<n>] [meandiff=<n>])}
  {adaptive=<n> [cfl=<n>]) | cfl=<n> | [dtmax=<n>]} [dtplot=<n>] [dx=<n>]
  [maxreflevel=<n>] [nband=<n>] [nonconvex] [refinefactor=<n>] [refineplot]
  [testfraction=<n>]
```

The automatic grid refinement starts with the specified value or the default value of `dx` and performs a level-set simulation. Then, `dx` is reduced by `refinefactor`, and the level-set

5: Input Commands

extract

simulation is repeated and the surfaces are compared. If the difference is smaller than at least one of the specified thresholds (`maxdiff`, `meandiff`, or `meansqdiff`), the refinement is stopped. Otherwise, `dx` is reduced by `refinefactor` and the refinement continues. If the maximum refinement level `maxreflevel` is reached and the difference between the surfaces of the last two refinement levels is too big, the refinement is stopped unsuccessfully.

If the parameter `timefraction` is specified, the level-set simulations run only for `timefraction` x `time` before the surfaces are compared. If the refinement is successful, the level-set simulation is run for the full time with the final value of `dx`.

NOTE The discretization size for the x- and y-direction is specified with the parameter `dx`. The parameter `dy` has no effect.

extract

The `extract` command is used to find certain geometric properties at specified locations on a structure formed by a series of topography evolution process steps. Targets are `thickness`, `slope`, `maxslope`, `minslope`, and `surface`.

The material name of the target layer and the coordinates of a point inside this layer must be specified to identify the layer from which the target will be extracted. `Extract` returns the target value and coordinates of the points:

```
extract material=<c> xlayer=<n> ylayer=<n> [file=<c>] [maxslope] [minslope]
  [[slope] [thickness] {[xcut=<n>] | ycut=<n>}]

extract surface [file=<c>]
```

Table 3 Parameters of `extract` command

Parameter	Type	Description	Default	Unit
<code>file</code>	character	Base name of the command file to which the specified locations and the extracted target values at these locations are saved. Unless a new file name is specified, the output of the subsequent <code>extract</code> commands will be appended to this file.	Base name of command file	none
<code>material</code>	character	Material of the layer on which <code>extract</code> is to be performed.	none	none
<code>maxslope</code>	logical	Activates extraction of the maximum slope of the upper surface of a layer.	false	none
<code>minslope</code>	logical	Activates extraction of the minimum slope of the upper surface of a layer.	false	none

Table 3 Parameters of extract command

Parameter	Type	Description	Default	Unit
slope	logical	Activates extraction of the slope of the upper surface of a layer at a specific location (defined by either <code>xcut</code> or <code>ycut</code>).	false	none
surface	logical	Extracts the coordinates of the vertices of the exposed surface.	false	none
thickness	logical	Activates extraction of the thickness of a layer at a specific location (defined by either <code>xcut</code> or <code>ycut</code>).	false	none
xcut	number	The x-coordinate value of the location at which the thickness or slope is to be calculated.	xlayer	micrometer
xlayer	number	The x-coordinate of a point inside the material layer of which the thickness or slope is desired.	0	micrometer
ycut	number	The y-coordinate value of the location at which the thickness or slope is to be calculated.	none	micrometer
ylayer	number	The y-coordinate of a point inside the material layer of which the thickness or slope is desired.	0	micrometer

Command Use

The `extract` command is used to find the profile slope and layer thickness values at a specific location, or to find the minimum or maximum values of the slope of the upper surface of a layer. The `extract` command can be used to extract the coordinates of the vertices of the exposed surface. The extracted information can be used to analyze simulation results.

The `extract` command can be placed in the input file anywhere except before `initialize` and can be used repeatedly for extracting different target values.

The target is specified using any of the following logical parameters: `slope`, `thickness`, `minslope`, and `maxslope`. One or more logical parameters can be specified for a single `extract` command or they can be specified in separate commands.

The `extract` command needs the exact coordinates of points on the surface curve to perform calculations for slope or thickness. However, these coordinates are not easily specified. The `material` parameter is required to help identify the correct layer where the slope or thickness

5: Input Commands

extract

is extracted. Since different layers can contain the same material, the location (x_{layer} , y_{layer}) uniquely identifies the layer.

A cutline must be provided to help to determine the location of the target. This is necessary to perform extraction on the complex geometric structures that are formed due to the number of topography evolution steps.

x_{cut} (or y_{cut}) is used to define the cutline to extract slope and thickness. The thickness is measured from the coordinate where the line x_{cut} (or y_{cut}) intersects the boundary of the specified layer. The slope of a surface is measured counterclockwise from the positive x-direction. An example is shown in [Figure 15](#).




Figure 15 Example showing extraction of thickness and slope using x_{cut}

To extract the y-thickness and slope at an intermediate point of the shown structure, use the command:

```
extract material=Nitride file=myfile xlayer=1.25 ylayer=1.2 thickness slope  
+ maxslope minslope
```

The generated output (in the `myfile.ext` file) is:

```
max slope = 1.22144 between (1.58973, 1.80147) and (1.55, 1.80147)  
min slope = -1.22144 between (1.45, 1.85) and (1.41027, 1.85)  
slope at x = 1.25 um  
y = 1.98477 um -0.585317  
y-thickness at x = 1.25 um  
y = 1 um dy = 0.984769 um
```

The first two lines in the output give the maximum and minimum slopes of the upper surface of the layer and the range of the points on the surface between which it was found. Next, the extracted slope at the specified location (given by x_{cut} , which in this example takes the default

value) is written along with the y-coordinate at the upper surface of the specified layer. Finally, the y-thickness at the specified location (also given by `xcut`) is written along with the y-coordinate (the base of the layer) from which it was computed.

Depending on the shape of the layer and the target location, there may be multiple values for both the slope and the extracted thickness as shown in the following example.

To extract the x-thickness and slope at an intermediate location of the surface of [Figure 15 on page 78](#), use the command:

```
# Extract the x-thickness and slope at intermediate point of the
# structure (ycut=2.0)
extract material=Nitride xlayer=1.5 ylayer=1.2 thickness slope maxslope
+ minslope ycut=2.0
```

The generated output (in the `myfile.ext` file) is:

```
max slope = 1.22144 between (1.58973, 1.80147) and (1.55, 1.80147)
min slope = -1.22144 between (1.45, 1.85) and (1.41027, 1.85)
slope at y = 2 um
x = 1.77602 um 0.548108
x = 1.77602 um 0.585317
x = 1.22398 um -0.585317
x = 1.22398 um -0.548108
x-thickness at y = 2 um
x = 0 um dx = 1.22398 um
x = 1.77602 um dx = 1.22398 um
```

As in the last example, the first two lines in the output give the maximum and minimum slopes of the upper surface of the layer and the range of the points on the surface between which it was found.

The specified value of `ycut` cuts the upper surface of the specified layer at two points. Since each of these points is a vertex on the curve, at each vertex, there are two values of the slope (the left and the right). This results in a total of four values of the extracted slope, which are written along with the x-coordinate of the specified layer.

There are two extracted values for the x-thickness at the specified location (given by `ycut=2.0`) as measured from the x-coordinates where the `ycut` intersects the two vertical sides of the structure (`x=0` and `x=3.0`).

NOTE Use a visualization tool to determine the location of `xcut` or `ycut`.

`surface` is used to extract the coordinates of the vertices of the exposed surface. The resulting file can be used for coordinate etching or deposition.

5: Input Commands

initialize

initialize

The `initialize` command defines the initial structure for a Sentaurus Topography simulation. There are two different modes:

- Initialization with an external structure:

```
initialize file=<c> [reflect=<c> [cylindrical]] [(tdr [invert])] | sat]
```

- Initialization with a new structure:

```
initialize [diel=<n>] [height=<n>] [material=<c>] [name=<c>]  
[reflect=<c> [cylindrical]] [volt=<n>] [width=<n>]
```

Table 4 Parameters of initialize command

Parameter	Type	Description	Default	Unit
cylindrical	logical	Indicates that the cylindrical symmetry model is used for flux integration.	false	none
diel	number	Relative dielectric constant of the initialized insulator region.	1	none
file	character	Base name of the file containing information about the initial structure.	none	none
height	number	Specifies the thickness of the substrate.	1.0	micrometer
invert	logical	Specifies that the initial structure information in the TDR format is in a coordinate system that is inverted with respect to the internal coordinate system of Sentaurus Topography.	true	none
material	character	Specifies the substrate material when a new structure is defined. This layer is the material on which the rest of the structure is built.	Silicon	none
name	character	Specifies the name of the substrate region when a new structure is defined.	substrate	none
reflect	character	Reflection mode for calculation of visibility angles, reemission flux, and redeposition flux.	off	none
sat	logical	Specifies that the file containing the initial structure information is in SAT format.	false	none
tdr	logical	Specifies that the file containing the initial structure information is in TDR format.	true	none
volt	number	Potential of the initialized conductor or semiconductor region.	0	volt
width	number	Specifies the width of the substrate.	5.0	micrometer

Command Use

The `initialize` command enables you to set up the initial structure in a simulation.

NOTE It must be used before any command that requires a structure (`deposit`, `etch`, `extract`, `litho`, `merge`, and `save`).

Initializing With an External Structure

```
initialize file=<c> [reflect=<c> [cylindrical]] [(tdr [invert])| sat]
```

Sentaurus Topography can read the boundary information of a previously generated structure in TDR or SAT formats. Such boundary files can be generated by Sentaurus Process or Sentaurus Structure Editor. The base name is specified by the `file` parameter; the extension is added automatically.

When a structure is read from a TDR or an SAT file, all gas regions are removed automatically. As described in the `set` command (see [set on page 104](#)), by default, gas regions are created when saving TDR or SAT files. However, it is not guaranteed that the names of the newly created gas regions for the voids are the same as in the loaded file.

Defining a New Structure

```
initialize [diel=<n>] [height=<n>] [material=<c>] [name=<c>]  
[reflect=<c> [cylindrical]] [volt=<n>] [width=<n>]
```

If no structure file is defined, an initial rectangular structure is created.

The parameter `material` in this command can be any one of the materials defined in the standard file `datexcodes.txt`. If the material you want to use in this command is not in the standard file `datexcodes.txt`, you can create a local version of this file and define your material in this file.

The parameters `diel` and `volt` can be used to specify the relative dielectric constant and the potential for an insulator and a conductor or semiconductor regions, respectively, for export to an RC2 file.

Simulating Half of a Symmetric Structure

The parameter `reflect` can be used to specify the left and right boundary conditions for flux integration. Using a boundary condition for which the surface is reflected allows the efficient simulation of symmetric structures. The reflection mode is valid for the whole simulation, but it is not stored in TDR files.

5: Input Commands

initialize

For the calculation of the visibility angles, the reemission flux, and the redeposition flux, the surface at the left and right boundaries is assumed to be either flat or reflected. Possible values for `reflect` are:

Value	Left Boundary	Right Boundary
both	Reflected	Reflected
left	Reflected	Flat
off	Flat	Flat
right	Flat	Reflected

Figure 16 shows examples of the extended surface, which is used for flux integration for the values `off` and `left`.




Figure 16 (Left) Extension of the surface used for flux integration for `reflect=off` and (right) extension of the surface used for flux integration for `reflect=left`

NOTE Setting the parameter `reflect` to a value other than `off` causes different results only for etching and deposition models for which a flux integration is performed.

NOTE In this version, the reemission flux is not taken into account properly.

NOTE In this version, the `chem` model for etching and deposition can be used only with `reflect` set to `off`.

Simulating Half of a Cylindrically Symmetric Structure

The parameter `cylindrical` can be used to specify that cylindrical symmetry is used for integration of the direct flux.

In addition to setting `cylindrical` to `true`, you must set the `reflect` parameter to either `left` or `right`.

NOTE The restrictions mentioned for the `reflect` parameter are also valid for the `cylindrical` parameter (see [Simulating Half of a Symmetric Structure on page 81](#)).

NOTE This feature has not been fully tested.

litho

The `litho` command is used to perform a lithography simulation and to add a resist region:

```
litho inputfile=<c> [cutline=<c>] [machname=<c>] [mask=<c>] [material=<c>]
      [options=<c>] [outputfile=<c>]
```

Table 5 Parameters of litho command

Parameter	Type	Description	Default	Unit
cutline	character	Cutline used by Sentaurus Lithography when creating a TDR file for the simulation results.	none	none
inputfile	character	Name of input SLO file.	none	none
machname	character	Name of the lithography machine to be used. This must be predefined with a <code>machlitho</code> command.	none	none
mask	character	Specifies the name of the mask to be used.	none	none
material	character	Name of the material of the created region.	Photoresist	none
options	character	Additional command-line options for Sentaurus Lithography.	none	none
outputfile	character	Name of output SLO file.	none	none

When Sentaurus Lithography creates a TDR file containing the simulation results, by default, it uses the first defined cutline. Usually, this cutline is named 'Cutline1.' The parameter `cutline` allows the specification of a different cutline.

When using the periodic pattern solver, the structure and the periodic mask must be aligned correctly. This can be achieved with the `Origin_X` and `Origin_Y` parameters of the `Periodic_Pattern` command in Sentaurus Lithography.

NOTE If `machname` is not specified, only the values specified in the SLO file are used for the lithography simulation.

NOTE If `mask` is not specified, the mask specified in the SLO file is used for the lithography simulation.

5: Input Commands

machdepo

NOTE If more than one command-line option is specified with the parameter options, they must be enclosed in double quotation marks.

machdepo

The `machdepo` command is used to define a new deposition machine. A deposition machine and its properties are used in a deposition simulation when the name of the machine is specified with the `machname` parameter in the `deposit` command:

isotropic:

```
machdepo [isotropic] material=<c> name=<c> rate=<n> [diel=<n>] [kcurv=<n>]
[volt=<n>]
```

chem:

```
machdepo chem name=<c> fluxinp=<c> material=<c> modeldir=<c>
[cutoffangle=<n>] [cutoffvalue=<n>] [diel=<n>] [ndphiion=<n>]
[ndthetaion=<n>] [ndthetaionrefl=<n>] [reflmodel=<c>] [rieniter=<n>]
[temperature=<n>] [tilt=<n>] [volt=<n>]
```

fullsog:

```
machdepo fullsog material=<c> name=<c> [diel=<n>] [georatio=<n>]
[initspin=<n>] [kcurv=<n>] [rate=<n>] [shrinkage=<n>] [sogreflow=<n>]
[sogxscale=<n>] [volt=<n>]
```

hdp:

```
machdepo hdp material=<c> name=<c> rate=<n> [anisotropy=<n>] [diel=<n>]
[[exponent=<n>] | plasmafile=<c>] [millrate=<n>] [redepratio=<n>]
[sc=<n>] [sputc1=<n>] [sputc2=<n>] [sputc4=<n>] [tilt=<n>] [volt=<n>]
```

hemispherical:

```
machdepo hemispherical material=<c> name=<c> rate=<n> [angle1=<n>]
[angle2=<n>] [anisotropy=<n>] [diel=<n>] [kcurv=<n>] [tilt=<n>]
[volt=<n>]
```

lpcvd:

```
machdepo lpcvd material=<c> name=<c> rate=<n> [diel=<n>] [sc=<n>]
[volt=<n>]
```

pecvd:

```
machdepo pecvd material=<c> name=<c> rate=<n> [anisotropy=<n>] [diel=<n>]
[[exponent=<n>] | plasmafile=<c>] [sc=<n>] [tilt=<n>] [volt=<n>]
```

pmi:

```
machdepo pmi material=<c> model=<c> name=<c> [character_param_x=<c>]
[logical_param_x] [numeric_param_x=<n>] [path=<c>] [tilt=<n>]
```

pvd:

```
machdepo pvd material=<c> name=<c> rate=<n> [diel=<n>]
[[exponent=<n>] | plasmafile=<c>] [tilt=<n>] [volt=<n>]
```

```

reflow:
  machdepo reflow material=<c> name=<c> rate=<n> [diel=<n>] [georatio=<n>]
    [kcurv=<n>] [volt=<n>]

sog:
  machdepo sog material=<c> name=<c> [diel=<n>] [initspin=<n>] [kcurv=<n>]
    [rate=<n>] [shrinkage=<n>] [sogxscale=<n>] [volt=<n>]

unidirectional:
  machdepo unidirectional material=<c> name=<c> rate=<n> [anisotropy=<n>]
    [diel=<n>] [kcurv=<n>] [tilt=<n>] [volt=<n>]

```

Table 6 Parameters of machdepo command

Parameter	Type	Description	Default [range]	Unit
angle1	number	The counterclockwise rotation from the positive direction of the x-axis specifying the minimum angle of the vapor stream for a hemispherical-type deposition machine.	0 [0, angle2]	degree
angle2	number	The counterclockwise rotation from the positive direction of the x-axis specifying the maximum angle of the vapor stream for a hemispherical-type deposition machine.	180 [angle1, 180]	degree
anisotropy	number	The degree of anisotropy of the deposition (the relationship between ion-induced deposition and thermal deposition). For deposition with no ion-induced component, <code>anisotropy=0</code> . For purely ion-induced deposition, <code>anisotropy=1</code> .	1 [0, 1]	none
character_param_[0-9]	character	User-defined parameter.	none	none
chem	logical	Indicates that the machine uses the chemical reaction model.	false	none
cutoffangle	number	Specifies maximum angle for ion flux integration.	20 [0,90]	degree
cutoffvalue	number	Specifies minimum flux value for ion flux integration.	1e-6]0,1[none
diel	number	Relative dielectric constant of the deposited insulator region.	1	none

5: Input Commands
machdepo

Table 6 Parameters of machdepo command

Parameter	Type	Description	Default [range]	Unit
exponent	number	The exponent used to characterize the ion-angular distribution as a function of $\cos^m \theta$. The specified value must be an integer.	1 [1, 5000]	none
fluxinp	character	Specifies name of file containing flux data.	none	none
fullsog	logical	Indicates that the machine is a full spin-on-glass machine. The simulation is a full emulation of curvature-dependent isotropic deposition, reflow, and shrinkage processes.	false	none
georatio	number	Indicates the effect of the surface geometric feature on the planarization speed of the reflow process. The higher this value is, the faster the planarization.	0.5 [0, 1]	none
hdp	logical	Indicates that the machine is used to simulate high-density plasma deposition systems.	false	none
hemispherical	logical	Indicates that the machine is a hemispherical-type deposition machine.	false	none
initspin	number	Specifies the thickness of the initial deposition (spin) in a spin-on-glass process before reflow and final shrinkage.	1 [0, 2]	micrometer
isotropic	logical	Indicates that the machine is an ideal isotropic-type deposition machine.	true	none
kcurv	number	Defines the degree of the dependency of the deposition rate on the curvature of the local surface. $k_{curv}=0$ indicates no dependency on the local curvature. The effect of the local curvature is to make the surface smoother as it evolves during a deposition process.	0 [0, 0.1]	none
logical_param_[0-9]	logical	User-defined parameter.	false	none

Table 6 Parameters of machdepo command

Parameter	Type	Description	Default [range]	Unit
lpcvd	logical	Specifies that the machine is simulated with a reemission model and is used to simulate low-pressure chemical vapor deposition problems.	false	none
material	character	Material name for which the properties are defined.	none	none
millrate	number	The total etch rate on a flat unshadowed surface for HDP deposition systems. Note that the net deposition rate is equal to $rate - millrate$.	0 [0, 2]	micrometer/ minute
model	character	Name of the library containing a PMI model.	none	none
modeldir	character	Specifies name of the directory that contains the chemical model files.	none	none
name	character	Name of the deposition machine. This name must be used for the subsequent <code>deposit</code> command for depositing a layer of the specified material.	none	none
ndphiion	number	Specifies number of integration intervals in the azimuth direction for ion flux integration.	20 [1,]	none
ndthetaion	number	Specifies number of integration intervals of the incident angle for ion flux integration.	20 [1,]	none
ndthetaionrefl	number	Specifies number of integration intervals of the reflection angle for ion flux integration.	20 [1,]	none
numeric_param_[0-9]	number	User-defined parameter.	none	none
path	character	Path to the library containing a PMI model.	". "	none
pecvd	logical	Indicates that the machine is used to simulate plasma-enhanced chemical vapor deposition systems.	false	none

5: Input Commands

machdepo

Table 6 Parameters of machdepo command

Parameter	Type	Description	Default [range]	Unit
plasmafile	character	Basename of the TDR file that contains the ion-angular distribution calculated with the command <code>plasma</code> that characterizes the plasma discharge.	none	none
pmi	logical	Indicates that the machine uses a PMI model.	false	none
pvd	logical	Indicates that the machine is a physical vapor deposition machine.	false	none
rate	number	Deposition rate on a flat unshadowed surface, associated with the specified machine or process.	none [0,]	micrometer/ minute
redepratio	number	Ratio of the amount of material redeposited to the amount of material sputtered from the surface.	0 [0, 1]	none
reflmodel	character	Specifies reflection model type. Three models are available: <ul style="list-style-type: none"> • <code>mirror</code>: Specular reflection. • <code>glossy</code>: Curvature-independent diffuse reflection. • <code>glossycurv</code>: Curvature-dependent diffuse reflection. 	mirror	none
reflow	logical	Indicates that the machine is a reflow machine.	false	none
rieniter	number	Specifies maximum number of iterations for the indirect flux calculation.	20 [1,]	none
sc	number	Specifies the sticking coefficients of the deposition precursor.	0 [0, 1]	none
shrinkage	number	Specifies the percentage of final shrinkage of the material deposited on a wafer by a spin-on-glass machine.	0.5 [0, 1]	none
sog	logical	Indicates that the machine is a simple spin-on-glass machine. The simulation is a simple combination of perfect planar deposition and shrinkage processes.	false	none

Table 6 Parameters of machdepo command

Parameter	Type	Description	Default [range]	Unit
sogreflow	number	Specifies the reflow rate of the reflow process in a spin-on-glass process.	1 [0, 1]	micrometer/ minute
sogxscale	number	Specifies the effective range of the shrinkage process for a spin-on-glass film. Film on a big trench (or cavity) tends to have higher shrinkage due to surface stress when this parameter exceeds the feature scale of the trench (or cavity).	0	micrometer
sputc1	number	Angle-dependent sputtering rate of first-order coefficient.	5.5 [5, 6]	none
sputc2	number	Angle-dependent sputtering rate of second-order coefficient.	-6 [-6.5, -5.5]	none
sputc4	number	Angle-dependent sputtering rate of fourth-order coefficient.	1.5 [0.5, 2.5]	none
temperature	number	Specifies surface temperature used for surface gas kinetics and surface reaction rates.	300]0,]	kelvin
tilt	number	Tilt angle of wafer. A positive value corresponds to a counterclockwise rotation of the wafer.	0]-90, 90[degree
unidirectional	logical	Indicates that the deposition is a combination of a pure isotropic (conformal) component and a unidirectional (beam) component. The ratio between the two components is defined by the <code>anisotropy</code> parameter.	false	none
volt	number	Potential of the deposited conductor or semiconductor region.	0	volt

NOTE The sum of `sputc1`, `sputc2`, and `sputc4` must be one.

Command Use

The `machdepo` command is used to define a new deposition machine. The characteristics of a deposition machine (that is, the type of deposition process performed) are described by one of several physical deposition models and the corresponding semiempirical parameters. The

5: Input Commands

machdepo

chosen model is used in a deposition simulation when the name of the deposition machine is specified with the `machname` parameter in the `deposit` command (see [deposit on page 63](#)).

The material deposited can be any one of the materials defined in the standard file `datexcodes.txt`. If the material you want to deposit is not defined in the standard `datexcodes.txt`, you can create a local version of this file and define your material in this file.

Only *one material* can be specified for a deposition machine.

A complete description of the available models, schematic representations of the corresponding machine types, and the relationship to the command parameters are in [Chapter 3 on page 13](#).

The parameters `diel` and `volt` can be used to specify the relative dielectric constant and the potential for an insulator and conductor or semiconductor regions, respectively, for export to a Raphael RC2 file.

NOTE Sentaurus Topography is case sensitive when specifying machine, mask, or material names.

When the `chem` model is used, the size of the time step is determined by the CFL criterion or by adaptive time-stepping. The parameter `cfl` of the `deposit` command is used to set the time-step size to a fraction of the maximum time step according to the CFL criterion. The parameter `adaptive` is used to activate adaptive time-stepping.

NOTE You cannot use a constant time-step size specified with the `dtmax` parameter.

The model directory specified with the `modeldir` parameter is searched for in the path defined by the environment variable `LSFLUX_LIBRARY_PATH`. If this environment variable does not exist, the model directory is expected to be located in the present directory. The environment variable `LSFLUX_LIBRARY_PATH` can be set using the `set` command (see [set on page 104](#)).

machetch

The `machetch` command is used to add a new etch machine or to add properties for a new material to an existing etch machine. An etch machine and its properties are used in an etch simulation when the name of the machine is specified with the parameter `machname` in the `etch` command.

A single etch machine is associated with one or more specified materials. The following list contains first, the material-independent form and second, the material-specific form of the `machetch` command for all machine types:

simple:

```
machetch simple name=<c> [rateonsurface [fmm]] [tilt=<n>]
machetch name=<c> material=<c> rate=<n> [anisotropy=<n>] [kcurv=<n>]
```

chem:

```
machetch chem name=<c> fluxinp=<c> modeldir=<c> [cutoffangle=<n>]
[cutoffvalue=<n>] [depomaterial=<c>] [fmm] [ndphiion=<n>]
[ndthetaion=<n>] [ndthetaionrefl=<n>] [reflmodel=<c>] [rieniter=<n>]
[temperature=<n>] [tilt=<n>]
```

cmp:

```
machetch cmp name=<c> [kcmp=<n>] [xscale=<n>]
machetch name=<c> material=<c> rate=<n>
```

dry:

```
machetch dry name=<c> depomaterial=<c> [rateonsurface] [reemrate=<n>]
[sc=<n>] [tilt=<n>]
machetch name=<c> material=<c> rate=<n> [sputc1=<n>] [sputc2=<n>]
[sputc4=<n>]
```

etchdepo:

```
machetch etchdepo name=<c> depomaterial=<c>
{exponent=<n> | (vertical [rotating])} [fmm] [reemrate=<n>] [sc=<n>]
[tilt=<n>]
machetch name=<c> material=<c> rate=<n> [sputc1=<n>] [sputc2=<n>]
```

hdpetch:

```
machetch hdp name=<c> [[exponent=<n>] | plasmafile=<c>]
[rateonsurface [fmm]] [tilt=<n>]
machetch name=<c> material=<c> rate=<n> [anisotropy=<n>] [sputc1=<n>]
[sputc2=<n>] [sputc4=<n>]
```

5: Input Commands

machetch

hemispherical:

```
machetch hemispherical name=<c> [angle1=<n>] [angle2=<n>]
[rateonsurface [fmm]] [tilt=<n>]
```

```
machetch name=<c> material=<c> rate=<n> [anisotropy=<n>]
```

ionmill:

```
machetch ionmill name=<c> [rateonsurface [fmm]] [rotating] [tilt=<n>]
```

```
machetch name=<c> material=<c> rate=<n> [anisotropy=<n>] [sputc1=<n>]
[sputc2=<n>] [sputc4=<n>]
```

pmi:

```
machetch pmi name=<c> model=<c> path=<c> [character_param_x=<c>]
[depomaterial=<c>] [fmm] [logical_param_x] [numeric_param_x=<n>]
[tilt=<n>]
```

```
machetch name=<c> material=<c> [character_param_x=<c>] [logical_param_x]
[numeric_param_x=<n>]
```

rie:

```
machetch rie name=<c> [[exponent=<n>] | plasmafile=<c>]
[rateonsurface [fmm]] [tilt=<n>]
```

```
machetch name=<c> material=<c> rate=<n> [anisotropy=<n>]
```

spetch:

```
machetch spetch name=<c> plasmafile=<c> [angle1=<n>] [angle2=<n>]
[rateonsurface [fmm]] [tilt=<n>]
```

```
machetch name=<c> material=<c> rate=<n> [anisotropy=<n>]
```

Table 7 Parameters of machetch command

Parameter	Type	Description	Default [range]	Unit
angle1	number	The counterclockwise rotation from the positive direction of the x-axis specifying the minimum angle of the vapor stream for a hemispherical-type etch machine.	0 [0, angle2]	degree
angle2	number	The counterclockwise rotation from the positive direction of the x-axis specifying the maximum angle of the vapor stream for a hemispherical-type etch machine.	180 [angle1, 180]	degree

Table 7 Parameters of machetch command

Parameter	Type	Description	Default [range]	Unit
anisotropy	number	Specifies the degree of anisotropy of the etch. For pure isotropic etch, <code>anisotropy=0</code> . For pure unidirectional (beam) etch, <code>anisotropy=1.0</code> .	1 [0, 1]	none
character_param_[0-9]	character	User-defined parameter.	none	none
chem	logical	Indicates that the machine uses the chemical reaction model.	false	none
cmp	logical	Indicates that the machine is a chemical-mechanical polishing etch machine.	false	none
cutoffangle	number	Specifies maximum angle for ion flux integration.	20 [0, 90]	degree
cutoffvalue	number	Specifies minimum flux value for ion flux integration.	1e-6]0,1[none
depomaterial	character	Specifies that the etchdepo mode is used and which material is deposited.	none	none
dry	logical	Indicates that the machine is a dry etch machine.	false	none
etchdepo	logical	Indicates that the machine is an improved dry etch machine.	false	none
exponent	number	The exponent used to characterize the ion-angular distribution as a function of $\cos^m \theta$. The specified value must be an integer.	1 [1, 5000]	none
fluxinp	character	Specifies name of file containing flux data.	none	none
fmm	logical	Activates the use of the fast marching method for the velocity extension instead of a search of the closest surface vertex.	true	none
hdpetch	logical	Indicates that the machine is a high-density plasma etch machine.	false	none
hemispherical	logical	Indicates that the machine is a combination of isotropic etch and hemispherical flux distribution for a second etch component.	false	none

5: Input Commands

machetch

Table 7 Parameters of machetch command

Parameter	Type	Description	Default [range]	Unit
ionmill	logical	Indicates that the named machine uses an ion-mill etch model.	false	none
kcmp	number	Indicates the planarization speed of a chemical-mechanical polishing process. The higher this value is, the faster the planarization.	0.5 [0, 5]	none
kcurv	number	Defines the degree of dependency of the etch rate on the curvature of the local surface. <code>kcurv=0</code> indicates no dependency on the local curvature. The effect of local curvature is to make the surface smoother as it evolves during an etch process.	0 [0, 0.1]	none
logical_param_[0-9]	logical	User-defined parameter.	false	none
material	character	Name of the material for which any specified etch rate coefficients apply.	none	none
model	character	Name of the library containing a PMI model.	none	none
modeldir	character	Specifies name of the directory that contains the chemical model files.	none	none
name	character	Name of the etch machine.	none	none
ndphiion	number	Specifies number of integration intervals in the azimuth direction for ion flux integration.	20 [1,]	none
ndthetaion	number	Specifies number of integration intervals of the incident angle for ion flux integration.	20 [1,]	none
ndthetaionrefl	number	Specifies number of integration intervals of the reflection angle for ion flux integration.	20 [1,]	none
numeric_param_[0-9]	number	User-defined parameter.	none	none
path	character	Path to the library containing a PMI model.	". "	none
plasmafile	character	Specifies the basename of the TDR file that contains the particle distributions simulated with the <code>plasma</code> command.	none	none

Table 7 Parameters of machetch command

Parameter	Type	Description	Default [range]	Unit
pmi	logical	Indicates that the machine uses a PMI model.	false	none
rate	number	The combined directional and isotropic component etch rates of the specified material.	none [0,]	micrometer/ minute
rateonsurface	logical	Activates the calculation of the etching rates on the surface.	false	none
reemrate	number	Specifies the deposition rate caused by reemission.	0 [0, 2]	µm /minute
reflmodel	character	Specifies reflection model type. Three models are available: <ul style="list-style-type: none"> • mirror: Specular reflection. • glossy: Curvature-independent diffuse reflection. • glossycurv: Curvature-dependent diffuse reflection. 	mirror	none
rie	logical	Indicates that the machine is a reactive ion etch machine.	false	none
rieniter	number	Specifies maximum number of iterations for the indirect flux calculation.	20 [1,]	none
rotating	logical	Specifies that the wafer rotates.	false	none
sc	number	Specifies the sticking coefficients of the deposition precursor.	0 [0, 1]	none
simple	logical	Indicates that the machine uses a simple combination of isotropic and perfectly anisotropic etch.	true	none
sptech	logical	Specifies that the named machine uses an ion-enhanced etch model.	false	none
sputc1	number	Angle-dependent sputtering rate of first-order coefficient.	5.5 [5, 6]	none
sputc2	number	Angle-dependent sputtering rate of second-order coefficient.	-6 [-6.5, -5.5]	none
sputc4	number	Angle-dependent sputtering rate of fourth-order coefficient.	1.5 [0.5, 2.5]	none
temperature	number	Specifies surface temperature used for surface gas kinetics and surface reaction rates.	300]0,]	kelvin

5: Input Commands

machetch

Table 7 Parameters of machetch command

Parameter	Type	Description	Default [range]	Unit
tilt	number	Tilt angle of wafer. A positive value corresponds to a counterclockwise rotation of the wafer.	0] -90, 90 [degree
vertical	logical	Specifies that the ion distribution is perfectly vertical.	none	none
xscale	number	Specifies the effective range of the local CMP process. This parameter is used to emulate the dependency of the local polishing rate on the local pattern density on a wafer surface. It must have a value close to the distance on a wafer at which the polishing rate shows significant variation due to the pattern density variation.	100 [100, 200]	micrometer

NOTE If the model type of an etching machine is repeated in `machetch` commands that do not create a new etching machine, the specified model type must match the model type of the machine. You cannot change the model type of an etching machine.

NOTE Except for the `etchdepo` model, the sum of `sputc1`, `sputc2`, and `sputc4` must be one. For the `etchdepo` model, only `sputc1` and `sputc2` are specified by the user. The value of `sputc4` is calculated automatically so that the sum of all sputter coefficients is one.

Command Use

The `machetch` command adds a new etch machine or adds properties for a new material to an existing etch machine. The characteristics of the etch machine (that is, the type of etch process that is performed) are described by a physical etch rate model and its associated semiempirical parameters. The model is used in an etch simulation when the name of the machine is specified with the `machname` parameter in the `etch` command (see [etch on page 68](#)).

For each machine type, there is a `machetch` command to set material-independent parameters and a separate `machetch` command to set material-specific parameters. This avoids confusion about the meaning of parameters and allows better checking of model parameters.

NOTE The material-independent form of the `machetch` command should be used only once for each etching machine.

NOTE The material-specific form of the `machetch` command should be used once for every material of an etching machine.

A new etching machine is created when no etching machine exists with the name specified in the `name` parameter of the `machetch` command. You should specify the type of the etching machine only when creating a new etching machine.

For simultaneous etching of different materials, you must add specifications for the different materials to one etch machine. In `machetch` commands used for adding settings to an existing etching machine, the type does not need to be specified.

The material etched can be any one of the materials defined in the standard file `datexcodes.txt`. If the material you want to etch is not defined in the standard `datexcodes.txt`, you can create a local version of this file and define your material in this file.

A complete description of the available models, schematic representations of the corresponding machine types, and the relationship to the command parameters are in [Chapter 3 on page 13](#).

NOTE Sentaurus Topography is case sensitive when specifying machine, mask, or material names.

NOTE For a `dry` etching machine, a reemission rate greater than zero must be defined for one material. This material will be used for the deposited polymer region. If a reemission rate greater than zero is defined for more than one material, the material with the maximum redeposition rate will be used for the deposited polymer region.

When the `chem` model is used, the size of the time step is determined by the CFL criterion or by adaptive time-stepping. The parameter `cfl` of the `etch` command is used to set the time-step size to a fraction of the maximum time step according to the CFL criterion. The parameter `adaptive` is used to activate adaptive time-stepping.

NOTE You cannot use a constant time-step size specified with the `dtmax` parameter.

The model directory specified with the `modeldir` parameter is searched for in the path defined by the environment variable `LSFLUX_LIBRARY_PATH`. If this environment variable does not exist, the model directory is expected to be located in the present directory. The environment variable `LSFLUX_LIBRARY_PATH` can be set using the `set` command (see [set on page 104](#)).

NOTE If the parameter `depomaterial` is used, the `etchdepo` mode is used.

5: Input Commands

machlitho

The parameter `rateonsurface` can be used to improve the handling of thin layers. When set to `true`, the material information and the etching rate are determined at the surface vertices and not at the level-set grid points. This improves the spatial resolution and allows for the use of coarser discretizations for structures with thin layers.

When calculating the etching rate on the surface, by default, the fast marching method [10] is used for the velocity extension. In the case of a failure of the fast marching method, the velocity extension is repeated automatically with a slower but more robust method and, for the following time steps, the fast marching method is used again. The parameter `fmm` can be used to switch off the fast marching method and to use the slower but more robust velocity extension method.

machlitho

The `machlitho` command is used to add a new lithography machine or to modify the properties of an existing machine. A lithography machine and its properties are used in a lithography simulation when the name of the machine is specified with the `machname` parameter in the `litho` command.

In general, material and simulation parameters should be specified in the SLO file or the Sentaurus Lithography material database. The `machlitho` command should be used mainly for varying a limited number of parameters, for example, in a parameterized Sentaurus Workbench project.

```
machlitho name=<c> command=<c> [arguments=<c>]
```

Table 8 Parameters of `machlitho` command

Parameter	Type	Description	Default	Unit
<code>arguments</code>	character	Arguments of the Sentaurus Lithography Tcl command without the connection handle.	none	none
<code>command</code>	character	Name of the Sentaurus Lithography Tcl command.	none	none
<code>name</code>	character	Name of the lithography machine. This name can be used in subsequent <code>litho</code> commands for creating a resist region by a lithography simulation.	none	none

Due to the Sentaurus Topography command file parser, depending on the number and the type of the argument, it may be necessary to modify the argument:

- If there is more than one argument (not including the connection handle), you must enclose the arguments in double quotation marks.
- If the only argument is a Tcl string, it must be enclosed in double quotation marks.

- Each double quotation mark in a Tcl string (including the opening and closing double quotation mark) must be replaced by two double quotation marks.

As an example, the Sentaurus Lithography Tcl command:

```
SL_Set_Param_Double $ConnectionHandle \
  "Global Parameters/Refraction\_\"ARC\"_at_193.0_nm" 1.71
```

is represented by the Sentaurus Topography command:

```
machlitho name=ml command=SL_Set_Param_Double
+ arguments="\"Global Parameters/Refraction\_\"ARC\"_at_193.0_nm" 1.71"
```

NOTE You are responsible for specifying the correct parameters depending on the specified Sentaurus Lithography Tcl command.

mask

The `mask` command is used to define new masks. Masks are used in Sentaurus Topography to perform geometric etch operations as described in [etch on page 68](#):

```
mask name=<c> [s0=<n> e0=<n>] [s1=<n> e1=<n>] ... [s9=<n> e9=<n>]
```

Table 9 Parameters of mask command

Parameter	Type	Description	Default	Unit
e0	number	The x-coordinate of the end of the first mask opening.	none	micrometer
e9	number	The x-coordinate of the end of the tenth mask opening.	none	micrometer
name	character	The name of the mask.	none	none
s0	number	The x-coordinate of the start of the first mask opening.	none	micrometer
s9	number	The x-coordinate of the start of the tenth mask opening.	none	micrometer

Command Use

The `mask` command is used to define a new mask. Masks defined with this command are restricted to ten open regions. For example, the command:

```
mask name=MY_MASK s0=1.0 e0=1.5 s1=2.0 e1=3.0
```

5: Input Commands

merge

specifies a mask named `MY_MASK` that has two openings of $0.5\ \mu\text{m}$ and $1.0\ \mu\text{m}$ (see Figure 17). The first starts at $1.0\ \mu\text{m}$ from the left boundary, and the second starts at $2.0\ \mu\text{m}$.




Figure 17 The mask command showing the dark regions and the open regions

NOTE Sentaurus Topography is case sensitive when specifying machine, mask, or material names.

merge

The `merge` command is used to simplify the current geometric structure by merging neighboring layers of the same material type:

```
merge [material=<c>]
```

After a series of process steps, the structure may consist of many layers. Neighboring layers of the same type of material can be merged to reduce the number of layers. Subsequent program execution takes less time based on the simplified geometric structure.

Table 10 Parameters of merge command

Parameter	Type	Description	Default	Unit
material	character	Material name of the neighboring layers.	none	none

Command Use

Use `merge` when the simulation structure contains many layers and when some of the neighboring layers are of the same material type. Program execution may be slow due to the increased number of layers. However, execution speeds up considerably if the `merge` operation is performed at an appropriate step.

The `merge` command without the parameter `material` merges all neighboring layers of the same material type.

With the parameter `material`, the `merge` command merges neighboring layers with the same material type specified by the `material` parameter.

NOTE Neighboring layers whose material types are different cannot be merged.

NOTE If a region consists of several disconnected layers, these can be merged with layers of different regions.

plasma

The `plasma` command simulates the ion and energetic neutral angular distributions on a flat wafer surface in a capacitively coupled plasma discharge. The resulting distributions can be used for plasma-based etching or deposition simulations.

As the field is not calculated in a self-consistent manner, the parameter `fieldmodel` is used to choose between the different models presented in [Plasma Modeling on page 42](#):

```
plasma file=<c>
{
  [acpot=<n>] [acthickness=<n>] [anglediv=<n>]
  [chargexsect=<n>]
  [dcpot=<n>] [dcthickness=<n>]
  [energydiv=<n>] [fieldmodel=<n>] [frequency=<n>]
  [gasmass=<n>] [gastemp=<n>] [ionmass=<n>] [iontemp=<n>]
  [momentumxsect=<n>]
  [neutrals] [numparticles=<n>]
  [pressure=<n>]
}
```

Table 11 Parameters of plasma command

Parameter	Type	Description	Default	Unit
acpot	number	Half of AC peak-to-peak component of the voltage at the sheath–bulk interface.	50	volt
acthickness	number	AC component of sheath thickness.	0	millimeter
anglediv	number	Specifies the number of divisions for the calculation of angular distribution. (It must be a multiple of 15.)	90	none
chargexsect	number	Specifies the charge-exchange cross section.	0	m ²
dcpot	number	DC part of the sheath voltage.	100	volt
dcthickness	number	Mean sheath thickness.	10	millimeter
energydiv	number	Specifies the number of divisions for calculation of energy distribution.	50	none

5: Input Commands

plasma

Table 11 Parameters of plasma command

Parameter	Type	Description	Default	Unit
fieldmodel	number	Specifies the number of the electric field-dependent model: 1 = Collisionless Child-Langmuir 2 = Collision-dominated discharge 3 = Linear variation 4 = Constant	1	none
file	character	The file basename for the angular distributions. This output file includes the full result of the Monte Carlo simulation of particle transport through the sheath of a capacitively coupled plasma discharge. It includes the energetic neutral and ion-angular distributions. This file can be loaded into Sentaurus Topography for deposition and etching simulations.	none	none
frequency	number	Specifies the frequency.	13.6e+06	hertz
gasmass	number	Specifies the atomic mass of the gas.	40	amu
gastemp	number	Specifies gas temperature.	300	kelvin
ionmass	number	Specifies the atomic mass of the ion.	40	amu
iontemp	number	Specifies ion temperature.	300	kelvin
momentumxsect	number	Specifies the momentum-transfer cross section.	2.e-19	m ²
neutrals	logical	Specifies if energetic neutrals are simulated in the discharge.	false	none
numparticles	number	Specifies number of particles to be simulated.	10000	none
pressure	number	Specifies reactor pressure.	100	mTorr

Command Use

This command is used to simulate the angular distribution of particles arriving at a wafer surface in processes that involve capacitively coupled plasma discharges. This can be used during an etching (*spetch* model) or a deposition (*hdp* model) simulation.

The angular distribution of the ions and neutrals, and the sum of ions and neutrals are stored in a TDR file, for which the basename is specified with the *file* parameter.

save

The `save` command is used to save the current structure:

```
save file=<c> [addgas] [rc2] [sat] [tdr [invert]]
```

Table 12 Parameters of `save` command

Parameter	Type	Description	Default	Unit
addgas	logical	Specifies that a gas region is added at the top of the structure.	true	none
file	character	Base name of the file in which the structure is to be saved.	none	none
invert	logical	Specifies that the TDR structure information is to be saved in a coordinate system that is inverted with respect to the internal coordinate system of Sentaurus Topography.	true	none
rc2	logical	Specifies that the structure information is to be saved in Raphael RC2 format.	false	none
sat	logical	Specifies that the structure information is to be saved in SAT format.	false	none
tdr	logical	Specifies that the structure information is to be saved in TDR format.	true	none

Command Use

The `save` command saves the resulting boundary structure of the topography simulation in one of the available formats (TDR, SAT, or RC2).

A `save` command can appear at any point in a processing sequence after the `initialize` command.

To use the boundaries created by Sentaurus Topography in Sentaurus Process, it is necessary to fill voids with gas regions and to add a gas region at the top of the existing structure. These gas regions are added by default when TDR and SAT files are created in Sentaurus Topography.

The parameter `addgas` is used to switch on or off the creation of the top gas region. The name of this region is `Top_gas`.

5: Input Commands

set

The parameter `fillvoids` is used to specify whether voids in the structure are filled with gas regions. These regions are named `Void_<n>` where `<n>` is the number of the void starting at zero. See also [initialize on page 80](#) for issues regarding the names of voids.

NOTE At the end of a simulation, the structure is automatically saved in a TDR file using the same base name as the command file. The voids are filled with gas regions and a gas region is added at the top of the structure.

set

The `set` command is used to change global simulator settings:

```
set [infolevel=<n>] [lsfluxlib=<c>] [simplify]
```

Table 13 Parameters of set command

Parameter	Type	Description	Default [range]	Unit
<code>infolevel</code>	number	Sets the verbosity of the output.	2 [1, 4]	none
<code>lsfluxlib</code>	character	Value to which the environment variable <code>LSFLUX_LIBRARY_PATH</code> is set.	none	none
<code>simplify</code>	logical	Specifies that the surface created during deposition or etching is simplified.	false	none

The parameter `infolevel` is used to set the verbosity of information written to standard output and the log file. When `infolevel` is set to a value of 1, only the most important messages are output. At higher levels, more information is printed. The `set` command can be used repeatedly and at any location in a command file.

The parameter `lsfluxlib` is used to set the environment variable `LSFLUX_LIBRARY_PATH`, which is used by the `chem` model.

The parameter `simplify` is used to reduce the number of vertices in the top surface created by deposition or etching. The reduced number of vertices in the boundary can lead to a considerable reduction of the CPU time, which is required for subsequent Boolean operations.

During the simplification, edges that are collinear or nearly collinear merge. Neighboring edges for which the direction differs by less than 0.01 rad merge.

For surfaces extracted at each time step for models that use flux integration, the number of edges that can merge into one edge during simplification of the surface is limited to four. This is necessary to avoid inaccurate flux integration.

NOTE The simplification affects only new surfaces. Region boundaries between existing regions are not affected.

NOTE The surface of voids is not simplified.

stop

The `stop` command is used to end the execution of Sentaurus Topography. Its main use is to perform the execution of only the first part of a process flow. It is not necessary to use this command as the last command of the command file:

```
stop
```

truncate

The `truncate` command is used to truncate the structure below a specified y-coordinate:

```
truncate y=<n>
```

Table 14 Parameters of truncate command

Parameter	Type	Description	Default [range]	Unit
y	number	The y-coordinate below which the structure will be truncated.	none	micrometer

Command Use

The `truncate` command is used to remove the bottom part of the structure. The y-coordinate at which the structure is truncated must be chosen in such a way that the remaining structure is not split into disconnected parts or that the maximum width of the resulting structure is smaller than the width of the initial structure.

References

- [1] R. Courant, K. Friedrichs, and H. Lewy, “On the Partial Difference Equations of Mathematical Physics,” *IBM Journal*, vol. 11, no. 2, pp. 215–234, 1967.
- [2] J. A. Sethian and D. Adalsteinsson, “An Overview of Level Set Methods for Etching, Deposition, and Lithography Development,” *IEEE Transactions on Semiconductor Manufacturing*, vol. 10, no. 1, pp. 167–184, 1997.
- [3] S. Osher and J. A. Sethian, “Fronts Propagating with Curvature-Dependent Speed: Algorithms Based on Hamilton–Jacobi Formulations,” *Journal of Computational Physics*, vol. 79, no. 1, pp. 12–49, 1988.
- [4] J. A. Sethian, “Numerical Algorithms for Propagating Interfaces: Hamilton-Jacobi Equations and Conservation Laws,” *Journal of Differential Geometry*, vol. 31, no. 1, pp. 131–161, 1990.
- [5] D. Adalsteinsson and J. A. Sethian, “A Level Set Approach to a Unified Model for Etching, Deposition, and Lithography I: Algorithms and Two-Dimensional Simulations,” *Journal of Computational Physics*, vol. 120, no. 1, pp. 128–144, 1995.
- [6] D. Adalsteinsson and J. A. Sethian, “A Level Set Approach to a Unified Model for Etching, Deposition, and Lithography II: Three-Dimensional Simulations,” *Journal of Computational Physics*, vol. 122, no. 2, pp. 348–366, 1995.
- [7] J. A. Sethian, “Theory, algorithms, and applications of level set methods for propagating interfaces,” *Acta Numerica*, vol. 5, A. Iserles (ed.), Cambridge: Cambridge University Press, pp. 309–395, 1996.
- [8] J. A. Sethian, “A fast marching level set method for monotonically advancing fronts,” *Proceedings of the National Academy of Sciences*, vol. 93, no. 4, pp. 1591–1595, 1996.
- [9] H. Zhao, “A Fast Sweeping Method for Eikonal Equations,” *Mathematics of Computation*, vol. 74, no. 250, pp. 603–627, 2005.
- [10] D. Adalsteinsson and J. A. Sethian, “The Fast Construction of Extension Velocities in Level Set Methods,” *Journal of Computational Physics*, vol. 148, no. 1, pp. 2–22, 1999.

This chapter describes the syntax of the surface reaction files used by the chem model and the organization of the models in a model library. A chemical reaction model comprises reaction files for different materials and files for distributions of ion and neutral fluxes.

Model Library

Each of the chemical models used by the chem model of Sentaurus Topography consists of reaction and flux distribution files, which are organized in a special directory structure. To facilitate the use of calibrated chemical models among a group of users, an arbitrary number of models can be stored in a common model library.

The top directory of the model library is specified by the environment variable `LSFLUX_LIBRARY_PATH`. This environment variable can be set either in the global environment or using the `lsfluxlib` parameter of the `set` command (see [set on page 104](#)).

An arbitrary directory hierarchy is used to organize the model directories within the model library directory, for example:

```
+ model_library
|
- species.dat
+ ...
+ ...
|
+ ...
|
+ example_model
|
+ chem
| |
| - Silicon.chem
| - Oxide.chem
| - ...
|
+ flux
|
- exa.tdr
```

6: Chemical Reaction Models

Model Library

Each model directory contains the subdirectories `chem` and `flux`, which contain the reaction files and the flux distributions, respectively. The `modeldir` parameter of the `machdepo` and `machetch` commands is used to specify the relative path from the model library directory to the model directory (see [machdepo on page 84](#) and [machetch on page 91](#)).

The species.dat File

The `species.dat` file contains information about all gas-phase neutral and ion species. Only species listed in this file can be used in reaction and flux files. The file is located in the model library directory.

Each neutral or ion species is defined on one line. For neutral species, the molecular mass must be specified with the unit kg mol^{-1} .

Syntax

```
<neutral-name> NEUTRAL <molecular-mass>
...
<ion-name> ION
...
```

Example

```
F      NEUTRAL  19E-3
C      NEUTRAL  12E-3
O      NEUTRAL  16E-3
O2     NEUTRAL  32E-3
C4F8   NEUTRAL  200E-3
CF+    ION
CF3+   ION
O+     ION
F+     ION
CL+    ION
```

The chem Directory

The `chem` directory contains all reaction files for a specific model. Each reaction file contains the surface reactions for one bulk material. The name of a reaction file consists of the DATEX name of the bulk material and the suffix `.chem`.

For a deposition process, a reaction file for the deposited material must be available. For an etch process, reaction files for each exposed material must be available. In etchdepo mode, reaction files for each exposed material and the deposited material must be available.

The flux Directory

The `flux` directory contains distribution files for the ion and neutral fluxes. The directory can contain an arbitrary number of flux files. This allows you to use the reaction files with different plasma conditions.

The base name of a distribution file that is used is specified with the parameter `fluxinp` of the `machdepo` and `machetch` commands (see [machdepo on page 84](#) and [machetch on page 91](#)).

Neutral fluxes and analytic distributions for ion fluxes are specified in text files with the extension `.flux`.

The flux values for ion and neutral species are specified with the unit $\text{mol m}^{-2} \text{s}^{-1}$.

You can define more than one flux with different properties for an ion species. Different fluxes of one ion species are distinguished by their flux type number. The flux type number is a non-negative integer less than or equal to 20. However, usually only one flux is defined for an ion species, and the flux type should have the value 1.

The exponent is a non-negative integer and is used to characterize the angular distribution as a function of $\cos^m \theta$.

Syntax

```
NEUTFLX <neutral-name> <flux>
...
IONFLX <flux-type-number> <ion-name> <flux> <exponent>
...
```

Example

```
NEUTFLX CL2 0.005
IONFLX 1 CL+ 0.003 1500
```

Ion angular distributions, which were obtained by measurements or simulations and stored in TDR `xy` files, can also be used. Such a file must contain a dataset with the name `Angle` and the quantity `AngleDegree`, which contains the angles (in degrees) for which the flux is specified. The values must start at 0 and increase monotonically.

6: Chemical Reaction Models

Reaction File Structure

For each ion species, a dataset can be specified where the dataset name is given by the name of the ion species and the quantity is `IonAngularDistribution`. The unit for the ion angular distribution datasets is $\text{mol m}^{-2} \text{s}^{-1}$.

Reaction File Structure

The reaction files are text files with the following structure:

- Definition block
- Surface species block
- Bulk material block
- Density block
- Reaction block

The examples used here are part of a file named `Silicon.chem`.

A reaction file can contain comments. Comments start with `//` and continue to the end of the line.

Definition Block

The definition block contains an arbitrary number of definitions that associate a name with a numeric value or a mathematical expression, similar to the C preprocessor. Each definition should be written on one line.

Syntax

```
#DEFINE <name> <value>
```

Example

```
#DEFINE A1 0.5  
#DEFINE Y1 ((1.0-0.1*THI)*COS(THI)^5)
```

NOTE Avoid names that are part of other names.

NOTE It is recommended to enclose mathematical expressions in parentheses.

Surface Species Block

The surface species block begins with the keyword `SURFACES` and ends with the keyword `END`. It contains surface species sites for the Langmuir-type surface site model [1]. Each entry consists of a material name and the keyword `SURFACE`. Up to 15 surface species can be defined for each bulk material.

Syntax

```
SURFACES
<material> SURFACE
...
END
```

Example

```
SURFACES
SI SURFACE
SICL SURFACE
END
```

NOTE The material name used in the specification of a surface species does not have to be a DATEX material name. Instead, it is the name of a material used in the reaction block. This allows the use of the usual chemical material names in reaction formulas.

Bulk Material Block

The bulk material block begins with the keyword `BULKS` and ends with the keyword `END`. It contains the name of the bulk material for which the reactions are defined in the `chem` file and is followed by the keyword `BULK`.

Syntax

```
BULKS
<material> BULK
END
```

6: Chemical Reaction Models

Reaction File Structure

Example

```
BULKS
SI BULK
END
```

NOTE The material name used in the specification of the bulk material does not have to be a DATEX material name. Instead, it is the name of the bulk material used in the reaction block. This allows the use of the usual chemical material names in reaction formulas.

Density Block

The density block begins with the keyword `DENSITIES` and ends with the keyword `END`. It contains specifications of the volume density and surface site density of the bulk material. The volume density is specified with the keyword `DENS`, and the surface site density is specified with the keyword `SDEN`. The unit for `DENS` is mol m^{-3} and, for `SDEN`, the unit is mol m^{-2} .

Syntax

```
DENSITIES
DENS <value>
SDEN <value>
END
```

Example

```
DENSITIES
DENS 8.32E4
SDEN 2.3E-5
END
```

Reaction Block

The reaction block begins with the keyword `REACTIONS` and ends with the keyword `END`. It can contain up to 120 reaction paths. Each reaction path is specified on a separate line.

Syntax

```
REACTIONS
<reaction path>
...
END
```

Example

```
REACTIONS
R01 CL + SI<S> => SICL<S> RATE[1.0] PROB[SI<S>] FLUX[CL]
R02 SICL<S> => CL + SI<S> RATE[2.1E4 * EXP(-3400/T) * SDEN] PROB[SICL<S>] \
FLUX[1.0]
END
```

The syntax of a reaction path specification is described in [Reaction Path](#).

Reaction Path

As described in [Simplifications on page 33](#), a reaction path describes an irreversible reaction. If the reverse reaction should be taken into account, a separate reaction path for the reverse reaction must be added to the reaction block.

A reaction path consists of a:

- Reaction path name.
- Reaction formula.
- Parameter list.

[Syntax on page 115](#) describes the reaction path syntax formally.

Reaction Path Name

The reaction path name identifies a reaction path. Typically, it consists of characters and numbers.

6: Chemical Reaction Models

Reaction Path


Reaction Formula

A reaction formula consists of two reaction states:

- The first reaction state describes the state before the reaction.
- The second reaction state describes the state after the reaction.

The reaction states are separated by the characters "`␣=>␣`", where the spaces (`␣`) must be included. Only irreversible reactions can be specified.

To model a reversible reaction, the reverse reaction path must be added. For example:



Each reaction state consists of one or more chemical species terms. The chemical species terms are separated by the characters "`␣+␣`", where the spaces must be included.

A chemical species term consists of one mandatory part and three optional parts. The chemical symbol is mandatory and consists of alphanumeric characters. It can be prefixed by a stoichiometric coefficient and a yield coefficient, which are both optional. The chemical symbol can be followed by an optional species-type modifier.

In the following example, `C6OH7` is the chemical symbol and 2 is the stoichiometric coefficient. The species-type modifier `<S>` specifies that it is a surface species:



[Table 15](#) lists the available species-type modifiers. A chemical species term without a type modifier describes a general species.

Table 15 Species-type modifiers

Modifier	Description	Required parameters	Restrictions
	Nonsurface bulk material.		
<P>	Anisotropic neutral species emitted by sputtering.	SPPR [], SPUT [], YIEL []	Only applicable to emitted neutral species in the state after the reaction.
<R>	Ion species reflected from the surface.	RELF [], REPR []	Only applicable to the incoming ion species in the state before the reaction.
<S>	Surface species.		
<V>	Species that is not tracked.		

NOTE The chemical symbol is simply a name; it is not interpreted in any way. In the example for the reaction formula, the chemical symbols also could have been named X, Y, and Z instead of CL, SI, and SICL, respectively.

NOTE For the surface sites, the conservation law must be satisfied. Total species conservation is not required.

NOTE The yield coefficient # has no effect and is obsolete. To define a surface-ion reaction, the parameter YIEL [] must be specified. If the parameter YIEL [] is not specified in a reaction path and a value other than 1.0 is specified with FLUX [], the reaction is interpreted as a surface-neutral reaction. If there is no flux for the neutral species defined with FLUX [], the flux is considered to be zero and the reaction has no effect.

Parameter List

The parameter list contains expressions for the reaction parameters α_i , β_i , γ_i , and δ_i , which are used to calculate the reaction rate. There are two different forms of the parameter list for surface-neutral reactions and surface-ion reactions. Surface-surface reactions are handled in the same way as surface-neutral reactions.

The parameter list for surface-neutral reactions consists of three expressions RATE [], FLUX [], and PROB [] that represent the reaction rate parameters α_i , γ_i , and δ_i , respectively.

For surface-surface reactions where there is no incoming flux, the value specified with the FLUX [] parameter is 1.0 instead of a species name.

For surface-ion reactions, the parameter list consists of four mandatory and five optional expressions. The mandatory expressions are RATE [], YIEL [], FLUX [], and PROB [], which represent the reaction rate parameters α_i , β_i , γ_i , and δ_i , respectively. The optional expressions FLTP [], REFL [], REPR [], SPPT [], and SPUT [] are used to specify ion reflection and sputtering properties.

Syntax

NOTE In this section, optional syntactic elements are enclosed in braces instead of brackets, because brackets are part of some syntactic constructs.

6: Chemical Reaction Models

Reaction Path

<reaction-path>::=
 <reaction-path-name>▯*<reaction-formula>*▯*<parameter-list>*

<reaction-path-name>::=
 alphanumeric identifier

<reaction-formula>::=
 <reaction-state>▯*=*▯*<reaction-state>*

<reaction-state>::=
 <chemical-species-term-list>

<chemical-species-term-list>::=
 <chemical-species-term>{▯+▯*<chemical-species-term-list>*}

<chemical-species-term>::=
 {*<stoichiometric-coefficient>*}#*<chemical-symbol>*{*<type-modifier>*}

<stoichiometric-coefficient>::=
 integer

<chemical-symbol>::=
 alphanumeric identifier

<type-modifier>::=
 | <P> | <R> | <S> | <V>

<parameter-list>::=
 <surface-neutral-reaction-parameters> | *<surface-ion-reaction-parameters>*

<surface-neutral-reaction-parameters>::=
 <angle-independent-yield>▯*<flux-species>*▯*<surface-parameter>*

<surface-ion-reaction-parameters>::=
 <angle-independent-yield>▯*<angle-dependent-yield>*▯*<flux-species>*▯
 <surface-parameter>▯{*<reflection-probability>*}▯{*<sputtering-yield>*}▯
 {*<flux-type>*}▯{*<reflection-spread>*}▯{*<sputtering-spread>*}

<angle-independent-yield>::=
 RATE[*<numeric-expression>*]

<angle-dependent-yield>::=
 YIEL[*<numeric-expression>*]

<numeric-expression>::=
mathematical expression involving operators and functions from [Table 16 on page 119](#)
and variables from [Table 18 on page 120](#)

<flux-species>::=
FLUX[*<species-name>*]

<species-name>::=
alphanumeric identifier

<surface-parameter>::=
PROB[*<surface-species-list>*]

<surface-species-list>::=
<surface-species>{ **<surface-species-list>* }

<surface-species>::=
*<chemical-symbol>**<S>*{ ^integer }

<reflection-probability>::=
REFL[*<numeric-expression>*]

<sputtering-yield>::=
SPUT[*<numeric-expression>*]

<flux-type>::=
FLTP[integer]

<reflection-spread>::=
REPR[*<numeric-expression>*]

<sputtering-spread>::=
SPPR[*<numeric-expression>*]

Examples

This section shows some simple reaction examples.

Deposition of Polysilicon

Both reaction paths describe surface–neutral reactions in which polysilicon and hydrogen molecules are created. The type modifier <V> indicates that the reaction module does not keep track of the hydrogen molecules:

```
1 SIH2 + SI<S> => SI<S> + SI<B> + H2<V> RATE[1.0] PROB[SI<S>] FLUX[SIH2]
2 SIH4 + SI<S> => SI<S> + SI<B> + 2H2<V> RATE[9.4E-5] PROB[SI<S>] FLUX[SIH4]
```

Deposition of Doped Polysilicon

As in the previous example, polysilicon is deposited, but here the doping gas AsH₃ is added. This reduces the deposition of silicon by blocking surface sites. Reactions 5 and 6 are the adsorption and desorption reactions for AsH₃, respectively.

The flux parameter value 1.0 in Reactions 5 and 6 indicates that these are surface–surface reactions.

Reaction 6 describes the incorporation of arsenic into silicon. However, the doping concentration in the bulk is not calculated:

```
1 SIH2 + SI<S> => SI<S> + SI<B> + H2<V> RATE[1.0] PROB[SI<S>] FLUX[SIH2]
2 SIH4 + SI<S> => SI<S> + SI<B> + 2H2<V> RATE[9.4E-5] PROB[SI<S>] FLUX[SIH4]
3 SIH2 + SIASH3<S> => SI<S> + SI<B> + H2<V> RATE[1.0] PROB[SIASH3<S>] \
FLUX[SIH2]
4 ASH3 + SI<S> => SIASH3<S> RATE[1.0] PROB[SI<S>] FLUX[ASH3]
5 SIASH3<S> => SI<S> + ASH3 RATE[1.79E-5] PROB[SIASH3<S>] FLUX[1.0]
6 SIASH3<S> => SI<S> RATE[4.3E-7] PROB[SIASH3<S>] FLUX[1.0]
```

Isotropic Etching of Silicon

In this example, fluorine is the etching species. It reacts with a surface silicon and a bulk silicon atom. An FSi molecule is formed and removed from the surface, as indicated by the species-type modifier <V>, and a bulk silicon atom is converted to a surface silicon atom:




Table 16 Available operators and functions

Function	Description
+	Addition
-	Subtraction
*	Multiplication
/	Division
^	Power
COS ()	Cosine function
EXP ()	Exponential function
SIN ()	Sine function
(MAX ())	Maximum
(MIN ())	Minimum

NOTE The extra pair of parentheses around MAX () and MIN () are required to avoid parsing problems and to achieve correct results.

Table 17 Rate parameters

Rate parameter	Description	Possible variables
FLTP	Flux type number.	none
FLUX	Gas-phase ion or neutral species.	none
PROB	Surface species involved in the reaction.	none
RATE	Angle-independent part of the overall reaction yield.	PI, SDEN, T
REFL	Probability of ion reflection.	PI, T, THI
REPR	Diffusive factor of ion reflection.	PI, T, THI
SPPR	Diffusive factor of sputtered particle.	none
SPUT	Sputter yield.	PI, T, THI
YIEL	Angle-dependent part of the overall reaction yield.	PI, T, THI

6: Chemical Reaction Models

References

Table 18 Variables

Variable	Description	Rate parameters
PI	π	RATE [], REFL [], SPUT [], YIEL []
SDEN	Surface density	RATE []
T	Surface temperature [K]	RATE [], REFL [], SPUT [], YIEL []
THI	Ion incident angle	REFL [], SPUT [], YIEL []

References

- [1] J. M. Thomas and W. J. Thomas, *Principles and Practice of Heterogeneous Catalysis*, Weinheim, Germany: VCH Verlagsgesellschaft, 1997.

CHAPTER 7 Physical Model Interface for Deposition and Etching

This chapter discusses the physical model interface (PMI) for deposition and etching models in Sentaurus Topography.

Overview

The PMI gives you the possibility to extend the modeling capabilities of Sentaurus Topography by implementing a new deposition model, etching model, or simultaneous etching and deposition model in the form of a C++ class.

To keep the PMI and the models based on it as simple and independent of the implementation of Sentaurus Topography as possible, the main input of the model at each time step is the coordinates of the surface vertices, and the output is the deposition or etching rate at these surface vertices.

For some models, it may be necessary to determine if an arbitrary point lies above or below the current surface or to calculate the distance between an arbitrary point and the current surface. Limited access to the level-set function and level set-related data is provided to enable the efficient implementation of these types of query.

The following sections describe the command file interface for using a PMI-based deposition model, etching model, or simultaneous etching and deposition model, the C++ interface for creating a new model, and the available input and output parameters.

Command File Interface for Deposition Models

To use a PMI-based deposition machine, the model named `pmi` is specified with the `machdepo` command. The parameters `model` and `path` are used to specify the name of the shared library and a search path for the shared library, respectively.

Generic Command File Parameters for Deposition Models

In addition to the `model` and `path` parameters, the `pmi` model has ten generic character, logical, and numeric parameters. The developer of a PMI-based deposition model is free to define the meaning of these parameters in the model.

Due to limitations of the command file parser of Sentaurus Topography, the names of these parameters are fixed and cannot be changed. The parameters are named:

- `character_param_[0-9]`
- `logical_param_[0-9]`
- `numeric_param_[0-9]`

Defining a PMI-Based Deposition Machine

The following example shows the definition of a deposition machine that uses a PMI-based model named `Pmi_depo_rate_simple` (see [Example Model for Deposition on page 128](#) for the code of this model).

The shared library for this model is located in the current working directory. One numeric parameter is specified, which is interpreted as the deposition rate by the `Pmi_depo_rate_simple` model:

```
machdepo pmi material=Nitride name=m1 model=Pmi_depo_rate_simple
+ numeric_param_0=0.15
```

C++ Interface for Deposition Models

At the C++ level, the interface consists of the abstract base classes `Pmi_depo_rate` and `Pmi_depo_param`, which are declared in the public header files `Pmi_depo_rate.hh` and `Pmi_depo_param.hh`, respectively. These header files are located in the directory `${STROOT}/tcad/${STRELEASE}/lib/sptopo/include`.

`Pmi_depo_rate` is a base class for calculating the deposition rate at the surface vertices for each time step. `Pmi_depo_param` is a base class for transferring input data from Sentaurus Topography to the PMI-based deposition model.

Figure 18 shows a UML diagram of the class hierarchy.




Figure 18 PMI class hierarchy

Implementing a New Deposition Model

To implement a PMI-based deposition model, it is necessary to derive a concrete class from `Pmi_depo_rate` and to provide a definition for the two free functions declared in `Pmi_depo_rate.hh`.

The input data for the model is contained in an object derived from the abstract base class `Pmi_depo_param`. This makes it possible to include additional data in a later version of the interface without needing to change the rest of the interface or any existing models. It will only be necessary to recompile existing models to be able to use them with a new version of Sentaurus Topography that supports additional input data. See [Input and Output Parameters for Deposition Models on page 128](#) for a list of available input data.

Sentaurus Topography uses the factory function `pmi_depo_rate_factory()` to create an object of the derived class when starting the level-set simulation. The command file parameters and the coordinates of the initial surface are available as input data. The constructor of the derived model is called only from this function.

For each time step, the function `calculate_rate()` is called once to calculate the deposition rates at the surface vertices. The command file parameters, the coordinates of the current surface, the size of the previous time step, and certain level set-related data are available as input data.

At the end of the level-set simulation, the `pmi_depo_rate_delete()` function is called to delete the object of the derived class that was created with `pmi_depo_rate_factory()`. The destructor of the derived class is called only from this function.

Level Set–Related Data

As previously mentioned, for some deposition models, it may be necessary to determine if an arbitrary point lies above or below the current surface or to calculate the distance between an arbitrary point and the current surface.

These queries can be implemented easily when the level-set function of the current structure is available. Therefore, access to the values of the level-set function in the narrow band is available. In addition, other level set–related data, which may be helpful for the efficient implementation of some models, is available in the narrow band.

The level set–related data is only available to a deposition model from within `calculate_rate()`, but not from within the constructor of the deposition model.

To access the level-set function and level set–related data, it is first necessary to determine whether a point is located in the narrow band of the level set. If this is the case, the following level set–related data for this point can be queried:

- The level-set function.
- The derivative of the level-set function in the x- and y-direction.
- The curvature of the level-set function.

Additional Input Data

Additional input data that is too complicated to be read from the command file may be required by a model, for example, complex chemical reactions. This kind of data can be read and stored as member data by the constructor of the derived class for later use in `calculate_rate()`.

In some models, it may be necessary to store data from previous time steps. This additional data also can be stored as member data of the derived class object.

Error Handling

Very simple deposition models can be developed in such a way that runtime errors do not occur. For more sophisticated models, the possibility of runtime errors must be taken into account.

The only safe way to signal to the calling code that an error has occurred in a constructor is to throw an exception. However, C++ does not allow exceptions to cross interfaces as they are used for the PMI. An exception that is thrown in a PMI model and that is not caught and handled in the PMI model will cause the immediate abort of the simulation.

For a PMI model, this means that exceptions that were thrown in the constructor must be caught in the factory function `pmi_depo_rate_factory()`. In the case of an error, the null pointer is returned, and the simulation is stopped in a controlled way. The documentation of `pmi_depo_rate_factory()` in `Pmi_depo_rate.hh` demonstrates how this is performed.

Similarly, exceptions must not leave `calculate_rate()`. Here, an error is signaled to the calling code by returning the value `false`. The simulation is then stopped in a controlled way.

The function `Pmi_depo_param::message()` can be used to output messages to the standard output and the log file. For error messages, the verbosity level should be set to `low`; while for other messages, the verbosity level `medium` or higher should be used.

Compiling the Source Code

The source code can be compiled and linked using the `cmi` tool, which calls the C++ compiler and linker with the correct command-line options for each supported platform.

The `cmi` tool is contained in each TCAD release and is mainly used for Sentaurus Device CMI-based and PMI-based models.

See [Compact Models User Guide, Compilation of C++ \(.C\) Files on page 141](#) for more information.

When using the `cmi` tool for compiling a PMI-based deposition model, you must specify the directory containing the model header files with the `-I` option:

```
cmi -I${STROOT}/tcad/${STRELEASE}/lib/sptopo/include Pmi_depo_rate_simple.cc
```

Using Additional Source Files or Libraries

A PMI-based deposition model is not limited to the functionality declared in `Pmi_depo_rate.hh` or directly derived from it. You can use additional source files or libraries, which provide additional functionality, to build the shared library for a model. For example, a model may need to solve a linear equation system. In this case, it is possible to link with a library that provides this functionality.

Additional source files or libraries can be specified as command-line parameters for the `cmi` tool, which will combine them into one shared library.

Using the Standard Template Library

When using standard template library (STL) features in the implementation of the PMI model, it may be necessary to link an additional library that provides this functionality. For example, on 64-bit Linux, it is necessary to link `libstdc++` by adding `-lstdc++` to the command-line parameters of the `cmi` tool.

To avoid problems at link time or runtime, it is necessary to use exactly the same version of the C++ compiler for the compilation of the PMI code as has been used for the compilation of Sentaurus Topography.

Refer to the *Compilers for CMI and PMI* in the TCAD Sentaurus release notes for information about the compiler versions used in Sentaurus Topography Version N-2017.09.

Loading the Shared Library

The shared library specified in the `machdepo` command is loaded when executing a `deposit` command that references this deposition machine. When the `deposit` command is finished, the shared library is unloaded again. This must be taken into account when using static variables.

Debugging PMI Code

Debugging the PMI code is more difficult than debugging a standard program for several reasons. First, only the PMI code created by the user is available as source code, and debugging symbols are not available for Sentaurus Topography. Second, the library containing the PMI code is loaded dynamically when it is used. Third, typically Sentaurus Topography is started by a wrapper script that sets some environment variables. When using a debugger, it is necessary to set these environment variables manually and then to start the debugger with the executable of Sentaurus Topography without the wrapper script.

The details of debugging are highly platform dependent and tool dependent, especially when using shared libraries.

The following procedure shows how to debug PMI code on Linux using `gdb` and `ddd`:

1. Since the shared library that contains the PMI code is loaded only when the PMI model is used and unloaded when the PMI model is finished, you must set a breakpoint each time the PMI model is used. The breakpoint must be set after the shared library is loaded. The definition of the breakpoint is lost when the shared library is unloaded.

One way to make it easier to set the breakpoint, when the shared library is loaded, is to add a message and a call to `sleep()` to the constructor of the PMI model. The sleep gives you the chance to interrupt the execution and to set a breakpoint:

```
sptopo::Pmi_depo_rate_simple::Pmi_depo_rate_simple(
    Pmi_depo_param const& param)
    : Pmi_depo_rate(),
    rate_m(param.numeric_param(0))
{
    param.message(Pmi_depo_param::low,
        "interrupt, set breakpoint, and continue\n");
    sleep(15);

    assert(0.0 <= rate_m);
}
```

2. Compile the PMI code in debug mode and use the command-line option `-g` when creating the shared library with the `cmi` tool:

```
cmi -g -I${STROOT}/tcad/${STRELEASE}/lib/sptopo/include -lstdc++
Pmi_depo_rate_simple.cc
```

3. Since the `sptopo` executable must be called directly with the debugger, you must set the environment variable `LD_LIBRARY_PATH` explicitly before running Sentaurus Topography. Depending on your platform, the appropriate path must be used. The definition for Linux is:

```
setenv LD_LIBRARY_PATH ${STROOT}/tcad/${STRELEASE}/linux/lib/deviselib
```

4. Run Sentaurus Topography in the debugger. Here, again, the Linux version is used:

```
ddd ${STROOT}/tcad/${STRELEASE}/linux/bin/sptopo
```

5. Set the command-line arguments for Sentaurus Topography:

```
set args pmi_depo_rate_simple.cmd
```

6. Start Sentaurus Topography and interrupt the execution as soon as the message “interrupt, set breakpoint, and continue” appears in the output:

```
r
i
```

7. Set a breakpoint, for example, in the first line of `calculate_rate()`:

```
b Pmi_depo_rate_simple.cc:43
```

8. Continue the execution:

```
c
```

9. Debug your code as usual.

7: Physical Model Interface for Deposition and Etching

Input and Output Parameters for Deposition Models

Steps 6, 7, and 8 for setting the breakpoint must be repeated each time the PMI model is used. For other platforms or debuggers, it may be possible to set breakpoints in shared libraries before these libraries are loaded.

Input and Output Parameters for Deposition Models

This section describes the input and output parameters available to a PMI-based deposition model through the interface. These parameters are sufficient to develop a wide range of deposition models.

The following input data is available from an object derived from `Pmi_depo_param` for model initialization and rate calculation:

- Ten generic character parameters from the command file.
- Ten generic logical parameters from the command file.
- Ten generic numeric parameters from the command file.
- Array of coordinates of surface vertices.

The following input data is available from an object derived from `Pmi_depo_param` for rate calculation:

- Size of the previous time step.
- Whether an arbitrary point lies inside the narrow band.
- Level-set function for points in the narrow band.
- Derivatives of the level-set function in the x- and y-direction for points in the narrow band.
- Curvature of the level-set function for points in the narrow band.

The output parameter for rate calculation is an array containing the deposition rate at each surface vertex.

Example Model for Deposition

This example demonstrates how to create a PMI-based deposition model for isotropic deposition. The parameter `numeric_param_0` of the `machdepo` command is interpreted as the deposition rate by the model and is stored as a data member of the derived class.

The source files and a command file are available in the directory `${STROOT}/tcad/${STRELEASE}/lib/sptopo/src/pmi_depo_rate_simple`.

Pmi_depo_rate_simple.hh

```
// -*- C++ -*-  
  
//-----  
#ifndef PMI_DEPO_RATE_SIMPLE_HH  
#define PMI_DEPO_RATE_SIMPLE_HH  
  
//-----  
#include "Pmi_depo_rate.hh"  
  
//-----  
namespace sptopo {  
  
//-----  
/**  
 * @brief Concrete class derived from @c Pmi_depo_rate for isotropic  
 * deposition.  
 *  
 * @invariant  
 * @li @c 0 @c <= @c rate_m  
 *  
 * $Revision: #1 $  
 */  
class Pmi_depo_rate_simple : public Pmi_depo_rate {  
public:  
    // basic queries -----  
  
    // derived queries -----  
  
    // creation commands -----  
  
    /**  
     * @brief Constructor.  
     */  
    Pmi_depo_rate_simple(  
        Pmi_depo_param const& param);  
  
    // other commands -----  
  
    /**  
     * @brief Calculates the rates at the surface.  
     *  
     * @par Requires:  
     * @li @c 0 @c != @c rate  
     * @li @c 0 @c < @c param.size_surface()  
     *  
     */
```

7: Physical Model Interface for Deposition and Etching

Example Model for Deposition

```
* @par Modifies:
* @li @c rate
*
* @par Effects:
* Calculates the deposition rate for every vertex of the exposed surface
* and stores the rate in @a rate. @a param stores the command file
* parameters and the current exposed surface. Returns @c true on
* success.
*
* @note Any exception thrown in @c calculate_rate() or any functions
* called from it must be caught to avoid an abort. A failure has to be
* signaled by the return value @c false, which causes the simulation to
* stop in a controlled way.
*
* @note @a param is only guaranteed to be valid during the duration of
* the call of @c calculate_rate().
*
* @li @c 0 @c <= @c i @c < @c param.size_surface()_vert:
*   @c 0.0 @c <= @c rate[i]
*/
virtual
bool
calculate_rate(
    double* rate,
    Pmi_depo_param const& param);

// -----

private:
    /**
     * @brief Deposition rate.
     */
    double const rate_m;
};

//-----

}

//-----

#endif // PMI_DEPO_RATE_SIMPLE_HH
```

Pmi_depo_rate_simple.cc

```
// -*- C++ -*-
//-----
#include "Pmi_depo_rate_simple.hh"
#include "Pmi_depo_param.hh"

#include <cassert>
#include <vector>

// basic queries -----
// derived queries -----
// creation commands -----

sptopo::Pmi_depo_rate_simple::Pmi_depo_rate_simple(
    Pmi_depo_param const& param)
    : Pmi_depo_rate(),
      rate_m(param.numeric_param(0))
{
    assert(0.0 <= rate_m);
}

// other commands -----

bool
sptopo::Pmi_depo_rate_simple::calculate_rate(
    double* rate,
    Pmi_depo_param const& param)
{
    int const ss = param.size_surface();

    for (int i = 0; i < ss; i++) {
        rate[i] = rate_m;
        assert(0.0 <= rate[i]); // postcondition
    }

    return true;
}

//-----

sptopo::Pmi_depo_rate*
sptopo::pmi_depo_rate_factory(
    Pmi_depo_param const& param)
{
    try {
        return new Pmi_depo_rate_simple(param);
    }
}
```

7: Physical Model Interface for Deposition and Etching

Command File Interface for Etching Models

```
        catch (...) {
            param.message(Pmi_depo_param::low,
                "initialization of Pmi_depo_rate_simple failed\n");
            return 0;
        }
    }
}

//-----

void
sptopo::pmi_depo_rate_delete(
    Pmi_depo_rate* model)
{
    delete model;
}

//-----
```

Command File Interface for Etching Models

To use a PMI-based etching machine, the model named `pmi` is specified with the `machetch` command. The parameters `model` and `path` are used to specify the name of the shared library and a search path for the shared library, respectively.

Similar to most etching models, the `machetch` command for the `pmi` model has a material-independent and a material-dependent form. The material-independent form is used to create a new machine and to define the material-independent parameters of this machine. The material-dependent form is used to add material-specific parameters to an existing machine.

Material-Independent Form of `machetch`

The parameters `model` and `path` specify the name and a search path for the shared library, respectively. In addition, the material-independent form of the `machetch` command for the `pmi` model has ten generic character, logical, and numeric parameters. The developer of a PMI-based model is free to define the meaning of these parameters in the model.

Due to limitations of the parser of Sentaurus Topography, the names of these parameters are fixed and cannot be changed by the developer of a PMI-based etching model. The parameters are named `character_param_[0-9]`, `logical_param_[0-9]`, and `numeric_param_[0-9]`:

```
machetch pmi name=<c> model=<c> path=<c> [character_param_x=<c>]
        [logical_param_x] [numeric_param_x=<n>] [tilt=<n>]
```

Material-Dependent Form of machetch

The material-dependent form of the `machetch` command has the parameter `material` that specifies the material for which the properties are defined and the parameter `name` that specifies to which machine these properties will be added. In addition, there are ten generic character, logical, and numeric parameters. The developer of a PMI-based model is free to define the meaning of these parameters in the model.

Due to limitations of the parser of Sentaurus Topography, the names of these parameters are fixed and cannot be changed by the developer of a PMI-based etching model. The parameters are named `character_param_[0-9]`, `logical_param_[0-9]`, and `numeric_param_[0-9]`:

```
machetch name=<c> material=<c> [character_param_x=<c>] [logical_param_x]
      [numeric_param_x=<n>]
```

NOTE The names of the generic parameters of the material-independent and the material-dependent forms are identical, but the parameters are independent of each other.

Defining a PMI-Based Etching Machine

The following example shows the definition of an etching machine that uses a PMI-based model named `Pmi_etch_rate_simple` (see [Pmi_etch_rate_simple.cc on page 138](#) for the code of this model). The shared library for this model is located in the current working directory. One material-dependent numeric parameter is specified for two different materials, which is interpreted as the etching rate by `Pmi_etch_rate_simple`:

```
machetch pmi name=m1 model=Pmi_etch_rate_simple
machetch name=m1 material=Silicon numeric_param_0=0.1
machetch name=m1 material=Oxide numeric_param_0=0.05
```

C++ Interface for Etching Models

At the C++ level, the structure of the PMI for etching models is analogous to the PMI for deposition models. For a detailed description, see [C++ Interface for Deposition Models on page 122](#) and replace `depo` with `etch` in the names of all classes and functions.

Structure and Surface Material Information

In contrast to deposition models, the knowledge of the material at each vertex of the current surface is required for etching models. Therefore, `Pmi_etch_param` contains information about all the materials of the input structure and the materials at each vertex of the current surface. Together with the material-dependent parameters, this information allows you to calculate material-specific etching rates.

The array of materials contains the names of all materials in the input structure and is valid for the entire duration of the etching simulation.

The information about the material at each surface vertex is stored in a second array. For each surface vertex, this array contains an index into the array of materials. This array will change at every time step. Figure 19 illustrates this with a simple example.




Figure 19 Structure and surface material information for a structure consisting of three materials and a surface with 10 vertices: the material is “Nitride” at the first six surface vertices and “Oxide” at the remaining four surface vertices

Material Interfaces

In general, for etching models, special treatment of material interfaces is necessary. Therefore, the PMI for etching models must be able to report that a surface vertex is located at the interface of two or more materials.

If a surface vertex is located at a material interface, the corresponding entry in the array of material indices is negative, and the absolute value gives the index to a special entry in the array of material indices. This entry starts with the number of materials forming the interface and is

followed by the indices into the array of materials of the input structure. Figure 20 illustrates this with a simple example.




Figure 20 Structure and surface material information for a structure consisting of three materials and a surface with 10 vertices: the surface vertex at index 3 lies on the interface between the materials "Nitride" and "Silicon"

Input and Output Parameters for Etching Models

This section describes the input and output parameters available through the interface.

The following input data is available from an object derived from `Pmi_etch_param` for model initialization and rate calculation:

- Ten generic character parameters from the command file specified with the material-independent form of the `machetch` command.
- Ten generic logical parameters from the command file specified with the material-independent form of the `machetch` command.
- Ten generic numeric parameters from the command file specified with the material-independent form of the `machetch` command.
- Array of the materials defined with the material-dependent form of the `machetch` command. Each entry contains the name of the material and:
 - Ten generic character parameters from the command file specified with the material-dependent form of the `machetch` command.

7: Physical Model Interface for Deposition and Etching

Example Model for Etching

- Ten generic logical parameters from the command file specified with the material-dependent form of the `machetch` command.
- Ten generic numeric parameters from the command file specified with the material-dependent form of the `machetch` command.
- Array of all materials of the input structure.
- Array of coordinates of surface vertices.
- Array of indices into the array of materials for surface vertices.

The following input data is available from an object derived from `Pmi_etch_param` for rate calculation:

- Size of the previous time step.
- Whether an arbitrary point lies inside the narrow band.
- Level-set function for points in the narrow band.
- Derivatives of the level-set function in the x- and y-direction for points in the narrow band.
- Curvature of the level-set function for points in the narrow band.

The output parameter for rate calculation is an array containing the etching rate at each surface vertex.

Example Model for Etching

This example demonstrates how to create a PMI-based etching model for isotropic etching. The parameter `numeric_param_0` of the material-dependent `machetch` command is interpreted as the etching rate by the model and is stored as a data member of the derived class.

Pmi_etch_rate_simple.hh

```
// -*- C++ -*-  
  
//-----  
#ifndef PMI_ETCH_RATE_SIMPLE_HH  
#define PMI_ETCH_RATE_SIMPLE_HH  
  
//-----  
#include "Pmi_etch_rate.hh"  
#include <vector>  
  
//-----  
namespace sptopo {
```

```
//-----
/**
 * @brief Concrete class derived from @c Pmi_etch_rate for isotropic etching.
 *
 * The material-dependent numeric_param_0 is interpreted as the isotropic
 * etching rate. For consistency with non-PMI etching models, the isotropic
 * etching rate specified by the user must be nonnegative.
 *
 * @note: The etching rates calculated by calculate_rate() for each surface
 * vertex must be less than or equal to zero.
 *
 * @invariant
 * @li @c 0 @c <= @c mat_rate_m[i]
 *
 * $Revision: 1.5 $
 */
class Pmi_etch_rate_simple : public Pmi_etch_rate {
public:
    // basic queries -----

    // derived queries -----

    // creation commands -----

    /**
     * @brief Constructor.
     */
    Pmi_etch_rate_simple(
        Pmi_etch_param const& param);

    // other commands -----

    /**
     * @brief Calculates the rates at the surface.
     *
     * @par Requires:
     * @li @c 0 @c != @c rate
     * @li @c 0 @c < @c param.size_surface()
     *
     * @par Modifies:
     * @li @c rate
     *
     * @par Effects:
     * Calculates the etching rate for every vertex of the exposed surface
     * and stores the rate in @a rate. @a param stores the command file
     * parameters and the current exposed surface. Returns @c true on
     * success.
     */
}
```

7: Physical Model Interface for Deposition and Etching

Example Model for Etching

```
* @note Any exception thrown in @c calculate_rate() or any functions
* called from it must be caught to avoid an abort. A failure has to be
* signaled by the return value @c false, which causes the simulation to
* stop in a controlled way.
*
* @note @a param is only guaranteed to be valid during the duration of
* the call of @c calculate_rate().
*
* @li @c 0 @c <= @c i @c < @c param.size_surface()_vert:
*     @c rate[i] @c <= @c 0.0
*/
virtual
bool
calculate_rate(
    double* rate,
    Pmi_etch_param const& param);

// -----

private:
    /**
     * @brief Material dependent etching rate.
     */
    std::vector<double> mat_rate_m;
};

//-----
}

//-----

#endif // PMI_ETCH_RATE_SIMPLE_HH
```

Pmi_etch_rate_simple.cc

```
// -*- C++ -*-

//-----

#include "Pmi_etch_rate_simple.hh"
#include "Pmi_etch_param.hh"

#include <cassert>
#include <string>

// basic queries -----
// derived queries -----
// creation commands -----
```



```

sptopo::Pmi_etch_rate_simple::Pmi_etch_rate_simple(
    Pmi_etch_param const& param)
    : Pmi_etch_rate()
{
    int const ssm = param.size_structure_material();

    // Initialize the material-dependent etching rate for all structure
    // materials with 0.
    mat_rate_m.resize(ssm, 0.0);
    int const smm = param.size_machine_material();
    for (int i = 0; i < smm; i++) {
        std::string machine_material(param.machine_material(i));
        int str_mat_idx = -1;
        for (int j = 0; j < ssm; j++) {
            if (machine_material == param.structure_material(j)) {
                str_mat_idx = j;
                break;
            }
        }
        if (-1 < str_mat_idx) {
            mat_rate_m[str_mat_idx] = param.numeric_param(i, 0);
            assert(0.0 <= mat_rate_m[str_mat_idx]);
        } else {
            // The current machine material is not a structure material.
            // Therefore, it can be ignored.
        }
    }
}

// other commands -----

bool
sptopo::Pmi_etch_rate_simple::calculate_rate(
    double* rate,
    Pmi_etch_param const& param)
{
    int const ss = param.size_surface();
    int const* surface_mat_idx = param.surface_mat_idx();
    for (int i = 0; i < ss; i++) {
        // Determine the surface material for the i-th vertex.
        int smi = surface_mat_idx[i];
        if (smi < 0) {
            // The vertex lies on a material interface. Search for the
            // interface material with the maximum absolute rate.
            int const num_int_mat = surface_mat_idx[-smi];
            int const first_int_mat_idx = -smi + 1;
            int const end = first_int_mat_idx + num_int_mat;

            smi = surface_mat_idx[first_int_mat_idx];
        }
    }
}

```

7: Physical Model Interface for Deposition and Etching

Example Model for Etching

```
        double r = mat_rate_m[smi];
        for (int j = first_int_mat_idx + 1; j < end; j++) {
            if (r < mat_rate_m[surface_mat_idx[j]]) {
                r = mat_rate_m[surface_mat_idx[j]];
                smi = surface_mat_idx[j];
            }
        }
    }

    // Calculate the etching rate for the i-th vertex. In this simple
    // model, the etching rate is given by the negative value of the
    // material-dependent etching rate specified by the user.
    rate[i] = -mat_rate_m[smi];
    assert(rate[i] <= 0.0); // postcondition
}
return true;
}

//-----
sptopo::Pmi_etch_rate*
sptopo::pmi_etch_rate_factory(
    Pmi_etch_param const& param)
{
    try {
        return new Pmi_etch_rate_simple(param);
    }
    catch (...) {
        param.message(Pmi_etch_param::low,
            "initialization of Pmi_etch_rate_simple failed\n");
        return 0;
    }
}

//-----
void
sptopo::pmi_etch_rate_delete(
    Pmi_etch_rate* model)
{
    delete model;
}

//-----
```

Command File Interface for Simultaneous Etching and Deposition Models

The command file interface for the PMI for simultaneous etching and deposition is the same as for the PMI for etching, except for the additional parameter `depomaterial` in the material-independent form of the `machetch` command. The parameter `depomaterial` specifies the material of a new region that is created by deposition.

NOTE The PMI for simultaneous etching and deposition is used only if the parameter `depomaterial` of the material-independent form of the `machetch` command is used. Otherwise, the PMI for etching is used, for which the names of the classes and free functions are different.

C++ Interface for Simultaneous Etching and Deposition Models

At the C++ level, the structure of the PMI for simultaneous etching and deposition is analogous to the PMI for etching. For a detailed description, see [C++ Interface for Etching Models on page 133](#) and replace `etch` with `etch_depo` in the names of all classes and functions.

Input and Output Parameters for Simultaneous Etching and Deposition Models

The input data available from an object derived from `Pmi_etch_depo_param` includes all input data available from `Pmi_etch_param`. In addition, the indices of the deposited material and of `Gas` in the list of structure materials are available.

The output parameter for the rate calculation is an array containing the etching or deposition rate at each vertex. Positive values correspond to deposition and negative values correspond to etching.

7: Physical Model Interface for Deposition and Etching

Command File Interface for Simultaneous Etching and Deposition Models

CHAPTER 8 **Deposition Examples**

This chapter illustrates the deposition capabilities of Sentaurus Topography with some typical examples.

The first two examples show the coordinate and planar modes of deposition, which are used to create initial structures, while the remaining examples demonstrate the use of Sentaurus Topography to simulate different deposition processes: isotropic (conformal), physical vapor deposition (PVD), low-pressure chemical vapor deposition (LPCVD), plasma-enhanced chemical vapor deposition (PECVD), high-density plasma (HDP) deposition, reflow, and spin-on-glass (SOG).

Coordinate Deposition

The input commands in the file `spt_depo_ex01.cmd` shown here define a basic structure for coordinate deposition of a material layer:

```
# Coordinate depo simulation (with an external profile)
# Example: spt_depo_ex01.cmd

# Initialization
initialize width=1.0 height=0.3

# Planar deposition of PolySilicon layer
deposit material=PolySilicon thickness=0.2

# Coordinate depo using an existing string data
deposit material=Resist file=spt_depo_ex01_inp.data
```

8: Deposition Examples

Coordinate Deposition




Figure 21 Coordinate deposition using an external geometry profile: (*left*) initial structure and (*right*) structure after coordinate deposition. The dashed line depicts the polygon used for the deposition.

See [Coordinate Deposition \(Using an External Profile\)](#) on page 66 for a detailed description of this mode of deposition and the parameters used. A geometry profile is created using the profile from the file `spt_depo_ex01_inp.data` shown here:

```
-0.1  1.0
0.2   1.0
0.3   0.2
0.7   0.2
0.8   1.0
1.1   1.0
```

The coordinates in the profile file are given in the Sentaurus Topography coordinate system (with the positive y-direction pointing upwards).

This coordinate deposition method is an easy way to build a customized initial profile. In [Chapter 9 on page 161](#), more examples are given illustrating the use of this method.

Planar Deposition (With a Specified Thickness at a Given X-Location)

The input commands in the file `spt_depo_ex02.cmd` shown below illustrate the planar mode of deposition (at a given x-location) using Sentaurus Topography. See [Planar Deposition on page 65](#) for a detailed description of this mode of deposition and the parameters used:

```
# 2D planar depo simulation (at given x location)
# Example: spt_depo_ex02.cmd

# Initialization with existing structure
initialize file=spt_depo_ex02_inp

# Planar deposition with a thickness at a given x location
deposit material=Nitride thickness=0.2 xloc=0.5
```




Figure 22 Planar deposition of polysilicon with a specified thickness at a given x-location: (*left*) initial structure before deposition and (*right*) structure after deposition. The initial structure also shows where `xloc` and thickness are applied.

An initial structure in TDR format is first read and the planar deposition of nitride with the specified thickness is performed at the specified x-location using the parameter `xloc`. See [Planar Deposition on page 65](#) for detailed descriptions of this mode of deposition.

8: Deposition Examples

Isotropic (Conformal) Deposition

Isotropic (Conformal) Deposition

The input commands in the file `spt_depo_ex03.cmd` shown here define a basic structure for the deposition of a conformal (isotropic) deposition layer:

```
# Simple (isotropic) conformal deposition
# Example spt_depo_ex03.cmd

# Initialization
initialize width=3 height=0.5 material=Silicon

# Planar layer deposition and ideal masked etch
deposit material=Oxide thickness=0.5
mask name=Mask1 s0=1 e0=2
etch material=Oxide mask=Mask1

# Define a new deposition machine
machdepo material=Nitride name=Conformal_depo rate=1

# Deposit by using a machine
deposit machname=Conformal_depo time=0.6 dx=0.05 dy=0.05 dtplot=0.2
```

The `machdepo` command defines a new deposition machine `Conformal_depo`. A deposition machine of type `isotropic` is selected by default. This machine requires the parameter `rate` to be specified. See [Isotropic Deposition Model on page 19](#) and [machdepo on page 84](#) for detailed descriptions of this parameter.

The `deposit` command that follows the `machdepo` command specifies a total simulation time of 0.6 minutes and a plotting time interval of 0.2 minutes. The level-set grid size in both directions is set to 0.05 μm for greater accuracy. The degree of conformality of the deposited profile can be judged by analyzing the output results.

Two of the results output by Sentaurus Topography are shown in [Figure 23](#) for the simulation times 0.2 and 0.6 minutes.




Figure 23 Profile evolution at (*left*) 0.2 minutes and (*right*) 0.6 minutes for `spt_depo_ex03.cmd`

To create these plots, Sentaurus Topography creates intermediate TDR files following the naming convention explained in [Boundary Output Files: <basename>.tdr](#) on page 50. The output files are called:

- spt_depo_ex03_006_depo_001.tdr
- spt_depo_ex03_006_depo_002.tdr
- spt_depo_ex03_006_depo_003.tdr

Curvature-Dependent Deposition

This example illustrates the use of the curvature-dependent deposition in Sentaurus Topography. This model simulates boron silicate glass (BSG) or similar deposition processes that show flow-shape behavior or processes in which the local deposition rate has strong dependency on surface stress and curvature:

```
# Curvature-dependent deposition simulation
# Example spt_depo_ex04.cmd

# Initialization
initialize file=spt_depo_ex04_inp

# A new (curvdepo) deposition machine for a new material
machdepo isotropic name=CurvDepo material=Oxide rate=0.5 kcurv=0.02

# Deposit using a defined (curvdepo) machine
deposit machname=CurvDepo time=0.5 dx=0.01 dy=0.01 dtmax=0.01 dtplot=0.05
```

An existing structure as shown in [Figure 24](#) is used to demonstrate the curvature-dependent deposition process.




Figure 24 Time evolution of curvature-dependent deposition; the evolution of the surface is shown in steps of 3 seconds

8: Deposition Examples

Physical Vapor Deposition

A new deposition machine named `Curv_depo` is defined in the `machdepo` command. Although the machine type is the default type (`isotropic`) as in the previous example, the parameter of `kcurv` defines the curvature dependency of this deposition process. See [Isotropic Deposition Model on page 19](#) and [machdepo on page 84](#) for detailed descriptions of these parameters.

This deposition machine `Curv_depo` is used in the `deposit` command. The level-set grid size in both directions is set to $0.01\ \mu\text{m}$ and the value of `dtmax` is set to 0.01 for greater accuracy. In [Figure 24](#), the profile evolution is shown in steps of 3 seconds. The deposition shows a flow-shape behavior, especially at sharp surface corners. In the final structure, the overhang structure (the cavity) is filled completely, leaving no voids. This type of deposition process has stronger gap-fill capability than conformal deposition processes.

Physical Vapor Deposition

This example illustrates the use of the physical vapor deposition (PVD) model in Sentaurus Topography. The input file (`spt_depo_ex05.cmd`) is:

```
# PVD deposition model
# Example: spt_depo_ex05.cmd

# Initialization
initialize file=spt_depo_ex05_init tdr

# Define a new deposition machine
machdepo pvd material=Nitride name=Pvd_depo rate=1 exponent=1

# Deposit by using a machine
deposit machname=Pvd_depo time=1.2 dx=0.01 dy=0.01 dtmax=0.05 dtplot=0.5
```




Figure 25 Physical vapor deposition model: (*left*) initial structure, (*middle*) profile evolution at 0.5 minutes, and (*right*) profile evolution at 1 minute

A new deposition machine named `Pvd_depo` is defined in the `machdepo` command. See [Physical Vapor Deposition Model on page 19](#) and [machdepo on page 84](#) for a description of this model and its parameters. The `deposit` command uses the level-set grid size in both directions of 0.01 μm for greater accuracy. The deposition profile is controlled by the incoming angular distribution of the ions (characterized by the parameter `exponent`, which remains at the default value of 1, corresponding to isotropic distribution of the ions) and the geometric shadowing effect.

[Figure 25 on page 148](#) shows the profile evolution at 0.5 minutes and 1 minute; the deposited thickness at the bottom of the trench does not change significantly with time due to the shadowing effect.

Low-Pressure Chemical Vapor Deposition

Low-pressure chemical vapor deposition (LPCVD) of silicon dioxide is a key process in integrated circuit manufacturing. Most conditions of oxide deposition are accurately simulated with the reemission model implemented for the machine types `lpcvd` and `hdp`.

The input file (`spt_depo_ex06.cmd`) is:

```
# LPCVD deposition using reemission model in a trench
# (aspect ratio=0.7)
# Example: spt_depo_ex06.cmd

# Simple initialization
initialize file=spt_depo_ex06_init

# Define a new deposition machine
machdepo lpcvd material=BSG name=LPCVD_depo rate=1.0 sc=0.35

# Deposit by using a machine
deposit machname=LPCVD_depo dx=0.025 dy=0.025 time=0.8 dtplot=0.2

extract material=BSG xlayer=1 ylayer=0.7 thickness xcut=1.0
```

This input file illustrates the use of the machine type `lpcvd` and the reemission model for low-pressure chemical vapor deposition modeling of boron silicate glass (BSG). The input file (`spt_depo_ex06.cmd`) creates a trench of a 0.7 aspect ratio (defined here as the ratio of the height to the width of the trench). Another input file (`spt_depo_ex06a.cmd`) using the same settings as `spt_depo_ex06.cmd` shows the results on a trench with a different aspect ratio (1.2).

In both these input files, the new deposition machine of type `lpcvd` is defined to utilize a reemission model when calculating the total deposition rate at every point of the structure. The

8: Deposition Examples

Low-Pressure Chemical Vapor Deposition

most important parameters necessary to characterize a deposition process of this type are the deposition rate and the sticking coefficient of the deposition precursors (the parameters `rate` and `sc`, respectively). See [Low-Pressure Chemical Vapor Deposition Model on page 21](#) for a description of this model and [machdepo on page 84](#) for a description of the parameters of this model.

The sticking coefficient is a key parameter that controls conformality in deposition processes. Better step coverages are obtained with smaller sticking coefficients. Typical values of this parameter for low-pressure chemical vapor deposition of silicon dioxide range from 0.01 to 0.4, depending on the chemical precursors and process conditions such as pressure, temperature, and flow rates.

Values for silane-based chemistries range from 0.3 to 0.4. For diethoxysilane (DES)-based chemistries, the values are approximately 0.1; for tetraethoxysilane (TEOS)-based chemistries, the values are usually below 0.05.




Figure 26 Profile evolution at (*left*) 0.4 minutes and (*right*) 0.8 minutes for `spt_depo_ex06.cmd` (aspect ratio 0.7)

The `deposit` command uses the level-set grid size in both directions of $0.025\ \mu\text{m}$ for greater accuracy. In [Figure 26](#), the profile evolution is shown at 0.4 and 0.8 minutes.




Figure 27 Profile evolution at (*left*) 0.4 minutes and (*right*) 0.8 minutes for `spt_depo_ex06a.cmd` (aspect ratio 1.2)

The results obtained with the example file `spt_depo_ex06a.cmd` are shown in [Figure 27 on page 150](#) at two different times, 0.4 and 0.8 minutes.

For exactly the same process conditions, in this example, it is important to observe the difference in step coverages at the same time intervals for the two different trenches. These differences are the result of different shadowing in both cases. Therefore, using the `extract` command, the deposited thickness of BSG at the center point of the trench ($x=1$) with an aspect ratio of 0.7 is $0.43\ \mu\text{m}$, while in the case of a trench with an aspect ratio of 1.2, the deposited thickness is $0.3\ \mu\text{m}$.

Plasma-Enhanced Chemical Vapor Deposition

Plasma-enhanced chemical vapor deposition (PECVD) is a very important process for dielectric deposition in integrated circuit manufacturing. As described in [Plasma-Enhanced Chemical Vapor Deposition Model on page 21](#), the PECVD simulation model included in Sentaurus Topography considers two important deposition components in the process:

- Conformal thermal CVD
- Directional ion-induced deposition

In this example, Sentaurus Topography is used to perform a PECVD simulation on a trench with an aspect ratio of 1.25:

```
# PECVD deposition with void formation
# Example: spt_depo_ex07.cmd

# Initialization
initialize file=spt_depo_ex07_init

# A new (pecvd) deposition machine
machdepo pecvd name=Pecvd_depo material=Nitride rate=1.0 sc=0.05
+ anisotropy=0.6 exponent=30

# Deposit using a defined (pecvd) machine
deposit machname=Pecvd_depo time=0.6 dtmax=0.02 dx=0.01 dy=0.01
```

This input file (`spt_depo_ex07.cmd`) illustrates the use of the machine type `pecvd` and the simulation parameters for the PECVD model. It first creates an initial structure (a trench of 1.25 aspect ratio with a vertical sidewall by ideal masked etch) and then performs PECVD for 0.6 minutes.

The most notable aspect of this example is the definition of simulation parameters, including `rate`, `sc`, `exponent`, and `anisotropy`, in the `machdepo` command. This command defines a new machine of the type `pecvd` for the material `Nitride`. The `rate` defines the total deposition rate of both components. The parameter `anisotropy` defines the ratio of the

8: Deposition Examples

Plasma-Enhanced Chemical Vapor Deposition

directional deposition rate to the total rate, sc defines the sticking coefficient of the thermal CVD component, and $exponent$ characterizes the directionality of the ion-induced deposition component. See [Plasma-Enhanced Chemical Vapor Deposition Model on page 21](#) for the description of this model and [machdepo on page 84](#) for the description of the parameters of this model.

The newly defined deposition machine named `pecvd_depo` is used in the `deposit` command. The level-set grid size in both directions is set to $0.01\ \mu\text{m}$ for greater accuracy.




Figure 28 Profile after (*left*) 0.02 minutes and (*right*) at 0.2 minutes for `spt_depo_ex07.cmd`

[Figure 28](#) (*left* and *right*) shows the profile of the structure after 0.02 and 0.2 minutes, respectively. In [Figure 29](#), the profile evolution is shown at 0.4 and 0.6 minutes.




Figure 29 Deposition profile at (*left*) 0.4 minutes and (*right*) 0.6 minutes for `spt_depo_ex07.cmd`

It is important to observe that (as shown in [Figure 29](#) (*right*)) a void is formed in the trench, and the top closes as the deposition continues. If SEM pictures of experimental PECVD results are available, simulation parameters are obtained by adjusting them and matching the simulations to the experimental results. This process is completed quickly, and the parameters offer a good interpretation of the process conditions.

High-Density Plasma Deposition

This example illustrates the use of the high-density plasma (HDP) deposition model implemented in Sentaurus Topography. The complete list of Sentaurus Topography commands for the first part of this example is shown here:

```
# High-density plasma deposition (no redeposition)
# Example: spt_depo_ex08.cmd

# Initialization
initialize file=spt_depo_ex08_init tdr

# Define a new deposition machine
machdepo hdp material=BSG name=HDP_depo rate=1.3 millrate=0.95 anisotropy=0.7
+ exponent=100

# Deposit by using the machine
deposit machname=HDP_depo dx=0.01 dy=0.01 dtmax=0.002 time=1.0
```

A mask is defined with two trenches separated by a distance equal to the trench width. The purpose of such an initial structure is to demonstrate one of the key mechanisms that contributes to the self-planarization characteristics of HDP deposition systems: the collision of two stable fronts to form a stationary cusp, as shown in the resulting output (see [Figure 30 on page 154](#) to [Figure 33 on page 155](#)).

Competing Deposition and Etching Effects

High-density plasma deposition processes involve competitive deposition and etching effects. The physical and chemical mechanisms involved require a large number of processes to be modeled. As a result, the final topography has a broad range of shapes, from PECVD-like profiles (with more or less uniform thickness in vertical walls) to stationary facets. The HDP model implemented in Sentaurus Topography simulates all these effects.

See [High-Density Plasma Deposition Model on page 22](#) for the description of this model and [machdepo on page 84](#) for the description of the parameters of this model.

The `machdepo` command in the file `spt_depo_ex08.cmd` defines a net deposition rate of $0.35 \mu\text{m}/\text{minute}$. (This value results from the subtraction of the `millrate` parameter from the `rate` parameter.) In addition, an `anisotropy` of 0.7 indicates that the total deposition rate on a flat surface is 70%, due to an ion-enhanced deposition mechanism, and 30% thermal deposition contribution. The default value of `sc` ($= 0$) results in isotropic deposition for the thermal deposition contribution.

8: Deposition Examples

High-Density Plasma Deposition

For this example, it is assumed that all material sputtered from the surface is lost and does not stick to any point on the surface. This is because the `redepratio` parameter has been set to the default value of zero.

Default values for the parameters `sputc1`, `sputc2`, and `sputc4` are used for the angular dependence of the yield.

The only difference between the files `spt_depo_ex08.cmd` and `spt_depo_ex08a.cmd` is that the redeposition ratio has been defined as 0.5 in the second file. This is indicated in the `machdepo` command shown here:

```
# Define a new deposition machine
machdepo material=BSG name=HDP_depo hdp rate=1.3 millrate=0.95 anisotropy=0.7
+ redepratio=0.5 exponent=100
```

Comparative Simulation Results at Selected Intervals

The results of the simulations for these two cases are shown at different moments in time in [Figure 30](#) to [Figure 33 on page 155](#). For each figure, the left graphic shows the simulation results of 0% redeposition. This result is compared to the right graphic that includes 50% redeposition.

In [Figure 30](#) and [Figure 31](#), the times selected for comparison are 3 s and 12 s for the two cases, respectively. In [Figure 32](#) and [Figure 33](#), the results are shown for 39 s and 60 s, respectively. These different time intervals have been selected because they exhibit interesting feature formation.

At 3 s (see [Figure 30](#)), the slopes of the profiles deposited inside the trenches differ for the two cases due to the different value of the equilibrium between the deposition rate and etch rate. In the case of redeposition (*right*), more material is deposited compared to the case without redeposition (*left*), especially towards the bottom of the trench.




Figure 30 Profile evolutions after 3 s for (*left*) `spt_depo_ex08.cmd` and (*right*) `spt_depo_ex08a.cmd`

At 12 s (see [Figure 31](#)), the sloped profiles in the top of the pillar that separates the trenches merge and become stationary until the trenches are completely filled. The redeposition contribution in this region is smaller than inside the trench. As a result, the slope at the top does not greatly differ in either case. However, note that, in the case of redeposition (*right*), the trenches fill up faster than the trenches in the case of no redeposition (*left*) because of the contribution of redeposited material sputtered from the walls.




Figure 31 Profile evolutions after 12 s for (*left*) `spt_depo_ex08.cmd` and (*right*) `spt_depo_ex08a.cmd`

At 39 s (see [Figure 32](#)), the trenches in the case of redeposition (*right*) already fill up and the stationary front in the center pillar starts moving upwards, while the trenches in the case of no redeposition fill up at 60 s (see [Figure 33](#), *left*).




Figure 32 Profile evolutions after 39 s for (*left*) `spt_depo_ex08.cmd` and (*right*) `spt_depo_ex08a.cmd`




Figure 33 Profile evolutions after 60 s for (*left*) `spt_depo_ex08.cmd` and (*right*) `spt_depo_ex08a.cmd`

Reflow Simulation

Reflow is an important process in the semiconductor manufacturing industry. At high temperatures and under certain chemical and physical environments, the deposited thin film redistributes on the surface to improve the planarity characteristics of the film. This example uses the `reflow` model in Sentaurus Topography.

This model assumes a surface diffusion process driven by curvature effects such that convex corners act as sources of material and concave corners behave as sinks. In this way, material flows from convex regions to concave regions:

```
# Reflow simulation
# Example: spt_depo_ex10.cmd

# Initialization
initialize file=spt_depo_ex10_init tdr

# A new (lpcvd) deposition machine for a new material
machdepo lpcvd name=lpcvd_depo material=Nitride rate=0.5 sc=0.8

# Deposit using a defined (lpcvd) machine
deposit machname=lpcvd_depo time=0.6 dtmax=0.02 dx=0.04 dy=0.04 dtplot=0.1

# A new (reflow) deposition machine for a new material
machdepo reflow name=Reflow_depo material=Nitride rate=0.5 kcurv=0.05
+ georatio=0.9

# Deposit using a defined (reflow) machine
deposit machname=Reflow_depo material=Nitride time=0.8 dtmax=0.02 dx=0.02
+ dy=0.02 dtplot=0.1
```

This input file (`spt_depo_ex10.cmd`) first creates perfect trenches using an ideal masked etch. Subsequently, a layer of nitride is deposited onto the structure by an LPCVD machine, which is defined by the `machdepo` command. [Figure 34 \(left\)](#) shows the structure after the first plot step. The sticking coefficient for this LPCVD process is set to 0.8. [Figure 34 \(right\)](#) shows the profile of the structure after the LPCVD process.




Figure 34 Profile (*left*) after first plot step of LPCVD and (*right*) before reflow for `spt_depo_ex10.cmd`




Figure 35 Reflow profile at (*upper left*) 0.2, (*upper right*) 0.4, (*lower left*) 0.6, and (*lower right*) 0.8 minutes for `spt_depo_ex10.cmd`

A new deposition machine named `Reflow_depo` is defined in the `machdepo` command for the material `Nitride`. The machine type is `reflow`. See [Reflow Deposition Model on page 24](#) for a description of this model and [machdepo on page 84](#) for a description of the parameters of this model.

The parameter `kcurv` defines the curvature dependency of the reflow process, while `rate` characterizes the speed of the material flowing from a higher point to a lower point. The parameter `georatio` indicates the effect of the surface geometric feature on the planarization speed. In [Figure 35](#), the profile evolution is shown at 0.2, 0.4, 0.6, and 0.8 minutes. The final profile is fully planarized.

Full Spin-on-Glass

This example illustrates a key process called spin-on-glass (SOG), which is used to deposit silicon dioxide and low dielectric constant materials. To emulate this process, the example uses a three-subprocess sequence: conformal deposition, reflow, and shrinking. The conformal deposition usually shows obvious flow-shape and, therefore, is simulated with the curvature-dependent deposition model. The reflow process is simulated using the reflow model illustrated in [Reflow Simulation on page 156](#). The shrinking process is simulated assuming similar surface stress dependency. This example illustrates the use of the `fullsog` model in Sentaurus Topography.

The input file (`spt_depo_ex11.cmd`) creates the initial structure by an ideal masked etch:

```
# Full spin-on-glass (fullsog) simulation
# Example spt_depo_ex11.cmd

# Initialization
initialize file=spt_depo_ex11_init

# A new (fullsog) deposition machine for a new material
machdepo fullsog name=sog_depo material=Oxide sogreflow=0.5 initspin=0.5
+ shrinkage=0.2 sogxscale=0.5 georatio=0.5 kcurv=0.09

# Deposit using the defined (fullsog) machine
deposit machname=sog_depo time=0.6 dtmax=0.02 dx=0.04 dy=0.04 dtplot=0.06
```

The structure shown in [Figure 36](#) has a trench and a wide open space.




Figure 36 Profile (*upper left*) after first plotting step of conformal deposition, (*upper right*) at end of deposition, (*lower left*) at beginning of shrinking, and (*lower right*) at end of shrinking for `spt_depo_ex11.cmd`

A new deposition machine named `sog_depo` is defined in the `machdepo` command for the material `Nitride`. The machine type is `fullsog`. See [Spin-on-Glass Deposition Model on page 24](#) for a description of this model and [machdepo on page 84](#) for a description of the parameters of this model.

The parameter `initspin` defines the thickness of the initial (conformal) deposition, `sogreflow` represents the planarization speed of the reflow process, `kcurv` characterizes the effect of surface stress and the curvature dependency, and `georatio` is also the simulation parameter for reflow (see [Reflow Simulation on page 156](#) for details). The parameter `shrinkage` is the shrinking percentage of the film, and $(1 - \text{shrinkage})$ is the ratio of the final film thickness to the film thickness before shrinking. The parameter `sogxscale` specifies the effective range of the local shrinking process. A film close to a big trench (or cavity) tends to have higher shrinkage due to surface stress. This parameter is usually set to be the feature scale of the trench.

As noted, a full SOG process is approximated by three subprocesses: conformal deposition, reflow, and shrinking. [Figure 36 on page 158](#) (*upper left*) shows the profile after the initial deposition, but before reflow, while the lower-right figure shows the final profile after film shrinking. This example assumes a 20% shrinkage.

Simple Spin-on-Glass

The previous example illustrated the use of the full spin-on-glass (SOG) model. However, you can use a simple SOG model to approximate the SOG process. Instead of using three subprocesses (initial deposition, reflow, and shrinking), this model assumes perfect planar deposition followed by a shrinking process.

The input file (`spt_depo_ex12.cmd`) is:

```
# Simple spin-on-glass simulation
# Example: spt_depo_ex12.cmd

# Initialization using an existing structure
initialize file=spt_depo_ex12_init

# A new (simple sog) deposition machine for a new material
machdepo sog name=sog_depo material=Oxide initspin=0.45 shrinkage=0.25
+ sogxscale=0.7 kcurv=0.09

# Deposit using a defined (simple sog) machine
deposit machname=sog_depo time=1. dtmax=0.02 dx=0.02 dy=0.02 dtplot=0.1
```

8: Deposition Examples

Simple Spin-on-Glass

A new deposition machine named `sog_depo` is created in the `machdepo` command. In this case, the machine type is `sog`. See [Spin-on-Glass Deposition Model on page 24](#) for a description of this model and [machdepo on page 84](#) for a description of the parameters of this model. The parameters `initspin`, `shrinkage`, `kcurv`, and `sogxscale` are used.

[Figure 37](#) shows a complex initial profile. This is created in the `initialize` command using an existing structure `spt_depo_ex12_init.tdr`.




Figure 37 (Top) initial structure, (middle) after planarization, and (bottom) final profile after shrinking for `spt_depo_ex12.cmd`

[Figure 37 \(middle\)](#) shows the result of a perfect planar deposition process. The final film profile after shrinking is shown at the bottom. In this case, the example assumes a 25% shrinkage.

This chapter illustrates the plasma simulation and etching capabilities of Sentaurus Topography with some typical examples.

The first example illustrates the plasma modeling capabilities in Sentaurus Topography for calculating the angular distribution of the energetic particles. The next two examples show the geometric and coordinate mode of etching, used for creating initial structures and for cleaning up the final structures obtained from machine-based deposition and etching. The remaining examples demonstrate the use of Sentaurus Topography for simulating different etching processes: isotropic/anisotropic etch, hemispherical etch, ion-enhanced etch, ion-milling, reactive ion etch, high-density plasma etch, and chemical-mechanical polishing.

Plasma Example: Angular Distribution

This example illustrates the use of the Monte Carlo plasma sheath module available in Sentaurus Topography (see [Plasma Modeling on page 42](#) for a detailed description of this module and [plasma on page 101](#) for the parameters used).

This module calculates the angular distribution of energetic particles (both ions and neutrals) arriving at a wafer surface in capacitively coupled plasma discharge equipment. The distributions obtained are used to study profile evolution under ion-enhanced etching conditions, plasma-enhanced chemical vapor deposition, or high-density plasma deposition processes.

This example uses the following input files: `spt_plasmaex1.cmd`, `spt_plasmaex1a.cmd`, `spt_plasmaex1b.cmd`, and `spt_plasmaex1c.cmd`. They correspond to four different pressures 50, 150, 300, and 600 mTorr, respectively.

The purpose of these simulations is to study the change in the characteristics of the ion and energy distributions on the flat surface of a wafer in a capacitively coupled plasma discharge reactor at different pressures. The input file `spt_plasmaex1.cmd` is:

```
# Ion distribution at 50 mTorr
# Example: spt_plasmaex1.cmd

# Do a plasma simulation
plasma file=spt_plasmaex1_dis pressure=50 dcpot=50 acpot=55 dthickness=4
+ gasmass=55 ionmass=50 momentumxsect=8.E-20 numparticles=100000
```

9: Plasma and Etch Examples

Plasma Example: Angular Distribution

The simulation is activated with the `plasma` command. In the input file, parameters for which values are not explicitly specified are set to their default values. The `numparticles` parameter specifies the number of particles used for the Monte Carlo simulation (in this case, 100000). All the parameters refer to the physical characteristics of the discharge as explained in [Plasma Modeling on page 42](#). In this case, the simulation is performed at 50 mTorr.

The ion-angular distribution is saved in the file `spt_plasmaex1_dis.tdr`.

[Figure 38](#) shows the results obtained with the input files `spt_plasmaex1`, `spt_plasmaex1a`, `spt_plasmaex1b`, and `spt_plasmaex1c` at 50, 150, 300, and 600 mTorr, respectively. At the lowest pressure range, the angular distribution is highly peaked. With increased pressure, due to scattering mechanisms, the noncollisional peak is lowered towards larger angles. The angular spread has a strong influence on the conformality of the deposited profiles in PECVD systems and on the RIE lag effect in etching. See [Ion-Enhanced Etch Model: Sidewall Bowing and RIE Lag Effects on page 171](#) for an example.




Figure 38 Angular distributions at 50, 150, 300, and 600 mTorr

Geometric Etch

As described in [etch on page 68](#), Sentaurus Topography provides the geometric mode of etching where structures can be etched to a given depth (using the mask information if also specified). Layers of a specific material can also be etched to a given depth. This can be used to prepare initial structures for input to the machine deposition/etching or to perform cleanup tasks such as resist removal on the final structures (after the machine-based deposition/etching).

This example shows the various capabilities that this mode of etching provides. The result of each step is shown in [Figure 39 on page 164](#):

```
# Geometric etch
# Example: spt_etchex1.cmd

# Initialization with an existing structure
initialize file=spt_etchex1inp

# Etch the structure with a depth
etch depth=0.2
save file=structure_depth

# Etch the structure with a depth and a mask
mask name=Mask1 s0=0 e0=0.5
etch depth=0.5 mask=Mask1
save file=structure_depth_mask

# Etch a material with a depth and mask
mask name=Mask2 s0=0 e0=1.2
etch material=Nitride depth=0.5 mask=Mask2
save file=material_depth_mask

# Etch (remove) a material
etch material=Nitride
save file=material_remove

# Remove all the exposed material layers
etch
save file=allexposed_remove
```

In [Figure 39](#), the initial structure is shown in the upper left. The etching of this structure to a depth of 0.2 μm removes the exposed portion of this initial structure by this specified amount. This result is shown in the upper middle. In the next step, this structure is used as an initial structure to demonstrate the etching with a specified mask (Mask1) and depth (0.5 μm). Note that portions of both, the nitride (yellow) layer as well as the oxide (brown) layer not covered by the mask, are etched to the specified depth. The upper-right graphic shows the resulting structure. See [Geometric Etch a Structure by Depth on page 71](#) for a detailed description of this mode of etching and the parameters used.

9: Plasma and Etch Examples

Geometric Etch




Figure 39 Geometric etch: (*upper left*) Initial structure, (*upper middle*) structure etch with depth, (*upper right*) structure etch with mask and depth, (*lower left*) material etch with mask, (*lower middle*) material remove, and (*lower right*) complete removal of all exposed layers

The next step illustrates the etching of a specified material (nitride, in this case) with a specified mask (Mask2) to a given depth of $0.5\ \mu\text{m}$. As a result of this step, only the exposed portion of the nitride layer (not covered by the mask) is etched leaving the oxide untouched. The result is shown in the lower left. If no mask or depth is specified for material etching, Sentaurus Topography removes the exposed layer of this material. This is illustrated in the next step, where the exposed nitride layer from the previous step is removed as shown in the lower middle. Note that the oxide layer is untouched. See [Geometric Etch a Material on page 71](#) for a detailed description of this mode of etching and the parameters used.

In the last step, the `etch` command without any arguments removes all the exposed layers (the remaining oxide layer, in this case, leaving the substrate). This is shown in the lower right. See [Geometric Etch a Structure \(Remove All Exposed Layers\) on page 71](#) for a detailed description of this mode of etching and the parameters used.

Coordinate Etch

The input commands in the file `spt_etchex2.cmd` shown here define a basic structure for coordinate etching of a specified structure:

```
# Coordinate etch simulation (with an external profile)
# Example: spt_etchex2.cmd

# Initialization
initialize width=3.5 height=0.6

# Planar layer deposition of some materials
deposit material=Tantalum thickness=0.05
deposit material=Aluminum thickness=0.75
deposit material=Tantalum thickness=0.05
deposit material=Photoresist thickness=1.8

# Coordinate etch the structure using the external profile
etch file=spt_etchex2inp.data
```




Figure 40 Example showing (*left*) initial structure and (*right*) structure after coordinate etch

See [Coordinate Etch a Structure \(Using an External Profile\) on page 73](#) for a detailed description of this mode of etching and the parameters used.

Figure 40 shows the initial structure before coordinate etching. A geometry profile is created using the coordinates from the file `spt_etchex2inp.data`:

```
-0.1 1.3
0.5 1.3
0.7 3.3
1.2 3.3
```

9: Plasma and Etch Examples

Simple Etch Model: From Directional Etch to Isotropic Etch

```
1.4  1.3
2.1  1.3
2.3  3.3
2.8  3.3
3.0  1.3
3.6  1.3
```

The resulting structure after coordinate etching is shown in [Figure 40 on page 165](#). This coordinate etching method is an easy way to build a customized initial profile. In the following sections, more examples are presented illustrating the use of this method.

Simple Etch Model: From Directional Etch to Isotropic Etch

The simple etch model in Sentaurus Topography is used to simulate a wide variety of etch processes that render profiles from perfectly directional etch (dry etch mechanisms) to isotropic behavior (where the lateral etch is the same as the vertical etch rate). A series of input files is used to simulate different etch conditions.

The commands used for perfectly anisotropic behavior are shown here and correspond to those in example `spt_etchex3.cmd`:

```
# Perfectly anisotropic etch
# Example: spt_etchex3.cmd

# Initialization
initialize width=3 height=1

# Mask definition
mask name=Mask1 s0=1 e0=2

# Create initial structure
deposit material=Oxide thickness=0.5
etch material=Oxide mask=Mask1

# Define the simple etch machine
machetch name=Etcher1
machetch name=Etcher1 material=Silicon rate=1

# Do the etch operation using the defined machine
etch machname=Etcher1 time=0.6 dx=0.005 dy=0.005 dtplot=0.1
```




Figure 41 (Upper left) initial structure used to demonstrate (upper right) perfectly anisotropic etch to (lower left) isotropic/anisotropic etch to (lower right) perfectly isotropic etch

The first `etch` command is used to produce an ideal directional etch in the oxide layer by using a sequence of the geometric mode of etching in Sentaurus Topography. The structure in [Figure 41 \(upper left\)](#) is then used as the starting structure for the machine etch using the simple model as described below.

A new etch machine named `Etcher1` is defined in the `machetch` command using the default model (`simple`) of etching. See [Simple Etch Model on page 26](#) and [machetch on page 91](#) for detailed descriptions of these parameters. The `rate` is set to the value of 1 for silicon, and the `anisotropy` parameter value is set to the default value of unity. The etching rate for materials that were not added to the etch machine is zero.

The `etch` command that follows the `machetch` command specifies a total simulation time of 0.6 minutes and a plotting time interval of 0.1 minutes. The level-set grid size in both directions is set to 0.005 μm for greater accuracy. Under these etch conditions, the resulting profile gives vertical walls and a flat bottom as shown in [Figure 41 \(upper right\)](#).

The only modification required for the result shown in [Figure 41 \(lower left\)](#) is to specify different etch conditions for the silicon. In this case, the commands are saved in the input file `spt_etchex3a.cmd`. An `anisotropy` factor of 0.5 is defined to obtain a 50% anisotropic behavior (the total etch rate on the bottom of the trench is a 50% contribution from isotropic etch and 50% from perfectly anisotropic behavior).

To obtain a perfectly isotropic behavior as shown in [Figure 41 \(lower right\)](#), the `anisotropy` parameter in the `machetch` command is changed to a value of 0. A perfectly isotropic etch behavior is usually obtained under wet etch conditions as well as under certain dry etch processes. The most important characteristic of this process is that the amount of underetch is equal to the vertical etch depth at every instant of time. Commands for this example are in the input file `spt_etchex3b.cmd`.

Curvature-Dependent Etch

This example illustrates the modeling of curvature-dependent etching in Sentaurus Topography. This model is used to simulate chemical etch (wet etch) processes in which the local etch rate has a strong dependency on the local surface curvature, that is, the material has higher etch rates at sharp convex corners and lower rates at concave corners.

The input file `spt_etchex4.cmd` shown here first creates some perfect trenches of photoresist by an ideal masked etch:

```
# Curvature-dependent etch simulation
# Example: spt_etchex4.cmd

# Initialization
initialize width=1.2 height=0.3

# Planar deposition of oxide layer
deposit material=Oxide thickness=0.4

# Planar deposition of photoresist layer
deposit material=Photoresist thickness=0.1

# Define a new mask and etch
mask name=Mask1 s0=0.2 e0=0.5 s1=0.7 e1=1
etch material=Photoresist mask=Mask1

# Define a new (curvetch) etch machine
machetch name=curvetch_test
machetch name=curvetch_test material=Silicon rate=0.2 anisotropy=0.1
+ kcurv=0.02
machetch name=curvetch_test material=Oxide rate=0.4 anisotropy=0.9 kcurv=0.02

# Etch using the defined machine
etch machname=curvetch_test time=2 dtmax=0.01 dx=0.01 dy=0.01 dtplot=0.1
```

A new etch machine named `curvetch_test` is defined in the `machetch` command. Although the machine type is simple, the parameter `kcurv` defines the curvature dependency of this etch process.

See [Simple Etch Model on page 26](#) for a description of this model and [machetch on page 91](#) for a description of the parameters used in this model.

The parameter `rate` specifies the etch rate of each material and the parameter `anisotropy` characterizes the directionality of the etch process. A zero `anisotropy` suggests that the lateral etch rate is the same as that in the vertical direction, whereas a unity `anisotropy` indicates that the etch is purely directional and there is no lateral etch. Materials with nonzero etch rates have their properties defined for this machine. The etch rate for silicon is half the rate for oxide.




Figure 42 Profile (*upper left*) after first plotting step, (*upper right*) after 1 minute, (*lower left*) 1.5 minutes, and (*lower right*) 2 minutes for `spt_etchex4.cmd`

This machine is used in the `etch` command. The level-set grid size in both directions is set to $0.01\ \mu\text{m}$ for greater accuracy. [Figure 42](#) (*upper left*) shows the structure after the first plotting step of the curved etch simulation. In [Figure 42](#) (*upper right*, *lower left*, and *lower right*), the profile evolution is shown at 1, 1.5, and 2 minutes, respectively. The final profile is clearly rounded, and the anisotropic shape is due to the fact that silicon and oxide have different etch rates and different values of `anisotropy`.

Hemispherical Etch Model: Emulating Broad Ion-Angular Distributions

At high pressures, the preferential directionality of ions towards the wafer surface is lost due to collisions in their path through the sheath. Usually, when the number of momentum-transfer collisions is greater than five, the shape of the ion-angular distribution closely matches a cosine distribution. This example illustrates the etch profiles obtained under such conditions.

A new etch machine `Etcher1` is defined in the `machetch` command with the specification of the etch machine as a hemispherical type. See [Hemispherical Etch Model on page 27](#) for a description of this model and [machetch on page 91](#) for descriptions of the parameters used in this model.

9: Plasma and Etch Examples

Hemispherical Etch Model: Emulating Broad Ion-Angular Distributions

Default values are assumed for parameters that are not explicitly set ($\text{anisotropy}=1$, $\text{angle1}=0$, and $\text{angle2}=180$). This machine is then used in the `etch` command. The level-set grid size in both directions is set to $0.025\ \mu\text{m}$ for greater accuracy.

The command file (`spt_etchex5.cmd`) is:

```
# Dry etch for a collision-dominated discharge
# Example: spt_etchex5.cmd

# Initialization
initialize width=3 height=1

# Mask definition
mask name=Mask1 s0=1 e0=2

# Create the initial structure
deposit thickness=0.5 material=Oxide
etch material=Oxide mask=Mask1

# Define the etch machine
machetch name=Etcher1 hemispherical
machetch name=Etcher1 material=Silicon rate=1

# Do the etch operation
etch machname=Etcher1 time=1.0 dx=0.025 dy=0.025 dtplot=0.1
```

The final result is saved in the TDR file `spt_etchex5.tdr`.

In [Figure 43](#) (*left*), as a result of a broad angular distribution, the sidewalls formed during etching show strong bowing and a rounded bottom. The result for the same settings as `spt_etchex5.cmd`, except $\text{angle1}=70$ and $\text{angle2}=170$, is shown on the right.




Figure 43 Etch profile (*left*) resulting from broad angular distribution from output file `spt_etchex5.tdr` and profile (*right*) resulting from distribution from variation of `spt_etchex5.cmd`

Ion-Enhanced Etch Model: Sidewall Bowing and RIE Lag Effects

This example illustrates the use and effect of the ion-angular distributions created with the plasma simulations in [Plasma Example: Angular Distribution on page 161](#). The commands defined in the input file `spt_etchex6.cmd` are:

```
# Ion-enhanced etch with an angular distribution (50 mTorr)
# Example: spt_etchex6.cmd

# Initialization
initialize width=3 height=1

# Mask definition
mask name=Mask1 s0=1 e0=2

# Initial structure generation
deposit material=Oxide thickness=1
deposit material=Photoresist thickness=0.4
etch material=Photoresist mask=Mask1

# Define a new etch machine
machetch name=myetcher spetch plasmafile=spt_plasmaex1_dis
machetch name=myetcher material=Oxide rate=1

# Etch by using the defined machine
etch machname=myetcher time=1.7 dx=0.05 dy=0.05 dtplot=0.2
```

An initial structure is first created by depositing oxide and photoresist, and by etching the photoresist. The subsequent commands, which define a new etch machine of type `spetch` for the different materials using the `plasmafile` parameter, specify that the ion-angular distribution used for etching under these conditions has been saved in the file (`spt_plasmaex1_dis.tdr`) obtained in the plasma example described in [Plasma Example: Angular Distribution on page 161](#).

See [Ion-Enhanced Etch Model on page 27](#) for a description of this model and [machetch on page 91](#) for descriptions of the parameters used in this model. Default values are assumed for parameters that are not explicitly set (`anisotropy=1`, `angle1=0`, and `angle2=180`). This machine is then used in the `etch` command.

The level-set grid size in both directions is set to 0.05 μm for greater accuracy. The final result is saved in the TDR file `spt_etchex6.tdr`, shown in [Figure 44 on page 172](#) (*left*). Under these etch conditions, sidewalls tend to be more vertical and show less bowing than for higher pressures.

9: Plasma and Etch Examples

Ion-Enhanced Etch Model: Sidewall Bowing and RIE Lag Effects




Figure 44 Ion-enhanced etch at (left) 50 mTorr, (middle) 150 mTorr, and (right) 300 mTorr

A series of different results is observed when pressure increases. The examples `spt_etchex6a.cmd` and `spt_etchex6b.cmd` correspond to initial structures that are identical to the one defined in `spt_etchex6.cmd`. The only difference is that the plasma process conditions are at higher pressures: 150 mTorr and 300 mTorr, respectively, using these corresponding files in the `plasmafile` parameter.

The details of the input files for these distributions are described in [Plasma Example: Angular Distribution on page 161](#). The final results for these two cases are saved in the TDR files `spt_etchex6a.tdr` and `spt_etchex6b.tdr`, and are shown in [Figure 44](#) (middle and right), respectively. The increased spread of the ion-angular distribution due to the increased pressure becomes noticeable in the different shapes of the sidewalls, which are formed during etching. They tend to show more bowing as shown in [Figure 44](#).

An important effect of the spread of the angular distribution is called reactive ion etch (RIE) lag. This effect refers to the experimentally observed evidence that narrower features etch with slower rates for identical etch process conditions. One of the key mechanisms that contributes to this effect is the increased shadowing at narrower mask widths.




Figure 45 Ion-enhanced etch at 150 mTorr with narrow mask from output file `spt_etchex6c.tdr`

The corresponding input file for this example is `spt_etchex6c.cmd`. The only difference between this file and `spt_etchex6a.cmd` is that a narrower mask has been used to define the oxide width. This effect is shown in [Figure 45](#) for a $0.4\ \mu\text{m}$ wide mask opening when etching

at 150 mTorr. For the same total etching time, the oxide–silicon interface is reached for a wider mask opening, as shown in [Figure 44 on page 172 \(middle\)](#). It has not been reached in the case of the narrower mask opening.

Ion-Mill Simulation

In this example, Sentaurus Topography simulates an ion-milling process using a sputter yield function. The input commands in the file `spt_etchex7.cmd` are:

```
# Ion-mill etch
# Example: spt_etchex7.cmd

# Initialization
initialize width=3.5 height=0.6

# Planar layer deposition and etching using an external profile
deposit material=Tantalum thickness=0.05
deposit material=Aluminum thickness=0.75
deposit material=Tantalum thickness=0.05
deposit material=Photoresist thickness=1.8

etch file=spt_etchex7inp.data

# Etch machine definition
machetch name=ionmill_test ionmill
machetch name=ionmill_test material=Aluminum rate=0.505 sputc1=5.5 sputc2=-6
+ sputc4=1.5
machetch name=ionmill_test material=Photoresist rate=0.18 sputc1=5.5 sputc2=-6
+ sputc4=2
machetch name=ionmill_test material=Tantalum rate=0.18 sputc1=5.5 sputc2=-6
+ sputc4=2

# Do the etch operation
etch machname=ionmill_test time=2.0 dtmax=0.01 dx=0.02 dy=0.02 dtplot=0.2

# Remove the resist
etch material=Photoresist
```

After depositing a series of planar layers, an initial structure is created as shown in [Figure 46 on page 174 \(left\)](#), by the coordinate etch method using the profile in `spt_etchex7inp.data`. The input profile (`spt_etchex7inp.data`) is the same as in [Coordinate Etch on page 165](#) (`spt_etchex2inp.data`).

A new etch machine named `ionmill_test` is defined in the `machetch` command. The machine type is `ionmill`. The default value of 1 is assumed for the anisotropy parameter. The only simulation parameters for this model are rate and the sputter yield, which are `sputc1`, `sputc2`, and `sputc4`. See [Ion-Mill Etch Model on page 29](#) and [machetch on page 91](#) for detailed descriptions of these parameters.

9: Plasma and Etch Examples

Reactive Ion Etch Simulation

In [Figure 46 \(right\)](#), the etch profile after 1 minute is shown. The profile evolution is shown after 2 minutes in [Figure 47 \(left\)](#). Observe the strong mask erosion due to the sputtering process. The critical dimension of the metal width is also affected by the ion-milling process.




Figure 46 (Left) Initial structure before ion-milling and (right) profile after 1 minute of etching




Figure 47 (Left) Ion-mill profile at 2 minutes and (right) after removal of resist

After the ion-mill process, the mask layer is removed by etching the photoresist material. The final profile of metal layers is shown in the [Figure 47 \(right\)](#).

Reactive Ion Etch Simulation

In this example, Sentaurus Topography simulates a reactive ion etch (RIE) process. The input commands in the file `spt_etchex8.cmd` are:

```
# RIE etch
# Example: spt_etchex8.cmd

# Initialization
initialize width=3.5 height=0.7

# Planar deposit and mask etch
deposit material=Aluminum thickness=0.8
deposit material=Photoresist thickness=1.8
```

```
mask name=Mask1 s0=0.7 e0=1.4 s1=2.1 e1=2.8
etch material=Photoresist mask=Mask1

# Etch machine definition
machetch name=RIEetch rie exponent=100
machetch name=RIEetch material=Aluminum rate=0.7
machetch name=RIEetch material=Photoresist rate=0.5

# Do the etch operation
etch machname=RIEetch time=1.8 dx=0.03 dy=0.03 dtmax=0.01 dtplot=0.2

# Remove the resist
etch material=Photoresist
```

After depositing a series of planar layers and a geometric etch using the specified mask, the initial structure is created as shown in [Figure 48 \(left\)](#).




Figure 48 (Left) Initial profile and (right) at end of reactive ion etch simulation

A new etch machine named RIEetch is defined in the machetch command. The machine type is rie. The simulation parameters for this model are rate, anisotropy, and exponent. See [Reactive Ion Etch Model on page 29](#) and [machetch on page 91](#) for detailed descriptions of these parameters. The default value of 1 is used for anisotropy for all materials.

The value of 100 for the exponent implies almost a beam-like ion distribution. This, together with the specified value of anisotropy, results in profiles as shown in the [Figure 48 \(right\)](#).

High-Density Plasma Etch Simulation

In this example, Sentaurus Topography simulates a high-density plasma (HDP) etch. The input commands in the file `spt_etchex9.cmd` are:

```
# HDP etch
# Example: spt_etchex9.cmd

# Initialization
initialize width=3.5 height=0.5
```

9: Plasma and Etch Examples

High-Density Plasma Etch Simulation

```
# Planar deposit and mask etch
deposit material=Aluminum thickness=0.95
deposit material=Photoresist thickness=1.5

mask name=Mask1 s0=0.7 e0=1.4 s1=2.1 e1=2.8
etch material=Photoresist mask=Mask1

# Etch machine definition
machetch name=HDPetch hdpetch exponent=15
machetch name=HDPetch material=Aluminum rate=1.13 anisotropy=0.04
machetch name=HDPetch material=Photoresist rate=0.663 anisotropy=0.95

# Do the etch operation
etch machname=HDPetch dx=0.03 dy=0.03 dtmax=0.005 time=2 dtplot=0.2

# Remove the resist
etch material=Photoresist
```

After depositing a series of planar layers and geometric etch using the specified mask, the input file creates the initial structure (see [Figure 49, left](#)).




Figure 49 (Left) Initial profile before HDP etch and (right) after 1 minute of etching

A new etch machine named HDPetch is defined in the machetch command. The machine type is hdpetch. The parameters sputc1, sputc2, and sputc4 define the sputter yield for the physical sputtering process. In general, the sputter yield coefficients are material dependent. In this example, the default values are used for aluminum and photoresist. The parameter exponent defines the ion directionality. The rate is the total etch rate on a flat open surface and is the summation of the sputter etch rate and the reactive ion etch rate. The parameter anisotropy defines the ratio of sputter rate to the total etch rate. See [High-Density Plasma Etch Model on page 30](#) and [machetch on page 91](#) for detailed descriptions of these parameters.

In [Figure 49 \(right\)](#), the profile evolution is shown at 1 minute. In this case, the metal layer is etched mainly by the reactive ion etch process while the mask (photoresist) layer is subjected more to the physical sputtering process. Note the strong mask erosion due to the sputtering

process. The critical dimension of the metal width is also affected by the ion-milling process. The etch profile after 1.6 minutes of etching is shown in [Figure 50 \(left\)](#).




Figure 50 (Left) HDP etch profile at 1.6 minutes and (right) final profile after removing photoresist

After the etch process, the mask layer is removed by etching the photoresist. The final profile of metal layers is shown in [Figure 50 \(right\)](#).

Chemical-Mechanical Polishing

Chemical-mechanical polishing (CMP) is commonly used in the industry as a planarization method. This example illustrates the use of the CMP model in Sentaurus Topography.

The input commands of file `spt_etchex10.cmd` are shown. To demonstrate the CMP model, an initial structure as shown in [Figure 51 on page 178 \(upper left\)](#) is first generated:

```
# CMP simulation
# Example: spt_etchex10.cmd

# Initialization
initialize width=3.0 height=0.1

# Planar deposit and coordinate etch
deposit material=Nitride thickness=0.85
deposit material=Oxide thickness=0.05
deposit material=Photoresist thickness=0.3

etch file=spt_etchex10inp.data

# Deposit oxide in the trenches
machdepo name=IsoDepo material=Oxide rate=0.5

deposit machname=IsoDepo time=1 dtmax=0.01 dx=0.01 dy=0.01

# Etch machine definition for the materials
machetch name=CmpEtch cmp kcmp=1.3 xscale=100
machetch name=CmpEtch material=Oxide rate=0.5
machetch name=CmpEtch material=Photoresist rate=0.02

# Do the etch operation
etch machname=CmpEtch time=1.5 dtmax=0.01 dx=0.02 dy=0.02 dtplot=0.1
```

9: Plasma and Etch Examples

Chemical-Mechanical Polishing

```
# Remove the resist  
etch material=Photoresist complete
```

This initial structure is generated with the coordinate etch method, using the profile `spt_etchex10inp.data`:

0.0	1.2
0.57	1.2
0.59	1.0
0.68	0.5
1.06	0.5
1.15	1.0
1.17	1.2
1.95	1.2
1.97	1.0
2.06	0.5
2.34	0.5
2.43	1.0
2.45	1.2
3.0	1.2

The oxide layer is then deposited (using the default model of deposition) to create the initial structure for CMP.

A new etch machine `CmpEtch` is defined in the `machetch` command with the `cmp` machine type, and the materials oxide and photoresist. See [Chemical-Mechanical Polishing Model on page 30](#) and [machetch on page 91](#) for detailed descriptions of the simulation parameters of this model.




Figure 51 (Upper left) initial profile before CMP etch, (upper right) after 1 minute of etching, (lower left) 1.5 minutes of etching, and (lower right) final structure

The structure after 1 minute of CMP simulation is shown in [Figure 51 \(upper right\)](#). The oxide layer is planarized, and the planarization of the photoresist layer is about to begin. The structure

after 1.5 minutes of CMP (*lower left*) shows the polishing of the photoresist layer in addition to the oxide layer. The final structure after the resist removal, using the geometric etch, is shown in the lower right.

NOTE The parameter `complete` is used for the geometric etch of the resist in order to remove the resist completely.

Dry Etch: Deep Trench Effects

Plasma (dry) etch is a very important etch technique. The major advantage is its highly directional etch profile with good resolution. It etches a very deep trench with nearly vertical sidewalls. The example uses an oxide etch to illustrate this process and its mechanisms.

The most important phenomenon in the dry etch process is that there is a simultaneous deposition of a thin polymer layer on the sidewalls. The polymer sources can be a by-product of the plasma reaction or the physical sputtering process. The amount of this polymer layer is mainly determined by the sputter yield and the plasma conditions. The thin polymer layer forms an etch inhibitor to prevent further etching of the sidewalls and, therefore, can strongly affect the etch profile.

In this example, the sidewalls of the oxide trench exhibited a large slope after the etch process due to the formation of the inhibiting polymer layer on the sidewalls. This slope gradually decreases with increasing depth, and the oxide sidewalls become vertical as the dry etch process continues. The example demonstrates this effect.

```
# Dry etch - deep trench
# Example: spt_etchex11.cmd

# Load the initial structure
initialize file=spt_etchex11init tdr

# Define a dry etch machine
machetch name=dryetch dry depomaterial=Anyinsulator reemrate=0.25 sc=0.3
machetch name=dryetch material=Oxide rate=2.00 sputc1=5.5 sputc2=-6.0
+ sputc4=1.5
machetch name=dryetch material=Resist rate=0.10 sputc1=5.5 sputc2=-6.0
+ sputc4=1.5
machetch dry name=dryetch material=Anyinsulator rate=0.10 sputc1=5.5
+ sputc2=-6.0 sputc4=1.5

# Dry etch
etch machname=dryetch time=1.8 dx=0.02 dy=0.05 dtplot=0.2
```

9: Plasma and Etch Examples

Dry Etch: Deep Trench Effects

In [Figure 52](#), the profile evolution is shown after 12, 60, and 108 s. With progression of the etch depth, the slope of the trench sidewalls increases.




Figure 52 (Far left) initial structure before the dry etch, (left) after 12 s, (right) after 60 s, and (far right) final structure after 108 s

Glossary

This glossary contains the most frequently used terms in the Sentaurus™ Topography User Guide.

A

angular distribution

The distribution of incoming particles as a function of the angle between the incoming direction and the surface normal of the reference surface. Usually the open, flat surface of a wafer is used as the reference surface in a topography simulation.

anisotropy

The ratio of the directional deposition or etch rate to the total deposition or etch rate, which is a combination of a directional component and an isotropic component.

aspect ratio

The ratio of the height to the width of the cross-sectional profile of a trench or via structure.

B

beam deposition

A deposition process in which the reactive species comes to the surface vertically with no angular spread.

beam distribution

The reactive species comes to the surface vertically with no angular spread.

bottom rounding

The deposition or etch profile is rounded at the bottom of a surface feature, such as a trench.

BSG

Boron silicate glass.

bulk region

The region in a plasma reactor where plasma is generated. It is isolated from the electrodes by a sheath region, over which the electrical field drops from plasma voltage to almost zero. *See* **plasma region**.

C

CDE

Chemical dry etch.

CFL criterion

The Courant–Friedrichs–Lewy (CFL) criterion is a stability condition that defines an upper limit for the time step when integrating an initial value problem.

charge exchange

An ion neutralization process in which ions (charged particles) and neutrals (uncharged particles) exchange charges.

chemical radicals

Reactive particles that directly contribute to the deposition or etching of surface film in CVD or chemical etch processes.

chemical vapor deposition (CVD)

The growth of the material from a gaseous medium containing a mixture of reactants that chemically interact and convert to the desired material.

chemical-mechanical polishing (CMP)

A wafer planarization method using both a chemically reactive slurry and a mechanical polishing pad.

CMP

Chemical-mechanical polishing.

conformal deposition

A deposition process in which film grows at the same rate anywhere along the surface.

conformality

A parameter to measure the growth rate variation between an open flat surface and sidewall or bottom of a surface.

coordinate deposition/etch

A simulation method using coordinates to define a customized profile.

curvature-dependent deposition/etch

The deposition rate along a curved surface is a function of the local curvature, which smooths the surface as it evolves.

CVD

Chemical vapor deposition.

D

dielectric deposition

The deposition of dielectric materials.

directional etch

An etching process that creates a trench or via structure of vertical sidewalls.

dry etch

An etching process that uses plasma gas a reactive source. *See* **plasma etch**.

E

energy distribution

The distribution of particles as a function of the energy level. Usually, it is used as a measure of ion distribution.

etch

The process that removes materials from the wafer surface.

F

flow-shape behavior

The deposited film has a smooth surface that emulates the free surface of a fluid flow.

flux

A flow of particles coming to a surface.

G

gap-fill capability

The performance measurement of a deposition method to fill a trench or via structure completely without leaving a void in the structure.

H

HDP

High-density plasma.

HDPCVD

High-density plasma chemical vapor deposition.

hemispherical etch

An etch process in which reactive species come to the surface with an isotropic angular distribution, which results in a bowing shape of the etched sidewall.

high-density plasma (HDP) deposition

A deposition process that uses high-density plasma sources to produce deposition precursors. Usually, this process results in simultaneous deposition and sputter etching of thin film on the wafer surface, due to highly energetic ions.

I

IADF

Ion-angular distribution function.

ideal masked etch

An etch simulation that assumes a perfectly directional etch of the regions not covered by the mask, forming vertical sidewalls.

IEDF

Ion-energy distribution function.

initial structure

The single layer of material that serves as the foundation for the deposition of material layers.

ion-milling

A synonym for ion-mill etch.

ion-mill etch

An etch process purely caused by physical sputtering of the surface by highly energetic ions. The sputter yield (the number of particles knocked off the surface per incoming ion) is a function of the angle between the surface normal and the direction of the incoming ion.

isotropic deposition

The deposition of material conformally over the surface.

K

Knudsen number

The ratio of the length of the mean free path and the thickness of the plasma sheath.

L

lag effect

Due to the increased shadowing at narrower mask widths, narrower features etch with slower rates for identical etch process conditions.

lateral etch

An etch in the sidewall direction due to the isotropic flow of chemical solvent in a wet etch process. This flow creates undercut and overhang structures if the protecting photoresist layer on top is etched at a lesser rate. A similar flow also occurs in a dry etch process if the incoming reactive species has an imperfect directional flux.

layer

Singly or multiply connected area used to describe the geometry of a region. If a region consists of more than one layer, these are not connected to each other.

level set method

A numeric method to calculate the movement of a surface. The zero level of the so-called level set function defines the position of the surface.

low-pressure chemical vapor deposition (LPCVD)

The deposition environment is at such a low pressure that particle–particle collision based on gas-vapor deposition is negligible compared to particle–surface collision. The particles travel between surfaces in a ballistic trajectory.

LPCVD

Low-pressure chemical vapor deposition.

M

masked etch process

An etch simulation that assumes the mask will cover certain areas on the wafer and etch other regions.

N

nonconformal layer

A layer of different thicknesses in the direction of the surface normal.

O

overhang structure

The structure of a cavity with an undercut.

P

PECVD

Plasma-enhanced chemical vapor deposition.

physical vapor deposition (PVD)

The condensation of material from its own vapors.

planar deposition

A simulation scheme that assumes the deposited film is fully planarized.

plasma

A format of material existence.

plasma etch

An etching process that uses plasma gas as a reactive source, which is contrary to the etching processes that use a chemical solvent. *See* **wet chemical etch**.

plasma region

A glowing bulk region that is isolated from electrodes and is a source of ions. *See* **sheath region**.

plasma-enhanced chemical vapor deposition (PECVD)

A chemical vapor deposition technique that employs a plasma chemical vapor discharge to enhance the deposition characteristics.

profile evolution simulation

The simulation of surface advancement as a function of time.

PVD

Physical vapor deposition.

R

RC2

File format used in the capacitance extraction tool Raphael for 2D simulations.

reactive ion etch (RIE)

An etch process in which chemically reactive ions are the major source of the reaction that removes particles from the surface.

redeposition

Particles that are sputtered away from the surface in an ion-mill process redeposit on the surface at a certain ratio when interacting with the surfaces.

reemission

Chemical species absorbed by a surface can emit back to the gas phase and can travel to another surface.

reflow

The top layer of a deposited thin film redistributes at high temperatures between surface regions of different free energies.

region

Regions and their associated properties (`material`, `name`, and `diel` or `volt`) are created with the `deposit` command. They consist of one or more layers, which are used to define the geometry of the region. If a region consists of more than one layer, these are disconnected. Etching may cause the layers of a region to be split into a larger number of smaller layers.

RIE

Reactive ion etch.

S

SAT

Standard ACIS Text. A geometry description format that Sentaurus Structure Editor uses and that is common to many commercial tools in structure analysis.

self-planarization characteristics

A deposition method such as HDPCVD can produce film characteristics of a flat top surface over a nonplanar substrate without any after-process planarization operations.

SEM

Scanning electron microscope.

Sentaurus Process

A multidimensional process simulation tool.

Sentaurus Topography

A two-dimensional topography simulation tool performing analysis of integrated circuit fabrication, etch, deposition, and other geometric operations.

shadowing effect

Particles coming to a surface in a ballistic trajectory can only reach unblocked regions.

sheath region

A dark region that surrounds the electrodes and walls. *See* **plasma region**.

sidewall bowing

The lateral etch of a sidewall due to nondirectional etch species.

SLO

File format used by Sentaurus Lithography.

SOG

Spin-on-glass.

spin coating

A specific material is first deposited on the surface, is subsequently reflowed for planarization, and then undergoes a shrinking process at high temperature.

spin-on-glass (SOG)

A synonym for the spin coating process.

sputtering

Strong ion bombardment.

SRAM

Static random access memory.

sticking coefficient

The statistical probability that an incoming precursor will stay on the surface and contribute to the deposition of thin film, contrary to bouncing back to the gas phase. It controls the conformality in a reemission process.

T

TDR

File format used for TCAD Sentaurus tools.

TEOS

Tetraethyloxysilane.

U

underetch

A lateral etch in the sidewall direction.

unidirectional source vapor deposition

Simulates the PVD process of unidirectional-angle evaporation.

V

void

A hole capped in a trench or via structure during a deposition process.

W

wet chemical etch

An etching process that uses chemical solvents compared to a plasma (dry) etch, which uses plasma gas as a reactive source. *See* **dry etch**.

Y

yield

The number of particles sputtered away from the surface per incoming ion.

Glossary

Y