

## Lecture 2

### Basic Semiconductor Physics

---

In this lecture you will learn:

- What are semiconductors?
- Basic crystal structure of semiconductors
- Electrons and holes in semiconductors
- Intrinsic semiconductors
- Extrinsic semiconductors
  - n-doped and p-doped semiconductors

### Semiconductors in the Periodic Table

Atomic number


	III A	IV A	V A	VIA
5	B	C	N	O
13	Al	Si	P	S
30	Zn	Ga	Ge	As
48	Cd	In	Sn	Sb

Group IV semiconductors

Each element in group IV has 4 electrons in its outer most atomic shell


A Silicon atom has:

- 2 electrons in the first atomic shell
- 8 electrons in the second atomic shell
- 4 electrons in the third outermost atomic shell




A Silicon atom

## Semiconductors in the Periodic Table



- The outermost electrons are called valence electrons
- The inner electrons are called the core electrons




A Silicon atom

## Covalent Bonding in Silicon

- A Silicon atom with 4 electrons in the valence shell is drawn in a cartoon way as:




- Two Silicon atoms can come together to form a covalent bond by sharing two electrons among themselves



- Covalent bonding is energetically favorable (i.e. Silicon atoms “like” to form covalent bonds with each other)


### A Silicon Crystal Lattice (A Cartoon View)



In a Silicon crystal:


- Each Silicon atom is surrounded by 4 other Silicon atoms
- Each Silicon atom forms 4 covalent bonds with the neighboring Silicon atoms

### Actual 3D Structure of a Silicon Crystal Lattice




- Each Silicon atom is surrounded by 4 other Silicon atoms in a tetrahedral configuration
- Silicon atomic density =  $5 \times 10^{22} \text{ cm}^{-3}$

## Electrons and Holes in Semiconductors - I



A perfect Silicon crystal lattice


## Electrons and Holes in Semiconductors - II



A Silicon crystal lattice with one broken bond

- It requires energy to break a covalent bond
- The required energy is called the “**bandgap**” (bandgap of Silicon is ~1.12 eV)
- A broken bond results in one negatively charged “free electron” and one positively charged “hole”
- The “free electron” can freely move around in the crystal


### Electrons and Holes in Semiconductors - III



A Silicon crystal lattice with one broken bond

- A hole can also move through the lattice !!
- A hole moves when an electron from a neighboring bond jumps over to fill that "hole"

### Electrons and Holes in Semiconductors - III




A Silicon crystal lattice with one broken bond

- A hole can also move through the lattice !!
- A hole moves when an electron from a neighboring bond jumps over to fill that "hole"

### Definitions and Notations Used in ECE 3150

- The word electron will usually mean a “free electron” (and not an electron forming the covalent bond or a core electron)
  - The electron density is denoted by:  $n$  (units:  $1/\text{cm}^3$ )
  - The hole density is denoted by:  $p$  (units:  $1/\text{cm}^3$ )
  - The charge of an electron is:  $-q$
  - The charge of a hole is:  $+q$
- $q = 1.6 \times 10^{-19}$  Coulombs


### Electrons and Holes at Near Zero Temperature



A perfect Silicon crystal lattice at temperature  $T \approx 0$  K

- There are no broken bonds and no electrons and holes (i.e.  $n = p = 0$ )

### Electrons and Holes at Nonzero Temperature



A Silicon crystal lattice at temperature  $T > 0$  K

- Thermal energy breaks the covalent bonds and electron-hole pairs are generated (remember it takes energy to break a covalent bond)
- The number of electrons and holes generated are equal - for every electron generated there is also a hole generated ( i.e.  $n = p$  )
- Question: what is the electron and hole density at room temperature?

### Thermal Energy

Thermal energy is typically measured in units of “  $KT$  ”

“  $K$  ” is the Boltzmann’s constant and equals  $\sim 1.38 \times 10^{-23}$  Joules/Kelvin

Temperature “  $T$  ” is measured in degrees Kelvin

Room temperature corresponds to  $T = 300$  K


Room temperature corresponds to a “  $KT$  ” value of  $4.14 \times 10^{-21}$  Joules or 25.8 meV

$\text{Energy in eV} = \frac{\text{Energy in Joules}}{\text{Electron charge in Coulombs}}$
--

## Generation and Recombination in Semiconductors - I

### Generation:


The breaking of a bond to generate an electron-hole pair is called generation



- Generation rate  $G(T)$  is a function of temperature
- Units of  $G(T)$  are:  $\text{cm}^{-3}\cdot\text{s}^{-1}$

### Recombination:

An electron can also combine with a hole to form a bond. This process is called recombination. It is the reverse of generation.



- Recombination rate  $R(T)$  is proportional to the product  $np$

$$R(T) \propto np \quad \Rightarrow \quad R(T) = k(T) np$$

(you need electrons as well as holes for recombination to happen)

- Units of  $R(T)$  are also:  $\text{cm}^{-3}\cdot\text{s}^{-1}$

## Generation and Recombination in Semiconductors - II

### Condition of Thermal Equilibrium:

- In thermal equilibrium a steady state exists in which the rate of electron-hole generation is equal to the rate of electron-hole recombination,

$$\left. \begin{aligned} R(T) &= G(T) \\ \Rightarrow k(T)n_o p_o &= G(T) \\ \Rightarrow n_o p_o &= \frac{G(T)}{k(T)} \end{aligned} \right\} \begin{array}{l} \text{thermal equilibrium electron and hole} \\ \text{densities are usually denoted by } n_o \\ \text{and } p_o \end{array}$$

- By convention, the ratio  $\frac{G(T)}{k(T)}$  is written as  $n_i^2(T)$
- Therefore, in thermal equilibrium,  $n_o p_o = n_i^2(T)$
- Since equal number of electrons and holes are present in thermal equilibrium, we have,  $n_o = p_o = n_i(T)$
- $n_i$  is called the “intrinsic” carrier density. It equals the number of electrons (or holes) present in a pure semiconductor in equilibrium at a given temperature.
- For Silicon,  $n_i \approx 1 \times 10^{10} \text{ cm}^{-3}$  at room temperature (i.e. at  $T = 300\text{K}$ )



## Doping in Semiconductors

### Doping:

The introduction of certain impurity atoms in a pure semiconductor to control its electronic properties is called doping

- Doping is done by two kinds of impurity atoms:
  - a) Donor atoms
  - b) Acceptor atoms

### Donors:


Donor atoms are used to increase the electron density in a semiconductor

	IIIA	IVA	VA	VIA	
	5 B	6 C	7 N	8 O	
	13 Al	14 Si	15 P	16 S	
IIB	30 Zn	31 Ga	32 Ge	33 As	34 Se
	48 Cd	49 In	50 Sn	51 Sb	52 Te

• Group V elements have 5 electrons in their outermost atomic shell (one more than group IV atoms)

• Group V elements can act as electron "donors" in Silicon

### Doping by Donors in Silicon (n-doping)



- Donor atom concentration is denoted by:  $N_d$  (units:  $1/\text{cm}^3$ )
- Each donor atom contributes one free electron to the crystal
- Donor atom after giving off an electron becomes positively charged

## Doping in Semiconductors

### Acceptors:


Acceptor atoms are used to increase the hole density in a semiconductor

	III A	IV A	V A	V I A
	B 5	C 6	N 7	O 8
	Al 13	Si 14	P 15	S 16
II B				
	Zn 30	Ga 31	Ge 32	As 33
	Cd 48	In 49	Sn 50	Sb 51
			Te 52	

- Group III elements have 3 electrons in their outermost atomic shell (one less than group IV atoms)

- Group III elements can act as electron "Acceptors" in Silicon

### Doping by Acceptors in Silicon (p-doping)



- Acceptor atom concentration is denoted by:  $N_a$  (units:  $1/\text{cm}^3$ )
- Each acceptor atom contributes one hole to the crystal by "accepting" one electron from a neighboring bond
- Acceptor atom after giving off a hole (or equivalently, after accepting an electron) becomes negatively charged

### Electron-Hole Density in Doped Semiconductors

Consider a N-doped semiconductor in thermal equilibrium:

Doping density =  $N_d$

• Use condition of charge neutrality:  $q(+N_d - n_o + p_o) = 0$

• Together with the relation:  $n_o p_o = n_i^2$

• To obtain:

$$n_o = \frac{N_d}{2} + \sqrt{\left(\frac{N_d}{2}\right)^2 + n_i^2}$$

$$p_o = -\frac{N_d}{2} + \sqrt{\left(\frac{N_d}{2}\right)^2 + n_i^2}$$

• If  $N_d \gg n_i$ , which is usually the case for N-doping, then the above relations simplify:

$$\left. \begin{array}{l} n_o \approx N_d \\ p_o \approx \frac{n_i^2}{N_d} \end{array} \right\} \text{n-doping lets one make the electron density much greater than the intrinsic value } n_i$$

### Electron-Hole Density in Doped Semiconductors

Now consider a P-doped semiconductor in thermal equilibrium:

Doping density =  $N_a$

• Use condition of charge neutrality:  $q(-N_a - n_o + p_o) = 0$

• Together with the relation:  $n_o p_o = n_i^2$

• To obtain:

$$p_o = \frac{N_a}{2} + \sqrt{\left(\frac{N_a}{2}\right)^2 + n_i^2}$$


$$n_o = -\frac{N_a}{2} + \sqrt{\left(\frac{N_a}{2}\right)^2 + n_i^2}$$

• If  $N_a \gg n_i$ , which is usually the case for P-doping, then the above relations simplify:

$$\left. \begin{array}{l} p_o \approx N_a \\ n_o \approx \frac{n_i^2}{N_a} \end{array} \right\} \text{p-doping lets one make the hole density much greater than the intrinsic value } n_i$$

## Electron-Hole Density Vs Doping Density

### N-doped semiconductors



• With increasing N-doping the electron density increases above the intrinsic value and the hole density decreases below the intrinsic value

#### Example:

Suppose

$$N_d = 10^{17} \text{ cm}^{-3} \quad \text{and} \quad n_i = 10^{10} \text{ cm}^{-3}$$

then


$$n_o \approx 10^{17} \text{ cm}^{-3} \quad (\text{Since } N_d \gg n_i)$$

and

$$p_o = \frac{n_i^2}{n_o} \approx 10^3 \text{ cm}^{-3}$$

## Electron-Hole Density Vs Doping Density

### P-doped semiconductors



• With increasing P-doping the hole density increases above the intrinsic value and the electron density decreases below the intrinsic value

#### Example:

Suppose

$$N_a = 10^{17} \text{ cm}^{-3} \quad \text{and} \quad n_i = 10^{10} \text{ cm}^{-3}$$

then

$$p_o \approx 10^{17} \text{ cm}^{-3} \quad (\text{Since } N_a \gg n_i)$$

and

$$n_o = \frac{n_i^2}{p_o} \approx 10^3 \text{ cm}^{-3}$$


## Compound Semiconductors

	IIIA	IVA	VA	VIA
	5 B	6 C	7 N	8 O
	13 Al	14 Si	16 P	16 S
IIIB	30 Zn	31 Ga	32 Ge	33 As
	48 Cd	49 In	50 Sn	51 Sb
		60 Sn	61 Sb	52 Te


### III-V semiconductors:

Elements in group III can be combined with elements in group V to give compound semiconductors (as opposed to elemental semiconductors of group IV)

\*One can also have II-VI semiconductors




## Elemental and Compound Semiconductors



A Diamond Lattice

(Si, C, Ge, etc)



A Zincblende Lattice

(ZnS, GaS, InP, etc)

